

HP 8970B

NOISE FIGURE METER

Including the HP 8970S

Noise Figure Measurement System

*Trigger Hold^N and Trigger Execute can be used in
one stroke T1T2 No need to use commas etc*

SERIAL NUMBERS

This manual applies directly to instruments with serial numbers prefixed 2645A.

For additional important information about serial numbers, see INSTRUMENTS COVERED BY MANUAL in Section I.



© Copyright HEWLETT-PACKARD COMPANY 1987
1501 PAGE MILL ROAD, PALO ALTO, CALIFORNIA, U.S.A.

Operating Manual Part No. 08970-90022
Operating Manual Microfiche Part No. 08970-90024
Service Manual Part No. 08970-90023
Service Manual Microfiche Part No. 08970-90030

Printed: MARCH 1987

CERTIFICATION

Hewlett-Packard Company certifies that this product met its published specifications at the time of shipment from the factory. Hewlett-Packard further certifies that its calibration measurements are traceable to the United States National Bureau of Standards, to the extent allowed by the Bureau's calibration facility, and to the calibration facilities of other International Standards Organization members.

WARRANTY

This Hewlett-Packard instrument product is warranted against defects in material and workmanship for a period of one year from date of shipment. During the warranty period, Hewlett-Packard Company will, at its option, either repair or replace products which prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by HP. Buyer shall prepay shipping charges to HP and HP shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to HP from another country.

HP warrants that its software and firmware designated by HP for use with an instrument will execute its programming instructions when properly installed on that instrument. HP does not warrant that the operation of the instrument, or software, or firmware will be uninterrupted or error free.

LIMITATION OF WARRANTY

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

NO OTHER WARRANTY IS EXPRESSED OR IMPLIED. HP SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

EXCLUSIVE REMEDIES

THE REMEDIES PROVIDED HEREIN ARE BUYER'S SOLE AND EXCLUSIVE REMEDIES. HP SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

ASSISTANCE

Product maintenance agreements and other customer assistance agreements are available for Hewlett-Packard products.

For any assistance, contact your nearest Hewlett-Packard Sales and Service Office. Addresses are provided at the back of this manual.

HP 8970B NOISE FIGURE METER

Before operating the Noise Figure Meter, read the following information:

- **Recording IF Cal Data** - Refer to paragraph 2-14, "Recording IF Cal Data", in Section II of the HP 8970B Operating Manual. The IF attenuator data is needed to return the Noise Figure Meter to specified operation should a non-volatile memory failure occur (Error E-80).
- **For those familiar with the HP 8970A Noise Figure Meter, please note:** The procedure for calibrating the IF attenuators has changed. If E-26 or E-13 should occur, refer to the "Calibrate, IF Attenuator" detailed operating instruction in Section III of the HP 8970B Operating Manual.
- **Maximum Input Power** - The maximum average power level for a CW signal at the RF INPUT connector of the HP 8970B must not exceed +20 dBm (100mW). The maximum power for a pulsed signal is also +20 dBm (100mW). The HP 8970B may be damaged by voltages exceeding +/- 20 Vdc at the RF INPUT connector.
- **Using the HP 346A Noise Source with the HP 8970S/T** - A preamplifier is required when using the HP 346A Noise Source to calibrate the HP 8970S/T system. Typically, a preamplifier with > 15 dB of gain and < 6 dB noise figure will work. Without a preamplifier, error E-19 will result when trying to perform a YIG-tuned filter fine peak calibration (36.3 SPECIAL FUNCTION or 36.4 SPECIAL FUNCTION) and error E-27 will result when trying calibrate the noise figure meter with 36.1 SPECIAL FUNCTION active (Disable YIG Tune in Cal). This applies to the HP 346A Noise Source only.
- **Using the HP 346A Noise Source with the HP 8970A/B** - A preamplifier may be required when using the HP 346A Noise source to calibrate the HP 8970A/B Noise Figure Meter. If error E-27 occurs after pressing the CALIBRATE key on the noise figure meter, use a preamplifier to correct the situation. Typically, a preamplifier with > 10 dB of gain and < 6 dB noise figure will work.

CONTENTS

| | Page | | Page |
|---|------|--|------|
| Section I | | Section III | |
| GENERAL INFORMATION | | OPERATION | |
| Introduction | 1-1 | Recording IF Attenuator Values | 2-5 |
| Specifications | 1-1 | Storage and Shipment | 2-5 |
| Safety Considerations | 1-1 | Environment | 2-5 |
| Instruments Covered by Manual | 1-1 | Packaging | 2-5 |
| Manual Changes Supplement | 1-1 | | |
| Description | 1-2 | | |
| Noise Figure Meter | 1-2 | | |
| Noise Figure Measurement System | 1-2 | | |
| Mechanical Options | 1-2 | | |
| Front Handle Kit (Option 907) | 1-3 | | |
| Rack Flange Kit (Option 908) | 1-3 | | |
| Rack Flange and Front Handle | | | |
| Combination Kit (Option 909) | 1-3 | | |
| Hewlett-Packard Interface Bus (HP-IB) | 1-3 | | |
| Compatibility | 1-3 | | |
| Selecting the HP-IB Address | 1-3 | | |
| System Interface Bus (SIB) | 1-3 | | |
| Compatibility | 1-3 | | |
| Selecting the SIB Address | 1-3 | | |
| Accessories Supplied | 1-3 | | |
| Equipment Required But Not Supplied | 1-3 | | |
| Electrical Equipment Available | 1-4 | | |
| HP-IB Controllers | 1-4 | | |
| External Mixers and System Local | | | |
| Oscillators | 1-4 | | |
| Waveguide/Coax Adapters | 1-4 | | |
| Front-to-Rear-Panel Connector | | | |
| Retrofit Kit | 1-4 | | |
| Mechanical Equipment Available | 1-4 | | |
| Chassis Slide Mount Kit | 1-4 | | |
| Chassis Tilt Slide Mount Kit | 1-4 | | |
| Recommended Test Equipment | 1-4 | | |
| | | Introduction | 3-1 |
| | | Operating Characteristics | 3-1 |
| | | Local Operation | 3-1 |
| | | Remote Operation | 3-1 |
| | | Operator's Checks | 3-2 |
| | | Operator's Maintenance | 3-2 |
| | | General Operating Instructions | 3-2 |
| | | Turn On | 3-2 |
| | | Keystroke Sequences | 3-3 |
| | | Operator's Checks | 3-15 |
| | | Basic Functional Checks | 3-15 |
| | | HP-IB Functional Checks | 3-21 |
| | | Noise Figure Measurement System | |
| | | Check | 3-28 |
| | | Remote Operation | 3-33 |
| | | HP-IB Compatibility | 3-33 |
| | | Remote Mode | 3-33 |
| | | Local Mode | 3-33 |
| | | Addressing | 3-33 |
| | | Data Messages | 3-34 |
| | | Receiving the Data Message | 3-34 |
| | | Sending the Data Message | 3-37 |
| | | Receiving the Clear Message | 3-38 |
| | | Receiving the Trigger Message | 3-40 |
| | | Receiving the Remote Message | 3-40 |
| | | Receiving the Local Message | 3-40 |
| | | Receiving the Local Lockout Message | 3-41 |
| | | Receiving the Clear Lockout/Set Local | |
| | | Message | 3-41 |
| | | Receiving the Pass Control Message | 3-41 |
| | | Sending the Require Service Message | 3-41 |
| | | Enabling the Service Request Condition | 3-41 |
| | | Sending the Status Byte Message | 3-42 |
| | | Clearing the Status Byte | 3-43 |
| | | Sending the Status Bit Message | 3-44 |
| | | Receiving the Abort Message | 3-44 |
| | | HP-IB Syntax and Characteristics | |
| | | Summary | 3-45 |
| | | Detailed Operating Instructions | |
| | | Calibrate | 3-59 |
| | | Calibration, Frequency | 3-65 |
| | | Calibration, IF Attenuators | 3-67 |
| | | Calibration, Input Gain Selection | 3-69 |

Section II
INSTALLATION

CONTENTS (cont'd)

| | Page | | Page |
|--|-------|--|-------|
| Controller Capability of the Noise Figure Meter | 3-71 | Preset Conditions and Power-Up Sequence ... | 3-205 |
| Data Output to Oscilloscopes, Recorders and Plotters | 3-73 | Programming the System LO | 3-210 |
| Display Control | 3-81 | Programs Available to Control the System LO | 3-219 |
| Display Resolution | 3-83 | RF Attenuation Selection | 3-222 |
| Display Units Selection | 3-85 | Sequence | 3-224 |
| ENR Table Entry | 3-87 | Sideband Selection | 3-226 |
| Error Messages and Recovery | 3-93 | Smoothing (Averaging) | 3-230 |
| Fixed Frequency Increment | 3-105 | Special Function Catalog | 3-233 |
| Fixed Frequency Tuning | 3-108 | Special Functions | 3-235 |
| Fixed IF or LO Frequency Selection | 3-110 | Spot ENR, T_{hot} , T_{cold} and ENR Table Selection | 3-254 |
| HP-IB and System Interface Bus (SIB) Addresses | 3-113 | Store and Recall | 3-257 |
| IF Attenuation Selection | 3-117 | Sweep | 3-258 |
| Loss Compensation | 3-119 | System Interface Bus Control | 3-262 |
| Manual Measurement Functions | 3-121 | Temperature Units Selection | 3-271 |
| Measurement Modes | 3-125 | Trigger Selection | 3-273 |
| Measurement Mode 1.0 | 3-132 | | |
| Measurement Mode 1.1 | 3-135 | Section IV | |
| Measurement Mode 1.2 | 3-140 | PERFORMANCE TESTS | |
| Measurement Mode 1.3 | 3-145 | Introduction | 4-1 |
| Measurement Mode 1.4 | 3-150 | Equipment Required | 4-1 |
| Measurement Mode 1.5 | 3-155 | Test Record | 4-1 |
| Measurement Mode 1.6 | 3-160 | Calibration Cycle | 4-1 |
| Measurement Mode 1.7 | 3-168 | Tuning Accuracy Performance Test | 4-2 |
| Measurement Mode 1.8 | 3-176 | Input SWR Performance Test | 4-4 |
| Measurement Mode 1.9 | 3-183 | Noise Figure Range and Accuracy Performance Test | 4-6 |
| Noise Figure Test Set YIG Filter Calibration | 3-190 | Gain Measurement Uncertainty Performance Test | 4-10 |
| Noise Figure (Uncorrected) and Noise Figure and Gain (Corrected) | 3-198 | Instrument Noise Figure Performance Test | 4-19 |
| Power Measurements | 3-200 | Spurious Response Performance Test | 4-20 |
| Preamplifier Selection | 3-202 | Jitter Performance Test | 4-22 |

ILLUSTRATIONS

| | Page | | Page |
|---|------|---|------|
| 1-1. HP 8970B Accessories Supplied, and Options 907, 908, and 909 | 1-0 | 3-3. GAIN MAX, GAIN MIN, NOISE MAX and NOISE MIN Features | 3-9 |
| 2-1. Line Voltage and Fuse Selection | 2-2 | 3-4. LINE Switch, PRESET and SOURCE Features | 3-10 |
| 2-2. Power Cable and Mains Plug Part Numbers | 2-2 | 3-5. SWEEP and FIXED FREQ Features | 3-11 |
| 2-3. Hewlett-Packard Interface Bus and System Interface Bus Connections | 2-4 | 3-6. DATA and SPECIAL FUNCTION Features | 3-12 |
| 2-4. Noise Figure Measurement System Interconnections | 2-5 | 3-7. MEASUREMENT and INPUT Features .. | 3-13 |
| 3-1. Front Panel Features | 3-4 | 3-8. Rear Panel Features | 3-14 |
| 3-2. Display and Remote Features | 3-8 | 3-9. Basic Functional Checks Setup | 3-15 |
| | | 3-10. Test Pattern on Oscilloscope | 3-16 |
| | | 3-11. Noise Figure Measurement System Check Setup | 3-28 |

ILLUSTRATIONS (cont'd)

| | Page | Figure | Page |
|---|------|--|------|
| 3-12. Example Flow Chart for Driving the Noise Figure Meter Using the Require Service Message (SRQ) | 3-43 | 4-3. IF Attenuator Calibration Setup | 4-11 |
| 4-1. Input SWR Test Setup | 4-4 | 4-4. Gain Measurement Uncertainty Test Setup | 4-16 |
| 4-2. Noise Figure Instrumentation Accuracy Test Setup | 4-7 | 4-5. Spurious Response Test Setup | 4-20 |

TABLES

| Table | Page | Table | Page |
|---|------|--|-------|
| 1-1. Noise Figure Meter Specifications | 1-5 | 3-5. HP-IB Data Output Summary | 3-38 |
| 1-2. Noise Figure Meter Supplemental Characteristics | 1-7 | 3-6. Response to a Clear Message (or Pressing PRESET) | 3-39 |
| 1-3. Noise Figure Measurement System Specifications | 1-8 | 3-7. Service Request Enabled Conditions Summary | 3-42 |
| 1-4. Noise Figure Measurement System Supplemental Characteristics | 1-9 | 3-8. Noise Figure Meter HP-IB Code to Parameter Summary | 3-47 |
| 1-5. Recommended Test Equipment | 1-10 | 3-9. Special Function to HP-IB Code | 3-51 |
| 2-1. Noise Figure Meter Factory Set Addresses | 2-3 | 3-10. Front Panel Keys to HP-IB Code Summary | 3-57 |
| 2-2. ASCII Address Codes to Decimal Equivalents | 2-3 | 3-11. Commonly Used Code Conversions | 3-58 |
| 3-1. Operating Characteristics | 3-3 | 3-12. Front Panel Summary | 3-206 |
| 3-2. Detailed Operating Instructions Table of Contents (Functional) | 3-6 | 3-13. Special Function 0.9 and Preset Default Values for Special Functions | 3-207 |
| 3-3. Message Reference Table | 3-35 | 3-14. Special Function Summary | 3-239 |
| 3-4. Functions Not Programmable Via HP-IB | 3-36 | 4-1. IF Attenuator Values | 4-14 |
| | | 4-2. Performance Test Record | 4-25 |

ENR table entry 3-88
How to measure noise figure 3-133
One amplifier selection and determining system NF 3-202
Example of pre-amp selection 3-204
When calibrating wait until calibration light goes out!
To obtain gain calibration values from factory data 4-15 Read these values out of RAM and record



SAFETY CONSIDERATIONS

GENERAL

This product and related documentation must be reviewed for familiarization with safety markings and instructions before operation.

This product is a Safety Class I instrument (provided with a protective earth terminal).

BEFORE APPLYING POWER

Verify that the product is set to match the available line voltage and the correct fuse is installed.

SAFETY EARTH GROUND

An uninterruptible safety earth ground must be provided from the main power source to the product input wiring terminals, power cord, or supplied power cord set.

WARNINGS

Any interruption of the protective (grounding) conductor (inside or outside the instrument) or disconnecting the protective earth terminal will cause a potential shock hazard that could result in personal injury. (Grounding one conductor of a two conductor outlet is not sufficient protection.) In addition, verify that a common ground exists between the unit under test and this instrument prior to energizing either unit.

Whenever it is likely that the protection has been impaired, the instrument must be made inoperative and be secured against any unintended operation.

If this instrument is to be energized via an auto-transformer (for voltage reduction) make sure the common terminal is connected to neutral (that is, the grounded side of the mains supply).

Servicing instruction are for use by service-trained personnel only. To avoid dangerous electric shock, do not perform any servicing unless qualified to do so. Adjustments described in the manual are performed with power supplied to the instrument while protective covers

are removed. Energy available at many points may, if contacted, result in personal injury.

Capacitors inside the instrument may still be charged even if the instrument has been disconnected from its source of supply.

For continued protection against fire hazard, replace the line fuse(s) only with 250V fuse(s) of the same current rating and type (for example, normal blow, time delay, etc.) Do not use repaired fuses or short-circuited fuseholders.

SAFETY SYMBOLS



Instruction manual symbol: the product will be marked with this symbol when it is necessary for the user to refer to the instruction manual (see Table of Contents for page references).



Indicates hazardous voltages.




Indicates earth (ground) terminal.

WARNING


The WARNING sign denotes a hazard. It calls attention to a procedure, practice, or the like, which, if not correctly performed or adhered to, could result in personal injury. Do not proceed beyond a WARNING sign until the indicated conditions are fully understood and met.

CAUTION


The CAUTION sign denotes a hazard. It calls attention to an operating procedure, practice, or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the product. Do not proceed beyond a CAUTION sign until the indicated conditions are fully understood and met.




HP 8970B




LINE POWER CABLE



OPTION 907
FRONT HANDLE KIT



OPTION 908
RACK FLANGE KIT



OPTION 909
RACK FLANGE AND FRONT
HANDLE COMBINATION KIT

Figure 1-1. HP 8970B Accessories Supplied, and Options 907, 908, and 909

SECTION I GENERAL INFORMATION

1-1. INTRODUCTION

HP 8970B operating and service documentation consists of an Operating Manual and a Service Manual. These two volumes contain all the information required to install, operate, test, adjust and service the HP 8970B Noise Figure Meter. Also, contained in the Operating Manual is complete installation and operating information for the HP 8970S Noise Figure Measurement System. Figure 1-1 shows the Noise Figure Meter with all of its externally supplied accessories.

The Operating Manual, which is shipped with each instrument, has four sections:

- Section I, General Information
- Section II, Installation
- Section III, Operation
- Section IV, Performance Tests

The Service Manual, which is shipped with the instrument as Option 915 or ordered separately, has four sections:

- Section V, Adjustments
- Section VI, Replaceable Parts
- Section VII, Manual Changes
- Section VIII, Service

Additional copies of the Operating Manual or the Service Manual can be ordered separately through your nearest Hewlett-Packard office. The part numbers are listed on the title page of this manual.

Also listed on the title page of this manual, below the manual part number, is a microfiche part number. This number may be used to order 100 x 150 millimetre (4 x 6 inch) microfilm transparencies of this manual. Each microfiche contains up to 96 photo-duplicates of the manual pages. The microfiche package also includes the latest Manual Changes supplement, as well as all pertinent Service notes.

1-2. SPECIFICATIONS

Instrument specifications for the Noise Figure Meter are listed in Table 1-1. These specifications are the performance standards or limits against which the instrument is tested. Supplemental characteristics are listed in Table 1-2. Supplemental characteristics are not warranted specifications, but are typical characteristics included as additional information for the user. Specifications for the Noise Figure Measurement System are listed in Table 1-3. Supplemental characteristics for the Noise Figure Measurement System are listed in Table 1-4.

mental characteristics are not warranted specifications, but are typical characteristics included as additional information for the user. Specifications for the Noise Figure Measurement System are listed in Table 1-3. Supplemental characteristics for the Noise Figure Measurement System are listed in Table 1-4.

1-3. SAFETY CONSIDERATIONS

This product is a Safety Class I instrument, (that is, provided with a protective earth terminal). The Noise Figure Meter and all related documentation should be reviewed for familiarization with safety markings and instructions before operation. Refer to the Safety Considerations page found at the beginning of this manual for a summary of the safety information. Safety information for installation, operation, performance testing, adjustment, or service is found in appropriate places throughout the Operating and Service manuals.

1-4. INSTRUMENTS COVERED BY MANUAL

Attached to the rear panel of the instrument is a serial number plate. The serial number is in the form: 0000A00000. The first four digits and the letter are the serial number prefix. The last five digits are the suffix. The prefix is the same for identical instruments; it changes only when a configuration change is made to the instrument. The suffix however, is assigned sequentially and is different for each instrument. The contents of this manual apply directly to instruments having serial number prefix(es) as listed under SERIAL NUMBERS on the title page.

1-5. MANUAL CHANGES SUPPLEMENT

An instrument manufactured after the printing of this manual may have a serial number prefix that is not listed on the title page. This unlisted serial number prefix indicates that the instrument is different from those documented in this manual. The manual for this newer instrument is accompanied by a Manual Changes supplement. The supplement contains change instructions that explain how to adapt the manual to the newer instrument.

MANUAL CHANGES SUPPLEMENT (cont'd)

In addition to change information, the supplement may contain information for correcting errors in the manual. To keep the manual as current and as accurate as possible, Hewlett-Packard recommends that you periodically request the latest Manual Changes supplement. The supplement is identified with the manual print date and part number, both of which appear on the manual title page. Complimentary copies of the supplement are available from Hewlett-Packard.

For information concerning a serial number prefix that is not listed on the title page or in the Manual Changes supplement, contact your nearest Hewlett-Packard office.

1-6. DESCRIPTION

1-7. Noise Figure Meter

The Hewlett-Packard Model 8970B Noise Figure Meter, together with an appropriate noise source, automatically measures the noise figure and gain of the device to which it is attached. The Noise Figure Meter can be tuned between 10 and 1600 MHz. It can also be swept over all or any part of that range. To measure the noise figure of devices with output frequencies greater than 1600 MHz, an external mixer and local oscillator can be used to convert the frequency to the 10–1600 MHz range. Measured noise can be displayed as noise figure, equivalent input noise temperature or Y-Factor. Gain is displayed in dB.

Once calibrated, a single keystroke of the Noise Figure Meter can automatically remove the measurement system noise and gain contribution (called second stage correction). The Noise Figure Meter then displays only the noise figure and gain of the device under test (DUT).

Five Excess Noise Ratio (ENR) tables (four stored tables and one working table) can be entered into the Noise Figure Meter. Each table can have up to 35 entries. The Noise Figure Meter uses this data to correct for ENR versus frequency variations. For measurements made between calibration points, ENR data is interpolated. When the instrument is turned off, the ENR tables are stored in nonvolatile memory.

X- and Y-Axis outputs on the rear panel allow for noise figure and gain versus frequency to be displayed on a storage or nonstorage oscilloscope, or output to a recorder. On an oscilloscope, gain can be displayed at a lower intensity than noise figure, to distinguish between the two traces. The Z-Axis

output blanks an oscilloscope or lifts a recorder pen. A storage oscilloscope can also be used, but the differences in trace intensity are obscured.

Most functions can be remotely programmed via the Hewlett-Packard Interface Bus (HP-IB) and all measurement data is available to the HP-IB. The Noise Figure Meter has a second bus, the System Interface Bus (SIB). The System Interface Bus is a private bus used by the Noise Figure Meter to control certain instruments in the Noise Figure Measurement System. Instruments controlled by the SIB are the Noise Figure Test Set, the System Local Oscillator and a plotter.

1-8. Noise Figure Measurement System

The Noise Figure Measurement System extends the frequency range of the Noise Figure Meter from 1600 MHz to 18000 MHz. The Noise Figure Measurement System consists of the Noise Figure Meter, the HP 8971B Noise Figure Test Set and a System Local Oscillator.

All the features described about the Noise Figure Meter apply to the Noise Figure Measurement System, with the following changes:

- The Noise Figure Measurement System can be tuned between 10 and 18000 MHz.
- The noise figure of devices with output frequencies greater than 18000 MHz can be measured with the addition of an external mixer and a second, user-controlled, local oscillator (double-down-conversion).
- Measurements using interpolated calibration data are not allowed for measurement modes 1.5 through 1.9 unless a special function has been selected.

For simplicity, the Noise Figure Measurement System can be thought of as one instrument. The Noise Figure Meter's System Interface Bus is used to control the Noise Figure Test Set and the System Local Oscillator.

1-9. MECHANICAL OPTIONS

The following options may have been ordered and received with the Noise Figure Meter. If they were not ordered with the original shipment, they can be ordered from the nearest Hewlett-Packard office using the part number included in each of the following paragraphs.

MECHANICAL OPTIONS (cont'd)**1-10. Front Handle Kit (Option 907)**

Ease of handling is increased with the front panel handles. Order HP part number 5061-9689.

1-11. Rack Flange Kit (Option 908)

The Noise Figure Meter can be solidly mounted to the instrument rack using the flange kit. Order HP part number 5061-9677.

1-12. Rack Flange and Front Handle Combination Kit (Option 909)

This is not a front handle kit and a rack flange kit packaged together; it is composed of a unique part which combines both functions. Order HP part number 5061-9683.

1-13. HEWLETT-PACKARD  INTERFACE BUS**1-14. Compatibility**

The Noise Figure Meter is compatible with HP-IB to the extent indicated by the following code: SH1, AH1, T5, TE0, L4, LE0, SR1, RL1, PP0, DC1, DT1, C0, and E1. The Noise Figure Meter interfaces with the bus via open collector TTL circuitry. An explanation of the compatibility code can be found in IEEE Standard 488 (1978), "IEEE Standard Digital Interface for Programmable Instrumentation" or the identical ANSI Standard MC1.1. For more detailed information relating to programmable control of the Noise Figure Meter, refer to Remote Operation, Hewlett-Packard Interface Bus in Section III of this manual.

1-15. Selecting the HP-IB Address

The Noise Figure Meter can use two HP-IB addresses. One is the address of the Noise Figure Meter. The second is the HP-IB address of the Noise Figure Meter when it is in Pass Through Mode. (Pass Through Mode allows commands to be passed through the Noise Figure Meter from a computer on the HP-IB to an instrument on the SIB.) Refer to the HP-IB and System Interface Bus (SIB) Addresses Detailed Operating Instruction, in Section III, for additional information.

1-16. SYSTEM INTERFACE BUS (SIB)

The System Interface Bus is a private bus used by the Noise Figure Meter to control the Noise Figure Test Set, the System Local Oscillator and a plotter.

1-17. Compatibility

The System Interface Bus is compatible with IEEE Standard 488 (1978) to the extent indicated by the following codes: SH1, AH1, T6, TE0, L4, LE0, RL1, PP0, DC1, DT0, C1, C2, C3, C4, C7 and E1. The Noise Figure Meter interfaces with the bus via open collector TTL circuitry. An explanation of the compatibility code can be found in IEEE Standard 488 (1978), "IEEE Standard Digital Interface for Programmable Instrumentation" or the identical ANSI Standard MC1.1.

1-18. Selecting the SIB Address

The Noise Figure Meter uses SIB addresses for the following:

- System Local Oscillator
- Noise Figure Test Set
- Plotter
- System Interface Bus
- Pass Control
- Pass Through Device on the SIB

For more information on selecting the SIB addresses, refer to the HP-IB and System Interface Bus (SIB) Addresses Detailed Operating Instruction, in Section III.

1-19. ACCESSORIES SUPPLIED

The accessories supplied with the Noise Figure Meter are shown in Figure 1-1.

a. The line power may be supplied in several configurations, depending on the destination of the original shipment. Refer to paragraph Power Cables in Section II of this manual.

b. Fuses with a 1.5A rating for 100/120 Vac operation and a 1.0A for 220/240 Vac operation are supplied. One fuse is factory installed according to the voltage available in the country of original destination. Refer to paragraph Line Voltage and Fuse Selection in Section II of this manual.

1-20. EQUIPMENT REQUIRED BUT NOT SUPPLIED

A noise source such as HP Model 346B (346A or 346C), must be used with the Noise Figure Meter. The Noise Figure Meter supplies +28.0V pulses to drive the noise source on and off.

1-21. ELECTRICAL EQUIPMENT AVAILABLE**1-22. HP-IB Controllers **

The Noise Figure Meter has an HP-IB interface and can be used with any HP-IB compatible computing controller or computer for automatic systems applications.

1-23. External Mixers and System Local Oscillators

The System Local Oscillator and a balanced mixer are used to extend the frequency range of the Noise Figure Meter. The System Local Oscillator is part of the Noise Figure Measurement System. Suitable local oscillators include the HP 8671B, HP 8672A or HP 8673B (standard) Synthesized Signal Generators and the HP 8340B or HP 8350B Sweep Oscillators. A suitable mixer is the HP HMXR-5001. This mixer is usable over a range of 2 to 12.4 GHz.

1-24. Waveguide/Coax Adapters

The HP 346B/C Noise Source combined with the HP X281C or P281C Waveguide/Coax Adapter makes a very accurate, calibrated waveguide noise source.

1-25. Front-to-Rear-Panel Connector Retrofit Kit

This kit contains all the necessary components and full instructions for converting instruments with a front panel INPUT connector to a rear panel connector. Order HP part number 08970-60100.

1-26. MECHANICAL EQUIPMENT AVAILABLE**1-27. Chassis Slide Mount Kit**

This kit is extremely useful when the Noise Figure Meter is rack mounted. Access to internal circuits and components or the rear panel is possible without removing the instrument from the rack. Order HP part number 1494-0060 for 430 mm (17 inch) fixed sides and part number 1494-0061 for the correct adapters for non-HP rack enclosures.

1-28. Chassis Tilt Slide Mount Kit

This kit is the same as the Chassis Slide Mount Kit above except that it also allows the tilting of the instrument up or down 90 degrees. Order HP part number 1494-0062 for 430 mm (17 inch) tilting slides and part number 1494-0061 for the correct adapters for non-HP rack enclosures.

1-29. RECOMMENDED TEST EQUIPMENT

Table 1-5 lists the test equipment recommended for use in testing, adjusting, and servicing the Noise Figure Meter. The Critical Specification column describes the essential requirements for each piece of test equipment. Other equipment can be substituted, if it meets or exceeds these critical specifications.

The Recommended Model column may suggest more than one model. The first model shown is usually the least expensive, single-purpose model. Alternate models are suggested for additional features that would make them a better choice in some applications.

Table 1-1. Noise Figure Meter Specifications (1 of 2)

| Characteristics | Performance Limits | Conditions |
|---|--|--|
| NOISE FIGURE MEASUREMENT | | |
| Range | 0 to 30 dB | For a noise source in a 0 to 55°C environment with an ENR of 14 to 16 dB. |
| Resolution | 0.01 dB ¹ | |
| Instrumentation Uncertainty | ±0.1 dB | |
| Jitter | Peak-to-peak ² Y-factor variation <0.15 dB Peak-to-peak ² Y-factor variation <0.02 dB | |
| GAIN MEASUREMENT | | |
| Range | -20 to > +40 dB | For total noise figures ≤30 dB. |
| Resolution | 0.01 dB ³ 0.1 dB ⁴ | Gain ≥ -9.99 dB Gain < -9.99 dB |
| Instrumentation Uncertainty | ±0.15 dB | |
| INPUT | | |
| Frequency Range | Tunable from 10 to 1600 MHz | From +10 to +40°C For input power levels below -60 dBm. 50Ω reference impedance. Between noise source and HP 8970B RF Input. For spurious levels below -45 dBm in the 10 to 2100 MHz range and -15 dBm in the 2.1 to 18 GHz range. |
| Frequency Resolution | 1 MHz | |
| Tuning Accuracy | ±(1 MHz + 1% of frequency), ±6 MHz maximum | |
| Noise Figure | <7 dB +0.003 dB/MHz | |
| Input SWR (Reflection Coefficient) | <1.7 (0.26) | |
| Maximum Operating Input Power | -10 dBm | |
| Maximum Net External Gain | >65 dB | |
| Spurious Response | <0.03 dB change in measured noise figure | |
| ¹ Resolution over the Hewlett-Packard Interface Bus is 0.001 dB. ² Peak-to-peak is defined as five times the standard deviation of a statistically valid set of readings. Five standard deviations about the mean includes 99% of the readings for a Gaussian distribution. ³ Resolution over the Hewlett-Packard Interface Bus is 0.001 dB. ⁴ Resolution over the Hewlett-Packard Interface Bus is 0.01 dB. | | |

Table 1-1. Noise Figure Meter Specifications (2 of 2)

| Characteristics | Performance Limits | Conditions |
|---|---|---|
| INPUT (cont'd) Reducing System Noise Figure with Preamplification | $<1.8 \text{ dB} + \text{noise figure of the external system}$ | Low noise external preamplification with net gain $>20 \text{ dB}$ |
| ELECTROMAGNETIC COMPATIBILITY EMI Conducted and Radiated Susceptibility | MIL STD 461B CISPR publication 11, and Messempfaenger Postverfuegung 526/527(1979) MIL STD 461B-1980 | Conducted and radiated interference is in compliance with MIL STD 461B Methods CE03 and RE02, CISPR publication 11 (1975), and Messempfaenger-Postverfuegung 526/527(1979) (Kennzeichnung Mit F-Nummer/ Funkschutzzeichen). Conducted and radiated susceptibility meets the requirements of methods CS01, CS02, and RS03 of MIL STD 461B dated 1980. |
| GENERAL Noise Source Drive Power Requirements Line Voltage: 100, 120, 220, or 240V Power Dissipation Temperature: Operating Storage Remote Operation (HP-IB) Dimensions: Height Width Depth Net Weight | $28.0 \pm 0.1\text{V}$ $<1\text{V}$ $+5, -10\%$ 150 VA maximum 0 to 55°C -55 to 75°C IEEE STD 488-1978 Compatibility Code: SH1, AH1, T5, TE0 L4, LE0, SR1, RL1, PP0, DC1, DT1, C0 and E1 146 mm (5.75 in.) 425 mm (16.8 in.) 462 mm (18.2 in.) 15.5 kg (34 lbs) | Noise source ON at up to 60 mA peak. Noise source OFF. 48 to 66 Hz, single phase. The Hewlett-Packard Interface Bus (HP-IB) is Hewlett-Packard's implementation of IEEE Std 488-1978, "Digital Interface for Programmable Instrumentation." Most functions are remotely programmable. Note: For ordering cabinet accessories, the module sizes are 5¼H, 1 MW (module width), and 17D. |

Table 1-2. Noise Figure Meter Supplemental Characteristics

Supplemental characteristics are intended to provide information useful in applying the instrument by giving typical, but non-warranted, performance parameters.

All parameters describe performance in automatic operation or properly set manual conditions.

Bandwidth: approximately 4 MHz.

Audible Noise Level: <5.5 bels at 1 metre.

Sensitivity: no external gain required; -100 dBm; able to measure its own noise figure.

Measurement Speed: about 6 to 9 measurements per second with minimum smoothing.

Sweep Speed at Minimum Smoothing (10 to 1600 MHz): 140 ms per frequency point.

Maximum Safe Input Level: ± 20 Vdc; +20 dBm peak (or average) at RF.

FUNCTIONAL PROPERTIES

Noise Figure Display Units: noise figure in dB or as a ratio, or uncorrected Y-Factor in dB or as a ratio, or effective input noise temperature in kelvins.

Displayed Measurement Frequency Range: 10 to 99999 MHz.

Number of Calibration Points in One Sweep: 181

System LO Control: frequency control over the System Interface Bus from 10 to 99999 MHz.

Noise Figure Display Jitter: <0.01 dB with appropriate smoothing.

Cold Noise Source Data Range: 0 to 9999K.

Hot Noise Source Data Range: stored table — ENR from -7 to +50 dB; spot frequency — from 0 to 14824K.

Storage Capacity of Hot Noise Source Tables: Four stored ENR tables with 35 frequencies each (plus one working ENR table).

Smoothing: exponential averaging of gain and noise figure before display according to $D = P(F-1) + M/F$ where D is the display result, prior to conversion to logarithmic form, P is the previous result, M is the latest measurement, and F is the averaging factor (1, 2, 4, 8, 16, 32, 64, 128, 256, or 512). Arithmetic averaging is used during swept operation.

Rear Panel Outputs: X-Axis and Y-Axis from 0 to 6V. Z-Axis is TTL for pen lift (on an X-Y recorder) and blanking (on an oscilloscope).

Plotter Capability: Noise figure and gain versus frequency plot with grid, title and noise figure, gain and frequency axis annotation.

Compatible Digital Plotters: HP 7470A, 7475A, 7550A, 7440A and 9872B.

Table 1-3. Noise Figure Measurement System Specifications

| Characteristics | Performance Limits | Conditions |
|--|---|--|
| <p>Specifications for the Noise Figure Measurement System are the same as the Noise Figure Meter, with the following exceptions. These specifications are valid when any of the recommended system local oscillators (HP 8671B, HP 8672A, HP 8673B [standard], HP 8673C, HP 8340A/B or HP 8341A/B) is used in the Noise Figure Measurement System.</p> | | |
| <p>NOISE FIGURE MEASUREMENT Range Instrumentation Uncertainty^{1,2}</p> | <p>0 to 30 dB $<\pm 0.25$ dB</p> | <p>All specifications certified for temperature range of +10 to +40° C For a noise source with an ENR of 14 to 16 dB. For $NF1 + G1 > 5$ dB where NF1 is the noise figure of the device under test and G1 is the gain of the device under test.</p> |
| <p>GAIN MEASUREMENT Instrumentation Uncertainty^{1,2}</p> | <p>$<\pm 0.45$ dB</p> | <p>For $NF1 + G1 > 10$ dB where NF1 is the noise figure of the device under test and G1 is the gain of the device under test.</p> |
| <p>INPUT Frequency Range Reducing System Noise Figure with Pre-amplification Noise Figure (maximum) SSB1 SSB2 SSB3 Input SWR SSB1 SSB2 SSB3</p> | <p>Tunable from 10 to 18000 MHz < 2 dB + noise figure of the external system ≤ 12 dB + 0.003 dB/MHz ≤ 21 dB ≤ 22 dB ≤ 24 dB ≤ 28 dB 1.7:1 2:1 2:1</p> | <p>Low noise external preamplification with net gain 30 dB 10 MHz to 1.6 GHz 1.6 to 2.4 GHz 2.4 to 12 GHz 12 to 15 GHz 15 to 18 GHz 10 MHz to 1.6 GHz 1.6 to 2.4 GHz 2.4 to 18 GHz</p> |
| <p>GENERAL Power, net weight and dimensions</p> | <p>Sum of HP 8970B, HP 8971B and local oscillator.</p> | |
| <p>¹ Noise figure accuracy and gain accuracy are dependent on the device under test. Refer to the Pre-amplifier Selection detailed operating instruction in Section III for more information on computing accuracy for your application. ² When making a measurement, the Noise Figure Measurement System must be tuned in the same direction and to the same frequency points used during calibration without skipping any frequency points.</p> | | |

Table 1-4. Noise Figure Measurement System Supplemental Characteristics

Supplemental characteristics are intended to provide information useful in applying the system by giving typical, but non-warranted, performance parameters.

Maximum Safe Input Level: +20 dBm, 0Vdc

Maximum Operating Input Power: -20 dBm

Maximum Net External Gain: >60 dB

Sensitivity: -90 dB (no external gain required, but recommended to lower measurement uncertainty; able to measure its own noise figure with HP 346B/C.

Double Sideband (DSB) Noise Figure: ≤18 dB typical

SWR (dB): 2.5:1 typical

Measurement Speed: 6 to 9 measurements per second with minimum smoothing

Sweep Speed at Minimum Smoothing (for each Noise Figure Test Set band):

| | |
|------------------------|----------------------------|
| SSB1 (10 to 1600 MHz): | 140 ms per frequency point |
| SSB2 (1.6 to 2.4 GHz): | 150 ms per frequency point |
| SSB3 (2.4 to 18 GHz): | 435 ms per frequency point |
| DSB (2.4 to 18 GHz): | 150 ms per frequency point |

Functional Properties

System Local Oscillator Control: The Noise Figure Meter will control the system local oscillator used in the Noise Figure Measurement System. The Noise Figure Meter will not control a local oscillator that is external to the Noise Figure Measurement System.

Displayed Measurement Frequency Range: 10 to 99999 MHz

Table 1-5. Recommended Test Equipment (1 of 2)

| Instrument | Specifications | Recommended Model | Use* |
|--|---|--|----------|
| Attenuator, 1 dB Steps | Steps: 1 dB from 0 to 11 dB Frequency Range: 10 to 1600 MHz | HP 8494A Option 001 | P, A |
| Attenuator, 10 dB Steps | Steps: 10 dB from 0 to 70 dB Frequency Range: 10 to 1600 MHz | HP 8495A Option 001 | P |
| Attenuator, Fixed 6 dB | Attenuation: 6 dB Frequency Range: 10 to 1600 MHz | HP 8491A Option 006 | P, A |
| Attenuator, Fixed 10 dB (2 required) | Attenuation: 10 dB Frequency Range: 10 to 1600 MHz | HP 8491A Option 010 | P |
| Attenuator, Fixed 20 dB | Attenuation: 20 dB Frequency Range: 10 to 1600 MHz | HP 8491A Option 020 | P |
| Calculator | Functions: Divide, multiply, square root Programmable | HP 41C | P, A |
| Controller, HP-IB | HP-IB compatibility as defined by IEEE Standard 488 and the identical ANSI Standard MC1.1: SH1, AH1, T2, TE0, L2, LE0, SR0, RL0, PP0, DC0, DT0, C1, 2, 3, 4, 5 | HP 85B/82936A (ROM Drawer)/00085-15005 (Advanced Programming ROM) or HP 9000 Series 200 or 300 | C, P, T |
| Digital Voltmeter | DC Voltage Range: Up to 100V Resolution (in high resolution mode): 1 μ V on 1 Vdc range Accuracy (in high resolution mode): $\pm 0.003\%$ of reading +4 counts Single Trigger capability | HP 3455A or HP 3456A (Systems DVM) | P, A, T |
| Directional Coupler | Frequency Range: 1380 to 2300 MHz | HP 778D | P |
| Display Module | X-, Y- and Z capability Bandwidth: 5 MHz Vertical and horizontal full scale deflection: 0—10 volts | HP 1332A Options 101 and 315 | C |
| Filter, Low-Pass | Insertion Loss: <1 dB below 0.9 times cut-off frequency Cut-Off Frequency: 1200 MHz Rejection: >50 dB at 1.25 times cut-off frequency | HP 360B | P, A |
| Frequency Counter | Range: 10 to 4000 MHz Resolution: 1 kHz | HP 5340A or HP 5343A | A |
| Interface HP-IB | Required for HP 85B only | HP 82937A | C, P, T, |
| *C = Operator's Checks; P = Performance Tests; A = Adjustments; T = Troubleshooting. | | | |

Table 1-5. Recommended Test Equipment (2 of 2)

| Instrument | Specifications | Recommended Model | Use* |
|---------------------------------------|--|--|---------------|
| Logic Analyzer | Input Lines: 43 Timing Analysis: 16 lines | HP 1630A, HP 1630D or HP 1631D | T |
| Noise Source | Power Required: +28V ENR: 15.2 dB Connector: Type N (male) | HP 346B Option 001 or HP 346C | C, P, T |
| Oscilloscope | Inputs: 2 Channel (A vs. B or X vs. Y) and Z-Axis | HP 1740A or HP 1980A (Oscilloscope Measuring System) HP 1980B, or HP 54200A/D | A, T |
| Power Meter | Uncertainty: ± 0.02 dB Mode: dB Relative | HP 436A | P, A, T |
| Power Sensor | Frequency Range: 10 to 4000 MHz Power Range: 0.1 nW to 10 μ W SWR (30 to 4000 MHz): 1.15 | HP 8484A, HP 8482A or HP 8485A | P, A, T |
| Power Splitter | Frequency Range: 10 to 1600 MHz | HP 11667A | P, A |
| Signal Generator (System LO) | Frequency Range: 10 to 1600 MHz Frequency Accuracy: ± 1 kHz Output Level: +13 dBm | HP 8340B (Sweep Oscil- lator) or HP 8672A or HP 8673B (Synthesized Signal Generators) | C, T P, A, |
| Signal Generator | Frequency Range: 1380 to 2300 MHz Output Level: +10 dBm Fundamental signal generator | HP 8614A | P |
| Signature Multimeter (Analyzer) | Because the signatures documented are unique to a given signature analyzer, no substitution is recommended | HP 5005A or HP 5005B or HP 5006A | T |
| Spectrum Analyzer | Frequency Range: 10 to 1600 MHz | HP 8565A or HP 8566A | A |
| Sweep Oscillator | Frequency Range: 20 to 2400 MHz Attenuation: 70 dB in 10 dB steps | HP 8620C/86222B Option 002 or HP 8340B or HP 8350B | A, C |
| SWR Bridge | Frequency Range: 10 to 1600 MHz Directivity: 40 dB | Wiltron 60N50 | P |
| Wideband Amplifier I | Frequency Range: 0.1 to 1300 MHz Gain: 26 dB Output Power for 1 dB Gain Compression: +7 dBm | HP 8447D Option 010 | P |
| Wideband Amplifier II | Frequency Range: 0.1 to 1300 MHz Gain: 48 dB Output Power for 1 dB Gain Compression: $> +15$ dBm | HP 8447F Option 010 | P |

*C = Operator's Checks; P = Performance Tests; A = Adjustments; T = Troubleshooting.

SECTION II INSTALLATION

2-1. INTRODUCTION

This section provides the information needed to install the Noise Figure Meter. Included is information pertinent to initial inspection, power requirements, line voltage selection, power cables, interconnection, environment, instrument mounting, storage, and shipment. In addition, interconnect information for the Noise Figure Measurement System is provided.

2-2. INITIAL INSPECTION

WARNING

To avoid hazardous electrical shock, do not perform electrical tests when there are signs of shipping damage to any portion of the outer enclosure (covers, panels, meters).

Inspect the shipping container for damage. If the shipping container or cushioning material is damaged, it should be kept until the contents of the shipment have been checked for completeness and the instrument has been checked mechanically and electrically. The contents of the shipment should be as shown in Figure 1-1. Procedures for checking electrical performance are given in Section IV. If the contents are incomplete, if there is mechanical damage or defect, or if the instrument does not pass the electrical performance tests, notify the nearest Hewlett-Packard office. If the shipping container is damaged or the cushioning material shows signs of stress, notify the carrier as well as the Hewlett-Packard office. Keep the shipping materials for the carrier's inspection.

2-3. PREPARATION FOR USE

2-4. Power Requirements

The Noise Figure Meter requires a power source of 100, 120, 220 or 240 Vac, +5% to -10%, 48 to 66 Hz single phase. Power consumption is 150 VA maximum.

WARNING

This is a Safety Class I product (that is, provided with a protective earth terminal). An uninterruptible safety earth

ground must be provided from the main power source to the product input wiring terminals, power cord or supplied power cord set. Whenever it is likely that the protection has been impaired, the product must be made inoperative and be secured against any unintended operation.

If this instrument is to be energized via an external autotransformer, make sure the autotransformer's common terminal is connected to the neutral (that is, the grounded side of the Mains supply).

2-5. Line Voltage and Fuse Selection

CAUTION

BEFORE PLUGGING THIS INSTRUMENT into the Mains (line) voltage, be sure the correct voltage and fuse have been selected.

Verify that the line voltage selection card and the fuse are matched to the power source. Refer to Figure 2-1, Line Voltage and Fuse Selection.

Fuses may be ordered under HP part numbers 2110-0043, 1.5A (250V, normal blow) for 100/120 Vac operation and 2110-0001, 1.0A (250V, normal blow) for 220/240 Vac operation.

2-6. Power Cables

WARNING

BEFORE CONNECTING THIS INSTRUMENT, the protective earth terminals of this instrument must be connected to the protective conductor of the (Mains) power cord. The Mains plug shall only be inserted in a socket outlet provided with a protective earth contact. The protective action must not be negated by the use of an extension cord (power cable) without a protective conductor (grounding).




Figure 2-1. Line Voltage and Fuse Selection

This instrument is equipped with a three-wire power cable. When connected to an appropriate ac power receptacle, this cable grounds the instrument cabinet. The power cable plug shipped with each instrument depends on the country of destination. Refer to Figure 2-2 for the part numbers of the power cables available.

2-7. Address Selection HP-IB

The Noise Figure Meter uses HP-IB and System Interface Bus (SIB) addresses. The HP-IB address is used when the Noise Figure Meter is accessed by an external controller. SIB addresses are used when the Noise Figure Meter acts as a controller to access other devices. When the Noise Figure Meter is shipped from the factory, it assumes that devices are set to the addresses shown in Table 2-1.

Both HP-IB and SIB addresses are selected by Special Function from the front panel. Refer to HP-IB and System Interface Bus (SIB) Addresses, and System Interface Bus Control in the detailed operating instructions in Section III for additional information.

Valid HP-IB and SIB addresses are 0 through 30. Refer to Table 2-2 for decimal equivalents of the ASCII Talk and Listen address codes.







| | | | |
|---|--|---|--|
|  220/240V OPERATION PLUG*: SEV 1011.1959-24507 TYPE 12 CABLE*: HP 8120-2104 |  220/240V OPERATION PLUG*: NZSS 198/AS C112 CABLE*: HP 8120-1369 |  100/120V OPERATION PLUG*: NEMA 5-15P CABLE*: 8120-1378 |  220/240V OPERATION PLUG*: NEMA 6-15P CABLE*: HP 8120-0698 |
|  220/240V OPERATION PLUG*: CEE7-VII CABLE*: HP 8120-1689 |  220/240V OPERATION PLUG*: DHCK 107 CABLE*: HP 8120-2956 |  220/240V OPERATION PLUG*: BS 1363A CABLE: HP 8120-1351 | |
| <p>*The number shown for the plug is the industry identifier for the plug only. The number shown for the cable is an HP part number for a complete cable including the plug.</p> | | | |

Figure 2-2. Power Cable and Mains Plug Part Numbers

Table 2-1. Noise Figure Meter Factory Set Addresses

| Instrument | HP-IB Address | SIB Address |
|-------------------------|---------------|-------------|
| Noise Figure Meter | 8 | |
| Plotter | | 5 |
| System Interface Bus | | 8 |
| Noise Figure Test Set | | 10 |
| Pass Control Device | | 16 |
| System Local Oscillator | | 19 |

2-8. Interconnections

Interconnection data for the Hewlett Packard Interface Bus (HP-IB) and the System Interface Bus (SIB) is identical. See Figure 2-3.

2-9. HP 8970S Noise Figure Measurement System

The HP 8970S Noise Figure Measurement System consists of the Noise Figure Meter, the Noise Figure Test Set and a System Local Oscillator. Interconnection data for the Noise Figure Measurement System is provided in Figure 2-4. If the System Local Oscillator is a free-running source, a coarse tune calibration must be performed. Refer to the Noise Figure Test Set YIG Filter Calibration detailed operating instruction in Section III for the coarse tune calibration procedure. The coarse tune calibration is not needed if a synthesizer is used for the local oscillator.

2-10. Mating Connectors

Interface Connector. The HP-IB and SIB mating connector is shown in Figure 2-3. Note that two securing screws are metric.

Coaxial Connectors. Coaxial mating connectors used with the Noise Figure Meter should be 50 ohm BNC, or type N male connectors. 50Ω type N and APC-3.5 male coaxial connectors are used with the Noise Figure Test Set.

2-11. Operating Environment

The operating environment for the Noise Figure Meter should be within the following limitations:
 Temperature 0 to +55°C
 Humidity <95% relative
 Altitude <4570 metres (15 000 feet)

2-12. Bench Operation

The instrument cabinet has plastic feet and fold-away tilt stands for convenience in bench operation. (The plastic feet are shaped to ensure self-aligning of the

instruments when stacked with other HP equipment.) The tilt stands raise the front of the instrument for easier viewing of the front panel.

Table 2-2. ASCII Address Codes to Decimal Equivalents


| ASCII Address Codes | | Decimal Equivalents |
|---------------------|------|---------------------|
| LISTEN | TALK | |
| SP | @ | 00 |
| ! | A | 01 |
| " | B | 02 |
| # | C | 03 |
| \$ | D | 04 |
| % | E | 05 |
| & | F | 06 |
| ' | G | 07 |
| (| H | 08 |
|) | I | 09 |
| * | J | 10 |
| + | K | 11 |
| , | L | 12 |
| - | M | 13 |
| . | N | 14 |
| / | O | 15 |
| 0 | P | 16 |
| 1 | Q | 17 |
| 2 | R | 18 |
| 3 | S | 19 |
| 4 | T | 20 |
| 5 | U | 21 |
| 6 | V | 22 |
| 7 | W | 23 |
| 8 | X | 24 |
| 9 | Y | 25 |
| : | Z | 26 |
| ; | [| 27 |
| < | \ | 28 |
| = |] | 29 |
| > | ^ | 30 |

2-13. Rack Mounting

WARNING

The Noise Figure Meter weighs 18.5 kg (40 lb), therefore, care must be exercised when lifting to avoid personal injury. Use equipment slides when rack mounting.

Rack mounting information is provided with the rack mounting kits. If the kits were not ordered with the instrument as options, they may be ordered through the nearest Hewlett-Packard office. Refer to the paragraph entitled Mechanical Options in Section I.



Logic Levels

The Hewlett-Packard Interface Bus and System Interface Bus Logic Levels are TTL compatible, i.e., the true (1) state is 0.0 Vdc to +0.4 Vdc and the false (0) state is +2.5 Vdc to +5.0 Vdc.

Programming and Output Data Format

Refer to Section III, Operation.

Mating Connector

HP 1251-0293; Amphenol 57-30240.

Mating Cables Available

HP 10833A, 1 metre (3.3 ft), HP 10833B, 2 metres (6.6 ft)
 HP 10833C 4 metres (13.2 ft), HP 10833D, 0.5 metres (1.6 ft)

Cabling Restrictions

1. A Hewlett-Packard Interface Bus system or System Interface Bus system may contain no more than 2 metres (6.6 ft) of connecting cable per instrument.
2. The maximum accumulative length of connecting cable for any Hewlett-Packard Interface Bus system or System Interface Bus system is 20.0 metres (65.6 ft).

Figure 2-3. Hewlett-Packard Interface Bus and System Interface Bus Connections

2-14. RECORDING IF ATTENUATOR VALUES

IF attenuator data is used to correct the gain readings during the gain measurement. It is critical that the Noise Figure Meter know the value of its internal IF attenuators in order to meet its gain accuracy specification. Recording these values ensures a backup record is kept if a nonvolatile memory failure should occur. *HP recommends that IF attenuator values be recorded in Table 4-1 when the Noise Figure Meter is turned on for the first time and after its annual calibration.* Table 4-1 is located in the Gain Measurement Uncertainty Performance Test in Section IV. This performance test also includes a procedure for reading the IF attenuator values. Refer to the "Entering IF Attenuator Values" portion of the performance test.

2-15. STORAGE AND SHIPMENT

2-16. Environment

The instrument should be stored in a clean, dry environment. The following environmental limitations apply to both storage and shipment:

- Temperature -55°C to +75°C
- Humidity <95% relative
- Altitude <15 300 metres (50 000 feet)

2-17. Packaging

Tagging for Service. If the instrument is being returned to Hewlett-Packard for service, please complete one of the blue repair tags located at the back of this manual and attach it to the instrument.

Original Packaging. Containers and materials identical to those used in factory packaging are available through Hewlett-Packard offices. Mark the container "FRAGILE" to assure careful handling. In any correspondence, refer to the instrument by model number and full serial number.

Other Packaging. The following general instructions should be used for re-packaging with commercially available materials:

- a. Wrap the instrument in heavy paper or plastic. (If shipping to a Hewlett-Packard office or service center, complete one of the blue tags and attach it to the instrument.)
- b. Use a strong shipping container. A double-wall carton made of 2.4 MPa (350 psi) test material is adequate.
- c. Use enough shock-absorbing material (75 to 100 mm layer; 3 to 4 inches) around all sides of the instrument to provide firm cushion and prevent movement in the container. Protect the front panel with cardboard.
- d. Seal the shipping container securely.
- e. Mark the shipping container "FRAGILE" to assure careful handling.




Figure 2-4. Noise Figure Measurement System Interconnections

SECTION III OPERATION

3-1. INTRODUCTION

This section provides complete operating information for the Noise Figure Meter. Included in this section are both general and detailed operating instructions, detailed descriptions of the front and rear panel, local and remote operator's checks, and operator's maintenance procedures. Also provided are operation and operator's checks for the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and System Local Oscillator). Operation of the Noise Figure Measurement System is described under Measurement Modes 1.5 through 1.9.

3-2. Operating Characteristics

Table 3-1 briefly summarizes the major operating characteristics of the Noise Figure Meter. This table is not intended to be an in-depth listing of all operations and ranges but gives a rough idea of the instrument's capabilities. For more information on the Noise Figure Meter's capabilities, refer to Table 1-1, Specifications and Table 1-2, Supplemental Characteristics. For information on HP-IB capabilities, refer to the summary contained in Table 3-3, Message Reference Table.

3-3. Local Operation

Information covering front panel operation of the Noise Figure Meter is given in the sections described below. To rapidly learn the operation of the instrument, begin with Simplified Operation and Operator's Checks. Once familiar with the general operation of the instrument, use the Detailed Operating Instructions for in-depth and complete information in operating the Noise Figure Meter.

General Operating Information. Instructions relating to the Noise Figure Meter turn-on procedure and various keystroke sequences are presented to acquaint the user with the general operation of the instrument.

Simplified Operation. The instructions located on the inside of this fold provide a quick introduction to front panel operation of the Noise Figure Meter. These instructions are designed to rapidly acquaint the new user with basic operating proce-

dures and therefore are not an exhaustive listing of all Noise Figure Meter functions. However, an index to the Detailed Operating Instructions appears opposite the fold to direct the operator to the more complete discussion of the topic of interest.

Panel Features. Front and rear panel features are described in detail in Figures 3-1 through 3-8.

Detailed Operating Instructions. The Detailed Operating Instructions provide the complete operating reference for the Noise Figure Meter user. The instructions are organized alphabetically by subject and are placed at the end of this section for easy reference. They are indexed by function in Table 3-2.

Operating Information Pull-Out Cards. The Operating Information pull-out cards are three flexible plastic reference sheets located in a tray below the front panel. They contain a listing of user special functions, HP-IB output formats, error codes, and measurement modes.

3-4. Remote Operation

The Noise Figure Meter is capable of remote operation via the Hewlett-Packard Interface Bus (HP-IB). In remote operation, the Noise Figure Meter operates in one of two modes: normal talker listener mode and talk only mode. The remote operation instructions provide information pertinent to HP-IB operation when the Noise Figure Meter is in the normal talker/listener mode or the talk only mode. Included are discussions on capabilities, addressing, input and output formats, the status bytes and service requests. At the end of the discussion is a complete summary of all codes and formats.

In addition to the section described above, information concerning remote operation appears in several other locations. The controller capability of the Noise Figure Meter is described in the Detailed Operating Instructions. A summary of HP-IB codes and output formats appear on one of the Operating Information pull-out cards. Numerous examples of program strings appear throughout the Detailed Operating Instructions.

3-5. Operator's Checks

Operator's Checks are procedures designed to verify the proper operation of the Noise Figure Meter's main functions. Also, Operator's Checks are provided for the Noise Figure Measurement System. Three procedures are described below.

Basic Functional Checks. This procedure requires only a noise source, an oscilloscope (or a display module), and interconnecting cables. It assures that most front panel controlled functions are being properly executed by the Noise Figure Meter.

HP-IB HP-IB Functional Checks. These procedures require an HP-IB compatible computing controller, an HP-IB interface and connecting cable. The HP-IB Functional Checks assume that front panel operation of the Noise Figure Meter, has been verified by performing the Basic Functional Checks. The procedures check all of the applicable bus messages summarized in Table 3-3.

Noise Figure Measurement System Check. This procedure only requires the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and System Local Oscillator) and a noise source. The check assures that the Noise Figure Measurement System is operating properly.

3-6. Operator's Maintenance

WARNING

For continued protection against fire hazard, replace the line fuse with a 250V fuse of the same rating only. Do not use repaired fuses or short-circuited fuse-holders.

Operator's maintenance consists of replacing blown fuses and cleaning the air filter.

The primary power fuse is located within the Line Power Module (A15). Refer to Figure 2-1 for instructions on how to change the fuse.

The rear panel fan has a filter inserted from the outside for ease of cleaning or replacement. To service the filter, disconnect power from the instrument and remove the filter by pulling it from the rear of the fan. To clean the filter, hold it under running water or wash it in warm soapy water and then rinse it in clear water. Dry the filter thoroughly before putting it back into place.

NOTE

The internal battery should be replaced once a year by qualified service personnel. In the Service Manual, Section VIII, is a procedure for replacing the battery. The part number of the Service Manual is on the title page of this manual.

If the instrument does not operate properly and is being returned to Hewlett-Packard for service, please complete one of the blue tags located at the end of this manual and attach it to the instrument. Refer to Section II for packaging instructions.

3-7. GENERAL OPERATING INSTRUCTIONS

WARNING

Before the Noise Figure Meter is switched on, all protective earth terminals, extension cords, auto-transformers, and devices connected to the instrument should be connected to a protective earth grounded socket. Any interruption of the protective earth grounding will cause a potential shock hazard that could result in personal injury.

CAUTION

Before the Noise Figure Meter is switched on, it must be set to the same line voltage as the power source or damage to the instrument may result.

3-8. Turn On

Turn-on Procedures. If the Noise Figure Meter is already plugged in, set the LINE switch to ON.

If the power cable is not plugged in, follow these instructions.

On the rear panel:

1. Check the line voltage selection card for correct voltage selection.
2. Check the fuse for correct current rating. The current rating is printed on the line power module label.
3. Plug in the power cable.

On the front panel, set the LINE switch to ON.

Turn On (cont'd)

Turn-on Sequence. The Noise Figure Meter performs a quick internal check at turn-on. During this check, all front panel indicators light for approximately two seconds to allow a quick visual inspection of each front panel display annunciator and display segment. If a failure is detected, an error code will appear in the NOISE FIGURE display to indicate the nature of the failure. For error codes E10 through E49, and E80, refer to Error Messages and Recovery in the Detailed Operating Instructions. For error codes E60 through E80, refer to Section VIII (Service)*.

If the memory check was successful, "Ctrl" will appear in the INSERTION GAIN display and "on" or "OFF" will appear in the NOISE FIGURE display. If the Noise Figure Meter is the system controller on the System Interface Bus (Special Function 48.0) "on" will be displayed. If the Noise Figure Meter is not the system controller on the System Interface Bus (Special Function 48.1) "OFF" will be displayed. Then, "Fr" will appear in the INSERTION GAIN display and "CAL" will appear in the NOISE FIGURE display for approximately five seconds while the Noise Figure Meter performs a frequency calibration.

After the frequency calibration, the instrument powers up to the last front panel configuration prior to being turned off. Refer to Preset Conditions and Power-Up Sequence in the Detailed Operating Instructions for additional information.

NOTE

An internal battery is used to retain data in continuous memory when the Noise Figure Meter is turned off. At turn-on, the Noise Figure Meter restores the same front panel configuration that was present when last powered down. Nine storage registers, the ENR tables and other information are also restored.

3-9. Keystroke Sequences

The Noise Figure Meter's functions can be selected in any order. However, each function selection

*Section VIII, Service, is in the Service Manual. The part number of the Service Manual is on the title page of this manual.

requires a prescribed sequence of keystrokes. A keystroke sequence can be either a single keystroke or several keystrokes that must be entered in a specific order. Functions requiring only single keystroke are: PRESET, LOCAL, UNCORRECTED NOISE FIGURE, CORRECTED NOISE FIGURE AND GAIN, INCREASE, DECREASE, AUTO, SINGLE, ▲ and ▼. The CALIBRATE function requires that the calibrate key be pressed twice.

Frequency parameters are entered in a Function-Data-ENTER format. Data entered following a function will be interpreted for that function only if terminated with the ENTER key. Data previously entered remains unaffected until the new data entry is terminated by pressing the ENTER key. If another function key is pressed before the data entry is terminated, that entry will be rejected and the last valid data for the function will remain active.


The STORE and RECALL functions are used to store and recall instrument configurations or Excess Noise Ratio (ENR) tables. When used to store and recall instrument configurations, the STORE and RECALL functions are entered in a Function-Data format. It is not necessary to use the ENTER key to terminate data entry. However, ENTER has no effect if it is used. Data is a single digit register number (0 through 9). When used to store and recall ENR tables, the STORE and RECALL functions are entered in a Function-ENR-Data format. It is not necessary to use the ENTER key to terminate data entry. However, ENTER has no effect if it is used. ENR is the ENR key. Data is a single digit table number (1 through 4).

Special Functions are entered in a Code-SPECIAL FUNCTION format. The code consists of a prefix, decimal, and suffix. 7.1 is an example of a special function code where 7 is the prefix and 1 is the suffix. If the suffix is zero, the zero and the decimal point can be omitted when entering the code. For example, 7 SPECIAL FUNCTION is equivalent to 7.0 SPECIAL FUNCTION. A Code-SPECIAL FUNCTION-Data-ENTER format is used to activate and enter data for special functions that require data entry.

Table 3-1. Operating Characteristics

| | |
|--------------------------------|--|
| <p>Measurements</p> | <p>Noise Figure (Corrected and Uncorrected Modes) Range: 0 to 30 dB Selectable Display Units: F dB, F, Y dB, Y, Te K Insertion Gain (Corrected Mode Only) Range: -20 to +40 dB Display Units: dB</p> |
| <p>Tuning</p> | <p>Fixed Frequency Range 10 to 1600 MHz (Noise Figure Meter) 10 to 18000 MHz (Noise Figure Measurement System) Sweep Linear sweep Range: 10 to 1600 MHz Resolution: 1 MHz Modes: Automatic, Single</p> |
| <p>Noise Source Parameters</p> | <p>Drive: +28V (pulsed) Entry Units: ENR in dB, °C, °F, K Hot Temp. Entry Range: 363 to 15000K Cold Temp. Entry Range: 0 to 1000K</p> |
| <p>Smoothing</p> | <p>Exponential or linear averaging of insertion gain and noise figure data before result is displayed. Selectable units in factors of 2.</p> |

FRONT PANEL FEATURES



FIXED FREQ keys cause the current tuned frequency and frequency increment values to be displayed, and enable the entry of new values (see Figure 3-5).

SWEEP keys cause the current sweep parameters to be displayed, enable the entry of new parameters, and initiate or terminate AUTO or SINGLE Sweep (see Figure 3-5).

HP-IB Annunciators indicate HP-IB status (see Figure 3-2).

LOCAL key returns the Noise Figure Meter to local keyboard control from remote control provided the instrument is not in local lockout.

PRESET key returns the instrument to the preset conditions shown in Simplified Operation.

ENR key enables entry of the "ENR versus Frequency" calibration data for specific noise sources (see Figure 3-4).

LINE switch applies power to the instrument when set to ON.

NOISE SOURCE DRIVE OUTPUT drives a noise source on and off with +28V pulses (see Figure 3-4).

INSERTION GAIN displays the gain of the device under test (for a corrected measurement) and ENR. Other displays are possible when using Special Functions (see Figure 3-2).

ENTER key completes a data entry (see Figure 3-6).

NOISE FIGURE displays measured noise (in selectable output units), error codes and ENR table number with number of table entries. Other displays are possible when using Special Functions (see Figure 3-2).

GRAPHIC SCALE keys set the vertical scaling for an oscilloscope or plotter (see Figure 3-3).

CALIBRATE key initiates a calibration sequence. This sequence measures the noise figure of the measurement system for use in corrected measurements (see Figure 3-7).

CORRECTED NOISE FIGURE AND GAIN key selects the noise figure and gain measurement. The measurement system noise contribution is automatically removed (see Figure 3-7).

INPUT couples the output signal from the measurement setup into the Noise Figure Meter (see Figure 3-7).

UNCORRECTED NOISE FIGURE key selects the noise figure measurement. Displayed values include noise contribution of all parts of the measurement system (see Figure 3-7).

SMOOTHING keys INCREASE or DECREASE the amount of smoothing (see Figure 3-7).

Left Display indicates frequency, entries in progress, temperature, and Special Function codes (see Figure 3-2).

DATA keys are used to enter numeric data (see Figure 3-6).

SPECIAL FUNCTION key completes entry of Special Function codes (see Figure 3-6).

STORE-RECALL-SEQ keys STORE up to 10 instrument configurations for RECALL at a later time. The SEQ key permits a sequential recall of up to 9 stored instrument configurations. Also used to STORE and RECALL the ENR tables. (See Figure 3-6).

Operating Information pull-out cards are quick operating references that show Special Functions, HP-IB codes, error codes and measurement modes.

Figure 3-1. Front-Panel Features

SIMPLIFIED OPERATION

PRESET

Press **PRESET** This sets the front panel functions to the following:

| | |
|----------------------|--|
| FREQUENCY = 30 MHz | STEP SIZE = 20 MHz |
| FREQ INCR = 20 MHz | SMOOTHING = 1 |
| START FREQ = 10 MHz | MEASUREMENT = UNCORRECTED NOISE FIGURE |
| STOP FREQ = 1600 MHz | CALIBRATE = Off |
| SWEEP = Off | |

In addition, default values are entered for some Special Functions. Refer to Table 3-14, Special Function Summary.

MEASUREMENT MODES

The Noise Figure Meter has ten Measurement Modes (1.0 through 1.9). Mode 1.0 is used for RF measurements ranging from 10 to 1600 MHz and requires no external equipment (except a noise source). Modes 1.1 through 1.4 are used for microwave measurements of up to 99999 MHz and require the system local oscillator (LO). Modes 1.1 and 1.2 also require an external mixer (the mixer is part of the device-under-test (DUT) in Modes 1.3 and 1.4). Modes 1.5 through 1.9 are also for microwave measurements. Mode 1.5 is used for measurements from 10 to 18000 MHz. Modes 1.6 through 1.9 are for measurements up to 99999 MHz. Modes 1.5 through 1.9 require use of the Noise Figure Test Set and the system LO. Along with the Noise Figure Meter, the Noise Figure Test Set and the system LO form the Noise Figure Measurement System, which extends the range of the Noise Figure Meter from 1600 to 18000 MHz. Modes 1.6 through 1.9 require use of a second LO (user-controlled). The user-controlled LO is used with the Noise Figure Measurement System, and, along with an external mixer, extend the range of the Noise Figure Measurement System from 18000 to 99999 MHz. Modes 1.6 and 1.7 require an external mixer (the mixer is part of the DUT in Modes 1.8 and 1.9). Refer to the operating information pull-out card and Measurement Modes in the Detailed Operating Instructions for more information. A Measurement Mode must be selected before performing a calibration or measurement. (Mode 1.0 is selected with PRESET.) Simplified Operation assumes that Mode 1.0 is selected.

FIXED FREQUENCY TUNING

Fixed frequency parameters are selected in a Function-Data-ENTER format. For example, to set the tuned frequency to 500 MHz and the frequency increment to 100 MHz:

press

| | FIXED FREQ (MHz) | DATA | | |
|------------------|------------------------|----------|----------|--------------|
| FREQUENCY | 5 | 0 | 0 | ENTER |
| FREQ INCR | 1 | 0 | 0 | ENTER |

 or  steps the frequency up or down by the 100 MHz increment set with the **FREQ INCR** key.

STORE AND RECALL

The Noise Figure Meter can store instrument configurations for recall at a later time. For example, to store an instrument configuration in storage register 5:

press **STORE** **5**

To recall the stored instrument configuration: press **RECALL** **5**


The Noise Figure Meter can store and recall four (1 through 4) Excess Noise Ratio (ENR) tables. For example, to store ENR data to table 3, use the following sequence:

press **STORE** **ENR** **3**

To recall ENR table 3, use the following sequence: press **RECALL** **ENR** **3**

SWEEP FUNCTIONS

Sweep parameters are selected in a Function-Data-ENTER format. For example, to set the start frequency to 1000 MHz, the stop frequency to 1600 MHz and the step size to 100 MHz:





The Noise Figure Meter can sweep the selected frequency range once (SINGLE) or repetitively (AUTO). The sweep can be terminated by pressing the same key again.

MEASUREMENT

Connect a noise source to the Noise Figure Meter as shown:

Uncorrected Noise Figure

To measure uncorrected noise figure: press .
The Noise Figure Meter is measuring its own noise figure.




Calibrate

Calibrate measures and stores the measurement system noise characteristic at each frequency for correction of later measurements. Set START FREQ, STOP FREQ and STEP SIZE parameters. To initiate a calibration:



Corrected Noise Figure and Gain

The Noise Figure Meter must be calibrated before a corrected noise figure and gain measurement can be made.

After calibration, to measure corrected noise figure and gain: press .


Note that the Noise Figure Meter removes its own noise figure from the measurement results.

Smoothing

To change the number of measurements averaged to optimize speed of response and reduce jitter in the INSERTION GAIN and NOISE FIGURE displays: press  or .

SPECIAL FUNCTIONS

Special Functions access capabilities of the Noise Figure Meter beyond those available with dedicated front panel keys. Special Functions are selected in a Code-SPECIAL FUNCTION format. For example, to display the ENR entry currently being used: press




Refer to the Special Functions Detailed Operating Instruction at the end of this section for more information.

Table 3-2. Detailed Operating Instructions Table of Contents (Functional) (1 of 2)

| Section | Page | Section | Page |
|---|-------|---|-------|
| Attenuation | | Measurements (cont'd) | |
| IF Attenuation Selection | 3-117 | Power Measurements | 3-200 |
| RF Attenuation Selection | 3-222 | Trigger Selection | 3-273 |
| Calibration | | Miscellaneous | |
| Calibrate | 3-59 | Data Output to Oscilloscopes, Recorders and Plotters | 3-73 |
| Calibration, Frequency | 3-65 | Error Messages and Recovery | 3-93 |
| Calibration, IF Attenuators | 3-67 | Preset Conditions and Power Up Sequence | 3-205 |
| Calibration, Input Gain Selection | 3-69 | Sequence | 3-224 |
| Noise Figure Test Set YIG Filter Calibration | 3-190 | Store and Recall | 3-257 |
| Displays | | Programs | |
| Display Control | 3-81 | Programming the System LO | 3-210 |
| Display Resolution | 3-83 | Programs Available to Control the System LO | 3-219 |
| Display Units Selection | 3-85 | Special Functions | |
| Smoothing (Averaging) | 3-230 | Calibration, Frequency | 3-65 |
| Temperature Units Selection | 3-271 | Calibration, IF Attenuators | 3-67 |
| ENR | | Calibration, Input Gain Selection | 3-69 |
| ENR Table Entry | 3-87 | Controller Capability of the Noise Figure Meter | 3-71 |
| Loss Compensation | 3-119 | Data Output to Oscilloscopes, Recorders and Plotters | 3-73 |
| Spot ENR, T_{hot} , T_{cold} and ENR Table Selection | 3-254 | Display Control | 3-81 |
| Temperature Units Selection | 3-271 | Display Resolution | 3-83 |
| HP-IB and SIB | | Display Units Selection | 3-85 |
| Controller Capability of the Noise Figure Meter | 3-71 | Fixed IF or LO Frequency Selection | 3-110 |
| HP-IB and System Interface Bus (SIB) Addresses | 3-113 | HP-IB and System Interface Bus (SIB) Addresses | 3-113 |
| System Interface Bus Control | 3-262 | IF Attenuation Selection | 3-117 |
| Measurement Modes | | Loss Compensation | 3-119 |
| Fixed IF or LO Frequency Selection | 3-110 | Manual Measurement Functions | 3-121 |
| Loss Compensation | 3-119 | Measurement Mode 1.0 | 3-132 |
| Measurement Modes | 3-125 | Measurement Mode 1.1 | 3-135 |
| Measurement Mode 1.0 | 3-132 | Measurement Mode 1.2 | 3-140 |
| Measurement Mode 1.1 | 3-135 | Measurement Mode 1.3 | 3-145 |
| Measurement Mode 1.2 | 3-140 | Measurement Mode 1.4 | 3-150 |
| Measurement Mode 1.3 | 3-145 | Measurement Mode 1.5 | 3-155 |
| Measurement Mode 1.4 | 3-150 | Measurement Mode 1.6 | 3-160 |
| Measurement Mode 1.5 | 3-155 | Measurement Mode 1.7 | 3-168 |
| Measurement Mode 1.6 | 3-160 | Measurement Mode 1.8 | 3-176 |
| Measurement Mode 1.7 | 3-168 | Measurement Mode 1.9 | 3-183 |
| Measurement Mode 1.8 | 3-176 | Noise Figure Test Set YIG Filter Calibration | 3-190 |
| Measurement Mode 1.9 | 3-183 | Power Measurements | 3-200 |
| Sideband Selection | 3-226 | Preset Conditions and Power Up Sequence | 3-205 |
| Measurements | | | |
| Manual Measurement Functions | 3-121 | | |
| Noise Figure (Uncorrected) and Noise Figure and Gain (Corrected) | 3-198 | | |

Table 3-2. Detailed Operating Instructions Table of Contents (Functional) (2 of 2)

| Section | Page | Section | Page |
|---|-------|--|-------|
| Special Functions (cont'd) | | Special Functions (cont'd) | |
| Programming the System LO | 3-210 | Spot ENR, T_{hot} , T_{cold} , and ENR Table Selection | 3-254 |
| Programs Available to Control the System LO | 3-219 | System Interface Bus Control | 3-262 |
| RF Attenuation Selection | 3-222 | Temperature Units Selection | 3-271 |
| Sequence | 3-224 | Trigger Selection | 3-273 |
| Sideband Selection | 3-226 | Tuning | |
| Smoothing (Averaging) | 3-230 | Fixed Frequency Increment | 3-105 |
| Special Function Catalog | 3-233 | Fixed Frequency Tuning | 3-108 |
| Special Functions | 3-235 | Sweep | 3-258 |



1 LOCAL Key. Returns the Noise Figure Meter to local operation (front panel control) from remote HP-IB control provided that the instrument is not in Local Lockout.

2 HP-IB Annunciators. Display the HP-IB status. The REMOTE annunciator lights when the Noise Figure Meter is in the remote mode. The TALK annunciator lights when the Noise Figure Meter is addressed to talk or is in Talk Only mode. The LISTEN annunciator lights when the Noise Figure Meter is addressed to listen. The SRQ annunciator lights when the Noise Figure Meter is sending a Require Service message to the controller.

3 Left Display. Depending upon the selected functions, the following information is displayed:

Frequency parameters — always displayed in MHz; 1 MHz resolution; 10 to 1600 MHz measurement range in Mode 1.0; 10 to 18000 MHz measurement range in Mode 1.5; up to 99999 MHz in Modes 1.1 through 1.4 and 1.6 through 1.9.

Special Function codes are displayed as they are entered.

Spot ENR — displayed in dB.

Temperature of the noise source — displayed in °C, °F, or K.

Sequence order.

Smoothing factor.


All data as it is being entered (except ENR in the “ENR versus Frequency” tables).

EXT MIX (external mixer) annunciator — lights when Measurement Mode 1.1 through 1.4 or 1.6 through 1.9 is active.

4 INSERTION GAIN Display. Displays (in dB) the gain of the device under test (DUT) to two decimal places. This display also shows ENR in dB when entering the ENR tables.


5 NOISE FIGURE Display. Displays measured noise. Five annunciators (F dB, Y dB, F, Te K, and Y) indicate the noise figure display units. This display is also used for power measurements (displayed in dB), error codes and during ENR Table entry displays the ENR table number with entry number.

Figure 3-2. Display and Remote Features



- 1 GRAPHIC SCALE.** The GRAPHIC SCALE keys are used to select the vertical scaling for an oscilloscope display or a plotter. The keys select the maximum and minimum limits for the display or plot. These keys perform the same functions as Special Functions 8.1 through 8.4.
- 2 GAIN MAX Key.** Used to display and enter the oscilloscope or plotter maximum vertical limit for insertion gain. When pressed the current GAIN MAX value appears in the left display. The allowable range of values for GAIN MAX is -9999 dB to 99999 dB. This key performs the same function as Special Function 8.4.
- 3 NOISE MAX Key.** Used to display and enter the oscilloscope or plotter maximum vertical limit for noise figure. When pressed the current NOISE MAX value appears in the left display. The allowable range of values for NOISE MAX is -9999 dB to 99999 dB. This key performs the same function as Special Function 8.2.
- 4 GAIN MIN Key.** Used to display and enter the oscilloscope or plotter minimum vertical limit for insertion gain. When pressed the current GAIN MIN value appears in the left display. The allowable range of values for GAIN MIN is -9999 dB to 99999 dB. This key performs the same function as Special Function 8.3.
- 5 NOISE MIN Key.** Used to display and enter the oscilloscope or plotter minimum vertical limit for noise figure. When pressed the current NOISE MIN value appears in the left display. The allowable range of values for NOISE MIN is -9999 dB to 99999 dB. This key performs the same function as Special Function 8.1.

Figure 3-3. GAIN MAX, GAIN MIN, NOISE MAX and NOISE MIN Features



- 1 **PRESET Key.** Returns the instrument to a known state. Refer to the Preset Conditions and Power-Up Sequence Detailed Operating Instruction for a list of preset conditions and default values.
- 2 **LINE Switch.** Applies power to the Noise Figure Meter when set to the ON position.
- 3 **ENR Key.** Used to display and enable entry of the excess noise ratio (ENR) versus frequency tables. Five ENR tables, each table containing 35 frequencies, can be entered into the Noise Figure Meter. Frequency is shown in the left display and the corresponding ENR is shown in the INSERTION GAIN

display. The NOISE FIGURE display shows the ENR table number (0—4) and the current table entry number (1 through 35). An ENR table is selected by using the following sequence:

RECALL ENR N.


N is the number of the ENR table being recalled. An ENR table is stored using the following sequence:

STORE ENR N.

N is the number of the ENR table being stored.


- 4 **NOISE SOURCE DRIVE OUTPUT.** This BNC connector provides the output to drive a noise source on and off with +28 volt pulses.

Figure 3-4. LINE Switch, PRESET and SOURCE Features



- 1 Frequency Function Keys.** In addition to the functions described below, the following keys are used to prefix numeric entries for the specified functions: START FREQ, STOP FREQ, STEP SIZE, FREQ, and FREQ INCR. Frequency is entered in MHz from the front panel. Frequency parameters are entered in a Function-Data-ENTER format.
- FIXED FREQUENCY Keys**
- 2 FREQUENCY Key.** Causes the tuned frequency to appear in the left display. This key also acts as a "clear" key when an error is made during entry; that is, it returns the instrument to the measurement frequency. (Also see Frequency Function Keys.)
- 3 FREQ INCR Key.** Causes the programmed frequency increment to appear in the left display while the key is depressed. (Also see Frequency Function Keys.)
- 4 \uparrow or \downarrow keys.** Increase or decrease the tuned fixed frequency by the programmed frequency increment. Holding either of these keys down causes the tuning to step continuously up or down.
- SWEEP Keys**
- 5 SINGLE Key.** Starts one sweep from START FREQ to STOP FREQ in increments determined by STEP SIZE.
- At the end of one sweep the instrument remains tuned to the stop frequency. Single sweep can be terminated by pressing the SINGLE key a second time.
- 6 AUTO Key.** Starts a sweep from the current frequency. The sweep repeats from START FREQ to STOP FREQ in increments determined by STEP SIZE until terminated. Auto sweep is terminated by pressing the AUTO key a second time.
- 7 STEP SIZE Key.** Causes the programmed frequency step size of the sweep to appear in the left display while the key is depressed. (Also see Frequency Function Keys.)
- 8 STOP FREQ Key.** Tunes the Noise Figure Meter to the programmed stop frequency and causes that frequency to appear in the left display. (Also see Frequency Function Keys.)
- 9 START FREQ Key.** Tunes the Noise Figure Meter to the programmed start frequency and causes that frequency to appear in the left display. (Also see Frequency Function Keys.)

Figure 3-5. SWEEP and FIXED FREQ Features




- 1 **DATA Keys.** Enter data or Special Function codes. Entries are completed by the ENTER key or the SPECIAL FUNCTION key (except for STORE and RECALL).
- 2 **ENTER Key.** Completes keyboard entries other than Special Function codes.
- 3 **SPECIAL FUNCTION Key.** Completes the keyboard entry of a Special Function code. Special Functions are instrument operations in addition to those accessible from dedicated front panel keys. Refer to Special Functions in the Detailed Operating Instructions for a complete listing of user special functions.
- 4 **STORE and RECALL Keys.** Store and recall up to ten instrument configurations in storage registers 0 through 9. Front panel features that cannot be stored and later recalled are CALIBRATE, SMOOTHING, AUTO or SINGLE SWEEP, UNCORRECTED NOISE FIGURE and CORRECTED NOISE FIGURE AND GAIN. STORE and RECALL are also used to store or recall an ENR table.

When the STORE key is used as a prefix for a numeric key (a single digit 0 — 9 to identify the register), the current instrument configuration is stored in that internal storage register.

When the RECALL key is used as a prefix to a numeric key (a single digit 0 — 9 to identify the register), the contents stored in that register are recalled and the instrument configuration is changed to the recalled parameter values.

- 5 **SEQ Key.** Recalls storage registers 1 through 9 in a preset sequence. Pressing the SEQ key momentarily displays the current storage register number. SEQ is used in conjunction with Special Function 35.
- 6 **— [Minus] Key.** Can be used as a prefix for loss, ENR, or temperature. Although the minus key can be used any time before an entry is completed, the minus sign is always inserted to the left of the entered digits. If the minus sign is used incorrectly an error message is displayed when ENTER is pressed.

Figure 3-6. DATA and SPECIAL FUNCTION Features



- 1 **CALIBRATE Key.** Initiates the calibration process which measures and stores the measurement system noise figure and gain. This data is used for second stage correction and gain measurements. Calibration is done from START FREQ to STOP FREQ in steps of STEP SIZE (see Figure 3-5). During calibration all front panel keys except PRESET, CALIBRATE and LOCAL are disabled. To start a calibration, the CALIBRATE key must be pressed twice. Pressing CALIBRATE before calibration is complete terminates the calibration.
- 2 **CORRECTED NOISE FIGURE AND GAIN Key.** Configures the Noise Figure Meter to measure noise figure and gain with second stage correction (that is, only the noise figure and gain of the device under test is displayed). A calibration must be completed prior to making corrected noise figure and gain measurements.
- 3 **INPUT.** This female type-N INPUT connector is used to connect the device under test to the Noise Figure Meter in Modes 1.0 through 1.4. In Modes 1.5 through 1.9, the Noise Figure Test Set is connected to this input. The nominal input impedance is 50 ohms. Specified operating input level is less than -10 dBm. The frequency range at the INPUT connector is 10 to 1600


MHz. The maximum average input power for a CW signal is $+20$ dBm. The maximum peak input power for a pulsed signal is $+20$ dBm.

CAUTION

Damage to the instrument can be caused by connecting signals to INPUT that exceed $+20$ dBm or $+20$ Vdc.

- 4 **SMOOTHING Keys.** INCREASE and DECREASE the number of measurements averaged (smoothing factor) when displaying measurement results. When pressed, these keys cause the smoothing factor to appear in the left display. The smoothing factor ranges from 1 to 512 and changes in factors of 2. Pressing INCREASE doubles the smoothing factor. Pressing DECREASE halves the smoothing factor. Both INSERTION GAIN and NOISE FIGURE displays are smoothed. Increasing the smoothing reduces the jitter in the display.
- 5 **UNCORRECTED NOISE FIGURE Key.** Configures the Noise Figure Meter to measure noise figure without second stage correction (that is, the noise contribution of the measurement system is included in the reading in the NOISE FIGURE display).

Figure 3-7. MEASUREMENT and INPUT Features



- 1 NOISE SOURCE DRIVE OUTPUT** drives a noise source on and off with +28V pulses and is in parallel to the front panel NOISE SOURCE DRIVE OUTPUT. (Only one noise source can be connected at a time.)
- 2 INPUT** is a rear panel input for coupling the output signal from the device under test or Noise Figure Test Set into the instrument.
- 3 IF** provides a rear panel output for the Noise Figure Meter's last IF (20 MHz) immediately prior to the detector. The power level is -50 to -30 dBm nominal. Output impedance is 50 Ω nominal.
- 4 DET** provides an output from the noise power detector. Level is 0.1 to 1.0 Vdc nominal, floating.
- 5 GAIN TRACE** adjusts the intensity of the gain trace (on an oscilloscope) relative to the noise figure trace.
- 6 Line Power Module** permits operation from 100, 120, 220 or 240 Vac. The number visible in the window indicates nominal line voltage to which the instrument must be connected (see Figure 2-1). Center conductor is a chassis connection for safety earth ground.
- 7 Fuse.** 1.5A (250V, Normal Blow) for 100/120 Vac. 1.0 (250V, Normal Blow) for 220/240 Vac.
- 8 System Interface Bus (SIB) Connector.** Connects the Noise Figure Meter to the System Interface Bus. This is the bus that the Noise Figure Meter uses to control the Noise Figure Test Set, System Local Oscillator and a plotter.
- 9 HP-IB Connector** connects the Noise Figure Meter to the Hewlett-Packard Interface Bus for HP-IB operation.
- 10 X-AXIS.** 0 to +6V output proportional to the measurement frequency when driving an analog oscilloscope or X-Y recorder. This output can be made proportional to noise figure for driving a strip chart recorder. Output impedance is 100 Ω .
- 11 Y-AXIS.** 0 to +6V output proportional to noise figure when driving an analog oscilloscope or X-Y recorder. This output can be made proportional to gain when driving a strip chart recorder. Output impedance is 100 Ω .
- 12 Z-AXIS/PEN LIFT.** TTL compatible output. When used with an analog oscilloscope, the Z-AXIS provides a TTL high signal for retrace and cursor blanking. When used with a recorder, the PEN LIFT provides a TTL high signal to lift the pen. Output impedance is 100 Ω .

CAUTION

Damage to the instrument can be caused by connecting signals to INPUT that exceed +20 dBm or +20 Vdc.

NOTE

DET is a direct connection to the instrument's detector. Loading or injecting a signal may cause inaccurate readings. Only connect this output to instrumentation with floating inputs. Output impedance is 10 k Ω nominal.

Figure 3-8. Rear Panel Features

OPERATOR'S CHECKS

3-10. OPERATOR'S CHECKS

3-11. Basic Functional Checks

Description The overall operation of the Noise Figure Meter is checked using a noise source and an analog display module. If the Noise Figure Meter is to be used to control the System LO, the optional System LO Check at the end of this procedure verifies that capability. This check should be performed sequentially.




Figure 3-9. Basic Functional Checks Setup

Equipment
 Noise Source HP 346B Option 001
 Analog Display Module HP 1332A Options 101 and 315
 System LO HP 8671B

Procedure Preliminary Check

1. Remove any cables from the Noise Figure Meter's INPUT and SOURCE. Set the LINE switch to OFF, and then back to ON. Verify the front panel LED annunciators, display segments, decimal points, and key lights turn on for approximately two seconds. Then, verify that "Ctrl" appears in the INSERTION GAIN display and "on" or "OFF" appears in the NOISE FIGURE display. If the Noise Figure Meter is the system controller on the System Interface Bus (Special Function 48.0) "on" will be displayed. If the Noise Figure Meter is not the system controller on the System Interface Bus (Special Function 48.1) "OFF" will be displayed. Then, "Fr" will appear in the INSERTION GAIN display and "CAL" will appear in the NOISE FIGURE display for approximately five seconds while the Noise Figure Meter performs a frequency calibration.
2. Press PRESET. After "Fr" disappears from the INSERTION GAIN display and "CAL" disappears from the NOISE FIGURE display, verify the following conditions:

NOTE

If error code E44 is displayed, press 45.0 SPECIAL FUNCTION. Since Measurement Mode 1.0 (default after PRESET) doesn't require the Noise Figure Test Set, Special Function 45.0 disables Noise Figure Test Set commands in Measurement Mode 1.0.

- a. Left display shows 30 MHz.
- b. INSERTION GAIN display is blank.
- c. NOISE FIGURE display shows "— FdB".
- d. UNCORRECTED NOISE FIGURE annunciator is on.

OPERATOR'S CHECKS

Basic Functional Checks (cont'd)**Procedure
(cont'd)**

3. Enter the Excess Noise Ratio (ENR) data for the noise source being used. For more information, refer to the ENR Table Entry Detailed Operating Instruction. Connect the noise source between the Noise Figure Meter's SOURCE and INPUT (see Figure 3-9). Verify the NOISE FIGURE display shows approximately 5 dB.
4. Connect the display to the X-, Y-, and Z-AXIS connectors on the rear panel of the Noise Figure Meter. Use the X-AXIS for the horizontal input and the Y-AXIS for the vertical input.
5. On the Noise Figure Meter, press 7 . 1 SPECIAL FUNCTION. Verify that a test pattern is seen on the display. It may be necessary to adjust rear panel GAIN TRACE control to obtain the test pattern. The test pattern should be 6 ± 0.5 volts vertically and horizontally. Adjust the display until the test pattern fills the grid area (see Figure 3-10). Press 7 . 0 SPECIAL FUNCTION to enable the Noise Figure Meter to output the noise figure and gain data to the display.




Figure 3-10. Test Pattern on Oscilloscope

Calibration and SWEEP Check

6. Press CORRECTED NOISE FIGURE AND GAIN. Verify the NOISE FIGURE display shows an error message.

NOTE

In step 6, error code E20 (not calibrated) is normally displayed.

7. Press UNCORRECTED NOISE FIGURE. Verify that the NOISE FIGURE display shows approximately 5 FdB indicating that the Noise Figure Meter can make uncorrected noise figure measurements prior to being calibrated.
8. Press CORRECTED NOISE FIGURE AND GAIN. Verify the NOISE FIGURE display again shows an error message.

OPERATOR'S CHECKS

Basic Functional Checks (cont'd)**Procedure
(cont'd)****NOTE**

All frequency data must be entered in MHz.

9. Press the following keys to enter the SWEEP calibration parameters:
 - a. START FREQ 1 2 3 ENTER.
 - b. STOP FREQ 7 8 9 ENTER.
 - c. STEP SIZE 4 0 ENTER.

10. Press CALIBRATE twice. Verify the following conditions:
 - a. CALIBRATE annunciator lights.

 - b. The frequency is swept from the start frequency (123 MHz) to the stop frequency (789 MHz) in 40 MHz steps. This sweep is performed three times.

 - c. After calibration is complete, the CALIBRATE annunciator turns off and the CORRECTED NOISE FIGURE AND GAIN annunciator lights.

 - d. The INSERTION GAIN display shows approximately 0 dB and the NOISE FIGURE display shows approximately 0 FdB.

11. Press SWEEP SINGLE. Verify that the key's LED lights. The established frequency range is swept once. After the sweep is completed, the LED turns off and the left display shows 789 MHz.

12. Press SWEEP AUTO. Verify that the key's LED lights and the frequency range is swept repetitively. Press SWEEP AUTO again. Verify the sweep stops at the current frequency and the LED goes off.

13. Press SMOOTHING INCREASE four times to set the smoothing (averaging) factor to 16. Press SWEEP SINGLE. Verify that the INSERTION GAIN and NOISE FIGURE displays are more stable and the time required for each measurement is longer. Press SMOOTHING DECREASE four times to return the smoothing factor to 1.

GRAPHIC SCALE Check

14. Verify that the display is set up as described in steps 3 through 5.

 15. Press 7.0 SPECIAL FUNCTION. This will enable Noise Figure and Insertion Gain to be seen on the display.

 16. Press NOISE MAX. Verify that 8.000 dB is shown in the left display. If 8.000 dB is not shown, press 8 and ENTER.

 17. Press NOISE MIN. Verify that 0.000 dB is shown in the left display. If 0.000 dB is not shown, press 0 and ENTER.

 18. Press GAIN MAX. Verify that 40.00 dB is shown in the left display. If 40.00 dB is not shown, press 40 and ENTER.
-

OPERATOR'S CHECKS

Basic Functional Checks (cont'd)**Procedure
(cont'd)**

19. Press GAIN MIN. Verify that 0.000 dB is shown in the left display. If 0.000 dB is not shown, press 0 and ENTER.
20. Press START FREQ. Verify that 10 is displayed in the left display. If 10 is not displayed, key in 10 and press ENTER. Press STOP FREQ. Verify that 1600 is displayed in the left display. If 1600 is not displayed, key in 1600 and press ENTER. Press STEP SIZE. Verify that 20 is displayed in the left display. If 20 is not displayed, key in 20 and press ENTER.
21. Press CALIBRATE twice. The Noise Figure Meter will perform a calibration from the start frequency to the stop frequency, using the step size selected.
22. Press CORRECTED NOISE FIGURE AND GAIN.
23. Press SINGLE SWEEP. Verify that the traces are along the bottom of the display.
24. Change the NOISE MAX and GAIN MAX limit to 2. Change the NOISE MIN and GAIN MIN limit to -2.
25. Press SINGLE SWEEP. The Noise Figure trace and Insertion Gain trace will appear in the center of the display.

FIXED FREQUENCY Tuning Check

26. Press the following keys to establish the tuned FIXED FREQUENCY parameters:
 - a. FREQUENCY 5 0 0 ENTER.
 - b. FREQ INCR 3 0 0 ENTER.
27. Press . Verify that the left display shows 800 MHz and the NOISE FIGURE display shows error code E21 (current frequency is out of calibrated range).
28. Press . Verify the left display shows 500 MHz and the INSERTION GAIN and NOISE FIGURE displays show approximately 0.

ENR Table Entry Check**NOTE**

This check verifies the capability of the ENR and ENTER keys to initiate and sequence through the ENR table. If it is necessary to change the ENR table, refer to the ENR Table Entry Detailed Operating Instruction.

29. Press ENR. Verify the MHz annunciator in the left display is flashing.
 30. Press ENTER. Verify that the MHz annunciator remains on and the dB annunciator in the INSERTION GAIN display is flashing.
 31. Press and hold ENTER. Verify the two displays sequence through the ENR table entries. Also, the ENR table entry should be changing in the NOISE FIGURE display. Release ENTER.
-

OPERATOR'S CHECKS

Basic Functional Checks (cont'd)**Procedure
(cont'd)****NOTE**

If ENTER is held down until all 35 frequency vs. ENR pairs have been displayed, both annunciators light and remain lit. When ENTER is released, the Noise Figure Meter returns to the measurement configuration it was in prior to pressing ENR. If ENTER is released prior to displaying all pairs, press FREQUENCY to return to the previous measurement configuration.

32. Verify that the CORRECTED NOISE FIGURE AND GAIN annunciator lights.

STORE, RECALL and SEQ Check

33. Press PRESET. Verify the left display shows 30 MHz.

NOTE

During the STORE and RECALL checks the complete instrument configuration is stored and recalled. The frequency change is merely a convenient indication that different setups have been stored and recalled.

34. Press STORE 1.
35. Press . Verify the left display shows 50 MHz. Press STORE 2.
36. Press RECALL 1. Verify the left display shows 30 MHz. Press RECALL 2. Verify the left display shows 50 MHz.
37. Press and hold SEQ. Verify the left display shows 1. Release SEQ. Verify the left display shows 30 MHz.
38. Press and hold SEQ. Verify the left display shows 2. Release SEQ. Verify the left display shows 50 MHz.

Minus Check

39. Press -. Verify the left display shows -.

System LO Check (Optional; for Measurement Modes 1.1 through 1.4)**NOTE**

The following steps check the Noise Figure Meter's capability to control the System LO. It is not necessary to perform this check unless the Noise Figure Meter is used for this purpose and a suitable System LO is available. It is assumed in the following check that the SIB addresses used by the Noise Figure Meter and the System LO are compatible.

40. Connect the System LO to the Noise Figure Meter's SYSTEM INTERFACE BUS connector (see Figure 3-9).
41. Press 48.0 SPECIAL FUNCTION. This will enable the Noise Figure Meter to be the system controller on the System Interface Bus.
-

OPERATOR'S CHECKS

Basic Functional Checks (cont'd)

- Procedure (cont'd)**
42. Press 46.0 SPECIAL FUNCTION. This will enable the commands for the system LO on the System Interface Bus.
 43. Press one of the following sequences of keys depending upon the System LO used:
 - a. For an HP 8350B, press 41.0 SPECIAL FUNCTION.
 - b. For an HP 8671B/8672A press 41.2 SPECIAL FUNCTION.
 - c. For an HP 8673B/C, press 41.3 SPECIAL FUNCTION.
 - d. For an HP 8340B/8341B, press 41.4 SPECIAL FUNCTION.
 - e. For the Custom Local Oscillator Program, press 41.5 SPECIAL FUNCTION.
 44. Press 1.1 SPECIAL FUNCTION. Verify the left display shows 10000 MHz and the EXT MIX annunciator lights. Also, verify that the remote and listen annunciators light on the system LO.
 45. On the Noise Figure Meter, press SWEEP START FREQ. Verify the left display shows 8000 MHz and the System LO is tuned to the same frequency.
 46. On the Noise Figure Meter, press SWEEP STOP FREQ. Verify the left display shows 12000 MHz and the System LO is tuned to the same frequency.

OPERATOR'S CHECKS

3-12. HP-IB Functional Checks **HP-IB**

Description The following procedures check the instrument's ability to perform the following functions:

- a. Process or send all of the applicable HP-IB messages described in Table 3-3.
- b. Recognize its own HP-IB address.
- c. Set all of the bus data, handshake, and control lines (except DIO8) to both their true and false states.

These procedures do not check if all Noise Figure Meter program codes are being properly interpreted and executed by the instrument. However, if the power-up sequence (including the memory checks) and the front panel operation is good, the program codes, in all likelihood, will be correctly executed.

The validity of these checks is based on the following assumptions:

- a. The Noise Figure Meter performs properly when operated via the front panel keys (that is, in local mode). This can be verified with the Basic Functional Checks.
- b. The bus controller properly executes HP-IB operations.
- c. The bus controller's HP-IB interface properly executes the HP-IB operations.

If the Noise Figure Meter appears to fail any of these HP-IB checks, the validity of the above assumptions should be confirmed before attempting to service the instrument.

The select code of the controller's HP-IB interface is assumed to be 7. The address of the Noise Figure Meter is assumed to be 8 (its address as set at the factory). This select code address combination (that is, 708) is not necessary for these checks to be valid. However, the program lines presented here have to be modified for any other combination.

These checks are intended to be as independent of each other as possible. Nevertheless, the first four checks should be performed in order before other checks are selected. Any special initialization or requirements for a check are described at its beginning.

Initial Setup The test setup is the same for all of the checks. Connect the Noise Figure Meter to the bus controller via the HP-IB interface. Do not connect any equipment, other than the noise source, to the Noise Figure Meter's INPUT.

Equipment HP-IB Controller HP 85B/82936A (ROM Drawer)/00085-15005
 (Advanced Programming ROM)
 —or— HP 9000 Series 200/300
 (BASIC 2.0 ROM based system)
 HP-IB Interface HP 82937A (HP 85B only)
 Noise Source HP 346B (Option 001)



OPERATOR'S CHECKS

HP-IB Functional Checks (cont'd)

Address Recognition

Note

This check determines if the Noise Figure Meter recognizes when it is being addressed and when it is not. This check assumes only that the Noise Figure Meter can properly handshake on the bus. Before beginning this check, set the Noise Figure Meter's LINE switch to ON, press PRESET, 4 5 . 0 SPECIAL FUNCTION, and 4 . 0 SPECIAL FUNCTION.

| Description | HP 85B (BASIC) | HP 9000 Series 200/300 (BASIC) |
|---|----------------|--------------------------------|
| Set the Remote Enable (REN) bus control line false. | LOCAL 7 | LOCAL 7 |
| Send the Noise Figure Meter's listen address. | OUTPUT 708 | OUTPUT 708 |

Operator's Response

Check that the Noise Figure Meter's REMOTE annunciator is off and that its LISTEN annunciator is on.

| | | |
|--|------------|------------|
| Unaddress the Noise Figure Meter by sending a different address. | OUTPUT 715 | OUTPUT 715 |
|--|------------|------------|

Operator's Response

Check that both the Noise Figure Meter's REMOTE and LISTEN annunciators are off.

Remote and Local Messages and the LOCAL Key

Note

This check determines if the Noise Figure Meter properly switches from local to remote control, from remote to local control, and if the LOCAL key returns the instrument to local control. This check assumes that the Noise Figure Meter is able to both handshake and recognize its own address. Before beginning this check, press the Noise Figure Meter's PRESET key. Then press 4 . 0 SPECIAL FUNCTION.

| Description | HP 85B (BASIC) | HP 9000 Series 200/300 (BASIC) |
|--|----------------|--------------------------------|
| Send the Remote message (by setting Remote Enable, REN, true and addressing the Noise Figure Meter to listen). | REMOTE 708 | REMOTE 708 |

Operator's Response

Check that the Noise Figure Meter's REMOTE and LISTEN annunciators are on.

| | | |
|--|-----------|-----------|
| Send the Local message to the Noise Figure Meter | LOCAL 708 | LOCAL 708 |
|--|-----------|-----------|

Operator's Response

Check that the Noise Figure Meter's REMOTE annunciator is off but its LISTEN annunciator is on.

| | | |
|--|------------|------------|
| Send the Remote message to the Noise Figure Meter. | REMOTE 708 | REMOTE 708 |
|--|------------|------------|

OPERATOR'S CHECKS

HP-IB Functional Checks (cont'd)**Remote and Local Messages and the LOCAL Key (cont'd)**

Operator's Response Check that both the Noise Figure Meter's REMOTE and LISTEN annunciators are on. Press the LOCAL key on the Noise Figure Meter. Check that the Noise Figure Meter's REMOTE annunciator is now off, but that its LISTEN annunciator remains on.

Sending the Data Message

Note This check determines if the Noise Figure Meter properly issues Data messages when addressed to talk. This check assumes that the Noise Figure Meter is able to handshake and recognize its own address. Before beginning this check, press the Noise Figure Meter's LINE switch twice (OFF then ON). Then, after the power-up sequence is completed, press CORRECTED NOISE FIGURE AND GAIN and 4 . 0 SPECIAL FUNCTION. (If an HP 9000 Series 200/300 controller is used, a short program is required to perform this check.)

| Description | HP 85B (BASIC) | HP 9000 Series 200/300 (BASIC) |
|--|-------------------|---|
| Address the Noise Figure Meter to talk and store its output in variable V. (The output is E20 since the Noise Figure Meter is not calibrated.) | ENTER 708;V | 10 V = 0 20 ENTER 708;V 30 DISP V 40 END |
| Display the value of V. | DISP V | DISP V |

Operator's Response Check that the Noise Figure Meter's REMOTE annunciator is off but that its TALK annunciator is on. The controller's display should read 90020000000 (HP 85B) or 9.002E+10 (HP 9000 Series 200/300). The 90020 portion of the display corresponds to the data output for the error code E20 (not calibrated) shown in the Noise Figure Meter's NOISE FIGURE display.

Receiving the Data Message

Note This check determines if the Noise Figure Meter properly receives Data messages. The Data messages sent cause the 7 least significant HP-IB data lines to be placed in both their true and false states. This check assumes the Noise Figure Meter is able to handshake, recognize its own address and properly make the remote/local transitions. Before beginning this check, press the Noise Figure Meter's PRESET key. Then press 4 . 0 SPECIAL FUNCTION.

| Description | HP 85B (BASIC) | HP 9000 Series 200/300 (BASIC) |
|---|-------------------------|-----------------------------------|
| Send the first part of the Remote message (enabling the Noise Figure Meter to remote). | REMOTE 7 | REMOTE 7 |
| Address the Noise Figure Meter to listen (completing the Remote message), then send a Data message. | OUTPUT 708; "FR15MZ" | OUTPUT 708; "FR15MZ" |



OPERATOR'S CHECKS

HP-IB Functional Checks (cont'd)**Receiving the Data Message (cont'd)**

Operator's Response Check that both the Noise Figure Meter's REMOTE and LISTEN annunciators are on and that the left display shows 15 MHz.

Local Lockout and Clear Lockout/Set Local Messages

Note This check determines if the Noise Figure Meter properly receives the Local Lockout message, disabling the LOCAL key. The check also determines if the Clear Lockout/Set Local message is properly received and executed by the Noise Figure Meter. This check assumes that the Noise Figure Meter is able to handshake, recognize its own address, and properly make the remote/local transitions. Before beginning this check, press the Noise Figure Meter's LINE switch OFF then ON and then press the PRESET key. Then press 4 . 0 SPECIAL FUNCTION.

| Description | HP 85B (BASIC) | HP 9000 Series 200/300 (BASIC) |
|--|--------------------|-----------------------------------|
| Send the first part of the Remote message (enabling the Noise Figure Meter to remote). | REMOTE 7 | REMOTE 7 |
| Send the Local Lockout message. | LOCAL LOCKOUT 7 | LOCAL LOCKOUT 7 |
| Address the Noise Figure Meter to listen (completing the Remote message). | OUTPUT 708 | OUTPUT 708 |

Operator's Response Check that both the Noise Figure Meter's REMOTE and LISTEN annunciators are on. Press the Noise Figure Meter's LOCAL key. Both its REMOTE and LISTEN annunciators should remain on.

| | | |
|---|---------|---------|
| Send the Clear Lockout/Set Local message. | LOCAL 7 | LOCAL 7 |
|---|---------|---------|

Operator's Response Check that the Noise Figure Meter's REMOTE annunciator is off but its LISTEN annunciator is on.

Clear Message

Note This check determines if the Noise Figure Meter properly responds to the Clear message. This check assumes that the Noise Figure Meter is able to handshake, recognize its own address, make the remote/local changes and receive Data messages. Before beginning this check press the Noise Figure Meter's PRESET key. When "Fr" disappears from the INSERTION GAIN display and "CAL" disappears from the NOISE FIGURE display, press CALIBRATE twice. Once the LED above the CALIBRATE key turns off, press 4 . 0 SPECIAL FUNCTION.

OPERATOR'S CHECKS

HP-IB Functional Checks (cont'd)**Clear Message (cont'd)**

| Description | HP 85B (BASIC) | HP 9000 Series 200/300 (BASIC) |
|--|---------------------|-----------------------------------|
| Send the first part of the Remote message (enabling the Noise Figure Meter to remote). | REMOTE 7 | REMOTE 7 |
| Address the Noise Figure Meter to listen (completing the Remote message), then send a Data message that selects the CORRECTED NOISE FIGURE AND GAIN measurement. | OUTPUT 708; "M2" | OUTPUT 708; "M2" |

Operator's Response

Check that both the Noise Figure Meter's REMOTE and LISTEN annunciators are on and that the CORRECTED NOISE FIGURE AND GAIN key light is on.

| | | |
|--|-----------|-----------|
| Send the Clear message (setting the Noise Figure Meter's measurement to UNCORRECTED NOISE FIGURE). | CLEAR 708 | CLEAR 708 |
|--|-----------|-----------|

Operator's Response

Check that both the Noise Figure Meter's REMOTE and LISTEN annunciators are on and that the UNCORRECTED NOISE FIGURE key light is on.

Abort Message**Note**

This check determines if the Noise Figure Meter becomes unaddressed when it receives the Abort message. Before beginning this check, enter LOCAL 708 and press the Noise Figure Meter's PRESET key. Then press 4 . 0 SPECIAL FUNCTION.

| Description | HP 85B (BASIC) | HP 9000 Series 200/300 (BASIC) |
|--|-------------------|-----------------------------------|
| Send the Remote message to the Noise Figure Meter. | REMOTE 708 | REMOTE 708 |

Operator's Response

Check that both the Noise Figure Meter's REMOTE and LISTEN annunciators are on.

| | | |
|---|-----------|---------|
| Send the Abort message, unaddressing the Noise Figure Meter from listening. | ABORTIO 7 | ABORT 7 |
|---|-----------|---------|

Operator's Response

Check that the Noise Figure Meter's LISTEN annunciator is off.

Status Byte Message**Note**

This check determines if the Noise Figure Meter sends the Status Byte message. Before beginning this check, press the Noise Figure Meter's PRESET key. Then press 4 . 0 SPECIAL FUNCTION.



OPERATOR'S CHECKS

HP-IB Functional Checks (cont'd)

Status Byte Message (cont'd)

| Description | HP 85B (BASIC) | HP 9000 Series 200/300 (BASIC) |
|---|-------------------|-----------------------------------|
| Place the Noise Figure Meter in serial-poll mode and address it to talk (causing it to send the Status Byte message). | SPOLL (708) | SPOLL (708) |

Operator's Response

Check that the controller's display reads 0.

Require Service Message

Note

This check determines if the Noise Figure Meter can issue the Require Service message (set the SRQ bus control line true). This check assumes that the Noise Figure Meter is able to handshake, recognize its own address, make the remote/local changes, and receive Data messages. Before beginning this check, press the Noise Figure Meter's PRESET key. Then press 4 . 0 SPECIAL FUNCTION. (If an HP 9000 Series 200/300 controller is used, a short program is required to perform the last half of this check.)

| Description | HP 85B (BASIC) | HP 9000 Series 200/300 (BASIC) |
|---|-------------------------|---------------------------------------|
| Send the first part of the Remote message (enabling the Noise Figure Meter to remote). | REMOTE 7 | REMOTE 7 |
| Address the Noise Figure Meter to listen (completing the Remote message), then send a Data message containing an invalid HP-IB code. This enables a Require Service message to be sent. | OUTPUT 708; "<" | OUTPUT 708; "<" |
| Make controller wait two seconds to allow time for the Noise Figure Meter to send the Require Service message. (This step is not necessary if sufficient time is allowed.) | WAIT 2000 | WAIT |
| Read the binary status of the controller's HP-IB interface and store the data in variable V (in this step, 7 is the interface's select code). | STATUS 7,2; V | 10 V = 0 20 STATUS 7,7; V |
| Display the value of the SRQ bit (in this step, 6 (HP 85B) and 10 (HP 9836) are the SRQ bits for the controller, numbered from 0). | DISP"SRQ="; BIT(V,6) | 30 DISP"SRQ="; BIT(V,10) 40 END |

Operator's Response

Check that the SRQ value is 1, indicating the Noise Figure Meter issued the Require Service message.

OPERATOR'S CHECKS

HP-IB Functional Checks (cont'd)**Trigger Message****Note**

This check determines if the Noise Figure Meter responds to the Trigger message. This check assumes that the Noise Figure Meter is able to handshake, recognize its own address, make the remote/local changes, and send and receive Data messages. Before beginning this check, enter LOCAL 708 and press the Noise Figure Meter's PRESET key. Then press 4.0 SPECIAL FUNCTION (If an HP 9000 Series 200/300 controller is used, a short program is required to perform this check.)

| Description | HP 85B (BASIC) | HP 9000 Series 200/300 (BASIC) |
|---|---------------------|-----------------------------------|
| Send the first part of the Remote message (enabling the Noise Figure Meter to remote). | REMOTE 7 | 10 REMOTE 7 |
| Address the Noise Figure Meter to listen (completing the Remote message), then send a Data message placing the Noise Figure Meter in the Trigger Hold mode. | OUTPUT 708, "T1" | 20 OUTPUT 708; "T1" |
| Send the Trigger message. | TRIGGER 708 | 30 TRIGGER 708 40 V = 0 |
| Address the Noise Figure Meter to talk and store the data in variable V. | ENTER 708,V | 50 ENTER 708; V |
| Display the value of V. | DISP V | 60 DISP V 70 END |

Operator's Response

Check that both the Noise Figure Meter's REMOTE and TALK annunciators are on. The controller's display should read the same as the NOISE FIGURE display.

OPERATOR'S CHECKS

3-13. Noise Figure Measurement System Check

Description This check will verify proper operation of the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and System Local Oscillator). The Noise Figure Test Set and the System Local Oscillator extend the input frequency range of the Noise Figure Meter from 1600 to 18000 MHz.

Equipment Noise Source HP 346B Option 001

- Procedure**
1. Set up the Noise Figure Measurement System as shown in Figure 3-11.
 2. Turn the Noise Figure Measurement System on and press PRESET.
 3. Verify the following conditions:
 - Special Function 48.0 is active.
 - Special Function 45.1 is active.
 - Special Function 46.0 is active.
 - The address of the Noise Figure Test Set is the one stored in the Noise Figure Meter (Special Function 40.2).
 - The address of the System Local Oscillator is the one stored in the Noise Figure Meter (Special Function 40.1).
 - The appropriate System Local Oscillator program (Special Function 41) is active.




Figure 3-11. Noise Figure Measurement System Check Setup

OPERATOR'S CHECKS

Noise Figure Measurement System Check (cont'd)**Procedure
(cont'd)****NOTE**

Steps 4 through 9 will verify that the Noise Figure Test Set and the System Local Oscillator are properly connected to the Noise Figure Meter and that the Noise Figure Meter can talk to the Noise Figure Test Set and System Local Oscillator. If steps 4 through 9 do not perform as indicated, go to step 17.

4. On the Noise Figure Meter, press 1.5 SPECIAL FUNCTION. Verify that 3000 and E28 are displayed. Error code E28 can be ignored.
5. Press FREQUENCY and key in 100. Press ENTER. Verify that the SSB1 annunciator on the Noise Figure Test Set is on.
6. Press FREQUENCY and key in 2000. Press ENTER. Verify that the SSB2 annunciator on the Noise Figure Test Set is on and the LO is set to 2700 MHz.
7. Press FREQUENCY and key in 3000. Press ENTER. Verify that the SSB3 annunciator on the Noise Figure Test Set is on and the LO is set to 3450 MHz. Error code E28 will be displayed, on the Noise Figure Meter. This error can be ignored.
8. Press 17.1 SPECIAL FUNCTION. Verify that the DSB annunciator on the Noise Figure Test Set is on, the LO is set to 3000 MHz and E28 is gone.
9. Press 17.0 SPECIAL FUNCTION and 36.2 SPECIAL FUNCTION. Verify that error code E28 is still gone. Press 36.0 SPECIAL FUNCTION.
10. If steps 4 through 9 performed as indicated, go to step 12. If there seems to be a problem, go to step 11.
11. If any one of the steps (4 through 9) did not perform as indicated, check the cabling between the instruments. Then, repeat steps 4 through 9. If the problem still exists, go to step 17.

NOTE

The following steps will verify if the Noise Figure Measurement System is operating properly. If steps 12 through 16 do not perform as indicated, go to step 17.

12. On the Noise Figure Meter, change the start frequency to 1000, the stop frequency to 5000 and the step size to 1000. The procedure is to press the appropriate key (START FREQ, STOP FREQ or STEP SIZE), key in the new value and press ENTER.

NOTE

Step 13 should not be performed until the Noise Figure Measurement System has had a twenty minute warm-up period. Twenty minutes is needed for the Noise Figure Measurement System to reach operating temperature.

13. On the Noise Figure Meter, press CALIBRATE twice. CALIBRATE is pressed twice to ensure that a calibration is performed only when desired. After CALIBRATE is pressed twice, the Noise Figure Test Set's YIG filter is fine tuned. Then,
-

OPERATOR'S CHECKS

Noise Figure Measurement System Check (cont'd)**Procedure
(cont'd)**

the Noise Figure Measurement System is calibrated. During the Noise Figure Test Set's YIG filter fine tuning, the following indications will be seen on the Noise Figure Meter, Noise Figure Test Set and System Local Oscillator:

NOTE

The fine tuning calibration will take from twenty-five to thirty seconds to complete.

Noise Figure Meter

- a. Each point that is being fine tuned and is included in band SSB3 (single sideband 3, on the Noise Figure Test Set; 2401 to 18000 MHz) is displayed in the left display. Frequency points that are included in bands SSB1 (single sideband 1, on the Noise Figure Test Set; 10 to 1600 MHz) or SSB2 (single sideband 2, on the Noise Figure Test Set; 1601 to 2400 MHz) are not displayed.
- b. "8971" appears in the INSERTION GAIN display.
- c. "CAL" appears in the NOISE FIGURE display.

Noise Figure Test Set

- a. The REMOTE annunciator is on.
- b. The LISTEN annunciator will flash.
- c. The annunciators for SSB1, SSB2 and SSB3 will be stepped from SSB1 to SSB2 to SSB3.

System Local Oscillator

- a. The REMOTE annunciator is on.
- b. The LISTEN annunciator will flash.
- c. The FREQUENCY display will move around.

When the Noise Figure Test Set YIG filter fine tuning is complete, the Noise Figure Measurement System is calibrated. The calibration will be done for each input gain setting at the frequencies set by START FREQ, STOP FREQ and STEP SIZE.

During calibration the following indications can be seen on the Noise Figure Meter, Noise Figure Test Set and System Local Oscillator:

Noise Figure Meter

- a. The frequency point being calibrated will be shown in the left display.
- b. The noise figure of the frequency point is shown in the NOISE FIGURE display.
- c. The INSERTION GAIN display is blank.

Noise Figure Test Set

- a. The REMOTE annunciator is on.
 - b. The LISTEN annunciator will flash.
 - c. The annunciators for SSB1, SSB2 and SSB3 will step from SSB1 to SSB2 to SSB3.
-

OPERATOR'S CHECKS

Noise Figure Measurement System Check (cont'd)**Procedure
(cont'd)****System Local Oscillator**

- a. The REMOTE annunciator is on.
- b. The LISTEN annunciator will flash.
- c. The FREQUENCY display will be changing.

14. When calibration is complete, press 17.1 SPECIAL FUNCTION. The annunciator for band DSB (double sideband) will light up on the Noise Figure Test Set.
 15. On the Noise Figure Meter, change the stop frequency by pressing SWEEP STOP FREQ, keying in 3000 and pressing ENTER.
 16. Observe the NOISE FIGURE display on the Noise Figure Meter. The noise figure displayed should be between 8 and 12 dB.

If the system performed as indicated in steps 13 through 16, the Noise Figure Measurement System is operating properly and this check is complete. If the system did not operate as indicated, go to step 17.
 17. Disconnect the Noise Figure Test Set from the Noise Figure Meter's SIB connector.
 18. If the Operator's Checks for the Noise Figure Meter have not been performed, perform the Operator's Checks for the Noise Figure Meter; a check for the System Local Oscillator is included. The Operator's Checks begin at paragraph 3-10, in this manual. If the Noise Figure Meter and System Local Oscillator are found to be operating properly, go to step 19. If either of the instruments is not operating properly, refer to the appropriate service manual.
 19. With both the Noise Figure Meter and System Local Oscillator operating properly, the following check should be completed before it is assumed that the Noise Figure Test Set is not operating properly.
 20. Disconnect all instruments from the Noise Figure Meter's HP-IB and SIB connectors. This test will verify that both buses are operating properly.
 21. Press 45.2 SPECIAL FUNCTION and 46.1 SPECIAL FUNCTION.
 22. Turn the Noise Figure Meter off and then back on. When "Fr CAL" is gone from the Noise Figure Meter's display, connect the SIB connector to the HP-IB connector.
 23. Press 98.1 SPECIAL FUNCTION; "SIB tEST" is displayed and there is a five second delay before the test begins. The results of the test will be displayed on the front panel using one of the error codes listed in the table below. The tests are performed as listed in the table. The first failure will abort the test.
 24. If an error is not encountered, the HP-IB and the SIB are operating properly. It is safe to assume that the Noise Figure Test Set is the instrument that is causing the Noise Figure Measurement System problem. Refer to the Noise Figure Test Set service manual for troubleshooting assistance.
 25. Remove the cable connecting the HP-IB and SIB connectors. Turn the Noise Figure Meter off and then back to on.
 26. Press 45.1 SPECIAL FUNCTION and 46.0 SPECIAL FUNCTION.
-

OPERATOR'S CHECKS

Noise Figure Measurement System Check (cont'd)**Procedure
(cont'd)**

| Error Code | Description of Error Code | Corrective Action |
|------------|--|--|
| E00 | No Errors | |
| E75 | A14U28, the interface hardware or the traces to A14U28 are bad. | Try another HP-IB cable; refer to Service ¹ |
| E74 | A14U2 or the interface hardware to A14U2 is bad. The interface hardware to A14U28 is good. | Try another HP-IB cable; refer to Service ¹ |
| E01 | May be caused by the following: REN or ATN line has failed, REN and/or ATN line drivers are bad or cable connecting the HP-IB and SIB connectors is defective. | Try another HP-IB cable; refer to Service ¹ |
| E02 | Data path has been broken. | Try another HP-IB cable; refer to Service ¹ |
| E03 | System Interface Bus could not send a message to the Hewlett-Packard Interface Bus. | Try another HP-IB cable; refer to Service ¹ |
| E04 | SRQ not being set by A14U28 or not being detected by A14U2. | Try another HP-IB cable; refer to Service ¹ |
| E05 | System Interface Bus could not serial poll Hewlett-Packard Interface Bus. | Try another HP-IB cable; refer to Service ¹ |
| E06 | Collision detect circuit not functioning. | Try another HP-IB cable; refer to Service ¹ |
| E07 | Hewlett-Packard Interface Bus could not address System Interface Bus. | Try another HP-IB cable; refer to Service ¹ |
| E08 | Hewlett-Packard Interface Bus could not send a message to the System Interface Bus. | Try another HP-IB cable; refer to Service ¹ |

¹Service is in Section VIII of the Service Manual. The part number of the Service Manual is on the title page of this manual.

3-14. REMOTE OPERATION **HP-IB**

The Noise Figure Meter can be operated through the Hewlett-Packard Interface Bus (HP-IB). Bus compatibility, programming and data formats are described in the following paragraphs.

The Noise Figure Meter can operate in two mutually exclusive modes on the HP-IB:

1. **Normal Talker/Listener Mode.** This mode is used when the Noise Figure Meter is under the control of an HP-IB compatible computer or controller.
2. **Talk Only Mode.** This mode is used to output data to a device that is operating in the Listen Only Mode.

Most front panel functions, special functions and remote-only functions are programmable via HP-IB. Table 3-4 lists the functions that cannot be programmed via HP-IB.

A quick test of the Noise Figure Meter's HP-IB interface is described earlier in this section under Remote Operator's Checks. These checks verify that the Noise Figure Meter can respond to or send each of the applicable bus messages described in Table 3-3.

3-15. HP-IB Compatibility

The Noise Figure Meter has an open-collector, TTL, HP-IB interface which can be used with any HP-IB computing controller or computer for automatic system applications. The Noise Figure Meter is programmable via the HP Interface Bus. Its programming capability is described by the twelve HP-IB messages listed in Table 3-3. The Noise Figure Meter's compatibility with HP-IB is further defined by the following list of interface functions: SH1, AH1, T5, TE0, L4, LE0, SR1, RL1, PP0, DC1, DT1, C0, and E1. A more detailed explanation of these compatibility codes can be found in IEEE Standard 488-1978 (and the identical ANSI Standard MC1.1). For more information about HP-IB, refer to the Hewlett-Packard Electronic Instruments and Systems catalog and the booklet titled "Improving Measurements in Engineering and Manufacturing" (HP part number 5952-0058).

3-16. Remote Mode

Remote Capability. The Noise Figure Meter communicates on the bus in both remote and local modes. In remote, most of the Noise Figure Meter's

front panel controls are disabled (except for the LINE switch and LOCAL key). However, front panel displays remain active and valid. In remote, the Noise Figure Meter can be addressed to talk or listen. When addressed to listen, the Noise Figure Meter can issue the Data and Status Byte messages. Whether addressed or not, the Noise Figure Meter responds to the Clear (DCL), Local Lockout, Clear Lockout/Set Local, and Abort messages. In addition, the Noise Figure Meter can issue the Require Service Message.

Local-to-Remote Mode Changes. The Noise Figure Meter switches to remote operation upon receipt of the Remote message. The Remote message has two parts. They are:

- a. Remote enable bus control line (REN) set true.
- b. Device listen address received once (while REN is true).

When the Noise Figure Meter switches to remote, the REMOTE annunciator on the front panel turns on.

3-17. Local Mode

Local Capability. In local, the Noise Figure Meter's front panel controls are fully operational and the instrument responds to the Remote message. Whether addressed or not, the Noise Figure Meter also responds to the Clear, Local Lockout, Clear Lockout/Set Local, and the Abort messages. When addressed to talk, the Noise Figure Meter can issue Data messages and the Status Byte message, and whether addressed or not, it can issue the Require Service message.

Remote-to-Local Mode Changes. The Noise Figure Meter always switches to local from remote whenever it receives the Local message (GTL) or the Clear Lockout/Set Local message. (The Clear Lockout/Set Local message sets the Remote Enable control line [REN] false.) The Noise Figure Meter can also be switched to local by pressing the front panel LOCAL key (assuming Local Lockout is not in effect).

3-18. Addressing

The Noise Figure Meter interprets the byte on the eight HP-IB data lines as an address or a bus command if the bus is in the command mode. The command mode is defined as attention control line

HP-IB

Addressing (cont'd)

(ATN) true and interface clear control line (IFC) false. Whenever the Noise Figure Meter is being addressed (if in local or remote), either the TALK or LISTEN annunciator on the front panel turns on.

The Noise Figure Meter's HP-IB address is selected by special function. To change the HP-IB address or to determine the present address setting, refer to the discussion titled HP-IB and System Interface Bus (SIB) Addresses in the Detailed Operating Instructions at the end of this section.

Local Lockout. When a data transmission is interrupted, which can happen by pressing the LOCAL key to return the Noise Figure Meter to local mode, the data could be lost. This would leave the Noise Figure Meter in an unknown state. To prevent this, a local lockout is recommended. Local lockout disables the LOCAL key and allows return-to-local only under program control.

NOTE

Return-to-local can also be accomplished by turning the Noise Figure Meter's LINE switch to OFF, then back to ON. However, this technique has some disadvantages:

- a. It defeats the purpose and advantage of local lockout (that is, the system controller will lose control of a system element).*
- b. There are several HP-IB conditions that reset to default states at turn-on.*

3-19. Data Messages

The Noise Figure Meter communicates on the interface bus primarily with data messages. Data messages consist of one or more bytes sent over the bus' data lines when the bus is in the data

mode (attention control line [ATN] false). Unless it is set to Talk Only, the Noise Figure Meter receives data messages when addressed to listen. Virtually all instrument operations available in local mode can be performed in remote mode via data messages. The major exceptions are changing the LINE switch setting, using the Talk Only capability, and changing the HP-IB address of the Noise Figure Meter (refer to Table 3-4).

3-20. Receiving the Data Message

Depending on the status of Special Function 4, the Noise Figure Meter can either talk only, or talk and listen both (normal operation). The instrument responds to Data messages when it is enabled to remote (REN control line true) and it is addressed to listen. The instrument remains addressed to listen until it receives an Abort message or until its talk address or a universal unlisten command is sent by the controller.

Data Input Format. The Data message string, or program string, consists of a series of ASCII codes. Each code is typically equivalent to a front panel keystroke in local mode. Thus, for a given operation, the program string syntax in remote mode is the same as the keystroke sequence in local mode. Example 1 shows a typical program string.

Program Codes. All of the HP-IB codes normally used by the operator to control the Noise Figure Meter are given in Tables 3-8, 3-9, and 3-10. Table 3-8 provides an HP-IB code to parameter summary. Table 3-9 provides a special function to HP-IB code summary. Table 3-10 provides a front panel key to HP-IB code summary. All front panel keys except LOCAL have corresponding program codes. Some functions have an additional code which terminates the numeric data entry in Hz rather than MHz as indicated on the front panel.

EXAMPLE 1: Typical Program String

{ Controller Talk
Noise Figure Meter }




Table 3-3. Message Reference Table (1 of 2)

| HP-IB Message | Applicable | Response | Related Commands and Controls | Interface Functions* |
|-------------------------------|------------|---|-------------------------------|----------------------------|
| Data | Yes | Most Noise Figure Meter operations are bus programmable. All measurement results, special displays, and error outputs are available to the bus. | | AH1, SH1, T5, TE0, L4, LE0 |
| Trigger | Yes | If in remote and addressed to listen, the Noise Figure Meter makes a measurement according to previously programmed setup. It responds equally to bus command GET and program code T2, Trigger Execute (a Data message). | GET | DT1 |
| Clear | Yes | The Noise Figure Meter is set to the same conditions established by pressing PRESET. Refer to Table 3-6. | DCL SDC | DC1 |
| Remote | Yes | Remote mode is enabled when the REN bus control line is true. However, remote mode is not entered until the first time the Noise Figure Meter is addressed to listen. The front panel REMOTE annunciator lights when the instrument is actually in the remote mode. When entering the remote mode, no instrument settings or functions are changed, but all front panel keys except LOCAL are disabled. | REN | RL1 |
| Local | Yes | The Noise Figure Meter returns to local mode (front panel control). It responds equally to the GTL bus command and the front panel LOCAL key. When entering the local mode, no instrument settings or functions are changed. | GTL | RL1 |
| Local Lockout | Yes | Disables all front panel keys including LOCAL. Only the controller can return the Noise Figure Meter to local (front panel control). | LL0 | RL1 |
| Clear Lockout/ Set Local | Yes | The Noise Figure Meter returns to local (front panel control) and local lockout is cleared when the REN bus control line goes false. When entering local mode, no instrument settings or functions are changed. | $\overline{\text{REN}}$ | RL1 |
| Pass Control/ Take Control | No | The Noise Figure Meter cannot pass or take control of HP-IB. | | C0 |

* Commands, Control lines, and Interface Functions are defined in IEEE Std 488-1978. Knowledge of these may not be necessary if your controller's manual describes programming in terms of the twelve HP-IB Messages shown in the left column.



Table 3-3. Message Reference Table (2 of 2)

| HP-IB Message | Applicable | Response | Related Commands and Controls | Interface Functions* |
|---|------------|---|-------------------------------|----------------------|
| Require Service | Yes | The Noise Figure Meter sets the SRQ bus control line true if an invalid program code is received (unless disabled). The following conditions also set SRQ true when they occur if they are enabled by the operator to do so: Data Ready, Noise Figure Meter Calibration Complete, SRQ on the System Interface Bus, Noise Figure Meter received control of the System Interface Bus, Instrument Error has occurred and Extended Status Byte enabled conditions are active. | SRQ | SR1 |
| Status Byte | Yes | The Noise Figure Meter responds to a Serial Poll Enable (SPE) bus command by sending an 8-bit byte when addressed to talk. If the instrument is holding the SRQ control line true (issuing the Require Service message) bit 6 (RQS bit) in the Status Byte and the bit representing the condition causing the Require Service message to be issued will both be true. The bits in the Status Byte are latched but can be cleared by: <ol style="list-style-type: none"> 1. removing the causing condition, and 2. reading the Status Byte or 3. by sending the program code OS (output status) or RS (reset status). | SPE SPD | TE5 TE0 |
| Status Bit | No | The Noise Figure Meter does not respond to a parallel poll. | | PP0 |
| Abort | Yes | The Noise Figure Meter stops talking and listening. | IFC | T5 TE0 |
| *Commands, Control lines, and Interface Functions are defined in IEEE Std 488-1978. Knowledge of these may not be necessary if your controller's manual describes programming in terms of the twelve HP-IB Messages shown in the left column. | | | | |

Complete HP-IB capability as defined in IEEE Std 488 and ANSI Std MC1.1 is: SH1, AH1, T5, TE0, L4, LE0, SR1, RL1, PP0, DT1, C0 and E1.

Table 3-4. Functions Not Programmable Via HP-IB

| Function | Description |
|---|--|
| Control Function Selection (Special Function 4) | Normal Talker and Listener Talk Only |
| HP-IB Addresses (Special Function 40.0) | Display and Enter Noise Figure Meter Address |
| LINE Switch | Turns instrument ON and OFF. |

Receiving the Data Message (cont'd)

Where more than one code is given for a function, either code will serve equally. However, the mnemonic code given is recommended since it is shorter and more closely represents the function selected. Also, the mnemonic code will make deciphering program code strings easier. The first codes given are the codes used in all programming examples in this manual.

The Noise Figure Meter's response to the ASCII character set is as follows:

- a. The ASCII characters used for the program codes are the alphabet (A through Z), the numbers 0 through 9, the period (.), and the minus (-).
- b. Lower case letters are treated the same as upper case letters.
- c. All other characters are ignored (however, they can not be used as the second character of a two-character HP-IB program code). If any of these other characters are used as a second character or if an undefined combination of valid characters is sent, SRQ is set if the HP-IB error condition has been enabled.

Turning Off Functions. When operating in local mode, CALIBRATE, and SINGLE and AUTO Sweep toggle on and off with successive key-strokes. In remote mode, these functions do not toggle on and off. Instead, both require that the HP-IB code W0 be used to turn off the function.

Programming Numeric Data. When programming tuned frequency or issuing any numeric data (other than specific HP-IB codes) to the Noise Figure Meter, certain precautions should be observed. Numeric data may consist of up to five digits, one decimal point, and a one-digit signed exponent.

Triggering Measurements with the Data Message. A feature that is available from both the front panel and via remote programming is the selection of free run, standby, or triggered operation of the Noise Figure Meter. The HP-IB codes and related Special Functions are discussed in detail in the Trigger Selection Detailed Operating Instruction later in this section.

3-21. Sending The Data Message


Depending on how the control functions are set, the Noise Figure Meter can either talk only, or talk and listen both (normal operation). If set to both

talk and listen, the instrument sends Data messages when addressed to talk. The instrument then remains configured to talk until it is unaddressed to talk by the controller. To unaddress the Noise Figure Meter, the controller must send either an Abort message, a new talk address, or a universal untalk command.

Talk Only Mode. If the Noise Figure Meter's Talk address is valid and Special Function 4.2 is selected, the Noise Figure Meter is placed in the Talk Only mode. In this mode the instrument is configured to send Data messages whenever the bus is in the data mode. Each time the measurement is completed, the measurement result will be output to the bus unless the listening device is not ready for data. If the listener is not ready for data, another measurement cycle is executed.

Data Output Format. As shown below, the output data is always formatted as a real constant: first the sign, then five digits (leading zeros not suppressed) followed by the letter E and a signed power-of-ten multiplier. The string is terminated by a carriage return (CR) and a line feed (LF), string positions 11 and 12. Data is always output in fundamental units (that is Hz, dB, etc.), and the decimal point (not sent) is assumed to be to the right of the fifth digit of the mantissa. Data values never exceed 1×10^5 . The one exception to this format is the voltmeter mode as shown in Table 3-5, HP-IB Data Output Summary.

The general data output format is as follows:



A summary of the different data outputs is listed in Table 3-5.

When an error is output to the bus, it follows the same 12-byte format described above except most of the numeric digits have predetermined values as shown below. Error outputs always exceed 90 000 000 000. The two-digit error code is represented by the last two digits of the five-digit mantissa. The error code can be derived from the string by subtracting 9×10^{10} , then dividing the result by 1 000 000.



Sending the Data Message (cont'd)


Table 3-5. HP-IB Data Output Summary

| Front Panel Display ¹ | HP-IB Output Format | Conditions |
|----------------------------------|---------------------|--|
| Left Display | +DDDDDE+06 | Frequency |
| | ±DDDDDE±NN | Data other than frequency |
| INSERTION GAIN ² | +90000E+06 | Display is blank |
| | ±DDDDDE±NN | Gain or Calibration data (GmKBm) is displayed. |
| NOISE FIGURE ² | +90000E+06 | Display is blank |
| | ±DDDDDE±NN | Normal display or second stage temperature |
| | +DDDDDE-05 | Voltmeter mode |
| | +900DDE+06 | Error codes where DD is the error code) |
| | +90000E+06 | Data not ready. Sent when the instrument receives a read command while "..." is displayed in Trigger Hold mode. Also sent when display is blank. |

¹ The HP-IB data output for mode H0 is NOISE FIGURE CR/LF. The HP-IB data output for mode H1 or H2 is Left Display, INSERTION GAIN, NOISE FIGURE CR/LF. EOI is set each time LF is sent.

² The HP-IB output has one more digit of resolution than the front panel display (except for the voltmeter mode which has two more digits of resolution than the front panel NOISE FIGURE display).

Error Output Format:



The Noise Figure Meter will output special HP-IB codes, for the NOISE FIGURE window, when a read of the Noise Figure Meter is attempted during the following operations: ENR editing, ENR cata-

log, Noise Figure Test Set Coarse or Fine Tuning Calibration. The special HP-IB codes are given below:


ENR Editing




ENR Catalog



Noise Figure Test Set Fine Tuning Calibration



Noise Figure Test Set Coarse Tuning Calibration



One purpose for these special codes would be to read back from the Noise Figure Meter until the codes stop being sent, which would mean the task is complete. This would be useful when doing a coarse or fine tune calibration.

Timeouts should not be used with these special codes. If a timeout is used, it should be at least sixty seconds. This is necessary because it may take the Noise Figure Meter many seconds to set up the special code for output. This is the case for coarse and fine tune calibration.

3-22. Receiving the Clear Message

The Noise Figure Meter responds to the Clear message by assuming the settings detailed in Table 3-6. The Noise Figure Meter responds equally to the Selected Device Clear (SDC) bus command when addressed to listen, and the Device Clear (DCL) bus command whether addressed or not. The Clear message clears any pending Require Service mes-

Table 3-6. Response to a Clear Message (or Pressing PRESET) (1 of 2)

| Parameter | Condition |
|---|--|
| START FREQ | 10 MHz |
| STOP FREQ | 1600 MHz |
| STEP SIZE | 20 MHz |
| SWEEP | Off |
| FREQUENCY | 30 MHz |
| FREQ INCR | 20 MHz |
| SMOOTHING | 1 |
| CALIBRATE | Off |
| MEASUREMENT | UNCORRECTED NOISE FIGURE |
| SPECIAL FUNCTION | <p>NOTE</p> <p><i>Most Special Functions are set to their zero suffix state (for example, Measurement Mode Selection is set to 1.0). Some are turned off (for example, Power Measurements). The following four Special Functions are not affected by either the Clear message or by pressing PRESET. These four Special Functions are affected by Special Function 0.9. For the default values of these four Special Functions, refer to Table 3-14, Special Function Summary, in the Special Functions Detailed Operating Instruction.</i></p> <ul style="list-style-type: none"> <i>a. Control Function Selection (Special Function 4).</i> <i>b. HP-B Addresses (Special Function 40).</i> <i>c. System LO Programs (Special Function 41).</i> <i>d. System LO Commands (Special Function 42).</i> <p><i>In addition, Service Request (Special Function 44) is set to enable HP-IB Code Error (Special Function 44.3).</i></p> <p>The following Special Functions are set to the indicated default values:</p> |
| IF (Special Function 3.0) | 30 MHz |
| LO Frequency (Special Function 3.1) | 10000 MHz |
| Smoothing Factor (Special Function 13.2) | 1 |
| Spot ENR (Special Function 5.3) | 15.2 dB |
| T _{hot} (Special Function 5.4) | 9893K |
| T _{cold} (Special Function 6) | 296.5K |
| Oscilloscope Limits (Special Function 8) | |
| Noise Figure Lower Limit | 0 |
| Noise Figure Upper Limit | 8 |
| Gain Lower Limit | 0 |
| Gain Upper Limit | 40 |
| System LO Sideband Crossover frequency; Measurement Modes 1.5 through 1.9 (Special Function 17.2) | 16 GHz |



Table 3-6. Response to a Clear Message (or Pressing PRESET) (1 of 2)

| Parameter | Condition |
|---|-----------------------------|
| Noise Figure Measurement System | |
| Internal IF (Special Function 19) | |
| SSB2 IF | 700 MHz |
| SSB3 IF | 450 MHz |
| DBS IF | 25 MHz |
| Plotter Functions (Special Function 25) | |
| Noise Pen Number | 1 |
| Gain Pen Number | 2 |
| Plot Title | HP 8970B Noise Figure Meter |
| Loss Compensation (Special Function 34) | |
| Before DUT | 0 dB |
| Temperature of Losses | 0K |
| After DUT | 0 dB |
| Set Sequence (Special Function 35.2) | 1 through 9 |

Receiving the Clear Message (cont'd)

sage and resets the Service Request Condition (Special Function 44) such that the Require Service message will be issued on HP-IB code errors only (Special Function 44.3).

Refer to Table 3-14 in the Special Functions Detailed Operating Instruction for a list of the Special Functions that are turned off or not affected by the Clear Message.

3-23. Receiving the Trigger Message

When in remote and addressed to listen, the Noise Figure Meter responds to a Trigger message by executing one measurement cycle. The Noise Figure Meter responds equally to a Trigger message (the Group Execute Trigger bus command [GET]) and a Data message, program code T2 (execute a measurement).

3-24. Receiving the Remote Message

The Remote message has two parts. First, the remote enable bus control line (REN) is held true; second, the device listen address is sent by the controller. These two actions combine to place the Noise Figure Meter in remote mode. Thus, the Noise Figure Meter is enabled to go into remote when the controller begins the Remote message, but it does not actually switch to remote until addressed to listen the first time. No instrument settings are changed by the transition from local to remote. When actually in remote, the Noise Figure Meter's

front panel REMOTE annunciator lights. When the Noise Figure Meter is being addressed (whether in remote or local), its front panel LISTEN or TALK annunciator turns on.

3-25. Receiving the Local Message

The Local message is the means by which the controller sends the Go To Local (GTL) bus command. If addressed to listen, the Noise Figure Meter returns to front panel control when it receives the Local message. If the instrument was in local lockout when the Local message was received, front panel control is returned, but lockout is not cleared. Unless it receives the Clear Lockout/Set Local message, the Noise Figure Meter will return to local lockout the next time it goes to remote. No instrument settings are changed by the transition from remote to local.

When the Noise Figure Meter goes to local mode, the front panel REMOTE annunciator turns off. However, when the Noise Figure Meter is being addressed (whether in remote or local), its front panel LISTEN or TALK annunciator lights.

If the Noise Figure Meter is not in local lockout mode, pressing the front panel LOCAL key might interrupt a Data message being sent to the instrument, leaving the instrument in a state unknown to the controller. This can be prevented by disabling the Noise Figure Meter's front panel keys entirely, using the Local Lockout message.

3-26. Receiving the Local Lockout Message

The Local Lockout message is the means by which the controller sends the Local Lockout (LLO) bus command. If in remote, the Noise Figure Meter responds to the Local Lockout Message by disabling the front panel LOCAL key. The local lockout mode prevents loss of data or system control due to someone accidentally pressing front panel keys. If, while in local, the Noise Figure Meter is enabled to remote (that is, REN is set true) and it receives the Local Lockout message, it will switch to remote mode with local lockout the first time it is addressed to listen. When in local lockout, the Noise Figure Meter can be returned to local only by the controller (using the Local or Clear Lockout/Set Local messages) or by setting the LINE switch to OFF and back to ON or by removing the bus cable.

3-27. Receiving the Clear Lockout/Set Local Message

The Clear Lockout/Set Local message is the means by which the controller sets the Remote Enable (REN) bus control line false. The Noise Figure Meter returns to local mode (full front panel control) when it receives the Clear Lockout/Set Local message. No instrument settings are changed by the transition from remote with local lockout to local. When the Noise Figure Meter goes to local mode, the front panel REMOTE annunciator turns off.

3-28. Receiving the Pass Control Message

The Noise Figure Meter does not respond to the Pass Control message because it does not have this control capability.

3-29. Sending the Require Service Message

The Noise Figure Meter sends the Require Service message by setting the Service Request (SRQ) bus control line true. The instrument can send the Require Service message in either local or remote mode. The Require Service message is cleared when a serial poll is executed by the controller or if a Clear message is received by the Noise Figure Meter. (During serial poll, the Require Service message is cleared immediately before the Noise Figure Meter places the Status Byte message on the bus.) There are seven conditions that can be enabled to cause the Require Service message to be sent when they occur. All seven conditions are described as follows:

1. Data Ready: When the Noise Figure Meter is ready to send any information except error codes.
2. HP-IB Code Error: When the Noise Figure Meter receives an invalid Data message. (Unless specifically disabled, this condition causes a Require Service message to be sent.)
3. Instrument Error: When any operator error (E10 through E49, and E99) is displayed by the Noise Figure Meter.
4. Calibration Complete: When a Noise Figure Meter calibration cycle is complete.
5. System Interface Bus SRQ: When an instrument on the System Interface Bus is issuing a Service Request (SRQ).
6. Received Control of the System Interface Bus: When the Noise Figure Meter has taken control of the System Interface Bus.
7. Extended Status Byte: When one of the enabled bits on the Extended Status Byte is true.

3-30. Enabling the Service Request Condition

Use Special Function 44 (or the related Service Request Condition HP-IB codes) to enable the Noise Figure Meter to issue the Require Service message on any of the conditions above. The Service Request Condition Special Function is entered from either the front panel or via the HP-IB. A description of the Service Request Condition Special Function and the procedure for enabling the various conditions are given in the following paragraphs:

NOTE

Each condition of the Status Byte can be enabled separately or all the conditions can be enabled at once (Special Function 44.7). Desired conditions of the Extended Status Byte must be enabled all at once (Special Function 44.9). If the enabled conditions of the Status Byte are changed, it is a good practice to first disable the SRQ capability and then enter the required enabled conditions.

A description of the Status Byte and Extended Status Byte bits is found in the HP-IB Syntax and Characteristics Summary.



Enabling the Service Request Condition (cont'd)

Table 3-7. Service Request Enabled Conditions Summary

| HP-IB Code HP-IB | Special Function | Description |
|---------------------|------------------|---|
| Q0 | 44.0 | Disables the SRQ capability (clears all enabled conditions) |
| Q1 | 44.1 | Enable Data Ready |
| Q2 | 44.2 | Enable Noise Figure Meter Calibration Complete (not for Zero Frequency or IF Calibration) |
| Q3 | 44.3 | Enable HP-IB Code Error |
| Q4 | 44.4 | Enable SRQ on the System Interface Bus |
| Q5 | 44.5 | Enable Noise Figure Meter received control on the System Interface Bus |
| Q6 | 44.6 | Enable Instrument Error |
| RM | 44.7 | Set entire Status Byte Mask |
| Q8 | 44.8 | Enable Extended Status Byte |
| RE | 44.9 | Set the Extended Status Byte Mask |

a. Send the HP-IB Code Q0 to clear all the enabled conditions of the Status Byte. The enabled conditions of the Extended Status Byte are not cleared with Q0. The Extended Status Byte enabled conditions are cleared with RE0EN.

b. Each of the desired conditions of the Status Byte may be set individually (Special Functions 44.1 through 44.6) or all the conditions may be set at once (Special Function 44.7).

c. To set conditions individually, send the applicable HP-IB Codes from Table 3-7. To set all the desired conditions at once, send the total binary weight of the bit positions desired. The command sequence would be as follows: RM132EN.

RM is the HP-IB code for Special Function 44.7; 132 is the total binary weight of bits 2 and 7 of the Status Byte; EN is the HP-IB code for ENTER.

d. The conditions of the Extended Status Byte can't be enabled individually; the desired conditions must be enabled with Special Function 44.9.

e. To set the conditions of the Extended Status Byte, send the total binary weight of the bit positions desired. The command sequence would be as follows: RE36EN.

RE is the HP-IB code for Special Function 44.9; 36 is the total binary weight of bits 2 and 5 of the Extended Status Byte; EN is the HP-IB code for ENTER.

Normally, device subroutines for the Noise Figure Meter can be implemented simply by triggering measurements and then reading the output data. In certain applications, the controller must perform other tasks while controlling the Noise Figure Meter. Figure 3-12 illustrates a flow chart for developing device subroutines using the instrument's ability to issue the Require Service message when data is ready. This subroutine structure frees the controller to process other routines until the Noise Figure Meter is ready with data.

3-31. Sending the Status Byte Message

After receiving a Serial Poll Enable bus command (SPE) and when addressed to talk, the Noise Figure Meter sends a Status Byte message.

The Status Byte message consists of one 8-bit byte in which 7 of the bits are set according to the enabled conditions described above under Sending the Require Service Message. If one or more of the seven conditions are enabled and present, all the bits corresponding to the conditions and also bit 6, the RQS bit, will be set true (and the Require Service message is sent). If one of the above conditions occurs but has not been enabled by Special Function 44 or the HP-IB codes, neither the bit corresponding to the condition nor the RQS bit will be set (and the Require Service message will not be sent). The bit pattern of the Status Byte is shown in the HP-IB Syntax and Characteristics Summary.

Extended Status Byte. A second status byte is available but can only be accessed via the Output Status function (refer to the following paragraph for an explanation of the Output Status function). Bit 7 of the Status Byte indicates that an enabled condition on the Extended Status Byte is true. If Bit 7 is true, the second status byte should be accessed via the Output Status function to determine what caused Bit 7 to become true. The bit pattern can be interpreted with the information in the HP-IB Syntax and Characteristics Summary.

Sending the Status Byte Message (cont'd)

Output Status Function. After receiving the program code OS (Output Status) and when addressed to talk, the Noise Figure Meter sends two binary bytes, each 8 bits wide. The first byte is identical to the Status Byte of the Serial Poll. The second byte is the Extended Status Byte which provides additional information. Refer to the HP-IB Syntax and Characteristics Summary for a description of each Status Byte. Bits in the main Status Byte and Extended Status Byte are cleared upon execution of the Output Status (OS) or Reset Status (RS) program code.

3-32. Clearing the Status Byte

Once the Noise Figure Meter receives the serial poll enable bus command (SPE), it is no longer allowed to clear the Status Byte. However, it can add additional bits to the status byte if the bit has been enabled and the condition occurs.

After the Status Byte message has been sent it will be cleared if the Serial Poll Disabled (SPD) bus command is received, if the Abort message is received, or if the Noise Figure Meter is unaddressed to talk. Nonvolatile error messages are




Figure 3-12. Example Flow Chart for Driving the Noise Figure Meter Using the Require Service Message (SRQ)

Clearing the Status Byte (cont'd)

also cleared when the Status Byte message is sent. Thus, some error messages that may have caused the Require Service Message to be issued disappear when a serial poll is performed. Refer to the Error Messages and Recovery Detailed Operating Instructions for a listing of volatile and nonvolatile errors. Regardless of whether or not the Status Byte message has been sent, the Status Byte and any Require Service message pending will be cleared if a Clear message is received.

3-33. Sending the Status Bit Message

The Noise Figure Meter does not respond to a Parallel Poll Enable (PPE) bus command and thus cannot send the Status Bit message.

3-34. Receiving the Abort Message


The Abort message is the means by which the controller sets the Interface Clear (IFC) bus control line true. When the Abort message is received, the Noise Figure Meter becomes unaddressed and stops talking or listening.

HP-IB SYNTAX AND CHARACTERISTICS SUMMARY

Address:

Selected and displayed on front panel using Special Function 44.0, Noise Figure Meter HP-IB Address.
Factory set to 8 decimal.


Numeric Data Input Format (Except in Voltmeter mode):*




Output Formats: (Except in Voltmeter mode).*

HP-IB code H0 (43.0 SP): **±DDDDDE±NNCRLF**

HP-IB code H1 (43.1 SP): **±DDDDDE±NN, ±DDDDDE±NN, ±DDDDDE±NNCRLF**
and H2 (43.2 SP)




Errors:




Special HP-IB error codes (used for ENR Editing, ENR Catalog and Noise Figure Test Set Coarse and Fine Tuning Calibration):

ENR Editing or Catalog:



Noise Figure Test Set Coarse or Fine Tuning Calibration:



Reserved Number (used for the "—" special display or a blank display):

+90000E+06CRLF

Reserved Number (used for the "—", overflow in measurement or measured noise figure > 32 dB):

+90099E+06CRLF

Return to Local:

Front panel LOCAL key if not locked out.

* For information on the Voltmeter mode refer to Section VIII. Section VIII is in the Service Manual. The part number of the Service Manual is on the title page of this manual.



HP-IB SYNTAX AND CHARACTERISTICS SUMMARY (cont'd)

Status Byte:

| Bit | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|---------------------------|--|-------------------------|------------------|-------------------------|-----------------------------|------------------|---|------------|
| Weight | 128 | 64 | 32 | 16 | 8 | 4 | 2 | 1 |
| Service Request Condition | Extended Status Byte | RQS Bit Require Service | Instrument Error | Received Control on SIB | SRQ on System Interface Bus | HP-IB Code Error | Noise Figure Meter Calibration Complete | Data Ready |
| Notes | 1. The condition indicated in bits 0—5 and 7 must be enabled to cause a Service Request by Special Function 44. Each condition can be enabled separately or all conditions can be enabled at once, using Special Function 44.7. 2. The RQS bit (bit 6) is set true whenever any of the conditions of bits 0—5 and 7 are enabled and occur. 3. For bit 7 to be enabled, both the Extended Status Byte mask and Special Function 44.8 must be enabled. | | | | | | | |

Extended Status Byte:

| Bit | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|---------------------------|---|----------------|----------------|-----------------------------------|-------------------------------------|---|--|---|
| Weight | 128 | 64 | 32 | 16 | 8 | 4 | 2 | 1 |
| Service Request Condition | 0 (always) | Power On Cycle | Plot Completed | Fine Tuning Calibration Completed | Coarse Tuning Calibration Completed | Noise Figure Test Set needs Coarse Tuning | Noise Figure Test Set needs Fine Tuning at Current Frequency | Noise Figure Test Set needs Fine Tuning Calibration (Special Function 36.3) |
| Notes | 1. The conditions indicated in bits 0 through 6 must be enabled to cause a Service Request, by Special Function 44.9. Special Function 44.9 enables all the conditions desired at once. The procedure is to press 44.9 SPECIAL FUNCTION, enter the total binary weights of the conditions desired and press ENTER. 2. Special Function 44.8 must also be used to enable bit 7, in the status byte, to generate an SRQ. | | | | | | | |

Complete HP-IB capability as defined in IEEE Std 488-1978, and ANSI Std MC1.1 is: SH1, AH1, T5, TE0, L4, LE0, SR1, RL1, PP0, DC1, DT1, C0, E1.

Table 3-8. Noise Figure Meter HP-IB Code to Parameter Summary (1 of 4)

| HP-IB Code HP-IB | Parameter | HP-IB Code HP-IB | Parameter |
|---------------------|--|---------------------|---|
| AC | System LO Auxiliary Commands | | Input Gain Calibration |
| AD | Sets the RAM address for modification/ inspection or ROM address for inspection and disables auto-increment mode | C0 | +20, +10, and 0 dB |
| | | C1 | +10, 0, and -10 dB |
| AF | Enable Smoothing Factor | C2 | 0, -10, and -20 dB |
| AI | Sets the RAM address for modification/ inspection or ROM address for inspection and enables auto-increment mode | C3 | -10, -20, and -30 dB |
| | | DA | Disable auto sweep abort |
| | Output to Oscilloscope | DB | dB |
| A0 | Noise Figure and Gain | DC | Disable Error 48 (E48) |
| A1 | Test Pattern | DD | Perform a Selective Device Clear of the Pass Through Device on the System Interface Bus |
| A2 | Noise Figure Only | DE | DECREASE Smoothing |
| A3 | Gain Only | DF | Measurement frequency is shown in the left display |
| A4 | Plot Noise Figure (for X-Y Recorder) | DG | Interpolated measurements disabled above 1600 MHz in Modes 1.5 through 1.9 |
| A5 | Plot Gain (for X-Y Recorder) | DI | Input to Noise Figure Meter (Modes 1.0 through 1.4) or Input to Noise Figure Test Set (Modes 1.5 through 1.9) displayed |
| A6 | X Axis is Noise Figure and Y Axis is Gain (Strip Chart Mode) | DN | ↓ (Step down) |
| A7 | Enable recorder test | DP | Disable Auto Pass Control |
| A8 | Oscilloscope display cursor enabled | DS | Perform a Device Clear on the System Interface Bus, if the Noise Figure Meter is the Active Controller. |
| A9 | Oscilloscope display cursor disabled | DT | Enable Display Test |
| BD | All displays are blanked | | Noise Source Temperature Units for Data Input |
| BF | Left display is blanked | D0 | K |
| B0 | Double Sideband | D1 | °C |
| B1 | Lower Single Sideband | D2 | °F |
| B2 | Upper Single Sideband | EA | Display and Enter System LO SIB Address |
| B3 | Signal Up Conversion $IF = F_{\text{signal}} + F_{LO}$ | EC | ENR Table for Calibration |
| B4 | Noise Figure Test Set single sideband operation; Modes 1.5 through 1.9 | EG | Enable Interpolated Measurements in Modes 1.5 through 1.9 |
| B5 | Noise Figure Test Set double sideband operation; Modes 1.5 through 1.9 | | Noise Figure Meter YIG Filter Tuning Functions |
| CA | CALIBRATE | EH | Enable Hysteresis Calibration when Frequency is Changed |
| CC | Cold Calibration (Manual Measurement) | EM | ENR Table for Measurement |
| CF | Upper and lower sideband crossover frequency selection; Modes 1.5 through 1.9 | EN | ENTER |
| CH | Hot Calibration (Manual Measurement) | EP | Enable Auto Pass Control |
| CI* | Calibrate IF Attenuators* | ER | Recalls Last Error Issued |
| CP | Noise Figure Test Set Coarse Tuning Calibration | | Measurement Modes |
| CR | Noise Figure Meter releases control of the System Interface Bus | E0 | Mode 1.0 |
| CS | Initialize Special Functions | E1 | Mode 1.1 |
| CT | Noise Figure Meter takes control of the System Interface Bus | | |
| CU | Selects Upper Frequency of Noise Figure Test Set | | |

* If code CI is used, the gain accuracy specification will be degraded from 0.15 dB to a typical value of 0.25 dB. For more information, refer to "Calibration, IF Attenuators" Detailed Operating Instruction.

HP-IB

Table 3-8. Noise Figure Meter HP-IB Code to Parameter Summary (2 of 4)

| HP-IB Code HP-IB | Parameter | HP-IB Code HP-IB | Parameter |
|---------------------|---|---------------------|---|
| | Measurement Modes (cont'd) | | Special Function Catalog (cont'd) |
| E2 | Mode 1.2 | G7 | Line 7 Status |
| E3 | Mode 1.3 | G8 | Line 8 Status |
| E4 | Mode 1.4 | HC | Display and Enter Pass Control System Interface Bus Address |
| E5 | Mode 1.5 | HP | Display and Enter Plotter System Interface Bus Address |
| E6 | Mode 1.6 | HS | Display and Enter System Interface Bus Address |
| E7 | Mode 1.7 | HT | Display and Enter Noise Figure Test Set System Interface Bus Address |
| E8 | Mode 1.8 | HZ | Hz |
| E9 | Mode 1.9 | | HP-IB Data Output |
| FA | START FREQ | H0 | NOISE FIGURE Display Only |
| FB | STOP FREQ | H1 | Left, INSERTION GAIN, and NOISE FIGURE Displays |
| FC | Custom LO CW Prefix and Suffix | H2 | During Calibration the Frequency, Calibration Data (GKB) and Second Stage Temperature are output. |
| FD | Disable Noise Figure Test Set Fine Tuning Calibration with Noise Figure Measurement System Calibration; warning (E28) when fine tune needed | IF | IF (for Modes 1.1, 1.3, 1.6 and 1.8) |
| FF | Noise Figure Test Set Fine Tuning Calibration at the current Frequency | IH | IF Attenuator Hold |
| FN | FREQ INCR | IN | INCREASE Smoothing |
| FR | FREQUENCY | IS | Perform an Interface Clear on the System Interface Bus, if the Noise Figure Meter is the System Controller. |
| FT | Noise Figure Test Set Fine Tuning Calibration with Noise Figure Measurement System Calibration; warning (E28) when fine tune needed. | | IF Attenuation Selection |
| FW | Disable Noise Figure Test Set Fine Tuning Calibration before Noise Figure Measurement System Calibration and disable Error 28 (E28) | I0 | Auto |
| F0 | Smoothing Factor = 1 | I1 | 0 dB |
| F1 | Smoothing Factor = 2 | I2 | 5 dB |
| F2 | Smoothing Factor = 4 | I3 | 10 dB |
| F3 | Smoothing Factor = 8 | I4 | 15 dB |
| F4 | Smoothing Factor = 16 | I5 | 20 dB |
| F5 | Smoothing Factor = 32 | I6 | 25 dB |
| F6 | Smoothing Factor = 64 | I7 | 30 dB |
| F7 | Smoothing Factor = 128 | I8 | 35 dB |
| F8 | Smoothing Factor = 256 | | System LO Programs |
| F9 | Smoothing Factor = 512 | J0 | HP 8350B Sweep Oscillator |
| GL | Gain Lower Limit (for Oscilloscope) | J2 | HP 8671B/8672A Syn. Signal Generator |
| GP | Select Gain Pen Number | J3 | HP 8673B Syn. Signal Generator |
| GU | Gain Upper Limit (for Oscilloscope) | J4 | HP 8340B Sweep Oscillator |
| | Special Function Catalog | J5 | Custom Local Oscillator Program |
| G0 | Scan Catalog Lines | | Keyboard Test |
| G1 | Line 1 Status | KY | Display Key Codes |
| G2 | Line 2 Status | K1 | Key Test — Row 1 |
| G3 | Line 3 Status | K2 | Key Test — Row 2 |
| G4 | Line 4 Status | K3 | Key Test — Row 3 |
| G5 | Line 5 Status | | |
| G6 | Line 6 Status | | |

Table 3-8. Noise Figure Meter HP-IB Code to Parameter Summary (3 of 4)

| HP-IB Code HP-IB | Parameter | HP-IB Code HP-IB | Parameter |
|---------------------|---|---------------------|--|
| | Key Test (cont'd) | | Power Measurements |
| K4 | Key Test — Row 4 | N5 | SOURCE Off (Uncal) |
| K5 | Key Test — Row 5 | N6 | SOURCE On (Uncal) |
| K6 | Key Test — Row 6 | N7 | SOURCE Off (Cal) |
| K7 | Key Test — Row 7 | N8 | SOURCE On (Cal) |
| K8 | Key Test — Row 8 | OS | Output Both Status Bytes |
| LA | Loss Compensation before DUT | PA | Plot Grid and Data |
| LB | Loss Compensation after DUT | PC | Custom LO Power Prefix and Suffix |
| LD | Disable System LO on System Interface Bus | PD | Plot Data Only |
| LE | Enable System LO on System Interface Bus | PF | Perform Noise Figure Test Set Fine Tuning Calibration |
| LF | LO Frequency (for Modes 1.2, 1.4, 1.7 and 1.9) | PG | Plot Grid and Axes Labels |
| LL | Go to Lower Left (for X-Y Recorder) | PI | Plotter is on the System Interface Bus |
| LT | Temperature of Losses | PL | System LO Power Level |
| L0 | Loss Compensation Off | PM | Plot Data read on HP-IB |
| L1 | Loss Compensation On | PR | PRESET |
| MB | Selects Modification or Inspection of a Byte in RAM or Inspection of a Byte in ROM. | PS | System LO CW Prefix and Suffix |
| MC | Cold Manual Measurement | PT | Display and Enter the Address of the Pass Through Device on the System Interface Bus |
| MF | Selects Modification or Inspection of a Floating Point Value in RAM or Inspection of a Floating Point Value in ROM. | P0 | Normal Display (to return from displaying manual measurement results) |
| MH | Hot Manual Measurement | P1 | Display Manual Measurement Results |
| MN | System LO Minimum Frequency in MHz | | Sequence Functions |
| MW | Selects Modification or Inspection of a Word in RAM or Inspection of a Word in ROM. | QA | Automatic |
| | | QC | Clear |
| | | QM | Manual |
| | | QS | Set |
| | | | Service Request |
| MX | System LO Maximum Frequency in MHz | Q0 | Disable SRQ Capability |
| MZ | MHz | Q1 | Enable Data Ready to Cause SRQ |
| M1 | UNCORRECTED NOISE FIGURE | Q2 | Enable Cal Complete to Cause SRQ |
| M2 | CORRECTED NOISE FIGURE AND GAIN | Q3 | Enable HP-IB Code Error to Cause SRQ |
| NC | Noise Figure Meter is not system controller on the System Interface Bus | Q4 | Enable SRQ on the System Interface Bus to Cause SRQ |
| ND | Sets all ENR Values to 15.20 dB and Noise Source ID No. to 00000. | Q5 | Enable Noise Figure Meter received control on the System Interface Bus to Cause SRQ |
| NE | Enter and Use ENR | Q6 | Enable Instrument Error to cause SRQ |
| NL | Noise Figure Lower Limit (for Oscilloscope) | Q8 | Enable Extended Status Byte to Cause SRQ |
| NP | Selects the Noise Pen Number | | RECALL |
| NR | Enter ENR Table | RC | Set Extended Status Byte Mask |
| NS | Noise Source Catalog | RE | RF Attenuator Hold |
| NU | Noise Figure Upper Limit (for Oscilloscope) | RH | Set Status Byte Mask |
| | Noise Figure Display Units | RM | Reset Status Bytes |
| N0 | F dB | RS | RF Attenuation Selection |
| N1 | F | | |
| N2 | Y dB | R0 | Auto |
| N3 | Y | R1 | +20 dB |
| N4 | Te K | R2 | +10 dB |



Table 3-8. Noise Figure Meter HP-IB Code to Parameter Summary (4 of 4)

| HP-IB Code HP-IB | Parameter | HP-IB Code HP-IB | Parameter |
|---------------------|---|---------------------|--|
| R3 | RF Attenuation Selection (cont'd) 0 dB | | Noise Figure Meter YIG Filter Tuning Functions |
| R4 | -10 dB | UY | YIG DAC is Updated when Frequency is Changed |
| R5 | -20 dB | U0 | 0 MHz Hold Off |
| R6 | -30 dB | U1 | 0 MHz Hold On |
| SB | Noise Figure Meter does a Serial Poll on the System Interface Bus | | Voltmeter Mode |
| SC | Noise Figure Meter is System Controller on the System Interface Bus | VC | Noise Source Off |
| SD | Displays Current Software Date | VH | Noise Source On |
| SE | Display Current ENR | VP | Display Pass Through Address of Noise Figure Meter |
| SI | Display IF Attenuator Setting | V0 | Exponential Smoothing |
| SN | Enter Noise Source Identifier | V1 | Arithmetic Smoothing |
| SP | SPECIAL FUNCTION | WT | Enter Plot Name |
| SQ | SEQ | W0 | Sweep Off |
| SR | Display RF Attenuator Setting | W1 | AUTO Sweep |
| SS | STEP SIZE | W2 | SINGLE Sweep |
| ST | STORE | | Recorder Test Functions |
| S0 | Use ENR Table | XV | X-Axis Test |
| S1 | Use Spot ENR | | Display Resolution |
| | Noise Figure Measurement System Internal IF Selection | X0 | Maximum Resolution |
| S2 | Display and Enter Internal IF for SSB2 | X1 | Less Resolution on Noise Figure |
| S3 | Display and Enter Internal IF for SSB3 | X2 | Less Resolution on Gain |
| S4 | Display and Enter Internal IF for DSB | | Recorder Test Functions |
| S5 | Display Noise Figure Meter Input Frequency | YV | Y-Axis Test |
| TC | T _{cold} | | Frequency Calibration |
| TD | Disable Noise Figure Test Set on the System Interface Bus | Y0 | Automatic |
| TE | Enable Noise Figure Test Set in Modes 1.5 through 1.9 | Y1 | Disable Frequency Cal |
| TH | T _{hot} | Y2 | Perform 1 Frequency Cal |
| TM | System LO Settling Time | Y8 | Disables Debug Oscilloscope Plots |
| TS | Enable Noise Figure Test Set in Modes 1.0 through 1.9 | Y9 | Enables Debug Oscilloscope Plots |
| | Trigger Selection | | Individual RF Attenuator Selection |
| T0 | Free Run | Z0 | Select RF Thru Path |
| T1 | Hold | Z1 | Select 10 dB Pad No. 1 |
| T2 | Execute | Z2 | Select 20 dB Input Amplifier |
| UL | Display User Controlled Local Oscillator Frequency; Modes 1.5 through 1.9 | Z4 | Select 10 dB Pad No. 2 |
| UP | ↑ (Step up) | Z5 | Select 10 dB Pad No. 3 |
| UR | Go to Upper Right (for X-Y Recorder) | | |

Table 3-9. Special Function to HP-IB Code (1 of 7)

| Special Function | | HP-IB Code | Description |
|--|-------|---------------------------|--|
| Name | Code* | HP-IB | |
| Initialize Special Functions | 0.0 | CS | Initializes many Special Functions. |
| Initialize Special Functions and Set Defaults | 0.9 | None | Initializes all Special Functions and Sets all Defaults to Factory Set Conditions. |
| Measurement Mode Selection | 1.0 | E0 | Mode 1.0 (10—1600 MHz measurement) |
| | 1.1 | E1 | Mode 1.1 (fixed IF; variable freq. Sys. LO) |
| | 1.2 | E2 | Mode 1.2 (variable IF; fixed freq. Sys. LO; SSB) |
| | 1.3 | E3 | Mode 1.3 (fixed IF; variable freq. Sys. LO; mixer is DUT) |
| | 1.4 | E4 | Mode 1.4 (variable IF; fixed freq. Sys. LO; mixer is DUT) |
| | 1.5 | E5 | Mode 1.5 (10 to 18000 MHz) |
| | 1.6 | E6 | Mode 1.6 (fixed IF; variable frequency User Controlled LO) |
| | 1.7 | E7 | Mode 1.7 (variable IF; fixed frequency User Controlled LO; SSB) |
| | 1.8 | E8 | Mode 1.8 (fixed IF; variable frequency User Controlled LO; mixer is DUT) |
| | 1.9 | E9 | Mode 1.9 (variable IF; fixed frequency User Controlled LO; mixer is DUT) |
| Sideband Frequency Offset | 2.0 | B0 | Double Sideband (no offset) |
| | 2.1 | B1 | Lower Single Sideband ($F_{\text{signal}} < F_{\text{LO}}$) |
| | 2.2 | B2 | Upper Single Sideband ($F_{\text{signal}} > F_{\text{LO}}$) |
| | 2.3 | B3 | Signal Up Conversion $F_{\text{(IF)}} = F_{\text{(signal)}} + F_{\text{(LO)}}$ |
| Enter IF and LO Frequencies | 3.0 | IF | IF (for Modes 1.1, 1.3, 1.6 and 1.8) |
| | 3.1 | LF | LO (for Modes 1.2, 1.4, 1.7 and 1.9) |
| | 3.2 | UL | Displays User Controlled LO Frequency in Modes 1.6 through 1.9 |
| Control Function Selection | 4.0 | none | Normal Talker and Listener |
| | 4.2 | none | Talk Only |
| ENR, T_{hot} Settings and ENR Table Selection | 5.0 | S0 | Use ENR Table |
| | 5.1 | S1 | Use Spot ENR |
| | 5.2 | SE | Display Current ENR in dB |
| | 5.3 | NE | Enter and Use Spot ENR |
| | 5.4 | TH | Enter and Use T_{hot} |
| | 5.5 | SN | Enter Noise Source Identifier |
| | 5.6 | NS | Noise Source Catalog |
| | 5.7 | EC | ENR Table for Calibration |
| 5.8 | EM | ENR Table for Measurement | |
| T_{cold} Setting | 6.0 | TC | Enter T_{cold} |
| Output to Oscilloscope | 7.0 | A0 | Noise Figure and Gain |
| | 7.1 | A1 | Test Pattern |
| | 7.2 | A2 | Noise Figure Only |
| | 7.3 | A3 | Gain Only |
| | 7.4 | A8 | Oscilloscope Display Cursor Enabled |
| | 7.5 | A9 | Oscilloscope Display Cursor Disabled |

*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code.



Table 3-9. Special Function to HP-IB Code (2 of 7)

| Special Function | | HP-IB Code | Description |
|--|--|------------|--|
| Name | Code* | HP-IB | |
| Enter Oscilloscope Limits | 8.1 | NL | Noise Figure Lower Limit |
| | 8.2 | NU | Noise Figure Upper Limit |
| | 8.3 | GL | Gain Lower Limit |
| | 8.4 | GU | Gain Upper Limit |
| Power Measurements | 9.1 | N5 | SOURCE Off (uncal) |
| | 9.2 | N6 | SOURCE On (uncal) |
| | 9.3 | N7 | SOURCE Off (cal) |
| | 9.4 | N8 | SOURCE On (cal) |
| Noise Figure Display Units | 10.0 | N0 | F dB |
| | 10.1 | N1 | F |
| | 10.2 | N2 | Y dB |
| | 10.3 | N3 | Y |
| | 10.4 | N4 | Te K |
| Select Noise Source Temperature Units for Data Input | 11.0 | D0 | K |
| | 11.1 | D1 | °C |
| | 11.2 | D2 | °F |
| Display Resolution | 12.0 | X0 | Maximum Resolution |
| | 12.1 | X1 | Less Resolution on Noise Figure |
| | 12.2 | X2 | Less Resolution on Gain |
| Smoothing (Averaging) | 13.0 | V0 | Exponential Smoothing |
| | 13.1 | V1 | Arithmetic Smoothing |
| | 13.2 | AF | Smoothing Factor |
| Manual Measurement Functions | 14.1 | MC | Cold Measurement (SOURCE-off) |
| | 14.2 | MH | Hot Measurement (SOURCE-On) |
| | 14.3 | CC | Cold Calibration (SOURCE-Off) |
| | 14.4 | CH | Hot Calibration (SOURCE-On) |
| | 15.0 | P0 | Display Current Measurement |
| | 15.1 | P1 | Display Manual Measurement Results |
| Display Control | 16.0 | DF | Displays Measurement Frequency in Left Display |
| | 16.1 | DI | Displays Input to Noise Figure Meter (Modes 1.0 through 1.4) or Input to Noise Figure Test Set (Modes 1.5 through 1.9) in Left Display |
| | 16.2 | BF | Left Display is Blanked |
| | 16.3 | BD | All Displays are Blanked |
| | Noise Figure Test Set Internal Sideband Frequency Offset | 17.0 | B4 |
| 17.1 | | B5 | Double Sideband Operation (Modes 1.5 through 1.9) |
| 17.2 | | CF | Upper and Lower Sideband Crossover Frequency Selection |
| Noise Figure Measurement System Internal IF | 19.2 | S2 | Internal IF for SSB2 |
| | 19.3 | S3 | Internal IF for SSB3 |
| | 19.4 | S4 | Internal IF for DSB |
| | 19.5 | S5 | Display Noise Figure Meter Input Frequency |

*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code.

Table 3-9. Special Function to HP-IB Code (3 of 7)

| Special Function | | HP-IB Code | Description |
|--|--------|------------|--|
| Name | Code* | HP-IB | |
| Recorder Functions | 20.0 | LL | Go to Lower Left |
| | 21.0 | UR | Go to Upper Right |
| | 22.0 | A4 | Plot Noise Figure |
| | 23.0 | A5 | Plot Gain |
| | 24.0 | A6 | X-AXIS Output is Noise Figure and Y-AXIS Output is Gain (Strip Chart mode) |
| Plotter Functions | 25.0 | PA | Plot Grid and Data |
| | 25.1 | PG | Plot Grid and Axes Labels |
| | 25.2 | PD | Plot Data Only |
| | 25.3 | NP | Select Noise Pen Number |
| | 25.4 | GP | Select Gain Pen Number |
| | 25.5 | WT | Select Plot Name |
| Trigger Selection | 30.0 | T0 | Free Run |
| | 30.1 | T1 | Hold |
| | 30.2 | T2 | Execute |
| Frequency Calibration | 31.0 | Y0 | Automatic |
| | 31.1 | Y1 | Disable Frequency Cal |
| | 31.2 | Y2 | Perform 1 Frequency Cal |
| Input Gain Calibration | 32.0 | C0 | +20, +10 and 0 dB |
| | 32.1 | C1 | +10, 0 and -10 dB |
| | 32.2 | C2 | 0, -10 and -20 dB |
| | 32.3 | C3 | -10, -20 and -30 dB |
| IF Attenuators Calibration** | 33.1** | CI** | Calibrate IF Attenuators** |
| Loss Compensation | 34.0 | L0 | Off |
| | 34.1 | L1 | On |
| | 34.2 | LA | Enter Loss before DUT in dB |
| | 34.3 | LT | Enter Temperature of Losses |
| | 34.4 | LB | Enter Loss after DUT in dB |
| Sequence Functions | 35.0 | QM | Manual |
| | 35.1 | QA | Automatic |
| | 35.2 | QS | Set |
| | 35.3 | QC | Clear |
| Noise Figure Test Set YIG Filter Fine Tuning Calibration | 36.0 | FT | Fine Tuning Calibration with Noise Figure Measurement System Calibration; enable Warning (E28) if Fine Tuning is needed. |
| | 36.1 | FD | Disable Fine Tuning Calibration before Noise Figure Measurement System Calibration. |
| | 36.2 | FW | Disable Fine Tuning Calibration before Noise Figure Measurement System Calibration and Disable Warning (E28) if Fine Tuning is needed. |
| | 36.3 | PF | Fine Tuning Calibration from Start to Stop Frequencies and Disable Fine Tuning Calibration before Noise Figure Measurement System Calibration. |

*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code.

**If Special Function 33.1 is used, the gain accuracy specification will be degraded from 0.15 dB to a typical value of 0.25 dB. For more information, refer to "Calibration, IF Attenuators" Detailed Operating Instruction.

Table 3-9. Special Function to HP-IB Code (4 of 7)

| Special Function | | HP-IB Code | Description |
|-----------------------------|-------|------------|--|
| Name | Code* | HP-IB | |
| Interpolated Measurements | 36.4 | FF | Fine Tuning Calibration at Current Frequency |
| | 39.0 | DG | Disable Interpolated Measurements in Modes 1.5 through 1.9 |
| | 39.1 | EG | Enable Interpolated Measurements in Modes 1.5 through 1.9 |
| HP-IB and SIB Addresses | 40.0 | none | Display and Enter Noise Figure Meter Address |
| | 40.1 | EA | Display and Enter System LO Address |
| | 40.2 | HT | Display and Enter Noise Figure Test Set SIB Address |
| | 40.3 | HP | Display and Enter Plotter SIB Address |
| | 40.4 | HS | Display and Enter SIB Address |
| | 40.5 | HC | Display and Enter Pass Control SIB Address |
| | 40.6 | PT | Display and Enter the SIB Address of the Pass Through Device on the SIB |
| | 40.7 | VP | Display the Pass Through Address of the Noise Figure Meter |
| System LO Programs | 41.0 | J0 | HP 8350B Sweep Oscillator |
| | 41.2 | J2 | HP 8671B/8672A Syn. Signal Generator |
| | 41.3 | J3 | HP 8673B/C Syn. Signal Generator |
| | 41.4 | J4 | HP 8340B/8341B Sweep Oscillator |
| | 41.5 | J5 | Custom Local Oscillator |
| System LO Commands | 42.0 | AC | Auxiliary Commands |
| | 42.1 | PS | CW Prefix and Suffix |
| | 42.2 | TM | Settling Time in ms |
| | 42.3 | MN | Minimum Frequency in MHz |
| | 42.4 | MX | Maximum Frequency in MHz |
| | 42.5 | PL | System Local Oscillator Power Level |
| | 42.6 | PC | Power Prefix and Suffix for Custom Local Oscillator |
| | 42.7 | FC | Frequency Prefix and Suffix for Custom Local Oscillator |
| HP-IB Data Output Selection | 43.0 | H0 | NOISE FIGURE Only |
| | 43.1 | H1 | Frequency (left display), INSERTION GAIN, NOISE FIGURE |
| | 43.2 | H2 | Frequency, Calibration Data (GmKBm) and Second Stage Temperature are Output over HP-IB during Calibration. |
| Service Request | 44.0 | Q0 | Disable SRQ Capability (clears all enabled conditions) |
| | 44.1 | Q1 | Enable Data Ready to cause an SRQ |
| | 44.2 | Q2 | Enable Cal Complete to cause an SRQ |
| | 44.3 | Q3 | Enable HP-IB Code Error to cause an SRQ |
| | 44.4 | Q4 | Enable SRQ on the SIB to Cause an SRQ |
| | 44.5 | Q5 | Enable Noise Figure Meter Received Control on the SIB to Cause an SRQ |

*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code.

Table 3-9. Special Function to HP-IB Code (5 of 7)

| Special Function | | HP-IB Code | Description |
|---------------------------------|-------|------------|--|
| Name | Code* | HP-IB | |
| | 44.6 | Q6 | Enable Instrument Error to cause an SRQ |
| | 44.7 | RM | Enable all desired Conditions on the Status Byte to Cause an SRQ |
| | 44.8 | Q8 | Enable Extended Status Byte to Cause an SRQ |
| | 44.9 | RE | Enable all desired Conditions on the Extended Status Byte |
| Noise Figure Test Set Control | 45.0 | TE | Enable Noise Figure Test Set in Modes 1.5 through 1.9 |
| | 45.1 | TS | Enable Noise Figure Test Set in all Modes |
| | 45.2 | TD | Disable Noise Figure Test Set in all Modes |
| System Local Oscillator Control | 46.0 | LE | Enable System Local Oscillator on the SIB |
| | 46.1 | LD | Disable System Local Oscillator on the SIB |
| Plotter Control | 47.0 | PI | Plotter is on the SIB |
| | 47.1 | PM | Enable Plot Data to be read on the HP-IB |
| SIB Controller | 48.0 | SC | Enable Noise Figure Meter as System Controller on the SIB |
| | 48.1 | NC | Disable Noise Figure Meter as System Controller on the SIB |
| | 48.2 | DC | Disable Error 48 (E48) |
| Sharing Control on the SIB | 49.0 | DP | Disable Auto Pass Control |
| | 49.1 | EP | Enable Auto Pass Control |
| | 49.2 | CR | Enable Noise Figure Meter to Release Control of the SIB |
| | 49.3 | CT | Enable Noise Figure Meter to Take Control of the SIB |
| | 49.4 | SB | Enable Noise Figure Meter to perform a Serial Poll on the SIB |
| | 49.5 | DD | Perform a Selective Device Clear of the Pass Through Device on the SIB. |
| | 49.6 | DS | Perform a Device Clear on the SIB, if the Noise Figure Meter is the Active Controller. |
| | 49.7 | IS | Perform an Interface Clear on the SIB, if the Noise Figure Meter is the System Controller. |
| Special Function Catalog | 50.0 | G0 | Scan Special Function Catalog Lines |
| | 50.1 | G1 | Line 1 Status |
| | 50.2 | G2 | Line 2 Status |
| | 50.3 | G3 | Line 3 Status |
| | 50.4 | G4 | Line 4 Status |
| | 50.5 | G5 | Line 5 Status |
| | 50.6 | G6 | Line 6 Status |
| | 50.7 | G7 | Line 7 Status |
| | 50.8 | G8 | Line 8 Status |
| RF Attenuation Selection | 60.0 | R0 | Auto |
| | 60.1 | R1 | +20 dB |
| | 60.2 | R2 | +10 dB |
| | 60.3 | R3 | 0 dB |
| | 60.4 | R4 | -10 dB |

*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code.

Table 3-9. Special Function to HP-IB Code (6 of 7)

| Special Function | | HP-IB Code | Description |
|---|-------|------------|---|
| Name | Code* | HP-IB | |
| | 60.5 | R5 | -20 dB |
| | 60.6 | R6 | -30 dB |
| Display RF Attenuator Settings | 61.0 | SR | Display RF Attenuators |
| RF Attenuator Hold | 62.0 | RH | RF Attenuators are held in the configuration that exists when Special Function 62.0 is activated. |
| Individual RF Attenuator Selection | 63.0 | Z0 | Select RF Thru Path |
| | 63.1 | Z1 | Select 10 dB Pad No. 1 |
| | 63.2 | Z2 | Select 20 dB Input Amplifier |
| | 63.4 | Z4 | Select 10 dB Pad No. 2 |
| | 63.5 | Z5 | Select 10 dB Pad No. 3 |
| Noise Figure Test Set YIG Filter | 64.0 | CP | Enable Coarse Tuning Calibration |
| Coarse Tuning Calibration | 64.1 | CU | Select Upper Frequency of Noise Figure Test Set |
| IF Attenuation Selection | 70.0 | I0 | Auto |
| | 70.1 | I1 | 0 dB |
| | 70.2 | I2 | 5 dB |
| | 70.3 | I3 | 10 dB |
| | 70.4 | I4 | 15 dB |
| | 70.5 | I5 | 20 dB |
| | 70.6 | I6 | 25 dB |
| | 70.7 | I7 | 30 dB |
| | 70.8 | I8 | 35 dB |
| Display IF Attenuator Settings | 71.0 | SI | Display IF Attenuators |
| IF Attenuator Hold | 72.0 | IH | IF Attenuators are held in the configuration that exists when Special Function 72.0 is activated. |
| Voltmeter Mode | 80.0 | VC | Noise Source Off |
| | 81.0 | VH | Noise Source On |
| Recorder Test Functions | 82.0 | A7 | Enable Recorder Test |
| | 82.1 | XV | X-Axis Test |
| | 82.2 | YV | Y-Axis Test |
| Keyboard Test | 90.0 | KY | Display Key Codes |
| | 90.1 | K1 | Key Test — Row 1 |
| | 90.2 | K2 | Key Test — Row 2 |
| | 90.3 | K3 | Key Test — Row 3 |
| | 90.4 | K4 | Key Test — Row 4 |
| | 90.5 | K5 | Key Test — Row 5 |
| | 90.6 | K6 | Key Test — Row 6 |
| | 90.7 | K7 | Key Test — Row 7 |
| | 90.8 | K8 | Key Test — Row 8 |
| Display Test | 91.0 | DT | Enable Display Test |
| 0 MHz Hold | 92.0 | U0 | Off |
| | 92.1 | U1 | On |
| RAM Inspection/Modification or ROM Inspection Utilities | 93.0 | AI | Sets the Address for Modification or Inspection and Enables Auto-Increment Mode. |

*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code.

Table 3-9. Special Function to HP-IB Code (7 of 7)

| Special Function | | HP-IB Code | Description | |
|--|----------------------------------|--------------|---|--|
| Name | Code* | HP-IB | | |
| Noise Figure Meter YIG Filter Tuning Functions | 93.1 | AD | Sets the Address for Modification or Inspection and Disables Auto-Increment Mode. | |
| | 93.2 | MB | Selects Modification or Inspection of a Byte in RAM or Inspection of a Byte in ROM. | |
| | 93.3 | MW | Selects Modification or Inspection of a Word in RAM or Inspection of a Word in ROM. | |
| | 93.4 | MF | Selects Modification or Inspection of a Floating Point Value in RAM or Inspection of a Floating Point Value in ROM. | |
| | 94.1 | — | Disable Hysteresis Calibration when Frequency is Changed. | |
| | 94.2 | EH | Enable Hysteresis Calibration when Frequency is Changed. | |
| | 94.3 | — | YIG DAC is not Updated when Frequency is Changed. | |
| | 94.4 | UY | YIG DAC is Updated when Frequency is Changed. | |
| | Default ENR | 95.5 | ND | Sets all ENR Values to 15.20 dB and Noise Source ID No. to 00000 |
| | Debug Oscilloscope Plots | 97.1 | Y9 | Enables Debug Oscilloscope Plots |
| | | 97.2 | Y8 | Disables Debug Oscilloscope Plots |
| | Noise Figure Test Set Protection | 97.3 | DA | Disable Auto Sweep Abort (See Error E102) |
| | Last Error | 99.1 | ER | Recalls Last Error Issued. |
| Software Date | 99.9 | SD | Displays Current Software Date | |

*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code.

Table 3-10. Front Panel Keys to HP-IB Code Summary

| Parameter | HP-IB Code | Parameter | HP-IB Code |
|-----------------------------------|--------------|---|--------------|
| | HP-IB | | HP-IB |
| AUTO | W1 | PRESET | PR |
| CALIBRATE | CA | RECALL | RC |
| DECREASE | DE | SEQ | SQ |
| ENR | NR | SINGLE | W2 |
| ENTER | EN | SPECIAL FUNCTION | SP |
| FREQ INCR | FN | START FREQ | FA |
| ▼ | DN | STEP SIZE | SS |
| ▲ | UP | STOP FREQ | FB |
| FREQUENCY | FR | STORE | ST |
| GRAPHIC SCALE | | Sweep and Calibrate Off (must be used to turn these functions off over the HP-IB) | W0 |
| GAIN MAX | GU | | |
| GAIN MIN | GL | | |
| NOISE MAX | NU | | |
| NOISE MIN | NL | | |
| INCREASE | IN | | |
| NOISE FIGURE (UNCORRECTED) | M1 | | |
| NOISE FIGURE AND GAIN (CORRECTED) | M2 | | |

Table 3-11. Commonly Used Code Conversions

| ASCII | Binary | Octal | Decimal | Hexa- decimal |
|-------|------------|-------|---------|------------------|
| NUL | 00 000 000 | 000 | 0 | 00 |
| SOH | 00 000 001 | 001 | 1 | 01 |
| STX | 00 000 010 | 002 | 2 | 02 |
| ETX | 00 000 011 | 003 | 3 | 03 |
| EOT | 00 000 100 | 004 | 4 | 04 |
| ENQ | 00 000 101 | 005 | 5 | 05 |
| ACK | 00 000 110 | 006 | 6 | 06 |
| BEL | 00 000 111 | 007 | 7 | 07 |
| BS | 00 001 000 | 010 | 8 | 08 |
| HT | 00 001 001 | 011 | 9 | 09 |
| LF | 00 001 010 | 012 | 10 | 0A |
| VT | 00 001 011 | 013 | 11 | 0B |
| FF | 00 001 100 | 014 | 12 | 0C |
| CR | 00 001 101 | 015 | 13 | 0D |
| SO | 00 001 110 | 016 | 14 | 0E |
| SI | 00 001 111 | 017 | 15 | 0F |
| DLE | 00 010 000 | 020 | 16 | 10 |
| DC1 | 00 010 001 | 021 | 17 | 11 |
| DC2 | 00 010 010 | 022 | 18 | 12 |
| DC3 | 00 010 011 | 023 | 19 | 13 |
| DC4 | 00 010 100 | 024 | 20 | 14 |
| NAK | 00 010 101 | 025 | 21 | 15 |
| SYN | 00 010 110 | 026 | 22 | 16 |
| ETB | 00 010 111 | 027 | 23 | 17 |
| CAN | 00 011 000 | 030 | 24 | 18 |
| EM | 00 011 001 | 031 | 25 | 19 |
| SUB | 00 011 010 | 032 | 26 | 1A |
| ESC | 00 011 011 | 033 | 27 | 1B |
| FS | 00 011 100 | 034 | 28 | 1C |
| GS | 00 011 101 | 035 | 29 | 1D |
| RS | 00 011 110 | 036 | 30 | 1E |
| US | 00 011 111 | 037 | 31 | 1F |
| SP | 00 100 000 | 040 | 32 | 20 |
| ! | 00 100 001 | 041 | 33 | 21 |
| " | 00 100 010 | 042 | 34 | 22 |
| # | 00 100 011 | 043 | 35 | 23 |
| \$ | 00 100 100 | 044 | 36 | 24 |
| % | 00 100 101 | 045 | 37 | 25 |
| & | 00 100 110 | 046 | 38 | 26 |
| ' | 00 100 111 | 047 | 39 | 27 |
| (| 00 101 000 | 050 | 40 | 28 |
|) | 00 101 001 | 051 | 41 | 29 |
| * | 00 101 010 | 052 | 42 | 2A |
| + | 00 101 011 | 053 | 43 | 2B |
| , | 00 101 100 | 054 | 44 | 2C |
| - | 00 101 101 | 055 | 45 | 2D |
| . | 00 101 110 | 056 | 46 | 2E |
| / | 00 101 111 | 057 | 47 | 2F |
| 0 | 00 110 000 | 060 | 48 | 30 |
| 1 | 00 110 001 | 061 | 49 | 31 |
| 2 | 00 110 010 | 062 | 50 | 32 |
| 3 | 00 110 011 | 063 | 51 | 33 |
| 4 | 00 110 100 | 064 | 52 | 34 |
| 5 | 00 110 101 | 065 | 53 | 35 |
| 6 | 00 110 110 | 066 | 54 | 36 |
| 7 | 00 110 111 | 067 | 55 | 37 |
| 8 | 00 111 000 | 070 | 56 | 38 |
| 9 | 00 111 001 | 071 | 57 | 39 |
| : | 00 111 010 | 072 | 58 | 3A |
| ; | 00 111 011 | 073 | 59 | 3B |
| < | 00 111 100 | 074 | 60 | 3C |
| = | 00 111 101 | 075 | 61 | 3D |
| > | 00 111 110 | 076 | 62 | 3E |
| ? | 00 111 111 | 077 | 63 | 3F |

| ASCII | Binary | Octal | Decimal | Hexa- decimal |
|-------|------------|-------|---------|------------------|
| @ | 01 000 000 | 100 | 64 | 40 |
| A | 01 000 001 | 101 | 65 | 41 |
| B | 01 000 010 | 102 | 66 | 42 |
| C | 01 000 011 | 103 | 67 | 43 |
| D | 01 000 100 | 104 | 68 | 44 |
| E | 01 000 101 | 105 | 69 | 45 |
| F | 01 000 110 | 106 | 70 | 46 |
| G | 01 000 111 | 107 | 71 | 47 |
| H | 01 001 000 | 110 | 72 | 48 |
| I | 01 001 001 | 111 | 73 | 49 |
| J | 01 001 010 | 112 | 74 | 4A |
| K | 01 001 011 | 113 | 75 | 4B |
| L | 01 001 100 | 114 | 76 | 4C |
| M | 01 001 101 | 115 | 77 | 4D |
| N | 01 001 110 | 116 | 78 | 4E |
| O | 01 001 111 | 117 | 79 | 4F |
| P | 01 010 000 | 120 | 80 | 50 |
| Q | 01 010 001 | 121 | 81 | 51 |
| R | 01 010 010 | 122 | 82 | 52 |
| S | 01 010 011 | 123 | 83 | 53 |
| T | 01 010 100 | 124 | 84 | 54 |
| U | 01 010 101 | 125 | 85 | 55 |
| V | 01 010 110 | 126 | 86 | 56 |
| W | 01 010 111 | 127 | 87 | 57 |
| X | 01 011 000 | 130 | 88 | 58 |
| Y | 01 011 001 | 131 | 89 | 59 |
| Z | 01 011 010 | 132 | 90 | 5A |
| [| 01 011 011 | 133 | 91 | 5B |
| \ | 01 011 100 | 134 | 92 | 5C |
|] | 01 011 101 | 135 | 93 | 5D |
| ^ | 01 011 110 | 136 | 94 | 5E |
| _ | 01 011 111 | 137 | 95 | 5F |
| ` | 01 100 000 | 140 | 96 | 60 |
| a | 01 100 001 | 141 | 97 | 61 |
| b | 01 100 010 | 142 | 98 | 62 |
| c | 01 100 011 | 143 | 99 | 63 |
| d | 01 100 100 | 144 | 100 | 64 |
| e | 01 100 101 | 145 | 101 | 65 |
| f | 01 100 110 | 146 | 102 | 66 |
| g | 01 100 111 | 147 | 103 | 67 |
| h | 01 101 000 | 150 | 104 | 68 |
| i | 01 101 001 | 151 | 105 | 69 |
| j | 01 101 010 | 152 | 106 | 6A |
| k | 01 101 011 | 153 | 107 | 6B |
| l | 01 101 100 | 154 | 108 | 6C |
| m | 01 101 101 | 155 | 109 | 6D |
| n | 01 101 110 | 156 | 110 | 6E |
| o | 01 101 111 | 157 | 111 | 6F |
| p | 01 110 000 | 160 | 112 | 70 |
| q | 01 110 001 | 161 | 113 | 71 |
| r | 01 110 010 | 162 | 114 | 72 |
| s | 01 110 011 | 163 | 115 | 73 |
| t | 01 110 100 | 164 | 116 | 74 |
| u | 01 110 101 | 165 | 117 | 75 |
| v | 01 110 110 | 166 | 118 | 76 |
| w | 01 110 111 | 167 | 119 | 77 |
| x | 01 111 000 | 170 | 120 | 78 |
| y | 01 111 001 | 171 | 121 | 79 |
| z | 01 111 010 | 172 | 122 | 7A |
| { | 01 111 011 | 173 | 123 | 7B |
| } | 01 111 100 | 174 | 124 | 7C |
| ~ | 01 111 101 | 175 | 125 | 7D |
| - | 01 111 110 | 176 | 126 | 7E |
| DEL | 01 111 111 | 177 | 127 | 7F |

Calibrate

(Includes Special Function 39)

Description

Special Functions 39.0 and 39.1 are ONLY used with Measurement Modes 1.5 through 1.9. Special Function 39.0 does not allow interpolated measurements between calibrated points. Special Function 39.1 does allow interpolated measurements between calibrated points.

Pressing the CALIBRATE key initiates a calibration of the instrument and any equipment that is currently connected to the INPUT. First a frequency calibration is performed and then the noise figure is measured at each selected calibration point. The calibration data obtained is used to measure gain and to perform the "second stage correction" computations needed to make a CORRECTED NOISE FIGURE AND GAIN measurement. The calibration points are the START FREQ setting, the STOP FREQ setting, and the frequency steps determined by the setting of STEP SIZE. Refer to the Sweep Detailed Operating Instruction for additional information on these keys. During calibration, each specified frequency in the selected range is calibrated at three input gain settings as selected by Special Function 32. The default gain settings are +20, +10 and 0 dB. In Measurement Modes 1.0 through 1.4, the calibration data is automatically interpolated between the calibrated points when it is used for a gain measurement and second stage correction. Therefore, it is not necessary to calibrate at every frequency that is to be measured. However, Hewlett-Packard recommends that each measured point should be a calibrated point. In Measurement Modes 1.5 through 1.9, the default (Special Function 39.0) is set, which does not allow interpolation between calibrated points. However, the calibration data can be interpolated between calibrated points by using Special Function 39.1.

If Special Function 39.0 is active and interpolation is attempted in Measurement Modes 1.5 through 1.9, error code E21 (Frequency Out of Calibrated Range or not a calibrated point) is generated. Also, if a corrected measurement is attempted at a frequency less than the START FREQ setting or more than the STOP FREQ setting of the calibration run, error code E21 is displayed.

During a calibration, the calibration data can be gathered over the Hewlett-Packard Interface Bus (HP-IB). For more information, refer to the Comments section at the end of this instruction.

Specific calibration setups and procedures are contained in the Detailed Operating Instructions for Measurement Modes 1.0 through 1.9.

Procedure

To initiate a calibration sequence, press CALIBRATE. The message "Press Cal" will be displayed. Press CALIBRATE again. Pressing the CALIBRATE key twice ensures that the CALIBRATE key is not inadvertently pressed. To terminate calibration before it is complete, press CALIBRATE again. Pressing PRESET also terminates the calibration sequence.

To select Special Function 39.0 or 39.1, enter the code desired and press the SPECIAL FUNCTION key.

Calibrate (cont'd)

(Includes Special Function 39)

Procedure (cont'd)

| Front Panel Key | Program Code | Stored in Continuous Memory | Can Be Stored and Recalled | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|-----------------|------------------|-----------------------------|----------------------------|-------------------------------------|---------------------------------|
| CALIBRATE | CA | N | N | Off | Off |

Table categories are described in the Preset Conditions and Power-Up Sequence Detailed Operating Instruction.

| Special Function | | Program Code | Lights Special ¹ Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|---|------|------------------|--|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| Disables interpolated measurements in Measurement Modes 1.5 through 1.9 | 39.0 | DG or 39.0 SP | N | Y | N | On | On | On |
| Enables interpolated measurements in Measurement Modes 1.5 through 1.9 | 39.1 | EG or 39.1 SP | N | Y | N | Off | Off | Off |

¹ Table categories are described in the Preset Conditions and Power-Up Sequence Detailed Operating Instruction.
N = No, Y = Yes, NC = No Change

Example

To initiate calibration at the existing SWEEP function settings:

| | |
|-----------------------|----|
| LOCAL (keystrokes) | |
| (program codes) | CA |

Calibrate (cont'd)

(Includes Special Function 39)

Program Codes

HP-IB

CA is the program code for the CALIBRATE key. The calibration sequence can not be toggled on and off over the HP-IB. Instead, successive CA codes cause the calibration to be restarted. To terminate calibration prior to completion, use the Sweep Stop command (W0). Refer to the Procedure for other HP-IB codes.

Indications

The CALIBRATE LED lights and remains lit until the calibration is complete. During frequency calibration, the INSERTION GAIN display shows "Fr" and the NOISE FIGURE display shows "CAL".

During second stage calibration, the left display indicates each tuned frequency and the NOISE FIGURE display indicates the noise figure at that frequency. The frequency range and step size are controlled by the SWEEP keys.

When calibration is completed, the instrument resumes making the measurement that was active when CALIBRATE was pressed. However, if the instrument was sweeping (either in AUTO or SINGLE) it does not resume sweeping. Instead, it performs the previously selected measurement at the frequency it was tuned to when CALIBRATE was pressed.

Comments

The maximum number of frequency points that can be calibrated is 181 for the Noise Figure Meter (frequency range 10 MHz to 1600 MHz) or the Noise Figure Measurement System (frequency range 10 MHz to 18000 MHz). For the Noise Figure Measurement System, this is approximately 100 MHz steps for the full range.

When a calibration is done in Measurement Modes 1.5 through 1.9 and Special Function 36.0 is active, the Noise Figure Test Set is calibrated before the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and System Local Oscillator) calibration. "8971 CAL" is displayed, on the Noise Figure Meter, during the Noise Figure Test Set calibration. For more information, refer to the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction.

During calibration, all of the front panel keys except LOCAL, PRESET, and CALIBRATE are disabled.

If LOCAL is pressed during calibration, the instrument returns to local control (if it was in remote, and the Local Lockout command was not in effect). Calibration is not interrupted by the LOCAL command.

Pressing PRESET or CALIBRATE terminates the calibration function. However, PRESET also resets the entire instrument to a specified set of conditions (refer to the Preset Conditions and Power-Up Sequence Detailed Operating Instruction). If either of these keys are pressed during the frequency calibration portion of the sequence (that is, "Fr CAL" is being displayed), calibration is not terminated. These commands cannot be used until the frequency calibration is completed.

The calibration data cannot be stored using the STORE key and it is not retained when the instrument is turned off. Therefore, it is necessary to calibrate the instrument each time power is turned on.

Calibrate (cont'd)

(Includes Special Function 39)

Comments (cont'd)

If smoothing (averaging) is used during calibration, the arithmetic averaging algorithm is used. Refer to the Smoothing (Averaging) Detailed Operating Instruction for a detailed discussion of the averaging techniques used by the instrument. A smoothing factor of 4 or 8 is recommended for the most accurate calibration. Note that once calibration is initiated, the SMOOTHING keys are disabled and the averaging factor cannot be changed during the calibration sequence.

If an external controller is being used to control both the Noise Figure Meter and the system local oscillator or the Noise Figure Measurement System and the user controlled local oscillator, the calibration sequence must be stepped using the HP-IB commands T1 (Trigger hold) and T2 (Trigger execute) after the local oscillator has been moved to each new frequency. Once the HP-IB command for calibration (CA) is issued, the T2 mnemonic for trigger execute must be used. The Noise Figure Meter will ignore the alternate HP-IB code of 30.2SP. Refer to the Trigger Selection Detailed Operating Instruction for additional triggering information.

It is assumed that the triggered calibration is being performed as a part of the procedure in the Comments section of the Detailed Operating Instructions for Measurement Modes 1.0 through 1.9. All Measurement Modes require a triggered calibration sequence. Therefore, the preliminary steps such as selecting Special Function 4.0 will have already been performed. The following general conditions must be observed when using an external controller to perform a triggered calibration:

- a. Remove the device under test (DUT) from the measurement system.
- b. Set the Noise Figure Meter to trigger hold (T1) mode.
- c. Set the Noise Figure Meter's calibrate function on (HP-IB code is CA).
- d. Set the LO to the appropriate frequency. Refer to the LO's operating manual for the required HP-IB codes. Allow sufficient settling time for the output of the LO to stabilize.
- e. Trigger a measurement using the HP-IB code T2. Do not use the alternate HP-IB code 30.2SP for it will be ignored.
- f. A method must be determined when to step to a new frequency and read the noise figure results. This read operation cannot be completed until the new data is ready. It is possible to write an SRQ interrupt routine on the Data Ready status bit. Refer to Enabling the Service Request Condition, paragraph 3-30.
- g. Continue to loop through steps d, e, and f. A method for determining when the calibration is complete must be programmed into the external controller. One method is to compare the frequency that is sent to the LO with the stop frequency programmed into the Noise Figure Meter and terminate the program after the third measurement in which they are equal. It is also possible to write an SRQ interrupt routine on the Calibration Complete SRQ. Refer to Enabling the Service Request Condition, paragraph 3-30.

Calibrate (cont'd)

(Includes Special Function 39)

Comments (cont'd)

Calibration data can be collected at the time the calibrate command is executed. This feature is useful for comparing calibrations, to see how the Noise Figure Meter is performing. The controller can command the Noise Figure Meter to send both the gain reference (GkB) and second stage temperature, using the HP-IB command H2. H2 will cause the Noise Figure Meter to output the following string:

+FFFFFFE+06,SCCCCCE+XX,STTTTTE+YY (CRLF)

Where FFFFFF is the calibration frequency, STTTTT is the sign followed by the second stage temperature value and SCCCCC is the sign followed by the calibration data of GkB for the point being sent. The exponents are shown above as XX and YY. The string is followed with carriage return and line feed.

The equations for GkB and the second stage temperature are given below:

$$GkB = \frac{P_{(hot)} - P_{(cold)}}{T_{(hot)} - T_{(cold)}}$$

$$\text{Second Stage Temperature} = \frac{T_{(hot)} - [(T_{(cold)})(Y)]}{Y - 1}$$

$$Y = \frac{P_{(hot)}}{P_{(cold)}}$$

P(hot) is the power (in joules/second) for a hot (noise source on) measurement during calibration. P(cold) is the power (in joules/second) for a cold (noise source off) measurement during calibration. T(hot) is the temperature (in Kelvin) for a hot measurement from the ENR (Excess Noise Ratio) tables. T(cold) is the temperature (in Kelvin) for a cold measurement set with Special Function 6.0.

The same general conditions (steps a through g), as described earlier, also apply when performing a triggered calibration and outputting the data to the controller. The exception is that the command H2 must be used.

The following is an example of a program that will perform a triggered calibration and output the calibration data, in Measurement Modes 1.0 or 1.5:

NOTE

This program was written in BASIC language 3.0 using the HP 9000 Series 200 Model 236 computer.

Calibrate (cont'd)

(Includes Special Function 39)

Comments (cont'd)

```

10 DIM AS$(80),TS$(10)
20 PRINTER IS CRT
30 Nfm=708                                !Noise Figure Meter address.
40 Start=20                                !Start Frequency
50 Stop=100                                !Stop Frequency
60 Step=20                                  !Step Size
70 OUTPUT Nfm;"H2"                          !Output second stage temperature and GkB during calibration
80 OUTPUT Nfm;"T1"                          !Trigger Hold
90 OUTPUT Nfm;"FA";Start;"EN FB";Stop;"EN" !Start and stop frequencies
100 OUTPUT Nfm;"SS";Step;"EN"              !Step Size
110 INPUT " MAKE SURE THE NOISE FIGURE METER IS SETUP FOR A CALIBRATION AND PRESS 'ENTER'",A
120 !
130 !
140 !NOW BEGIN TAKING DATA FROM THE CALIBRATION
150 !
160 OUTPUT Nfm;"RM 2 EN"                    !Setup calibration complete SRQ
170 OUTPUT Nfm;"RS"                        !Reset Noise Figure Meter Status Byte
180 OUTPUT Nfm;"CA"                        !Start the calibration
190 Loop:                                   !Loop to do all measurements
200 !IN MEASUREMENT MODES 1.6 THROUGH 1.9,
210 !APPROPRIATE COMMANDS TO CONTROL THE USER
220 !CONTROLLED LOCAL OSCILLATOR SHOULD BE ADDED HERE
230 OUTPUT Nfm;"T2"                        !Trigger a measurement
240 ENTER Nfm;Freq,GkB,Tem                 !Get the calibration frequency, gain reference and
                                           !second stage temperature

250 PRINT "FREQ, GkB, Tem =";Freq," ";GkB," ";Tem
260 S=SPOLL (Nfm)                          !Get Noise Figure Meter Status Byte
270 IF BIT (S,1)=0 THEN GOTO Loop          !Continue until done
280 !
290 PRINT "DONE."
300 !
310 END

```

If any of the 60 or 70 series of Special Functions (except 60.0 and 70.0) are active, the calibration sequence does not override them. Therefore, to calibrate on one range only, use any of these Special Functions except 60.0 or 70.0. If any of these Special Functions are inadvertently left active the calibration sequence may not cover the expected gain range.

Any loss compensation entered by Special Function 34 is ignored during the calibration sequence.

Related Sections

Calibration, Frequency
 Calibration, Input Gain Selection
 Measurement Modes 1.0 through 1.9
 Noise Figure (Uncorrected) and Noise Figure and Gain (Corrected)
 Sweep
 Trigger Selection

Calibration, Frequency (Special Function 31)

Description

Frequency Calibration is performed to ensure the accuracy of the displayed tuned frequency. During frequency calibration, the instrument's first local oscillator (the YIG oscillator) is tuned to the first IF (2050 MHz). Since the first mixer is not perfectly balanced, some of the first local oscillator power is fed through to the first IF. This signal is mixed down to the third IF. It is then detected by a special narrow-band detector (approximately 100 kHz wide).

The YIG oscillator is then stepped through the narrow-band detectors's pass band using a special fine tune digital-to-analog converter (DAC). When the peak output is detected, the YIG oscillator is tuned to 2050 MHz (first IF). This IF corresponds to 0 MHz on the front-panel frequency display. The fine tune DAC is held at this value. This correction value is then used when the YIG oscillator is tuned in response to subsequent tuning changes.

Frequency calibration is initiated by the following:

- a. The LINE switch is pressed to apply power to the instrument.
- b. The PRESET key is pressed or the CALIBRATE key is pressed if Special Function 31.0 is active.
- c. Special Function 31 is used to initiate and control frequency calibration.

Completion of Frequency Calibration does not set the CALIBRATION COMPLETE bit of the HP-IB status byte. That bit is used only for RF calibration.

Special Function 31 is defined as follows:

- a. 31.0—Selects the automatic frequency calibration mode. In addition to the initial frequency calibration described previously, a frequency calibration is automatically initiated 15 minutes after power on, 30 minutes later, 1 hour later, 2 hours later, and then every 2 hours until the instrument is turned off or a different 31 Special Function is entered. This mode is the default condition.
- b. 31.1—Disables the frequency calibration. In this mode, frequency calibration is still done if the PRESET key is pressed. However, frequency calibration is not initiated periodically as described in 31.0.
- c. 31.2—Initiates a frequency calibration immediately. After that frequency calibration, the operation returns to the mode active when 31.2 was entered. If 31.1 was active, it remains active after the frequency calibration is done.

Procedure

Frequency calibration is performed as a part of PRESET. Frequency calibration can also be done when the CALIBRATE key is pressed and Special Function 31.0 is active. In addition, the frequency calibration can be performed or disabled by keying in the corresponding Special Function code and then pressing the SPECIAL FUNCTION key.

Calibration Frequency (cont'd) (Special Function 31)


**Procedure
(cont'd)**

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored In Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|-----------------------------------|------|------------------------------|--|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| Automatic Frequency Calibration | 31.0 | Y0 or 31.0SP | N | N | N | On | On | On |
| Disable Frequency Calibration | 31.1 | Y1 or 31.1SP | N | N | N | Off | Off | Off |
| Perform One Frequency Calibration | 31.2 | Y2 or 31.2SP | N | N | N | Off | Off | Off |

¹Table categories are explained in the Special Functions Detailed Operating Instruction.

Example

To select the Disable Frequency Calibration Mode:



Program Codes



For HP-IB codes, refer to Procedure above.

Indications

The INSERTION GAIN and NOISE FIGURE displays are not affected by 31.0 and 31.1. If 31.2 is entered, the INSERTION GAIN display shows “Fr” and NOISE FIGURE display shows “CAL” until the frequency calibration is completed.

Related Sections

- Calibrate
- Preset Conditions and Power-Up Sequence
- Special Functions

Calibration, IF Attenuators

(Special Function 33.1)

READ THE FOLLOWING NOTE BEFORE CALIBRATING THE IF ATTENUATORS USING SPECIAL FUNCTION 33.1

NOTE

Using Special Function 33.1, to calibrate the IF attenuators, will reduce the gain instrumentation uncertainty specification to a typical value of ± 0.25 dB.

If error code E26 (IF calibration needed) is valid, the following methods can be used to calibrate the IF attenuators, while maintaining a gain instrumentation uncertainty specification of ± 0.15 dB:

- If the Noise Figure Meter is due for its annual calibration, refer to Section IV, Performance Tests. Before starting the tests, use Special Function 33.1, with an HP 346 B/C Noise Source, to clear error E26. OR, send the Noise Figure Meter to the nearest Hewlett-Packard service center for calibration.*
- If the Noise Figure Meter is not due for its annual calibration, enter the IF attenuator calibration data that should have been recorded in Section IV (Table 4-1), at the time of installation (see Section II). Enter the data using the "Entering IF Attenuator Values" section of the Gain Measurement Uncertainty Performance Test in Section IV. This method maintains the gain instrumentation uncertainty specification of ± 0.15 dB.*
- If the Noise Figure Meter is not due for its annual calibration, call the local Hewlett-Packard service center for the IF attenuator calibration data. The data can then be entered into the Noise Figure Meter. The data is entered using the procedure in Section IV, the "Entering IF Attenuator Values" section of the Gain Measurement Uncertainty Performance Test. This method maintains the gain instrumentation uncertainty specification of ± 0.15 dB.*
- Perform the "IF Attenuator Calibration" section of the Gain Measurement Uncertainty Performance Test in Section IV. This method maintains the gain instrumentation uncertainty specification of ± 0.15 dB.*
- Use Special Function 33.1 to perform the IF attenuator calibration. If Special Function 33.1 is used, the gain instrumentation uncertainty specification will be degraded from ± 0.15 dB to a typical value of ± 0.25 dB. Because of this degradation, Hewlett-Packard recommends that one of the other methods be used to calibrate the IF attenuators.*

Calibration, IF Attenuators (cont'd) (Special Function 33.1)


Description Special Function 33.1 is used to calibrate the IF Attenuators. The HP 346 B/C noise source **MUST** be connected to the Noise Figure Meter. The Noise Figure Meter turns on the noise source and uses its own internal noise power detector to measure each IF attenuator. This data is used to correct the gain readings during gain measurement. After the IF attenuation calibration is completed, this data is stored in the instrument's continuous memory and is retained when power is removed. Completion of IF calibration does not set the CALIBRATION COMPLETE bit of the HP-IB status byte.

Procedure To calibrate the IF Attenuators, connect the HP 346 B/C noise source to the instrument's INPUT connector, enter 33.1, and then press SPECIAL FUNCTION.

| Special Function | | Program Code HP-IB | Description | Lights Special ¹ Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|----------------------------|------|-----------------------|--------------------------|--|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Name | Code | | | | | | | | |
| IF Attenuators Calibration | 33.1 | CI or 33.1SP | Calibrate IF Attenuators | N | Y | N | Off | Off | Off |

¹Table categories are explained in the Special Functions Detailed Operating Instruction.

Example



Program Codes The HP-IB code for IF Attenuator Calibration is CI (or 33.1SP).



Indications During calibration, the NOISE FIGURE display shows "IF CAL". IF Attenuator Calibration takes only a few seconds. If for any reason the IF Attenuator Calibration is not successfully completed, error E13 (IF Attenuator Calibration failed) is displayed.

Comments Error code E26 is displayed if the IF Attenuator calibration data is not stored in the continuous memory. Error E26 always occurs after an error E80 (continuous memory failure). Therefore, an IF Attenuator calibration must always be performed after an error E80 has been cleared. Either an HP 346B or HP 346C Noise Source is needed for calibrating the IF attenuators. The HP 346A will work only with the addition of approximately 10 dB of gain (at the calibration frequency, of 30 MHz) between the Noise Source and the Noise Figure Meter INPUT connector.

Related Sections Error Messages and Recovery
Special Functions

Calibration, Input Gain Selection (Special Function 32)

Description

The gain setting for calibration can be selected using Special Function 32. Calibration is performed from the start frequency to the stop frequency in steps of the specified step size. At each frequency, calibration is done at the three most sensitive RF attenuator gain settings (that is, +20,+10, and 0 dB). These settings are the default value for Special Function 32. Three other sets of gain settings can be selected using the special functions shown below. Selection of the gain settings to be calibrated depends upon the specific application. Selecting a calibration gain setting does not initiate a calibration sequence.

Procedure


To select an alternate gain setting for calibration, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|----------------------|------|------------------------------|--|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| +20, +10, and 0 dB | 32.0 | C0 or 32.0SP | N | N | N | On | On | On |
| +10, 0, and -10 dB | 32.1 | C1 or 32.1SP | Y | N | N | Off | Off | Off |
| 0, -10, and -20 dB | 32.2 | C2 or 32.2SP | Y | N | N | Off | Off | Off |
| -10, -20, and -30 dB | 32.3 | C3 or 32.3SP | Y | N | N | Off | Off | Off |

¹ Table categories are explained in the Special Function Detailed Operation Instruction.

Example

To select +10, 0 and -10 dB as the gain settings for calibration:



Program Codes



For HP-IB codes, refer to Procedure above.

Calibration, Input Gain Selection (cont'd)

(Special Function 32)

Comments

The gain settings, other than the default values, are used primarily when the Noise Figure Meter is calibrated with high gain external to the Noise Figure Meter.

If external gain is not being used during calibration and Special Function 32.1 is active, error code E27 (too much loss while calibrating) may be generated. If external gain is not being used during calibration and Special Function 32.2 or 32.3 is active, error code E27 will be generated.

DUTs in the specified range of -20 to $+40$ dB can be measured using Special Function 32.0.

Related Sections

Calibrate
Special Functions

Controller Capability of the Noise Figure Meter (Special Function 4)


Description The Noise Figure Meter can be used as a limited controller for an external device connected to the HP-IB connector. This capability is limited to operating in the Talk Only Mode (outputting data to a recording device such as a printer). The Noise Figure Meter can also be controlled by an external controller when Special Function 4.0 is active. Only one of the two capabilities can be active at any one time.

Procedure To select an HP-IB control capability, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Con- tinuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|------------------------------------|------|-----------------------|---|----------------------------------|-------------------------------|------------------------------------|--|------------------------------------|
| Description | Code | | | | | | | |
| Normal Talker and Listener Mode | 4.0 | None | N | Y | N | NC | NC | On |
| Refer to Special Function 46.0 | 4.1 | | --- | --- | --- | --- | --- | --- |
| Talk Only Mode | 4.2 | None | N | Y | N | NC | NC | Off |

¹ Table categories are explained in the Special Function Detailed Operation Instruction.

Example To select the Talk Only Mode.



Indications When Special Function 4.2 is active, the HP-IB TALK annunciator lights.

Comments In the Talk Only Mode, the instrument continuously outputs data to a recording device that is in the Listen Only Mode. The data output format and content is controlled by Special Function 43. Refer to the HP-IB portion of this section for additional information on this Special Function.

Since the Noise Figure Meter has a second bus (System Interface Bus) to control the system LO, the Noise Figure Test Set and plotter, Special Function 4.1 is no longer used. Refer to Special Functions 45, 46 and 47.

Controller Capability of the Noise Figure Meter (cont'd) (Special Function 4)

| | |
|------------------------------|---|
| Comments (cont'd) | <p>An external controller cannot be used when Special Function 4.2 is active.</p> <p>The active function of Special Function 4 is not affected by PRESET, Special Function 0.0, or the LINE switch.</p> |
| Related Sections | <p>Special Functions. System Interface Bus Control</p> |

Data Output to Oscilloscopes, Recorders and Plotters

(Special Functions 7, 8, and 20 through 25)

Description

The Noise Figure Meter can output analog data to an oscilloscope, an X-Y recorder, or a strip chart recorder. The Noise Figure Meter can only be used with an analog oscilloscope. Also, digital data can be output to a plotter on the Hewlett-Packard Interface Bus or the System Interface Bus. However, only one of these devices can be used at a time. Since the setup procedures and operation are similar for all four devices, the operating information for all are covered in this operating instruction.

Normally it is simpler to perform a setup procedure using the oscilloscope and then do a plot or switch to a recorder mode (or use an oscilloscope camera) if a permanent record is required. In the example following the general procedure, this type of setup will be shown.

Procedure

To select one of the oscilloscope, recorder, or plotter output functions, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|---|------|-----------------------|--|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| Output to Oscilloscope | | | | | | | | |
| Noise Figure and Gain | 7.0 | A0 or 7.0SP | N | Y | N | On | On | On |
| Test Pattern | 7.1 | A1 or 7.1SP | N | Y | N | Off | Off | Off |
| Noise Figure Only | 7.2 | A2 or 7.2SP | N | Y | N | Off | Off | Off |
| Gain Only | 7.3 | A3 or 7.3SP | N | Y | N | Off | Off | Off |
| Cursor enabled for oscilloscope display | 7.4 | A8 or 7.4SP | N | Y | N | On | On | On |
| Cursor disabled for oscilloscope display | 7.5 | A9 or 7.5SP | N | Y | N | Off | Off | Off |
| Enter Oscilloscope Limits | | | | | | | | |
| Noise Figure Lower Limit | 8.1 | NL or 8.1SP | N | Y | Y | NC | 0 | 0 |
| Noise Figure Upper Limit | 8.2 | NU or 8.2SP | N | Y | Y | NC | 8 | 8 |
| Gain Lower Limit | 8.3 | GL or 8.3SP | N | Y | Y | NC | 0 | 0 |
| Gain Upper Limit | 8.4 | GU or 8.4SP | N | Y | Y | NC | 40 | 40 |
| Recorder Functions | | | | | | | | |
| Go to Lower Left | 20.0 | LL or 20.0SP | N | N | N | Off | Off | Off |
| Go to Upper Right | 21.0 | UR or 21.0SP | N | N | N | Off | Off | Off |
| Plot Noise Figure | 22.0 | A4 or 22.0SP | N | Y | N | Off | Off | Off |
| Plot Gain | 23.0 | A5 or 23.0SP | N | Y | N | Off | Off | Off |
| Strip Chart Mode (X = Noise Figure; Y = Gain) | 24.0 | A6 or 24.0SP | N | Y | N | Off | Off | Off |
| ¹ Table categories are explained in the Special Function Detailed Operating Instruction. | | | | | | | | |

Data Output to Oscilloscopes, Recorders and Plotters (cont'd)

(Special Functions 7, 8, and 20 through 25)

**Procedure
(cont'd)**

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|---|------|------------------------------|--|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| Plotter Functions | | | | | | | | |
| Plot the grid with units, title and curves. | 25.0 | PA or 25.0SP | N | N | N | Off | Off | Off |
| Plot only the grid and annotation. | 25.1 | PG or 25.1SP | N | N | N | Off | Off | Off |
| Plot only the data curves. | 25.2 | PD or 25.2SP | N | N | N | Off | Off | Off |
| Select the Noise curve pen. | 25.3 | NP or 25.3SP | N | N | N | Off | 1 | 1 |
| Select the Gain curve pen. | 25.4 | GP or 25.4SP | N | N | N | Off | 2 | 2 |
| Write the plot title for next plot. | 25.5 | WT or 25.5SP | N | N | N | Off | HP 8970B Noise Figure Meter | HP 8970B Noise Figure Meter |
| Enable plotter commands on the System Interface Bus | 47.0 | PI or 47.0SP | N | Y | N | NC | NC | On |
| Enable plot data on the Hewlett-Packard Interface Bus | 47.1 | PM or 47.1SP | N | Y | N | NC | NC | Off |
| ¹ Table categories are explained in the Special Function Detailed Operation Instruction. | | | | | | | | |

Example

The following example shows how to set up the Noise Figure Meter to output a swept CORRECTED NOISE FIGURE AND GAIN measurement result to an oscilloscope and then to plot noise figure and gain results independently. It is assumed that the Noise Figure Meter is already making this type of measurement in one of the Measurement Modes. It is also assumed that the oscilloscope has A vs B (or X/Y) capability.

Data Output to an Oscilloscope

NOTE

The oscilloscope must be an analog oscilloscope. Digital oscilloscopes will not work with the Noise Figure Meter.

- a. Connect the Y-AXIS, X-AXIS, and Z-AXIS outputs on the rear panel of the Noise Figure Meter to the A, B, and Z (or horizontal, vertical, and Z) inputs of the oscilloscope as appropriate. Select the DC mode for all oscilloscope inputs.

Data Output to Oscilloscopes, Recorders and Plotters (cont'd)

(Special Functions 7, 8, and 20 through 25)


Example (cont'd)

- b. To display the test pattern on the oscilloscope screen press 7.1 SPECIAL FUNCTION (or send HP-IB code A1).

NOTE

In the following step, first adjust the position controls on the oscilloscope to place the test pattern on the left side and the bottom. Then, adjust the gain controls to position the right side and top.

- c. Adjust the oscilloscope controls until the test pattern just fills the screen (touching the outer lines on all four sides). See figure below. Verify that the vertical and horizontal lines cross near the center of the screen.



Test Pattern on Oscilloscope

NOTE

In the following steps it is assumed that the DUT has a noise figure range of 0.5 to 4 dB and a gain range of 0 to 25 dB over the specified frequency range.

- d. To display the noise figure and gain traces on the oscilloscope screen, press 7.0 SPECIAL FUNCTION (or send HP-IB code A0).
- e. To display the noise figure lower limit in the left display, press the front panel key GRAPHIC SCALE NOISE MIN or press 8.1 SPECIAL FUNCTION (or send HP-IB code NL). If the left display shows the default value of 0.000 dB, continue with the next step. If the display shows a different value, press 0 and ENTER (or send HP-IB code 0EN).
- f. To display the noise figure upper limit in the left display, press the front panel key GRAPHIC SCALE NOISE MAX or press 8.2 SPECIAL FUNCTION (or send HP-IB code NU). The default value is 8.000 dB. To change the upper limit to 4 dB, press 4 and ENTER (or send HP-IB code 4EN).

Data Output to Oscilloscopes, Recorders and Plotters (cont'd)


(Special Functions 7, 8, and 20 through 25)

Example (cont'd)

g. In a similar manner, use front panel key GRAPHIC SCALE GAIN MIN (8.3 SPECIAL FUNCTION or HP-IB code GL) and front panel key GRAPHIC SCALE GAIN MAX (8.4 SPECIAL FUNCTION or HP-IB code GU) to display and change the lower and upper limits of the gain trace. The default values of 0.000 and 40.00 are satisfactory for this example.

h. To display the corrected swept measurement, press CORRECTED NOISE FIGURE AND GAIN (or send HP-IB code M2).

i. For a repetitive swept measurement beginning at the start frequency, press START FREQ and then AUTO (or send HP-IB codes FAW1). Verify the display is similar to that shown below. There should be a noise figure trace and a gain trace.



Swept Measurement on Oscilloscope

NOTE

If desired, the intensity of the gain trace can be adjusted relative to the noise figure trace. This can be done by turning the GAIN TRACE adjustment on the rear panel of the Noise Figure Meter (see Figure 3-8).

j. To stop the sweep press AUTO again (or send HP-IB code W0). Note that a different HP-IB code is required to turn off the sweep since this function cannot be toggled over the HP-IB.

NOTE

Step j completes the procedure for setting up the Noise Figure Meter for an oscilloscope display. If a permanent record of the measurement results is required, use an oscilloscope camera or perform the remaining steps, which provide a typical procedure for plotting the data on an X-Y recorder and plotter.

Data Output to Oscilloscopes, Recorders and Plotters (cont'd)

(Special Functions 7, 8, and 20 through 25)

Example
(cont'd)

Outputting Data to a Plotter on the System Interface Bus

NOTE

The following Hewlett-Packard plotters can be used with the Noise Figure Meter: HP 9872B, 7440A, 7470A, 7475A, 7550A. In general, most Hewlett-Packard plotters that use HP-IB and support the common command core of HP-GL will work with the Noise Figure Meter.

The maximum number of points that can be plotted is 251. If an attempt is made to plot more than 251 points, error code E39 will appear when Special Function 25.X is entered to start the plot. The maximum number of points is determined by the sweep START FREQ, STOP FREQ and STEP SIZE. Generally the number of points can be arrived at using the following equation:

$$\text{Number of plot points} = \frac{(\text{STOP FREQ} - \text{START FREQ})}{\text{STEP SIZE}} + 1$$

$$\text{If the fractional part of } \frac{(\text{STOP FREQ} - \text{START FREQ})}{\text{STEP SIZE}} + 1$$

does not equal 0, then add 1.

k. Connect the plotter to the SYSTEM INTERFACE BUS connector on the Noise Figure Meter.

l. Special Function 47.0 (plotter is on the System Interface Bus) active.

m. The address of the plotter must match the address of the plotter stored in the Noise Figure Meter. Use Special Function 40.3 (plotter system interface bus address) to display and change, if necessary, the address of the plotter stored in the Noise Figure Meter. The default address for the plotter is 5.

NOTE

When the plot starts, Error 45 (E45) will be given if the Noise Figure Meter can not find the plotter at the address set by Special Function 40.3, the plotter is not turned on or the plotter is not connected to the SYSTEM INTERFACE BUS connector with an HP-IB cable.

n. The default title of the plot will be HP 8970B Noise Figure Meter. The user can supply a title using Special Function 25.5. The title is placed at the top of the plot grid and can be sixty-five (65) characters long. The title is entered with ASCII characters (in decimal) using the front panel numeric key pad. When using HP-IB, the title is sent the way it will appear on the plot. For example, a title would be sent over HP-IB using the following format:

OUTPUT 708; "WT This would be a title of up to 65 characters."

o. The pens used to make the plot can be selected using Special Functions 25.3 (noise) and 25.4 (gain curve). The default pens are 1 (noise) and 2 (gain).

Data Output to Oscilloscopes, Recorders and Plotters (cont'd)

(Special Functions 7, 8, and 20 through 25)

Example (cont'd)

- p. Perform a SINGLE or AUTO sweep to gather data for the plot.

NOTE

The plot will be aborted if an HP-IB command is sent to the Noise Figure Meter or a front panel key is pressed during the plot.

- q. Start the plot by using Special Function 25.0, 25.1 or 25.2.

NOTE

If Special Function 7.1 (test pattern) was selected earlier and Special Function 25.0, 25.1 or 25.2 has been selected, the plotter will not produce a plot.

If the Noise Figure Meter measurement is UNCORRECTED, the gain curve will not be plotted.

- r. The plotted traces will be the same as the traces that were displayed on the oscilloscope.

Outputting Data to a Plotter on the Hewlett-Packard Interface Bus

NOTE

The controller should be able to accept a very large string on the order of 1000 to 6000 bytes or more depending on the number of points that are to be plotted.

In general, the controller should be able to accept the number of points as described in the following equation:

Number of points = 1000 + [12(The total number of noise figure and gain points)]

- s. Connect the controller and the plotter to the HP-IB connector on the Noise Figure Meter.

- t. Special Function 47.1 (plot data is on HP-IB) must be active.

- u. The address of the plotter must match the address that the controller will use later to send data to the plotter.

NOTE

If the controller sends a command to the Noise Figure Meter when it is expecting to have a plot read, the plot is aborted. Hitting a front panel key also aborts the plot.

When Special Function 47.1 is selected and a plot is started, the Noise Figure Meter's front panel will display "Plot." If data is not read from the Noise Figure Meter, the front panel will continue to display "Plot" until data is read, the Noise Figure Meter receives an HP-IB command or a front panel key is pressed.

Data Output to Oscilloscopes, Recorders and Plotters (cont'd)

(Special Functions 7, 8, and 20 through 25)

Example (cont'd)

v. The following program example shows how to get data from the Noise Figure Meter to the controller and from the controller to the plotter:

NOTE

The program assumes that the address of the Noise Figure Meter is set to eight and the plotter address is set to five. Also, it is assumed that a measurement has been made and now it is desired to plot the data.

This program was written in BASIC language 3.0 using the HP 9000 Series 200 Model 236 computer.

```

10 DIM A$(30000)           !Setup a large string for the plot data.
20 OUTPUT 708;"PM"         !Read plot data on HP-IB.
30 OUTPUT 708;"PA"         !Start the plot.
40 ENTER 708;A$            !Get the plot data.
50 OUTPUT 705;A$           !Send data to plotter at address 5.
60 END

```

w. The plotted traces should be the same as the traces that were displayed on the oscilloscope.

Plotting Data on an X-Y Recorder

x. Connect the X-AXIS, Y-AXIS, and Z-AXIS outputs from the Noise Figure Meter to the X, Y, and pen lifts inputs of the X-Y recorder. Select DC mode on all recorder inputs.

y. To adjust the lower left point on the recorder, press 2 0 . 0 SPECIAL FUNCTION (or send HP-IB code LL) and adjust the X and Y zero-set controls on the recorder.

z. To adjust the upper right point on the recorder, press 2 1 . 0 SPECIAL FUNCTION (or send HP-IB code UR) and adjust the X and Y vernier controls on the recorder.

NOTE

The X-AXIS and Y-AXIS output voltages from the Noise Figure Meter vary from 0 to 6V. Therefore, it may be necessary to adjust the recorder to accommodate this range of voltages.

aa. Check both the upper and lower limits on the recorder and readjust as required.

ab. To plot a single sweep of the noise figure results, press 2 2 . 0 SPECIAL FUNCTION and then SINGLE (or send HP-IB codes A4W2). When the single sweep is complete, the Noise Figure Meter remains tuned to the stop frequency.

ac. To plot a single sweep of the gain results, press 2 3 . 0 SPECIAL FUNCTION and then SINGLE (or send HP-IB codes A5W2). When the single sweep is complete, the Noise Figure Meter remains tuned to the stop frequency.

ad. The plotted traces should be similar to the traces that were displayed on the oscilloscope.

Data Output to Oscilloscopes, Recorders and Plotters (cont'd)

(Special Functions 7, 8, and 20 through 25)

Program Codes

For HP-IB codes, refer to Procedure.

HP-IB**Comments**

For the oscilloscope, recorder and plotter modes, whatever is displayed in the NOISE FIGURE display is treated as a noise figure trace. For example, if Special Function 9 is active, the power measurement information displayed is output to the oscilloscope, recorder or plotter as if it were noise figure information. Noise figure is displayed in the units selected by Special Function 10 and gain is displayed in dB.

Special Function 8 or the front panel Graphic Scale Keys are used to set both noise figure and gain limits.

Special Function 24 selects the strip chart mode. This mode is useful in plotting noise figure and gain versus time. For example, it can be used to plot noise figure versus emitter current on an X-Y recorder or to drive an external meter. The X-AXIS output is the noise figure information and the Y-AXIS output is the gain information.

Related Sections

Display Units Selection
Measurement Modes 1.0 through 1.9
Special Functions

Display Control

(Special Function 16)

Description

Special Function 16 allows the user to select the kind of information that will be shown by the left front panel display or to disable the front panel displays.

Special Function 16.0 enables the left display to display the measurement frequency. In this mode the front panel displays function normally.

Special Function 16.1 enables the left display to display the IF into the Noise Figure Meter (Measurement Modes 1.1 through 1.4) or the IF into the Noise Figure Test Set (Measurement Modes 1.5 through 1.9). Special Function 16.1 is particularly useful in Measurement Modes 1.2 and 1.7. In these modes the left display normally displays the measurement frequency before it has been down converted. With Special Function 16.1 the IF into the Noise Figure Meter or Noise Figure Test Set is displayed.

Special Function 16.2 blanks the left (frequency) display. In this mode, parameters being displayed or changed are shown in the left display until the ENTER or FREQUENCY key is pressed. When the START FREQ or STOP FREQ key is pressed, the start and stop frequencies are displayed. Once the start and stop frequencies have been entered, press the FREQUENCY key to blank the left display again. The left display is blank during a SINGLE or AUTO sweep.

Special Function 16.3 blanks all the front panel displays. The displays are not updated. The message DISP Off is displayed in the right displays. The Noise Figure Meter runs slightly faster in this mode.

Procedure

To select one of the Display Control special functions, key in the special function desired and then press the SPECIAL FUNCTION key.

| Special Function | | Program Code HP-IB | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|--|------|-----------------------|-----------------------------|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| Measurement frequency is displayed | 16.0 | DF or 16.0SP | N | Y | Y | On | On | On |
| Input IF is displayed | 16.1 | DI or 16.1SP | N | Y | Y | Off | Off | Off |
| Measurement frequency is not displayed | 16.2 | BF or 16.2SP | N | Y | Y | Off | Off | Off |
| Front panel displays are disabled | 16.3 | BD or 16.3SP | N | Y | Y | Off | Off | Off |

¹Table categories are explained in the Special Function Detailed Operating Instruction.

Display Control (cont'd) (Special Function 16)

Example To blank the left (frequency) display:

| | |
|---|---|
| LOCAL (keystrokes) | <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Code</p> <div style="display: flex; justify-content: center; gap: 5px;"> <div style="border: 1px solid black; padding: 2px 5px;">1</div> <div style="border: 1px solid black; padding: 2px 5px;">6</div> <div style="border: 1px solid black; padding: 2px 5px;">.</div> <div style="border: 1px solid black; padding: 2px 5px;">2</div> </div> </div> <div style="text-align: center;"> <p>Function</p> <div style="border: 1px solid black; padding: 2px 5px; display: flex; align-items: center; justify-content: center;"> • <p style="margin: 0;">SPECIAL FUNCTION</p> </div> </div> </div> |
| <div style="text-align: center; margin-bottom: 5px;"> HP-IB </div> (program codes) | BF |

Program Codes For HP-IB codes, refer to the Procedure above.

HP-IB

Related Sections Measurement Modes 1.1 through 1.9

Display Resolution (Includes Special Function 12)

Description

The Noise Figure Meter can vary the resolution of the INSERTION GAIN and NOISE FIGURE displays.

The table below shows the maximum resolution (to the right of the decimal point) allowed by Special Function 12.

| Display | 12.DSP Maximum Resolution | 12.1SP Less Resolution on NOISE FIGURE | 12.2SP Less Resolution on GAIN |
|----------------|---------------------------|--|--------------------------------|
| NOISE FIGURE | | | |
| F dB | dd.dd | dd.d | |
| F | d.ddd | d.dd | |
| Y dB | dd.dd | dd.d | |
| Y | d.ddd | d.dd | |
| Te K | ddd.d | ddd | |
| INSERTION GAIN | | | |
| dB | dd.dd | | dd.d |

Procedure

To select the desired display resolution, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|--|------|------------------------------|--|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| Maximum resolution for both INSERTION GAIN and NOISE FIGURE displays | 12.0 | X0 or 12.0SP | N | Y | N | On | On | On |
| Less resolution on NOISE FIGURE display | 12.1 | X1 or 12.1 SP | N | Y | N | Off | Off | Off |
| Less resolution on INSERTION GAIN display | 12.2 | X2 or 12.2SP | N | Y | N | Off | Off | Off |

¹Table categories are explained in the Special Function Detailed Operation Instruction.

Display Resolution (cont'd)

(Includes Special Function 12)

Example To have less resolution in the NOISE FIGURE display:

| | |
|---|--|
| LOCAL (keystrokes) | <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Code</p> <div style="display: flex; justify-content: center; gap: 5px;"> <div style="border: 1px solid black; padding: 2px 5px;">1</div> <div style="border: 1px solid black; padding: 2px 5px;">2</div> <div style="border: 1px solid black; padding: 2px 5px;">.</div> <div style="border: 1px solid black; padding: 2px 5px;">1</div> </div> </div> <div style="text-align: center;"> <p>Function</p> <div style="border: 1px solid black; padding: 2px 5px; display: flex; align-items: center; gap: 5px;"> • <p style="font-size: 0.8em; margin: 0;">SPECIAL FUNCTION</p> </div> </div> </div> |
| <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;">HP-IB</div> <p>(program codes)</p> | X1 |

Program Codes For HP-IB program codes, refer to Procedure above.

HP-IB

Indications The NOISE FIGURE and INSERTION GAIN displays reflect the resolution corresponding to the selected Special Function.

Comments Special Function 12 also affects the resolution of the HP-IB output. The HP-IB output always has one digit more of resolution than the front panel displays.

Related Sections Display Units Selection
Special Functions

Display Units Selection (Special Function 10)

Description

Noise measurements can be output in the following display units:

- a. noise figure in dB (F dB)
- b. noise figure as a ratio (F)
- c. Y factor in dB (Y dB)
- d. Y factor as a ratio (Y)
- e. equivalent input noise temperature in kelvins (Te K)

Procedure


To select a NOISE FIGURE display unit, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.

| Special Function | | Program Code HP-IB | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|------------------|------|-----------------------|-----------------------------|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| F dB | 10.0 | N0 or 10.0SP | N | Y | Y | On | On | On |
| F | 10.1 | N1 or 10.1SP | N | Y | Y | Off | Off | Off |
| Y dB | 10.2 | N2 or 10.2SP | N | Y | Y | Off | Off | Off |
| Y | 10.3 | N3 or 10.3SP | N | Y | Y | Off | Off | Off |
| Te K | 10.4 | N4 or 10.4SP | N | Y | Y | Off | Off | Off |

¹Table categories are explained in the Special Function Detailed Operation Instruction.

Example

To have measured noise displayed as Y factor in dB:



Program Codes



For HP-IB program codes, refer to Procedure above.

Indications

The selected display unit appears on the right side of the NOISE FIGURE display. Special Function 10 has no effect on the INSERTION GAIN display.

Comments

32 dB is the maximum value that can be displayed in units of F dB. Readings above this value cause the NOISE FIGURE display to show two dashes “ — — ”. The smoothed number is the value that is checked against 32 dB. Therefore, if the display is flashing between approximately 30 dB and “ — — ”, increasing the smoothing may provide a stable display if the noise figure is less than 32 dB.

The maximum value allowable for Te K is 9999K (noise figure of 15.5 dB).

Display Units Selection (cont'd)

(Special Function 10)

Comments (cont'd)

The maximum value allowable for F is 9999 (noise figure of approximately 40 dB).

Equations for the display units are as follows:

$$F = \frac{\text{noise power added by DUT} + \text{noise power out due to source}}{\text{noise power out due to source}}$$

(when the source is a 290K)

$$F(\text{dB}) = 10 \log F$$

$$Y = \frac{\text{power measured with noise source On}}{\text{power measured with noise source Off}}$$

$$Y(\text{dB}) = 10 \log Y$$

$$T_e = \frac{T_{\text{hot}} - Y \times T_{\text{cold}}}{Y - 1}$$

where: T_{hot} is the equivalent temperature of the noise source when it is On
and

T_{cold} is the equivalent temperature of the noise source when it is Off.

Related Sections

Display Resolution
Noise Figure (Uncorrected) and Noise Figure and Gain (Corrected)
Smoothing
Special Functions

ENR Table Entry

Description

The ENR key is used to store, recall or display an ENR (Excess Noise Ratio) table. The Noise Figure Meter can store the ENR tables for five noise sources. Each table can have up to thirty-five frequency/ENR pairs. This information is used to improve the accuracy of the noise figure and gain calculations made by the Noise Figure Meter. The information entered is the actual Excess Noise Ratio (ENR) value at the specified frequency. All noise sources have this calibration information available. In the case of the HP 346A, B and C Noise Sources, a separate printout is supplied, and a graph or table is printed on the side of the Noise Source showing the ENR versus Frequency data. The frequency/ENR pairs shown on the printout or graph are the values that are entered into one of the ENR tables. The valid frequency range for entries is from 10 MHz to 99999 MHz. The valid power range for the ENR entries is from -6 to +50 dB.

During a measurement the Noise Figure Meter searches the ENR table until the measurement frequency is found. If the measurement frequency is between ENR table entries, the Noise Figure Meter will interpolate the ENR data. If the measurement frequency is higher than the highest table entry, the Noise Figure Meter will use the ENR value of the highest table entry. If the measurement frequency is lower than the lowest table entry, the Noise Figure Meter will use the ENR value of the lowest table entry. When power is initially applied to the Noise Figure Meter, the ENR table contains the default value of 15.20 dB at all frequency points. After an ENR table is entered for a specific noise source, this information is retained in the continuous memory and need not be re-entered each time power is turned off and on.

Procedure

This discussion will cover the following areas:

- Entering a new ENR (Excess Noise Ratio) table
- Editing an ENR table
- Viewing information on stored ENR tables

NOTE

The Noise Figure Meter has five tables (Tables 0-4) that are used for ENR data. Tables 1-4 are used to store ENR data. Table 0 contains the ENR data that is currently being used. Information in Table 0 can be stored to Tables 1-4. Information in Tables 1-4 can be recalled to Table 0.

If ENR data has not been previously entered into any of the tables (as with a new Noise Figure Meter), the tables will contain the following default information: The frequency points will be 10, 100, 1000 through 26000 (every 1000 MHz) and 26500 MHz. There won't be any default frequencies after the thirty-first (31) table entry. The ENR value will be 15.20 dB for each frequency point.

Setting the ENR Source Identifier.

NOTE

The ENR source identifier is a unique number used to identify the Noise Source associated with one of the stored ENR tables. The ENR source identifier should be set before the ENR data is entered into the table. If a

ENR Table Entry (cont'd)

Procedure (cont'd)

table other than Table 0 is to be edited, that table will have to be recalled into Table 0, before the table can be edited. ENR editing is always done to Table 0. To recall a table, key in the following sequence:

RECALL ENR X

X is the number of the table (1—4) to be recalled. Rcl will appear in the INSERTION GAIN display and Enr will appear in the NOISE FIGURE display. After the table number is keyed in, the displays return to what they were displaying before the recall.

1. Press 5.5 SPECIAL FUNCTION. A five digit number will appear in the left display; if the number is less than five digits, leading zeros will be added to the number. In either case, five digits will be displayed. This number is used to identify the Noise Source associated with the ENR table currently in Table 0. The last five digits of the Noise Source serial number are suggested as the number to use as the identifier.

With Special Function 5.5 activated, key in the new identifier. The number will begin to appear in the left display; press ENTER. The values in the other two displays are dependent on what action the Noise Figure Meter is performing and are not affected by the entering of the Noise Source identifier.

Entering or Editing an ENR table

NOTES

The following procedure describes how to enter a new ENR table. The same procedure is used if an existing ENR table is being edited.

The following discussion describes four keys used to look at data, enter data or edit data in an ENR table after the ENR key has been pressed.

- *The UP ARROW and DOWN ARROW allow the user to scroll between ENR tables (Special Function 5.6) or to scroll through information within a table (ENR Editing).*
- *The DECREASE key is used to delete an ENR entry. Press the DECREASE key and the frequency currently being displayed is deleted. This key is very helpful in deleting unwanted default frequencies.*
- *The INCREASE key is used to insert a new ENR entry before the ENR data currently being displayed. After pressing INCREASE the ENR table entry number, in the NOISE FIGURE display, will be the same number that was displayed before the INCREASE key was pressed. The INSERTION GAIN display will show an ENR of 15.2 dB. The left display will show a frequency that is the average of the old frequencies that surround the new entry. The new frequency and ENR value can be entered using the procedure in steps 2 through 4.*

If data is read, over the Hewlett-Packard Interface Bus, from the Noise Figure Meter during ENR Table Entry, the Noise Figure Meter will output a special HP-IB code for the NOISE FIGURE window. For more information about this special HP-IB code, refer to the Error Messages and Recovery Detailed Operating Instruction.

ENR Table Entry (cont'd)

Procedure (cont'd)

1. If a new ENR table is being entered, go to step 2. If an existing ENR table is to be edited, continue with this step.

If the table to be edited is not in Table 0, the table will have to be recalled. Use the following key sequence to recall an existing ENR table:

RECALL ENR X

X is the number of the table (1—4) to be recalled.

When doing a recall, rcl appears in the INSERTION GAIN display and Enr appears in the NOISE FIGURE display. When the table number is keyed in, the displays return to what they were displaying before the recall was done.

2. Press the ENR key. The displays will be as shown below:

| | | |
|------|------|------|
| FFFF | EEEE | T-NN |
|------|------|------|

FFFF is the first frequency in Table 0. EEEE is the ENR for the first frequency in Table 0. T is the ENR table number (in this case 0). NN is the ENR table entry number (1 through 35).

NOTE

When editing, T is the number of the most recently recalled table. T will be zero if a change has been made to the table after it was recalled.

3. The MHz annunciator in the left display will be blinking. This indicates that the frequency can be changed, if desired. To change the frequency, key in the new frequency and press ENTER. The new frequency will appear as it is typed. If an error is made before ENTER is pressed, press NOISE FIGURE. This will return the original frequency to the display. The new frequency can then be re-entered. If an error was made after ENTER was pressed, press DOWN ARROW and then UP ARROW. The MHz annunciator in the left display will begin blinking indicating that the frequency can be changed. If the default frequency is being used, press ENTER. In either case, pressing ENTER will cause the dB annunciator in the INSERTION GAIN display to begin blinking.
4. The blinking dB annunciator indicates that the ENR value can be changed, if desired. To change the ENR value, key in the new value and press ENTER. The new ENR value will appear as it is typed. With one exception, the error recovery procedure is the same as that described for frequency in step 3. If the error is made after ENTER is pressed, press DOWN ARROW and ENTER. Then re-enter the ENR value. If the default ENR value is being used, press ENTER. In either case, pressing ENTER will cause the MHz annunciator in the left display to begin blinking and the next entry in the table will be displayed.

Once the frequency and the ENR value have been entered, the ENR table entry number, in the NOISE FIGURE display, will increase by one. If any values have been entered, the ENR table number will be set to zero.

ENR Table Entry (cont'd)

Procedure (cont'd)

5. Repeat steps 3 and 4 as needed to make all ENR table entries.
6. After all frequencies and ENR values have been entered, the information must be stored to Table 1, 2, 3 or 4. If the information is not stored, it will be lost the next time one of the tables (Tables 1-4) is recalled to Table 0. The store procedure will save the Noise Source identifier and the ENR data.
7. To store the information, key in the following sequence:

STORE ENR X

X is the number of the table (1—4) where the information is stored.

When a store is keyed in, the INSERTION GAIN display shows Sto and the NOISE FIGURE display shows Enr. After the table number is entered, the displays return to what they were previously displaying.

8. To terminate ENR table entry mode, press FREQUENCY or send HP-IB code FR.

Viewing Information on Stored ENR Tables

Press 5.6 Special Function. This special function will cause the following information to be displayed:

| | | |
|------|--|------|
| IIII | | T-NN |
|------|--|------|

IIII is the ENR source identifier. T is the ENR table number. NN is the number of entries in the table. The INSERTION GAIN display does not have any information displayed in this mode.

Information on other tables can be viewed by using the UP ARROW and DOWN ARROW keys.

NOTE

If data is read, over the Hewlett-Packard Interface Bus, from the Noise Figure Meter when Special Function 5.6 (HP-IB code NS) is active, the Noise Figure Meter will output a special HP-IB code for the NOISE FIGURE window. For more information about this special HP-IB code, refer to the Error Messages and Recovery Detailed Operation Instruction.

Pressing ENTER causes the Noise Figure Meter to resume normal measurement mode.

Program Codes

HP-IB

The HP-IB code to enable ENR table entry is NR. The HP-IB code for Special Function 5.5 (Noise Source identifier) is SN. The HP-IB code for Special Function 5.6 (Noise Source catalog) is NS.

Comments

The following program is an example of how to download an ENR table into the Noise Figure Meter:

ENR Table Entry (cont'd)

Comments (cont'd)

NOTE

This program example was written in BASIC language 3.0 using the HP 9000 Series 200 Model 236 computer.

```

10 DIM Freq(5,40),Enr(5,40)
20 Nfm=708                                !Address of the Noise Figure Meter
30 N=20                                    !Number for frequency/ENR pairs.
40 DATA 10,15.20,100,15.40,1000,15.20,2000,15.2,3000,15.00
50 DATA 4000,15.00,5000,15.10,6000,15.20,7000,15.20,8000,15.30
60 DATA 9000,15.40,10000,15.50,11000,15.60,12000,15.60,
70 DATA 13000,15.45,14000,15.50,15000,15.35,16000,15.30,
80 DATA 17000,15.30,18000,15.30
90 T=1                                     !ENR TABLE 1
100 FOR I=1 TO N                           !FILL UP A TABLE
110   READ Freq(T,I)                       !READ FREQUENCY VALUE
120   READ Enr(T,I)                        !READ ENR VALUE
130 NEXT I
140 OUTPUT Nfm;"NR"                        !GO INTO ENR EDIT MODE
150 FOR I=1 TO N                           !SEND THE ENR TABLE
160   OUTPUT Nfm;Freq(T,I);"EN";Enr(T,I);"EN"
170   PRINT "SENDING FREQ/ENR VALUES OF: ";Freq(T,I),Enr(T,I)
180 NEXT I
190 OUTPUT Nfm;"FR"                        !END ENR ENTRY
200 PRINT
210 PRINT "DONE DOWNLOADING THE ENR TABLE."
220 END

```

The ENR table is used during both UNCORRECTED NOISE FIGURE measurements and CORRECTED NOISE FIGURE AND GAIN measurements.

The specific ENR vs. frequency data that is used is determined by the stimulus frequency and the measurement mode that has been selected. Refer to Measurement Modes 1.0 through 1.9 Detailed Operating Instructions for additional information.

Special Function 0.9 or PRESET has no effect on data stored in the ENR tables.

Special Function 0.9 or PRESET sets Table 0 as the table that is used for calibration and the measurement.

Related Sections

Measurement Modes 1.0 through 1.9
Spot ENR, T_{hot} , T_{cold} and ENR Table Selection.

Error Messages and Recovery

Description

The instrument generates error messages to indicate operating problems, incorrect keyboard entries, or service-related problems. The error message is cleared when the error condition is removed. The error messages are grouped by error code as follows:

Error 10 through Error 49. These are operating and entry errors which indicate that not all conditions have been met to assure a calibrated measurement, or that an invalid keyboard or HP-IB entry has been made. Operating errors can usually be cleared by using the front panel controls, changing the equipment setup, or correcting the HP-IB code. Entry errors require that a new keyboard entry or function selection be made. A number of errors in this group may represent instrument malfunctions. The operator should try to clear the error condition using the corrective actions shown in the table below before referring the unit for service.

Error 60 through Error 80. These are service errors which provide service-related information. Service errors are discussed in Section VIII of the Service Manual.

Error 100 through Error 105. These are Noise Figure Test Set operational and service errors.

Errors may also be classified as volatile or nonvolatile.

Nonvolatile errors typically occur when the instrument has received conflicting commands from the operator. The instrument stops making measurements and waits for the conflict to be resolved by the operator. An example of this type of conflict is selecting a corrected measurement when a calibration has not been performed. All hardware errors are also nonvolatile.


Volatile errors typically represent invalid entries of either frequency, special function codes, numerical data, or HP-IB characters. Volatile errors are cleared when a front panel key is pressed or when a serial poll is performed over the HP-IB. Upon clearing a volatile error, the invalid entry is ignored by the instrument and measurements resume as if the entry was never received.

The last volatile or nonvolatile error generated can be displayed using Special Function 99.1 (HP-IB code ER). The error may already be resolved or can be active. When the error is requested over HP-IB, the error will be displayed using the error code or can be displayed in English. Using the English display, an error code does not have to be interpreted. The Comments section, at the end of this instruction, contains a program for displaying the error in English.

HP-IB Output Format



The HP-IB output format for errors is:



For example, Error 10 is output to the HP-IB as +90010E+06CRLF. This format differs from normal data outputs since normal data outputs will never exceed 1×10^5 . Once an error has been input to the computing controller, the error code is simply derived by subtracting 9×10^{10} from the input number, and then dividing the result by 1 000 000.

Error Messages and Recovery (cont'd)

HP-IB Output Format




Special Codes Over HP-IB. When a read of the Noise Figure Meter is attempted during the following operations: ENR editing, ENR catalog, Noise Figure Test Set Coarse or Fine Tuning Calibration, the Noise Figure Meter will output special HP-IB codes for the NOISE FIGURE window. The special HP-IB codes are given below:


ENR Editing




ENR Catalog



**Noise Figure Test Set
Fine Tuning Calibration:**



**Noise Figure Test Set
Coarse Tuning Calibration:**




One purpose for these special codes would be to read back from the Noise Figure Meter until the codes stop being sent, which would mean the task is complete. This would be useful when doing a coarse or fine tune calibration.

Timeouts should not be used with these special codes. If a timeout is used, it should be at least sixty seconds. This is necessary because it may take the Noise Figure Meter many seconds to set up the special code for output. This is the case for coarse and fine tune calibration.

Error Displays

There are three types of error displays. All three use the format shown above to output the error message to the HP-IB. The following examples illustrate each type:




The display above shows the general error display format. E means error while the number is the error code.

Error Messages and Recovery (cont'd)

Error Displays (cont'd)



This display indicates that a measurement overflow has occurred or that the measured noise figure exceeds 32 dB. This display is output to the HP-IB as E99 using the HP-IB output format 90099E+06CRLF.



The display above indicates that the data is not ready. This display is output to the HP-IB as a special reserved number (90000E+06CRLF).

Error Messages

The table below describes all operating and entry errors. The error code, message, and the action typically required to remove the error-causing condition are given. Additional information pertaining to particular errors is also given.

| Error Code | Volatile (V) or Nonvolatile (NV) | Message | Recommended Action/Comments |
|---|----------------------------------|---|--|
| Hardware Error | | | |
| General Remedy: Press PRESET and check that input signal is within the specified amplitude and frequency range. | | | |
| 10 | NV | A/D conversion failed. | Refer to Service-Related Errors in Section VIII, Service. ¹ |
| 11 | NV | A/D converter overflow. | Set IF and RF attenuators to autorange (Special Functions 70.0 and 60.0). If error persists, refer to Service-Related Errors in Section VIII, Service. ¹ Also check for proper operation of the Noise Source. |
| 12 | NV | Input overflow. | Set RF attenuators to autorange (Special Function 60.0). If error persists, refer to Service-Related Errors in Section VIII, Service. ¹ |
| 13 | NV | IF attenuator calibration failed. | Refer to the Calibration, IF Attenuators Detailed Operating Instruction. If error persists, refer to Service-Related Errors in Section VIII, Service. ¹ |
| 14 | NV | Proper IF or RF attenuators cannot be selected. | Refer to Service-Related Errors in Section VIII, Service. ¹ |

¹ Section VIII, Service, is in the Service Manual. The part number of the Service Manual is on the title page of this manual.

Error Messages and Recovery (cont'd)

Error Messages (cont'd)

| Error Code | Volatile (V) or Nonvolatile (NV) | Message | Recommended Action/Comments |
|--|----------------------------------|---|--|
| Hardware Error (cont'd) | | | |
| 18 | NV | Frequency calibration failed. | Refer to Service-Related Errors in Section VIII, Service. ¹ |
| 19 | NV | Noise Figure Test Set YIG Filter calibration (coarse or fine) failed. | Refer to the Comments section at the end of this instruction. |
| Not Properly Calibrated For Corrected Measurement | | | |
| General Remedy: Repeat calibration. | | | |
| 20 | NV | Not calibrated. | Perform calibration prior to selecting CORRECTED NOISE FIGURE AND GAIN measurement. |
| 21 | NV | Current frequency is out of calibrated range or not a calibrated point in Modes 1.5–1.9 | Select frequency within calibrated range, calibrate over a new frequency range, or refer to Special Function 39, in Modes 1.5–1.9. |
| 22 | NV | Current RF attenuation not calibrated | Select appropriate input gain calibration range (Special Function 32). |
| 23 | NV | Not calibrated in the current measurement and sideband modes. | Perform calibration in current measurement and sideband modes. |
| 24 | NV | Not calibrated for the current IF (Measurement Modes 1.1, 1.3, 1.6 and 1.8). | Perform calibration. (Changing any IF requires recalibration; refer to Special Functions 3 and 19.) |
| 25 | NV | Not calibrated for the current LO frequency (Measurement Mode 1.2 and 1.7). | Perform calibration. (Changing the LO frequency requires recalibration; refer to Special Function 3.) |
| 26 | NV | Internal IF attenuators not calibrated. | Refer to the Calibration, IF Attenuators Detailed Operating Instruction. |
| 27 | NV | Overflow while calibrating. | Too much loss in calibration system. Check input gain calibration setting (Special Function 32). Check for proper Noise Source |

¹ Section VIII, Service, is in the Service Manual. The part number of the Service Manual is on the title page of this manual.

Error Messages and Recovery (cont'd)

Error Messages (cont'd)

| Error Code | Volatile (V) or Nonvolatile (NV) | Message | Recommended Action/Comments |
|--|----------------------------------|--|---|
| Not Properly Calibrated For Corrected Measurement (cont'd) | | | |
| 28 | NV | Noise Figure Test Set fine tuning calibration is needed. | operation. Verify that the Noise Source can supply enough ENR (Excess Noise Ratio). Refer to comments. Refer to the Comments section at the end of this instruction and the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction. |
| 29 | NV | Noise Figure Test Set coarse tuning calibration is needed. | Refer to the Comments section at the end of this instruction and the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction. |
| Invalid Frequency Error | | | |
| General Remedy: Change frequency parameter and repeat measurement. | | | |
| 30 | V | Start frequency is greater than stop frequency during calibration or plot. Or, the lower limit is greater than the upper limit (noise or gain) during sweep. | Set start frequency (or lower limit) to a value less than the stop frequency (or upper limit). |
| 31 | V | Number of calibration points exceeds 181. | Reduce the number of calibration points. (Reduce calibration range or increase step size.) |
| 32 | V | LO (set by Special Function 3.1) frequency will be out of range. | Change IF, START FREQ, STOP FREQ, or sideband selection so that system LO does not tune through 0 MHz. |
| 33 | V | IF into Noise Figure Meter will be out of range. | If single sideband has been selected, change START FREQ, STOP FREQ, or LO (set by Special Function 3.1) frequency so that the difference between the LO (set by Special Function 3.1) frequency and the start or stop frequency is greater than 10 MHz and less than 1600 MHz (modes 1.1 to 1.4) or |

Error Messages and Recovery (cont'd)

Error Messages (cont'd)

| Error Code | Volatile (V) or Nonvolatile (NV) | Message | Recommended Action/Comments |
|---|----------------------------------|--|--|
| Invalid Frequency Error (cont'd) | | | |
| 34 | NV | Double sideband is not allowed in Measurement Modes 1.2 or 1.7. | 18000 MHz (1.6 to 1.9). If sum function (Special Function 2.3) is being used, change START FREQ, STOP FREQ or LO (set by Special Function 3.1) frequency so that LO plus START or STOP FREQ is within 10-1600 MHz range. Use single sideband (Special Function 2.1–2.3) with Measurement Modes 1.2 or 1.7. |
| Entry Error | | | |
| General Remedy: Check and repeat entry. | | | |
| 35 | V | Entered value is out of range. | Re-enter new value. |
| 36 | V | Undefined special function. | Check, then re-enter correct special function code. |
| 37 | V | Cannot enter specified parameter. | Select proper function that allows entry of this parameter. |
| 38 | V | Noise Figure Test Set IF will be out of range. | Refer to the Comments section at the end of this instruction. |
| 39 | V | The number of plot points exceeds 251. | Change START FREQ, STOP FREQ or STEP SIZE to reduce the number of plot points below 251. Also, refer to the Data Output to Oscilloscopes, Recorders and Plotters Detailed Operating Instruction. |
| HP-IB HP-IB Errors | | | |
| General Remedy: Check and repeat entry. | | | |
| 40 | V | Undefined HP-IB code. | Check, then re-enter correct HP-IB code. |
| 41 | V | Invalid HP-IB characters. | Check, then re-enter valid HP-IB characters. |
| 42 | NV | System Local Oscillator not found on System Interface Bus with 46.0 SP active. | Refer to the Comments section at the end of this instruction. |

Error Messages and Recovery (cont'd)

Error Messages (cont'd)

| Error Code | Volatile (V) or Nonvolatile (NV) | Message | Recommended Action/Comments |
|-------------------------------------|----------------------------------|---|--|
| HP-IB HP-IB Errors (cont'd) | | | |
| 43 | V | Codes received while in Talk Only Mode (4.2SP). | Only send codes when the instrument is addressed to listen. |
| 44 | NV | Noise Figure Test Set not found when 45.0 SP or 45.1 SP is active. | Refer to the Comments section at the end of this instruction. |
| 45 | NV | Plotter was not found on the System Interface Bus at the address specified by 40.3 SP. | Refer to the Comments section at the end of this instruction. |
| 46 | NV | Pass through device not found on the System Interface Bus or 40.6 SP set incorrectly. | Refer to the Comments section at the end of this instruction. |
| 47 | NV | Noise Figure Meter did not find a controller on the System Interface Bus while passing control. | If the Noise Figure Meter pass control capability (Special Function 49.1) is not being used, select Special Function 49.0. Also, refer to the comments section at the end of this instruction. |
| 48 | NV | Two or more controllers are on the System Interface Bus. | Refer to the Comments section at the end of this instruction. |
| Service Errors | | | |
| 60-79 | NV | Service-related errors. | Refer to Service-Related Errors in Section VIII, Service. ¹ |
| 80 | NV | Continuous memory failure. | Refer to Comments below. |
| Noise Figure Test Set Errors | | | |
| 100 | V | Noise Figure Test Set fine tune table will overflow. | Reduce the number of points by changing the START FREQ, STOP FREQ or STEP SIZE; then, perform a fine tune calibration. |
| 101 | NV | Noise Figure Test Set self-test failed. | Refer to Section VIII, Service ¹ and Special Function 98.7. |
| 102 | NV | Auto sweep was aborted to protect Noise Figure Test Set switches. | Start sweep again with SWEEP AUTO key. Also, refer to comments. |

¹ Section VIII, Service, is in the Service Manual. The part number of the Service Manual is on the title page of this manual.

Error Messages and Recovery (cont'd)

Error Messages (cont'd)

| Error Code | Volatile (V) or Nonvolatile (NV) | Message | Recommended Action/Comments |
|--|----------------------------------|--|---|
| Noise Figure Test Set Errors (cont'd) | | | |
| 103 | NV | Noise Figure Test Set cannot perform a single sideband measurement at this frequency. | Select Special Function 17.1. |
| 104 | NV | Interpolating across the Noise Figure Test Set's bands is not permitted. | Ensure that the frequency of interest is a calibrated point. |
| 105 | NV | The YIG filter temperature control loop will not lock, inside the Noise Figure Test Set. | Repeat the procedure that was used prior to error E105 being generated. Refer to Section VIII, Service, ¹ for the Noise Figure Meter or the Noise Figure Test Set. |

Comments

Error code E19 can be generated for either a coarse or fine tuning calibration of the Noise Figure Test Set. Check all cables and ensure that the LO INPUT, RF INPUT and IF OUTPUT signal paths have been properly connected. If the error occurs after another attempted calibration, the Noise Figure Meter is unable to locate the Noise Figure Test Set's YIG filter passband.

If a fine tune calibration is being performed, a coarse tune calibration may be needed. A coarse tune calibration is needed when the Noise Figure Measurement System is initially put together and the system local oscillator is a sweeper or if repairs are done to the Noise Figure Test Set. Also, if a fine tune calibration is being performed, loss after the Noise Source can cause this error. Some calibration setups, with loss between the Noise Source and the Noise Figure Test Set, may require the use of a preamplifier. It is possible to do a fine tuning calibration with the Noise Source connected directly to the Noise Figure Test Set's INPUT, if a preamplifier is not available. The Noise Source should have at least 12 dB ENR (Excess Noise Ratio) for a fine tuning calibration without a preamplifier. For additional information, refer to the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction.

Error code E21 is generated if the current frequency is out of the calibrated measurement range. In Measurement Modes 1.5 through 1.9 the current frequency may be in the calibrated measurement range, but the frequency may not be an actual calibrated frequency. Since corrected measurements are very susceptible to small changes in the system noise figure, it is not advisable to expect good data between calibration points, especially if the points are separated by many megahertz.

Also, because of discontinuities in the band crossings of the Noise Figure Test Set, the Noise Figure Meter cannot interpolate across the Noise Figure Test Set's band crossings. For instance, when one calibration point is in SSB1 and another is in SSB2, a corrected measurement of noise figure and gain would not yield a valid data point that did not require interpolating calibration data for a frequency between the two calibration points.

¹ Section VIII, Service, is in the Service Manual. The part number of the Service Manual is on the title page of this manual.

Error Messages and Recovery (cont'd)

Comments (cont'd)

Special Function 39.1 can be used to disable E21, for interpolated calibration data. Special Function 39.0 (default after a PRESET) enables E21.

Error code E27 usually occurs because the noise figure of the measurement system is too high during the calibration of the third input gain setting at one or more calibration frequency. Consider the error code as only a warning, and that the ability of the instrument to make valid measurements is most likely not impaired. But, if error code E22 occurs during the actual measurement, do one of the following:

1. Increase the instrument's smoothing factor and try to recalibrate.
2. The DUT probably has 30 dB or more of gain, causing the Noise Figure Meter to use the attenuator setting of the third calibration setting. Attach a 10 dB attenuator to the output of the DUT and use special functions 34.3, 34.4, and 34.1 to correct for the loss.
3. Add a preamp to the measurement system and recalibrate.

Error code E28 is generated when the Noise Figure Test Set needs a fine tuning calibration for the current set of frequencies defined by START FREQ, STOP FREQ and STEP SIZE. The calibration can be performed using Special Function 36.3. If a point between those defined by START FREQ, STOP FREQ and STEP SIZE needs to be fine tuned, Special Function 36.4 can be used. The error could have been generated due to the following reasons:

- The YIG filter, in the Noise Figure Test Set, has not been fine tuned at the current frequency and coarse tune data is being used.
- The current frequency of the Noise Figure Test Set YIG filter has been interpolated from the fine tuning calibration data.
- The Noise Figure Test Set has been fine tuned, but the temperature has drifted more than five degrees centigrade, since the last Fine Tuning Calibration. The YIG heater loop must be reset and new fine tuning data gathered. Use Special Function 36.3 to reset the heater loop and gather the new fine tune data.

Usually, the solution to error twenty-eight (E28) is to perform a Fine Tuning Calibration using Special Function 36.3.

Error code E29 is generated if a Noise Figure Test Set coarse tuning calibration is required before making a single sideband measurement within the frequency range of 2401 to 18000 MHz. Special Function 64.0 (refer to the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction) must be performed. The Noise Source (HP 346B or HP 346C) must have an ENR (Excess Noise Ratio) of at least 12 dB from 2401 to 18000 MHz.

Error code E38 is generated when the signal being input to the Noise Figure Test Set does not fall between 10 to 18000 MHz. Check the parameter (START FREQ, STOP FREQ, STEP SIZE, Special Functions 3.0 or 3.1 and Special Functions 2.0 through 2.3) that may have caused E38 or do a PRESET and re-enter the parameters. Verify that the measurement signal falls between 10 to 18000 MHz.

Error Messages and Recovery (cont'd)

Comments (cont'd)

Error code E42 is generated when the System Local Oscillator is not found at the address specified with Special Function 40.1. Verify that the System Local Oscillator is connected to the SYSTEM INTERFACE BUS connector and not to the HEWLETT-PACKARD INTERFACE BUS (HP-IB) connector. Also, verify that the address of the System Local Oscillator is the same address that is specified with Special Function 40.1.

If the Noise Figure Meter is not going to control the System Local Oscillator, error E42 can be eliminated by using Special Function 46.1. Special Function 46.1 is retained in memory, when the Noise Figure Meter is turned off. The next time it is desired to have the Noise Figure Meter control the System Local Oscillator, Special Function 46.0 will have to be active.

Error code E44 is generated when the Noise Figure Test Set is not found at the address specified by Special Function 40.2. Verify that the Noise Figure Test Set is connected to the SYSTEM INTERFACE BUS connector and not to the HEWLETT-PACKARD INTERFACE BUS connector.

If the Noise Figure Meter is not going to control the Noise Figure Test Set, Special Function 45.2 can be selected to avoid E44. The next time it is desired for the Noise Figure Meter to control the Noise Figure Test Set, Special Function 45.0 or 45.1 will have to be selected.

Error code E45 is generated when the plotter is not found at the address specified by Special Function 40.3. Verify that the plotter is connected to the SYSTEM INTERFACE BUS connector and not to the HEWLETT-PACKARD INTERFACE BUS connector. Also, verify that the address of the plotter is the same as the address specified by Special Function 40.3.

Error code E46 is generated when the "pass through device" is not found at the address specified by Special Function 40.6 (or HP-IB code PT). Verify that the "pass through device" is connected to the SYSTEM INTERFACE BUS connector and not to the HEWLETT-PACKARD INTERFACE BUS connector. Also, verify that the address of the "pass through device," sent with the PT command, is the valid address of the "pass through device" on the System Interface Bus. The address specified with Special Function 40.6 must be the same as the address sent with the PT command.

Error code E47 is generated when the Noise Figure Meter expects to find a controller on the System Interface Bus and the controller is not found. Error E47 could be caused by Special Function 49.1 being enabled when it is not desired. If Auto-Pass-Control is not desired, select Special Function 49.0 to disable Auto-Pass-Control. If Auto-Pass-Control (Special Function 49.1) should be active, verify, that the other controller is connected to the SYSTEM INTERFACE BUS connector and not to the HEWLETT-PACKARD INTERFACE BUS connector. Also, verify that the address of the controller is the same as the address specified by Special Function 40.5.

Error code E48 is generated when the Noise Figure Meter has detected the existence of another controller on the System Interface Bus; the Noise Figure Meter was told (Special Function 48.0) that it would be the controller. Verify that a controller is connected to the HEWLETT-PACKARD INTERFACE BUS connector and not to the SYSTEM INTERFACE BUS connector.

Error Messages and Recovery (cont'd)

Comments (cont'd)

In systems where there are multiple controllers on the System Interface Bus that are sharing resources such as a local oscillator or a plotter, only one of the controllers should be enabled to be the system controller or active controller at any given time. Verify that the other controllers are not set to be the system controller, at turn-on. If the Noise Figure Meter has been told to be the system controller, it will display "Ctrl on" in the right display after power-on. If the Noise Figure Meter has been told not to be the system controller, the message "Ctrl OFF" will appear in the right displays just after power-on.

Error code E80 indicates a continuous memory failure. The instrument may not retain data when powered down. However, the ability of the instrument to make valid measurements may not be impaired. If E80 occurs, press PRESET and proceed. The occurrence of E80 implies that stored information such as the IF attenuator calibration was not retained. Therefore, error code E26 will appear. Perform an IF attenuator calibration (refer to the Calibration, IF Attenuators Detailed Operating Instruction). If E80 persists, service should be performed on the internal battery and related circuits. Refer to Service-Related Errors in Section VIII, Service.¹

Error code E102 indicates that auto sweep has been aborted, in Measurement Modes 1.5 through 1.9. After one hundred sweeps, auto sweep is aborted to protect the switches in the Noise Figure Test Set. To disable auto sweep abort (and error code E102), use Special Function 97.3. PRESET will re-enable auto sweep abort and error code E102.

The following program describes how an error can be displayed in English, over HP-IB:

NOTES

This program was written in BASIC language 3.0 using the HP 9000 Series 200 Model 236 computer.

This program assumes that the Noise Figure Meter has an HP-IB address of 8 and the interface card has a select code of 7. Also, it is assumed that an error has occurred.

```

100 OUTPUT 708;"H1 ER"          !OUTPUT FREQUENCY, INSERTION GAIN
                                !AND NOISE FIGURE DISPLAYS AND DISPLAY
                                !THE ERROR.
110 ENTER 708;W1,W2,W3          !GET THE FREQUENCY, INSERTION GAIN AND
                                !NOISE FIGURE DISPLAYS.
120 PRINT "The last Noise Figure Meter error was: ";W1
130 OUTPUT 708;"FR"            !STOP THE ERROR REPORTING DISPLAY
140 Error_num=W1                !SETUP FOR ERROR READBACK
                                !
                                ! THE NEXT LINES ASK FOR THE TEXT OF THE ERROR
                                ! NUMBER THAT IS CONTAINED IN THE VARIABLE W1.
                                !
150 OUTPUT 708; "ER ";Error_num;"EN" !SETUP ERROR TEXT TO READ.
160 ENTER 708; Errmes$          !READ THE TEXT.
170 PRINT Errmes$
180 END

```

¹ Section VIII, Service, is in the Service Manual. The part number of the Service Manual is on the title page of this manual.

Error Messages and Recovery (cont'd)

Related Sections

Calibrate
Calibration, IF Attenuators
Calibration, Input Gain Selection
IF Attenuation Selection
Measurement Modes 1.1 through 1.9
Remote Operation, HP-IB
RF Attenuation Selection
Service-Related Errors, Section VIII¹
Special Functions

¹ Section VIII, Service, is in the Service Manual. The part number of the Service Manual is on the title page of this manual.

Fixed Frequency Increment

Description

The tuned frequency of the instrument can be changed by using a combination of the **FREQ INCR**, , and  keys. The **FREQ INCR** key is used to set the fixed increment size. The , and  keys step the fixed frequency up or down by the value of the current frequency increment. These keys provide a convenient method of controlling the fixed frequency of the instrument for applications such as locating the minimum noise figure of an amplifier.

The allowable range of values for a frequency increment is:

- 1 to 1600 MHz for Measurement Modes 1.0 and 1.4
- 1 to 18000 MHz for Measurement Modes 1.5 and 1.9
- 1 to 99999 MHz for Measurement Modes 1.1 through 1.3 and 1.6 through 1.8

Fractional increments are rounded to the nearest 1 MHz. If an attempt is made to enter an illegal frequency increment, error code E35 is displayed and the entry is not made.

The Measurement Mode selected determines the fixed frequency increment default. The table below lists the defaults for each of the Measurement Modes.

| Measurement Mode | Fixed Frequency Increment |
|------------------|---------------------------|
| 1.0 and 1.4 | 20 MHz |
| 1.1, 1.2 and 1.3 | 200 MHz |
| 1.5 and 1.9 | 250 MHz |
| 1.6, 1.7 and 1.8 | 500 MHz |

As shown in the table, the Measurement Modes have been placed into four groups. If the fixed frequency increment is changed for one Measurement Mode, the fixed frequency increment is changed for all the measurement modes of the group. When going from one measurement mode to another, the fixed frequency increment of the previous measurement mode is automatically saved by the Noise Figure Meter.

Procedure

To change the size of the frequency increment, press the **FREQ INCR** key, enter a value for frequency in MHz, and then press the **ENTER** key.

Use  or  to step the frequency up or down by the current frequency increment.

| Front Panel Key | Program Code  | Stored in ¹ Continuous Memory | Can Be Stored and Recalled | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|---|---|--|----------------------------------|---|---------------------------------------|
| FREQ INCR | FN | Y | Y | 20 MHz | 20 MHz |
|  | UP | — | — | — | — |
|  | DN | — | — | — | — |

¹Table categories are described in the Preset Conditions and Power-Up Sequence Detailed Operating Instruction.

Fixed Frequency Increment (cont'd)

Example To set the frequency increment to 50 MHz:

| | |
|--|--|
| LOCAL (keystrokes) | Function Data Function  |
|  (program codes) |  |

To decrease the tuned frequency by the current frequency increment:

| | |
|--|--|
| LOCAL (keystrokes) | Function  |
|  (program codes) | DN |

Holding either the  or  key down causes the frequency to step continuously. However, the frequency is slower to change when stepped downward.

Program Codes



In addition to the HP-IB program codes given in Procedure above, HZ and MZ are the program codes for Hz and MHz, respectively.

Indications

The currently programmed frequency increment is displayed in the left display for as long as the **FREQ INCR** key is depressed. After **FREQ INCR** is pressed, the new frequency increment data can be entered. This data is displayed in the left display until the **ENTER** key is pressed. The function is then implemented and the instrument returns to the last selected measurement.

When either  or  is pressed, the tuned frequency is changed in the selected direction. The new tuned frequency is displayed in the left display and the instrument continues with the selected measurement.

Comments

Front panel frequency increment values should be entered in integer MHz units. If a decimal MHz entry is made, the instrument rounds the entry to the nearest integer (0.5 MHz and above is rounded up).

The Hz unit, provided for HP-IB, is for programmer convenience. The instrument rounds all HP-IB tuned frequency inputs to the nearest MHz.

If  or  is pressed rapidly in succession, the left display updates the frequency each time the key is pressed. The noise measurement may be delayed (— — — will appear in the **NOISE FIGURE** display), especially if smoothing is used.

Fixed Frequency Increment (cont'd)

**Comments
(cont'd)**

For highest repeatability, always tune in the same manner (direction and step size) as the calibration was done.

**Related
Sections**

Fixed Frequency Tuning
Measurement Modes 1.0 through 1.9
Preset Conditions and Power-Up Sequence

Fixed Frequency Tuning

Description

The FREQUENCY key is used to display the frequency to which the instrument is tuned and to enter a new fixed frequency value. The allowable frequency range is:

- 10 to 1610 MHz in Measurement Modes 1.0 and 1.4
- 10 to 18000 MHz in Measurement Modes 1.5 and 1.9
- 10 to 99999 MHz in Measurement Modes 1.1 through 1.3 and 1.6 through 1.8

The Measurement Mode determines the default for fixed frequency tuning. The defaults are given in the table below.

| Measurement Mode | Fixed Frequency |
|------------------|-----------------|
| 1.0 and 1.4 | 30 MHz |
| 1.1, 1.2 and 1.3 | 10000 MHz |
| 1.5 and 1.9 | 3000 MHz |
| 1.6, 1.7 and 1.8 | 46000 MHz |

As shown in the table above, the Measurement Modes have been placed into groups. If the fixed frequency is changed for one Measurement Mode, the fixed frequency is changed for all the Measurement Modes of the group. When going from one Measurement Mode to another, the previous fixed frequency is automatically saved by the Noise Figure Meter.

The tuned fixed frequency of the instrument can also be changed by using a combination of the FREQ INCR key to set the increment size, and the  and  keys to step the fixed frequency in the selected direction.

The FREQUENCY key acts as a "clear entry" key. It clears entries in progress, returns the instrument to the last selected measurement with the left display showing the current tuned frequency, and halts the sweep if it is in progress.

Procedure

To display the current tuned frequency and enter a new tuned frequency, press FREQUENCY, enter the value of the new frequency in MHz, and press ENTER.


| Front Panel Key | Program Code  | Stored in ¹ Continuous Memory | Can Be Stored and Recalled | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|-----------------|---|--|----------------------------------|---|---------------------------------------|
| FREQUENCY | FR | Y | Y | 30 MHz | 30 MHz |

¹Table categories are described in the Preset Conditions and Power-Up Sequence Detailed Operating Instruction.

Fixed Frequency Tuning (cont'd)

Example

To tune the instrument to a new frequency of 100 MHz:



Program Codes



The HP-IB program code for FREQUENCY is FR. The program codes for Hz and MHz are HZ and MZ.

Indications

Pressing the FREQUENCY key clears an incomplete entry, displays the current tuned frequency, and enables the entry of a new tuned frequency. As the entry numbers are pressed, the specific numbers appear in the left display. When ENTER is pressed, the instrument is tuned to the specified frequency and the instrument continues to make the the last selected measurement.

Comments

Front panel frequency entries should be made in integer MHz units. If a decimal MHz entry is made, the instrument rounds the entry to the nearest integer (0.5 MHz and above is rounded up).

The Hz unit, provided for HP-IB, is for programmer convenience. The instrument rounds all HP-IB tuned frequency inputs to the nearest MHz.

If no other prefix key has been pressed, any digits entered followed by ENTER will be interpreted as if the FREQUENCY key were the prefix.

For highest repeatability, always tune in the same manner (direction and step size) as the calibration was done.

Related Sections

Fixed Frequency Increment
 Measurement Modes 1.0 through 1.9
 Preset Conditions and Power-Up Sequence

Fixed IF or LO Frequency Selection

(Special Functions 3 and 19)

Description

Special Function 3 displays and allows entry of the fixed IF and LO frequencies. This special function is used when the measurement signal is down converted prior to being input to the Noise Figure Meter (Measurement Modes 1.1 through 1.4) or the Noise Figure Test Set (Measurement Modes 1.6 through 1.9).

Special Function 19 is ONLY used in Measurement Modes 1.5 through 1.9. Special Function 19 displays and allows the user to change the internal IF between the Noise Figure Meter and the Noise Figure Test Set. The internal IF can only be changed when the measurement frequency is between 1601 and 18000 MHz.

Special Function 3.0 is used to display and enter the fixed IF for Measurement Modes 1.1, 1.3, 1.6 and 1.8. If no entry is made, the Noise Figure Meter uses the last entered value. The fixed IF value does not apply when the instrument is operated in Measurement Modes 1.0, 1.2, 1.4, 1.5, 1.7 or 1.9. The allowable range of values for IF entries is 10 to 1600 MHz (Measurement Modes 1.1 and 1.3) or 10 to 18000 MHz (Measurement Modes 1.6 and 1.8).

Special Function 3.1 is used to display and enter the fixed local oscillator frequency for Measurement Modes 1.2, 1.4, 1.7 and 1.9. If no entry is made, the Noise Figure Meter uses the last entered value. If the instrument is operated in Measurement Modes 1.0, 1.1, 1.3, 1.5, 1.6 or 1.8, the fixed local oscillator frequency does not apply. The allowable range of values for the local oscillator is 10 to 99999 MHz (Measurement Modes 1.7 and 1.9) and 0 to 99999 MHz (Measurement Modes 1.2, 1.4, 1.7 and 1.9).

Special Function 3.2 is used to display the user controlled local oscillator frequency in Measurement Modes 1.6 through 1.9. Special Function 3.2 is particularly useful in Measurement Modes 1.6 and 1.8. The frequency that the user controlled local oscillator should be set to is displayed. If zero is displayed, an error exists with the Special Function 3 frequency and Special Function 2 frequency mix.

Special Functions 19.2 through 19.4 are used when the Noise Figure Test Set is configured with the Noise Figure Meter. These special functions are used to change the internal IF between the Noise Figure Meter and the Noise Figure Test Set. Special Functions 19.2 through 19.4 can only be used when the measurement frequency is greater than 1601 MHz. The default IFs, for Special Functions 19.2 through 19.4, have been carefully chosen; only small deviations from the defaults should be used and only if the particular measurement requires that the default be changed.

Special Function 19.5 is used to display the current frequency (IF) that is being input to the Noise Figure Meter.

Front panel frequency entries should be made in integer MHz units. If a decimal MHz entry is made, the instrument rounds the entry to the nearest integer (0.5 MHz and above are rounded up).

Fixed IF or LO Frequency Selection (cont'd)

(Special Functions 3 and 19)

Procedure


To select a fixed IF or LO frequency, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key. Next, enter the appropriate value using the DATA keys and press ENTER.

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|---|------|------------------------------|--|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| Fixed IF (for modes 1.1 and 1.3) (for modes 1.6 and 1.8) | 3.0 | IF or 3.0SP | N | Y | Y | NC | 30 MHz | 30 MHz 3500 MHz |
| Fixed LO Frequency (for modes 1.2 and 1.4) (for modes 1.7 and 1.9) | 3.1 | LF or 3.1SP | N | Y | Y | NC | 10 000 MHz | 10000 MHz 44000 MHz |
| Display User Controlled LO frequency in Measurement Modes 1.6 through 1.9 | 3.2 | UL or 3.2SP | N | N | N | OFF | OFF | OFF |
| Fixed IF for Noise Figure Test Set band 2 (SSB2) | 19.2 | S2 or 19.2SP | N | Y | Y | NC | 700 MHz | 700 MHz |
| Fixed IF for Noise Figure Test Set band 3 (SSB3) | 19.3 | S3 or 19.3SP | N | Y | Y | NC | 450 MHz | 450 MHz |
| Fixed IF for Noise Figure Test Set band 4 (DSB) | 19.4 | S4 or 19.4SP | N | Y | Y | NC | 25 MHz | 25 MHz |
| Display Noise Figure Meter input frequency. | 19.5 | S5 or 19.5SP | N | N | N | NC | NC | NC |

¹Table categories are explained in the Special Function Detailed Operation Instruction.

Example

To select a fixed IF of 70 MHz:



Fixed IF or LO Frequency Selection (cont'd)

(Special Functions 3 and 19)

Program Codes

HP-IB

The HP-IB codes for Hz and MHz are HZ and MZ, respectively. For Special Functions 3 and 19 program codes, refer to Procedure.

Indications

When Special Function 3.0, 3.1 or 19.2 through 19.4 is selected, the left display shows the current IF or LO frequency. When a new frequency value is entered, it appears in the left display only for as long as the ENTER key is depressed. When the ENTER key is released, the left display returns to the display that was present when the special function was entered.

When Special Function 19.5 is selected, the left display shows the current frequency being input to the Noise Figure Meter. The display is cleared by pressing the FREQUENCY key.

Comments

If error code E32 is displayed when attempting to enter a fixed LO frequency, the entered frequency is outside the range specified for the LO. If the entered frequency was incorrect, re-enter the correct frequency. If the LO frequencies are incorrect, they can be changed using either Special Function 42.3 or 42.4 (refer to Programming the System LO Detailed Operating Instruction).

The Hz unit, provided for HP-IB, is for programmer convenience. The instrument rounds all HP-IB tuned frequency inputs to the nearest MHz.

Related Sections

Error Messages and Recovery
Measurement Modes 1.1 through 1.9
Programming the System LO
Special Functions

HP-IB and System Interface Bus (SIB) Addresses (Special Function 40)

Description

HP-IB

There are two HP-IB and six SIB (System Interface Bus) addresses.

The two HP-IB addresses are really both addresses of the Noise Figure Meter. One address is the address of the Noise Figure Meter. The other address is called the "Pass Through Address" of the Noise Figure Meter. The "Pass Through Address" is used when an external controller on the Hewlett-Packard Interface Bus (HP-IB) wants to control a device on the System Interface Bus (SIB). The Pass Through Address is set up automatically by the Noise Figure Meter, only after Pass Through Mode has been initialized using Special Function 40.6 (or HP-IB code PT). The Pass Through Address is one greater than the Noise Figure Meter's address if it is even and is one less than the Noise Figure Meter's address if it is odd. Refer to the System Interface Bus Control Detailed Operating Instruction for more information about Pass Through Mode and the Pass Through Address.

Special Function 40.7 can be used to display the Pass Through Address.

The six SIB addresses are listed below:

- System Local Oscillator
- Noise Figure Test Set
- Plotter
- System Interface Bus
- Pass Through Device
- Pass Control

The System Local Oscillator is used with the Noise Figure Meter in Measurement Modes 1.1 through 1.4 and the Noise Figure Meter and Noise Figure Test Set in Measurement Modes 1.5 through 1.9.

The Noise Figure Test Set is configured with the Noise Figure Meter in Measurement Modes 1.5 through 1.9 to extend the frequency range of the Noise Figure Meter.

The plotter is connected to the System Interface Bus to give a permanent record of a noise figure or gain measurement.

The system interface bus address is the address of the System Interface Bus (SIB) connector on the back of the Noise Figure Meter. This address only needs to be changed if some other instrument on the System Interface Bus has to use the default address that has been set up for the System Interface Bus.

The pass through device address is used in Pass Through Mode. The pass through device address selects an instrument on the System Interface Bus that is going to be controlled by an external controller connected to the Hewlett-Packard Interface Bus (HP-IB). For more information on using Pass Through Mode and the pass through device address, refer to the System Interface Bus Control Detailed Operating Instruction.

The pass control address is the address of the controller that will alternate control responsibilities with the Noise Figure Meter. The two instruments will alternate control on the System Interface Bus. This is an advanced capability and does not need to be set under normal circumstances.

HP-IB and System Interface Bus (SIB) Addresses (cont'd)

(Special Function 40)

Description
**HP-IB
(cont'd)**

The HP-IB and SIB addresses can be displayed and changed by Special Function 40. The selected address is displayed in decimal in the left display. The decimal value of the factory set addresses are as shown below:

- Noise Figure Meter=8
- Pass Control Address=16
- System Local Oscillator=19
- Noise Figure Test Set=10
- Plotter=5
- System Interface Bus=8
- Pass Through Device (There isn't any factory set address.)

A list of allowable addresses is given below.

| ASCII Address Codes | | Decimal Equivalents |
|---------------------|------|------------------------|
| LISTEN | TALK | |
| SP | @ | 00 |
| ! | A | 01 |
| " | B | 02 |
| # | C | 03 |
| \$ | D | 04 |
| % | E | 05 |
| & | F | 06 |
| ' | G | 07 |
| (| H | 08 |
|) | I | 09 |
| * | J | 10 |
| + | K | 11 |
| , | L | 12 |
| - | M | 13 |
| . | N | 14 |
| / | O | 15 |
| 0 | P | 16 |
| 1 | Q | 17 |
| 2 | R | 18 |
| 3 | S | 19 |
| 4 | T | 20 |
| 5 | U | 21 |
| 6 | V | 22 |
| 7 | W | 23 |
| 8 | X | 24 |
| 9 | Y | 25 |
| : | Z | 26 |
| ; | [| 27 |
| < | \ | 28 |
| = |] | 29 |
| > | ^ | 30 |

HP-IB and System Interface Bus (SIB) Addresses (cont'd) (Special Function 40)


Procedure To display the current HP-IB or SIB address, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.

To change an HP-IB or SIB address, first display the current address. Then, enter a decimal number from 0 to 30 for the new address and press the ENTER key.

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|---|------|------------------------------|--|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| Noise Figure Meter HP-IB Address | 40.0 | None | N | Y | N | NC | NC | 8 |
| System LO SIB Address | 40.1 | EA or 40.1SP | N | Y | N | NC | NC | 19 |
| Noise Figure Test Set SIB Address | 40.2 | HT or 40.2SP | N | Y | N | NC | NC | 10 |
| Plotter SIB Address | 40.3 | HP or 40.3SP | N | Y | N | NC | NC | 5 |
| System Interface Bus Address | 40.4 | HS or 40.4SP | N | Y | N | NC | NC | 8 |
| Pass Control SIB Address | 40.5 | HC or 40.5SP | N | Y | N | NC | NC | 16 |
| Pass Through Device SIB Address | 40.6 | PT or 40.6SP | N | Y | N | NC | NC | NC |
| Display the Noise Figure Meter's Pass Through Address | 40.7 | VP or 40.7SP | N | N | N | NC | NC | Off |

¹Table categories are explained in the Special Function Detailed Operation Instruction.

Example To display the system LO address and change it to 20:



Program Codes
HP-IB

The program code to display the SIB address of the system LO is EA. The system LO address can be changed by entering a decimal number from 0 to 30 and then EN (the program code for ENTER). The other addresses are changed in a similar manner. The HP-IB address of the Noise Figure Meter cannot be read or changed over the HP-IB.

HP-IB and System Interface Bus (SIB) Addresses (cont'd)

(Special Function 40)

| | |
|-------------------------|--|
| Indications | The HP-IB or SIB address of the corresponding special function appears in the left display when Special Function 40 is selected. When an address is changed, the new address appears in the left display for as long as the ENTER key is depressed. When the ENTER key is released, the instrument returns to the last selected measurement. |
| Comments | Do not set the Noise Figure Meter address equal to any of the other addresses. |
| Related Sections | Controller Capability of the Noise Figure Meter Remote Operation, HP-IB Special Functions |

IF Attenuation Selection (Special Functions 70, 71, and 72)

Description

IF attenuation selection, display, and hold are available in all measurement modes. It should be noted, however, that only the hold capability (Special Function 72.0) is normally used by most operators. The hold is required during manual measurements (refer to the Manual Measurements Detailed Operating Instruction for additional information). The selection and display of specific IF attenuation settings are more likely to be used during adjustment procedures, performance tests, or troubleshooting procedures. In some specialized applications these capabilities can be helpful, but care must be exercised when using them. It is possible to introduce some very subtle errors in the measurements that the Noise Figure Meter may not be able to guard against. Additional information on how to use and interpret these Special Functions is contained in Section VIII, Service!

Procedure

To select a specific IF attenuation setting, display, or hold, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.


| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|--|------|-----------------------|--|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| IF Attenuation Selection | | | | | | | | |
| Auto | 70.0 | I0 or 70.0SP | N | N | N | On | On | On |
| 0 dB | 70.1 | I1 or 70.1SP | Y | N | N | Off | Off | Off |
| 5 dB | 70.2 | I2 or 70.2SP | Y | N | N | Off | Off | Off |
| 10 dB | 70.3 | I3 or 70.3SP | Y | N | N | Off | Off | Off |
| 15 dB | 70.4 | I4 or 70.4SP | Y | N | N | Off | Off | Off |
| 20 dB | 70.5 | I5 or 70.5SP | Y | N | N | Off | Off | Off |
| 25 dB | 70.6 | I6 or 70.6SP | Y | N | N | Off | Off | Off |
| 30 dB | 70.7 | I7 or 70.7SP | Y | N | N | Off | Off | Off |
| 35 dB | 70.8 | I8 or 70.8SP | Y | N | N | Off | Off | Off |
| Display IF Attenuator Settings | | | | | | | | |
| Display IF Attenuator | 71.0 | SI or 71.0SP | N | N | N | Off | Off | Off |
| IF Attenuator Hold | | | | | | | | |
| IF Attenuator Hold | 72.0 | IH or 72.0SP | Y | N | N | Off | Off | Off |
| ¹ Table categories are explained in the Special Functions Detailed Operating Instruction. | | | | | | | | |

¹ Section VIII, Service, is in the Service Manual. The part number of the Service Manual is on the title page of this manual.

IF Attenuation Selection (cont'd)

(Special Functions 70, 71, and 72)

Example To select the IF attenuator hold function:



Program Codes



For HP-IB codes, refer to Procedure.

Indications

When Special Function 71 is implemented, three digits appear in the left display. The digits are either "1" (yes) or "0" (no) to indicate whether or not the corresponding attenuator is switched into the 20 MHz IF Assembly circuits (see Service Sheets 3 and 4 in Section VIII, Service¹). The first (most significant) digit represents 20 dB. The second digit represents 10 dB. The third (least significant) digit represents 5 dB. To obtain the IF attenuator setting, add the attenuation that is represented by each digit. For example, a display of "1 0 1" indicates an IF attenuator setting of 25 dB.

The following table lists the IF attenuation available (Special Function 70.1 through 70.8) and the ones (1) and zeros (0) that are displayed using Special Function 71.0.

| Attenuation (dB) | Special Function | Attenuator | | |
|------------------|------------------|------------|-------|------|
| | | 20 dB | 10 dB | 5 dB |
| 0 | 70.1 | 0 | 0 | 0 |
| 5 | 70.2 | 0 | 0 | 1 |
| 10 | 70.3 | 0 | 1 | 0 |
| 15 | 70.4 | 0 | 1 | 1 |
| 20 | 70.5 | 1 | 0 | 0 |
| 25 | 70.6 | 1 | 0 | 1 |
| 30 | 70.7 | 1 | 1 | 0 |
| 35 | 70.8 | 1 | 1 | 1 |

Comments

If any of the 60 or 70 series of Special Functions (except 60.0 and 70.0) are active, the calibration sequence does not override them. Therefore, to calibrate on one range only, use any of these Special Functions except 60.0 or 70.0. It is also true that if any of these Special Functions are inadvertently active, the calibration sequence will not cover the expected gain range.

Related Sections

- Calibrate
- Manual Measurements
- RF Attenuation Selection
- Special Functions

¹ Section VIII, Service, is in the Service Manual. The part number of the Service Manual is on the title page of this manual.

Loss Compensation (Special Function 34)

Description

Special Function 34 corrects for loss between the noise source and the device under test (DUT), and the DUT and the Noise Figure Meter. The loss in dB and the temperature of the loss must be entered prior to enabling loss compensation (Special Function 34.1) or else the default values of 0 dB and 0K are used.

The temperature of the loss is the ambient temperature. Therefore, both the loss before the DUT and the loss after the DUT are assumed to be at the same temperature. Only one temperature can be entered for both losses. The temperature of the loss can be entered in Kelvins, degrees Fahrenheit, or degrees Celsius. Temperature units are selected by Special Function 11.

The allowable range of loss in Kelvins is 0 to 9999. The allowable range of loss in dB is -100 to +100.

Procedure

To display, enter, or enable loss compensation, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.


| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|--|------|-----------------------|--|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| Turn loss compensation off. | 34.0 | LO or 34.0SP | N | Y | N | On | On | On |
| Turn loss compensation on. | 34.1 | L1 or 34.1SP | Y | Y | N | Off | Off | Off |
| Display and enter the amount of loss between the noise source and the DUT in dB. | 34.2 | LA or 34.2SP | N | Y | N | NC | 0 dB | 0 dB |
| Display and enter the temperature of losses (units are determined by Special Function 11). | 34.3 | LT or 34.3SP | N | Y | N | NC | 0K | 0K |
| Display and enter the amount of loss between the DUT and the Noise Figure Meter in dB. | 34.4 | LB or 34.4SP | N | Y | N | NC | 0 dB | 0 dB |

¹Table categories are explained in the Special Functions Detailed Operating Instruction.

Loss Compensation (cont'd) (Special Function 34)

Example

To compensate for a loss of 3 dB between the noise source and the DUT at a temperature of 290K (assume Special Function 11.0 is active — temperature in K) and to enable the loss compensation function:



Program Codes



For HP-IB codes, refer to Procedure above.

Indications

If Special Function 34.0 or 34.1 is selected, the left display returns to the previously selected display. The INSERTION GAIN and NOISE FIGURE displays are not affected by this function.

Comments

When a loss compensation entry is made in dB, the temperature of the loss should also be entered.

The Noise Figure Meter assumes that the loss was not present during calibration.

If a 2 dB attenuator is being used in the measurement, 2 dB would be entered as the loss. There is no need to characterize the device.

Related Sections

Special Functions
Temperature Units Selection

Manual Measurement Functions (Special Functions 14 and 15)

Description

The manual measurement functions calibrate and measure noise figure using a thermal (hot/cold) noise source. They also can be used to display either the current measurement or the result of the manual measurement. Manual measurement functions are used for fixed frequency measurements only.

Three general requirements must be understood when performing manual measurements:

1. A stable reading must be stored in the Noise Figure Meter's memory prior to disconnecting the noise source. This stable reading can be obtained by either activating the next manual measurement special function or by using the Trigger Selection Special Function (30). Since activating the next special function requires fewer keystrokes, that is the method used in the example shown in this instruction.
2. The device under test (DUT) must first be connected to the measurement system and the proper RF attenuation level determined. The RF attenuators must then be held fixed (Special Function 62) for the entire manual measurement.
3. The IF attenuators must be held fixed (Special Function 72) during the two measurement readings (noise source off and on) and again during the two calibration readings (noise source off and on). However, the IF attenuators must be allowed to autorange when switching between calibration and measurements, and vice versa.

Procedure

To measure, calibrate, or display manual measurements, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|--|------|-----------------------|--|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| Make cold measurements (source off) | 14.1 | MC or 14.1SP | N | Y | Y | Off | Off | Off |
| Make hot measurements (source on). | 14.2 | MH or 14.2SP | N | Y | Y | Off | Off | Off |
| Perform cold calibration (source off). | 14.3 | CC or 14.3SP | N | Y | Y | Off | Off | Off |
| Perform hot calibration (source on). | 14.4 | CH or 14.4SP | N | Y | Y | Off | Off | Off |
| Normal display mode. | 15.0 | P0 or 15.0SP | N | N | Y | On | On | On |
| Display manual measurement results. | 15.1 | P1 or 15.1SP | Y | N | Y | Off | Off | Off |

¹Table categories are explained in the Special Functions Detailed Operating Instruction.

Manual Measurement Functions (cont'd)

(Special Functions 14 and 15)

Example

The following example is a general procedure for making manual measurements. It may be necessary to determine the requirements of a specific application and make the necessary changes to obtain the best measurement results. For example, it is possible to make manual measurements using an external controller. Additional information on this method is contained in the Comments section of this instruction.

Find and Hold the RF Attenuation

- a. Enter the required parameters for the Measurement Mode that is going to be used.
- b. Connect the hot noise source to the DUT input. Connect the DUT output to the measurement system setup.
- c. Press 1 4 . 2 SPECIAL FUNCTION to obtain the noise power.
- d. Press 6 2 . 0 SPECIAL FUNCTION to hold the RF attenuation setting. The RF attenuation is held at this setting for the entire measurement.

Calibrate

- e. Remove the DUT and connect the hot noise source to the measurement system setup.
- f. Press 1 4 . 4 SPECIAL FUNCTION to calibrate the measurement system for the hot noise source.
- g. Press 7 2 . 0 SPECIAL FUNCTION to hold the IF attenuation setting.
- h. Press 1 4 . 3 SPECIAL FUNCTION to store the hot noise source calibration reading and to select the cold noise source calibration. Note that while the cold noise source calibration is selected, the results are not stored until after the cold noise source is connected and Special Function 14.2 is activated in step j.
- i. Remove the hot noise source and connect the cold noise source to the measurement system setup.
- j. Press 1 4 . 2 SPECIAL FUNCTION to select the hot noise source measurement and to store the cold noise source calibration reading.

Measure, then Calculate and Display Noise Figure

- k. Connect the hot noise source to the DUT and the DUT to the measurement system setup.
- l. Press 7 0 . 0 SPECIAL FUNCTION to allow the IF attenuators to autorange.
- m. Press 7 2 . 0 SPECIAL FUNCTION to hold the IF attenuation fixed at the new value.
- n. Press 1 4 . 1 SPECIAL FUNCTION to select the cold noise source measurement and to store the hot noise measurement reading.
- o. Disconnect the hot noise source from the DUT and connect the cold noise source to the DUT.

Manual Measurement Functions (cont'd)

(Special Functions 14 and 15)

Example (cont'd)

p. Press 15.1 SPECIAL FUNCTION to calculate and display the manual measurement noise figure result. Verify that the LED in the SPECIAL FUNCTION key lights when this special function is activated. The Noise Figure Meter continues to make cold noise source measurements and update the display.

NOTE

The calibration data remains stored. Therefore, if another DUT is to be tested immediately, it is only necessary to press 14.2 SPECIAL FUNCTION and repeat steps k through p. To exit manual measurements and return to the normal display, press 15.0 SPECIAL FUNCTION and then press UNCORRECTED NOISE FIGURE.

Program Codes

▶ HP-IB ◀

For HP-IB codes, refer to Procedure above.

Indications

When Special Functions 15.0 and any 14.N are selected, no unit annunciators are lit in the NOISE FIGURE display. The number displayed is the power into the detector in mW.

Comments

When Special Function 15.1 is selected, UNCORRECTED NOISE FIGURE, CORRECTED NOISE FIGURE AND GAIN, or any noise figure display unit (Special Function 10) can be selected.

Another way to ensure that stable readings are stored in the Noise Figure Meter's memory during Manual Measurements is to use the Trigger Hold Special Function (30.1) and Trigger Execute Special Function (30.2). In this type of operation only one measurement is taken and stored. Therefore, it is not critical if the equipment is disconnected prior to switching Manual Measurement Special Functions.

Related Sections

IF Attenuation Selection
RF Attenuation Selection
Special Functions
Trigger Selection

Measurement Modes

(Special Function 1)

Description

The Noise Figure Meter has ten Measurement Modes available. Each Measurement Mode, 1.0 through 1.9, is described individually in a separate Detailed Operating Instruction. This discussion covers the capabilities and differences of the individual modes. The following table lists the modes and shows their status in different instrument operations.

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Con- tinuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|--|------|-----------------------|---|----------------------------------|-------------------------------|------------------------------------|--|------------------------------------|
| Description | Code | | | | | | | |
| Measurement Mode 1.0—10 to 1600 MHz | 1.0 | E0 | N | Y | Y | On | On | On |
| Measurement Mode 1.1—variable frequency system LO; fixed IF | 1.1 | E1 | N | Y | Y | Off | Off | Off |
| Measurement Mode 1.2—fixed frequency system LO; variable IF; SSB | 1.2 | E2 | N | Y | Y | Off | Off | Off |
| Measurement Mode 1.3—variable frequency system LO; fixed IF; mixer in DUT | 1.3 | E3 | N | Y | Y | Off | Off | Off |
| Measurement Mode 1.4—fixed frequency system LO; variable IF; mixer in DUT | 1.4 | E4 | N | Y | Y | Off | Off | Off |
| Measurement Mode 1.5—10 to 18000 MHz | 1.5 | E5 | N | Y | Y | Off | Off | Off |
| Measurement Mode 1.6—variable frequency user controlled LO; fixed IF | 1.6 | E6 | N | Y | Y | Off | Off | Off |
| Measurement Mode 1.7—fixed frequency user controlled LO; variable IF; SSB | 1.7 | E7 | N | Y | Y | Off | Off | Off |
| Measurement Mode 1.8—variable frequency user controlled LO; fixed IF; mixer in DUT | 1.8 | E8 | N | Y | Y | Off | Off | Off |
| Measurement Mode 1.9—fixed frequency user controlled LO; variable IF; mixer in DUT | 1.9 | E9 | N | Y | Y | Off | Off | Off |

¹Table categories are explained in the Special Functions Detailed Operating Instruction.

Measurement Modes (cont'd)

(Special Function 1)

Description (cont'd)

The following definitions will be helpful when using the different Measurement Modes:

System Local Oscillator—The System Local Oscillator is used in Measurement Modes 1.1 through 1.9, is connected to the SYSTEM INTERFACE BUS connector and is controlled by the Noise Figure Meter. The System Local Oscillator is used for frequency conversion in Measurement Modes 1.1 through 1.4 and is part of the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and System Local Oscillator) in Measurement Modes 1.5 through 1.9.

User Controlled Local Oscillator—The User Controlled Local Oscillator is ONLY used in Measurement Modes 1.6 through 1.9. The User Controlled Local Oscillator is used for frequency conversion. This LO must be controlled by the user; the Noise Figure Meter doesn't control the User Controlled Local Oscillator. The User Controlled Local Oscillator is never connected to the SYSTEM INTERFACE BUS connector.

The ten Measurement Modes can be divided into the following three subsets:

a. Measurement Mode 1.0 is a stand alone mode with no external mixer or system local oscillator required and no frequency conversion in the device under test. The frequency range in this mode is 10 to 1600 MHz.

Measurement Mode 1.5 is similar to Measurement Mode 1.0. Measurement Mode 1.5 requires the use of the HP 8971B Noise Figure Test Set and a system local oscillator. The Noise Figure Meter, Noise Figure Test Set and system local oscillator form the HP 8970S Noise Figure Measurement System. The Noise Figure Meter controls the Noise Figure Test Set and the system local oscillator. This mode does not require the use of an external mixer (that is, external to the system) or second local oscillator. There is no frequency conversion in the device under test. The frequency range in this mode is 10 to 18000 MHz.

b. Measurement Modes 1.1 and 1.3 both require a variable frequency system local oscillator and an external mixer. Measurement Modes 1.6 and 1.8 both require the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and system local oscillator), external mixer and user controlled local oscillator. The Noise Figure Meter can be used to control the system local oscillator (Measurement Modes 1.1 and 1.3) and is used to control the Noise Figure Measurement System (Measurement Modes 1.6 and 1.8). The Noise Figure Meter controls the system local oscillator as directed by the system local oscillator program (Special Function 41 or 42). Measurement Modes 1.1 and 1.3 down convert the measurement frequency to 10 to 1600 MHz. Measurement Modes 1.6 and 1.8 down convert the measurement frequency to 10 to 18000 MHz. Measurement Modes 1.1 and 1.6 have no down conversion in the Device Under Test (DUT; for example, an amplifier or transistor). Measurement Modes 1.3 and 1.8 do provide for down conversion in the DUT (for example, a mixer or receiver).

c. Measurement Modes 1.2 and 1.4 require a fixed frequency system local oscillator and an external mixer. Measurement Modes 1.7 and 1.9 require the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and system local oscillator), an external mixer and fixed user controlled local oscillator. The Noise Figure Meter can be used to control the system local oscillator (Measurement Modes 1.2 and 1.4) and is used to control the Noise Figure Measurement System (Measurement Modes 1.7 and 1.9). The Noise Figure Meter controls the system local oscillator as

Measurement Modes (cont'd)

(Special Function 1)

Description (cont'd)

directed by the system local oscillator program (Special Function 41 or 42). Measurement Modes 1.2 and 1.4 down convert the measurement frequency to 10 to 1600 MHz. Measurement Modes 1.7 and 1.9 down convert the measurement frequency to 10 to 18000 MHz. Measurement Modes 1.2 and 1.7 have no down conversion in the DUT (for example, an amplifier or transistor). Measurement Modes 1.4 and 1.9 do provide for down conversion in the DUT (for example, a mixer or receiver). Modes 1.2 and 1.7 must be a single sideband measurement. Additional information on sideband selection is covered later in this instruction and in the Sideband Selection Detailed Operating Instruction.

For a summary of the ten Measurement Modes, refer to the Measurement Modes Summary table.

The calibration and measurement setups and procedures are illustrated and specific examples are provided in the Detailed Operating Instructions for Measurement Modes 1.0 through 1.9.

Signal Comparison

In the following discussion, signals present at different points in the measurement system are compared for the different measurement modes. The following signal points are covered:

- a. The output of the noise source (for example the HP 346B).
- b. The output of the system LO (Measurement Modes 1.1—1.4) and the user controlled LO (Measurement Modes 1.6—1.9).
- c. The measurement bandwidth of the Noise Figure Meter (Noise Figure Measurement System) as seen looking back into the mixer (translated to the frequency range of the system LO (Measurement Modes 1.1—1.4) and user controlled LO (Measurement Modes 1.6—1.9)).
- d. The input to the Noise Figure Meter (Noise Figure Test Set).

The noise source output is the same for all modes. For a noise source with a nominal Excess Noise Ratio (ENR) of 15.2 dB, the output is broadband random noise varying between approximately -158.8 dBm/Hz when on (hot) and -174 dBm/Hz when off (cold). The ENR of the noise source varies slightly over the frequency range of 10 to 18000 MHz. This variation in power level is compensated for in the Noise Figure Meter using the specific information entered into the ENR tables. Refer to the ENR Table Entry Detailed Operating Instruction for additional information on the ENR tables.

There is no system local oscillator used in Measurement Mode 1.0. The user controlled local oscillator is not used in Measurement Mode 1.5. In Measurement Modes 1.1 and 1.3, the system local oscillator can be swept over any range within a 2000 to 18000 MHz bandwidth. The system local oscillator is controlled by the existing system local oscillator programs, in the Noise Figure Meter. The system local oscillator programs can be modified to sweep the system local oscillator up to 99999 MHz. In Measurement Modes 1.6 and 1.8, the user controlled local oscillator can be swept over any range necessary, needed for a measurement. The user controlled local oscillator is controlled by the user and not by the Noise Figure Meter. The frequency that the user controlled local oscillator needs to be set to can be displayed using Special Function 3.2. In

Measurement Modes Summary

| Measurement Mode | Type of Measurement | Measurement Frequencies | Frequency Conversion in DUT? | System LO Required? | User-Controlled LO Required? | IF into NF Meter (Modes 1.1-1.4) or IF into NF Test Set (Modes 1.6-1.9) | Sideband Selection ¹ |
|------------------|---------------------------|----------------------------------|------------------------------|---|---|---|--|
| 1.0 | RF Amplifier | 10-1600 MHz | No | No | No | N/A ² | N/A ² |
| 1.1 | Microwave Amplifier | >1600 MHz | No | Yes-Variable frequency | No | Fixed IF into NF Meter set with Special Function 3.0. | Sideband selection is required only if NF Meter controls System LO. |
| 1.2 | Microwave Amplifier | >1600 MHz | No | Yes-Fixed frequency set with Special Function 3.1 | No | Variable IF into NF Meter | Double sideband is not allowed. Sideband selection is required to calculate IF. |
| 1.3 | Mixer/ Receiver | IF=10-1600 MHz | Yes | Mixer-Yes, variable frequency; Receiver-No | No | Fixed IF into NF Meter set with Special Function 3.0. | Sideband selection is required only if NF Meter controls System LO. |
| 1.4 | Mixer/ Receiver | IF=10-1600 MHz | Yes | Mixer-Yes, fixed frequency set with Special Function 3.1; Receiver-No | No | Variable IF into NF Meter | Sideband selection is required to calculate measurement frequency. |
| 1.5 | RF or Microwave Amplifier | 10-18000 MHz | No | Yes | No | N/A ² | N/A ² |
| 1.6 | Millimeter-Wave Amplifier | >18000 MHz and IF=1601-18000 MHz | No | Yes | Yes-Variable frequency | Fixed IF into NF Test Set set with Special Function 3.0. | No sideband selection is required unless Special Function 3.2 is used to find user LO frequency. |
| 1.7 | Millimeter-Wave Amplifier | >18000 MHz and IF > 1600 MHz | No | Yes | Yes-Fixed frequency set with Special Function 3.1. | Variable IF into NF Test Set | Double sideband is not allowed. Sideband selection is required to calculate IF. |
| 1.8 | Mixer/ Receiver | IF=1601-18000 MHz | Yes | Yes | Mixer-Yes, variable frequency; Receiver-No | Fixed IF into NF Test Set set with Special Function 3.0. | No sideband selection is required unless Special Function 3.2 is used to find user LO frequency. |
| 1.9 | Mixer/ Receiver | IF>16000 MHz | Yes | Yes | Mixer-Yes, fixed frequency set with Special Function 3.1; Receiver-No | Variable IF into NF Test Set | Sideband selection is required to calculate correct measurement signal or user LO frequency when Special Function 3.2 is used. |

¹ Double sideband = Special Function 2.0.
 Lower single sideband (measurement frequency < LO frequency) = Special Function 2.1.
 Upper single sideband (measurement frequency > LO frequency) = Special Function 2.2.
 Single sideband signal up conversion (IF = measurement frequency + LO frequency) = Special Function 2.3.
 An external filter is required for single sideband measurements.

² N/A = Not Applicable

Measurement Modes (cont'd) (Special Function 1)

Signal Comparison (cont'd)

Measurement Modes 1.2 and 1.4, the fixed system local oscillator frequency can be set to any point within the 10 to 99999 MHz range. In Measurement Modes 1.7 and 1.9, the fixed user controlled local oscillator frequency can be set to any point, necessary. The limiting factors within each range are the frequency range of the local oscillator and the noise source.


There is no mixer used in Measurement Modes 1.0 and 1.5. Looking back into the mixer in Measurement Modes 1.1, 1.3, 1.6 and 1.8, the Noise Figure Meter passband translates into two sidebands. Each sideband is separated from the local oscillator frequency by a fixed IF (the receiving frequency of the Noise Figure Meter or Noise Figure Test Set). As the local oscillator sweeps, the sidebands move with it. The frequency can be increased or decreased within the allowable frequency range. In Measurement Modes 1.2, 1.4, 1.7 and 1.9, the local oscillator frequency is held fixed. As the variable IF sweeps, the sidebands move away from the system local oscillator frequency in opposite directions for an increasing IF sweep and toward the local oscillator frequency for a decreasing IF sweep. Examples of both a fixed IF and a variable local oscillator, and a variable IF and fixed local oscillator are shown in the Noise Figure Meter Measurement Passband figure.

The Noise Figure Meter's input frequency range is 10 to 1600 MHz. In Measurement Mode 1.0 a swept measurement can sweep the Noise Figure Meter's 4 MHz passband over the 10 to 1600 MHz range. The Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and system local oscillator) has a frequency range of 10 to 18000 MHz. In Measurement Mode 1.5 a swept measurement can sweep the Noise Figure Measurement System's 4 MHz passband over the 10 to 18000 MHz range. In Modes 1.1, 1.3, 1.6 and 1.8, the IF is fixed and the local oscillator frequency is swept within the frequency ranges previously explained. In Modes 1.2, 1.4, 1.7 and 1.9, the local oscillator frequency is fixed and the IF is swept across the 10 to 1600 MHz (10 to 18000 MHz) range. In Modes 1.1, 1.3, 1.4, 1.6, 1.8 and 1.9 either upper, lower, sum or both sidebands can be accepted by the Noise Figure Meter (Noise Figure Measurement System). However, in Modes 1.2 and 1.7, a double sideband measurement cannot be made (the Noise Figure Meter will display error E34). In these modes, a double sideband measurement does not make sense since the IF sweeps and the sidebands get further and further apart. Suppose the IF is at 1000 MHz, in this condition the average between the two 4 MHz passbands, that are 2000 MHz apart, might easily be useless data.


Indications

The frequencies displayed in the left display for various measurement conditions are shown in the following table. The displayed frequency depends upon the measurement mode used and the sideband selected (Special Function 2). In Measurement Mode 1.0 and 1.5, no external conversion is performed so the left display represents the measurement signal (F_{signal}). In Measurement Modes 1.1 through 1.4 and 1.6 through 1.9 conversion is performed, thus creating an external IF. The Noise Figure Meter (Noise Figure Measurement System) is tuned to this IF while the system (user controlled) local oscillator is tuned to F_{LO} .

For Measurement Modes 1.1, 1.3, 1.6 and 1.8:



For Measurement Modes 1.2, 1.4, 1.7 and 1.9:



Noise Figure Meter Measurement Passband

Measurement Modes (cont'd)

(Special Function 1)

Indications

Noise Figure Meter Left Display

| Selected Sideband | Measurement Mode | | | | |
|-------------------------------|---------------------|-----------------------------|-----------------------------|-----------------------------|-------------|
| | 1.0 and 1.5 | 1.1 and 1.6 | 1.2 and 1.7 | 1.3 and 1.8 | 1.4 and 1.9 |
| Double Sideband (2.0SP) | F_{signal} | F_{LO} | not allowed | F_{LO} | IF |
| Lower Single Sideband (2.1SP) | F_{signal} | $F_{\text{LO}} - \text{IF}$ | $F_{\text{LO}} - \text{IF}$ | $F_{\text{LO}} - \text{IF}$ | IF |
| Upper Single Sideband (2.2SP) | F_{signal} | $F_{\text{LO}} + \text{IF}$ | $F_{\text{LO}} + \text{IF}$ | $F_{\text{LO}} + \text{IF}$ | IF |
| Sum (up conversion; 2.3SP) | F_{signal} | $\text{IF} - F_{\text{LO}}$ | $\text{IF} - F_{\text{LO}}$ | $\text{IF} - F_{\text{LO}}$ | IF |

Measurement Mode and Sideband Selection

Prior to making any measurement, the Measurement Mode and sideband operation that are best suited to that specific measurement must be chosen.

Each of the Detailed Operating Instructions for Measurement Modes 1.0 through 1.9 has valid examples of the type of measurements that are made in each mode.

Related Sections

Calibrate
ENR Table Entry
Fixed IF or LO Frequency Selection
Measurement Modes 1.0 through 1.9
Sideband Selection

Measurement Mode 1.0

(Special Function 1.0)

Description

Measurement Mode 1.0 provides direct noise figure and gain measurements in the frequency range of 10 to 1600 MHz. No external mixer or LO is required. All of the Measurement Modes can be set up to use many of the other capabilities of the Noise Figure Meter. For example, each mode can make either UNCORRECTED NOISE FIGURE or CORRECTED NOISE FIGURE AND GAIN measurements. In addition, the measurement results for each mode can be displayed on an oscilloscope or output to a recorder or plotter. For an explanation and comparison of the ten Measurement Modes and instructions on how to choose the appropriate Measurement Mode and sideband operation, refer to the Measurement Modes Detailed Operating Instruction.

Procedure

There are many possible measurement procedures. However, the following general procedure applies to all cases:

NOTE

High measurement system noise figure leads to high measurement uncertainty, when measuring low gain devices. A low noise preamplifier, between the device under test and the measurement system, can lower system noise figure, and therefore reduce the measurement uncertainty. For more information on determining if a preamplifier is needed and selection of the preamplifier, refer to the Preamplifier Selection Detailed Operating Instruction.

- a. Set frequency parameters.
- b. Calibrate in Mode 1.0 (this is only required for a CORRECTED NOISE FIGURE AND GAIN measurement).
- c. Insert DUT and measure.

Example

To make a swept CORRECTED NOISE FIGURE AND GAIN measurement in the 100 to 150 MHz range in 1 MHz steps:

- a. Press PRESET (or send HP-IB code PR) to establish initial conditions. This sets the Noise Figure Meter to Measurement Mode 1.0.
- b. Set the frequency parameters for both the calibration and measurement.
- c. Enter actual ENR for the Noise Source, if this has not previously been done.

Measurement Mode 1.0 (cont'd)

(Special Function 1.0)

Program Codes

The HP-IB code for Measurement Mode 1.0 is E0 (or 1.0SP).

HP-IB**Indications**

The left display shows each frequency at which a measurement is made. The INSERTION GAIN display shows the gain of the DUT at the displayed frequency. The NOISE FIGURE display shows the noise figure of the DUT at the displayed frequency.

Comments

Measurement Mode 1.0 is often referred to as an RF measurement. The other nine Measurement Modes are often referred to as microwave measurements.

Related Sections

Calibrate
Measurement Modes
Special Functions

Measurement Mode 1.1

(Special Function 1.1)

Description

Measurement Mode 1.1 provides a means of controlling a system LO to obtain a measurement frequency higher than 1600 MHz. This mode allows for frequency conversion in the measurement system but not in the device under test (DUT). Although the signal measured at the Noise Figure Meter INPUT is always in the range of 10 to 1600 MHz, the Noise Figure Meter uses the Excess Noise Ratio (ENR) of the noise source at the measurement frequency. A typical DUT is an amplifier or transistor. An LO and a mixer are required. All of the Measurement Modes can be set up to use many of the other capabilities of the Noise Figure Meter. For example, each mode can make either UNCORRECTED NOISE FIGURE or CORRECTED NOISE FIGURE AND GAIN measurements, plus the measurement results for each mode can be displayed on an oscilloscope and output to a recorder or plotter. For an explanation and comparison of the ten Measurement Modes and instructions on how to choose the appropriate Measurement Mode and sideband operation, refer to the Measurement Modes Detailed Operating Instruction.

Requirements

The following minimum requirements are necessary for the Noise Figure Meter to act as a controller in Measurement Mode 1.1:

- a. Connect the system local oscillator to the Noise Figure Meter's SYSTEM INTERFACE BUS connector with an HP-IB cable.
- b. Special Function 48.0 active (Noise Figure Meter is the controller on System Interface Bus; Special Function 48.0 is the default setting, after using Special Function 0.9).
- c. Special Function 46.0 active (Enable system local oscillator on the System Interface Bus; Special Function 46.0 is the default setting, after using Special Function 0.9).
- d. The address of the system LO must match the system LO address that is stored in the Noise Figure Meter. Use Special Function 40.1 (system LO address) to display and change this address if necessary. The default address is 19, after using Special Function 0.9.
- e. The correct system local oscillator program must be active if the Noise Figure Meter is going to control the system local oscillator. The system local oscillator programs are listed below:
 - HP 8350B Sweep Oscillator; Special Function 41.0
 - HP 8671B/8672A Synthesized Signal Generators; Special Function 41.2
 - HP 8673B/C Synthesized Signal Generator; Special Function 41.3
 - HP 8340B/8341B Sweep Oscillator; Special Function 41.4
 - custom local oscillator; Special Function 41.5

The custom local oscillator program will support local oscillators that may require a maximum of twenty-two characters for the frequency prefix and suffix and/or the output power prefix and suffix. The prefix and suffix define the command sequence that will set the frequency or output power.

Measurement Mode 1.1 (cont'd) (Special Function 1.1)

Requirements (cont'd) Use Special Function 42 to define a new program for other system local oscillators.

Procedure There are many possible measurement procedures. However, the following general procedure applies to all cases:

NOTE

High measurement system noise figure leads to high measurement uncertainty, when measuring low gain devices. A low noise preamplifier, between the device under test and the measurement system, can lower system noise figure and therefore reduce the measurement uncertainty. For more information on determining if a preamplifier is needed and selection of the preamplifier, refer to the Preamplifier Selection Detailed Operating Instruction.

- a. Verify that the minimum requirements specified under Requirements are satisfied.
- b. Press 1 . 1 SPECIAL FUNCTION to set the Noise Figure Meter to Measurement Mode 1.1.
- c. Set frequency parameters (including the fixed IF, Special Function 3.0).
- d. Calibrate in Mode 1.1. If a preamplifier will be used in the measurement, the preamplifier must be used during the calibration.
- e. Insert DUT and measure.

Example To make a swept double sideband CORRECTED NOISE FIGURE AND GAIN measurement in the 6 to 12 GHz range in 200 MHz steps with a fixed IF of 70 MHz:

NOTE

This example assumes that the Noise Figure Meter is acting as a controller on the System Interface Bus and the minimum requirements specified under Requirements are satisfied. Refer to Comments for a brief description of using an external controller when in Measurement Mode 1.1.

- a. Press PRESET to establish initial conditions.


NOTE

Measurement Mode 1.1 must be activated prior to entering the frequency parameters to avoid error E35 (entered value is out of range).


- b. Press 1 . 1 SPECIAL FUNCTION to activate Measurement Mode 1.1.
- c. Set the frequency parameters for both the calibration and measurement.
- d. Enter actual ENR for the Noise Source, if this has not previously been done.

Measurement Mode 1.1 (cont'd) (Special Function 1.1)

**Example
(cont'd)**




e. To calibrate the Noise Figure Meter, set up the equipment as shown below.



• IF THE PREAMPLIFIER IS USED DURING THE MEASUREMENT, IT MUST BE USED DURING CALIBRATION.

f. Calibrate the equipment in Measurement Mode 1.1 by pressing CALIBRATE twice.

g. To make the measurement, set up the equipment as shown below.



Measurement Mode 1.1 (cont'd)

(Special Function 1.1)

Example (cont'd)

- h. Press CORRECTED NOISE FIGURE AND GAIN.
- i. Press SINGLE. The Noise Figure Meter will sweep the system LO from 6 GHz to 12 GHz in 200 MHz steps and halt.

Program Codes

HP-IB

The HP-IB code for Measurement Mode 1.1 is E1 (or 1.1SP). Refer to Comments for additional information on using HP-IB program codes in Measurement Mode 1.1.

Indications

The left display shows each frequency at which a measurement is made and the EXT MIX annunciator lights. The INSERTION GAIN display shows the gain of the DUT at the displayed frequency. The NOISE FIGURE display shows the noise figure of the DUT at the displayed frequency.

Comments

An external controller can be used in place of the Noise Figure Meter to control the system LO and the Noise Figure Meter in Measurement Mode 1.1. The following general conditions must be observed when using an external controller:

- a. Connect the system local oscillator and the external controller to the HP-IB connector on the Noise Figure Meter.
- b. HP-IB code H1 must be active.
- c. Special Function 46.1 must be active.
- d. Special Function 4.0 (normal talker and listener) must be active. Note that there is no HP-IB code for this special function.
- e. Special Function 30.1 (trigger hold) must be active (HP-IB code is T1).
- f. The correct measurement parameters (for example, Measurement Mode, frequencies, etc.) must be established. Refer to Table 3-9, Special Function to HP-IB Code Summary, and Table 3-10, Front Panel Keys to HP-IB Code Summary, for applicable HP-IB codes.
- g. Perform a triggered calibration with the DUT out of the measurement system (refer to the Calibrate Detailed Operating Instruction).
- h. Set the Noise Figure Meter's calibrate function on (HP-IB code is CA).
- i. Set the system LO to the appropriate frequency. Refer to the LO's operating manual for the required HP-IB codes. Allow sufficient settling time for the output of the LO to stabilize.
- j. Trigger a measurement using the HP-IB code T2. Do not use the alternate HP-IB code 30.2SP for it will be ignored.
- k. A method must be determined when to step to a new frequency and read the noise figure results. This read operation cannot be completed until the new data is ready. It is possible to write an SRQ interrupt routine on the Data Ready status bit. Refer to Enabling the Service Request Condition, paragraph 3-30.

Measurement Mode 1.1 (cont'd)

(Special Function 1.1)

Comments (cont'd)

l. Continue to loop through steps i, j and k. A method for determining when the calibration is completed must be programmed into the external controller. One method is to compare the frequency that is sent to the system LO with the stop frequency programmed into the Noise Figure Meter and terminate the program after the third measurement in which they are equal. It is also possible to write an SRQ interrupt routine on the Calibration Complete SRQ. Refer to Enabling the Service Request Condition, paragraph 3-30.

m. Insert the DUT into the measurement system.

n. Set the Noise Figure Meter's SINGLE sweep on (HP-IB code is W2) or AUTO sweep on (HP-IB code is W1).

o. Set the system LO to the appropriate frequency. Refer to the LO's operating manual for the required HP-IB codes. Allow sufficient time for the output of the LO to stabilize.

p. Trigger a measurement using the HP-IB code T2. Do not use the alternate HP-IB code 30.2SP for Special Function 30.2 as it will reset the sweep.

q. A method must be determined when to step to a new frequency and read the noise figure results. This read operation cannot be completed until the new data is ready. It is possible to write an SRQ interrupt routine on the Data Ready SRQ. Refer to Enabling the Service Request Condition, paragraph 3-30.

r. Continue to loop through steps o, p, and q. A method for determining when the measurements are complete must be programmed into the external controller. One method is to compare the frequency that was read from the Noise Figure Meter with the stop frequency programmed into the Noise Figure Meter and terminate the program after the measurement in which they are equal.

External filtering is necessary for single sideband measurements using Special Functions 2.1 through 2.3.

Related Sections

Calibrate
Controller Capability of the Noise Figure Meter
Fixed IF or LO Frequency Selection
Measurement Modes
Sideband Selection
Special Functions
Trigger Selection

Measurement Mode 1.2

(Special Function 1.2)

Description

Measurement Mode 1.2 provides a means of using a fixed-frequency system LO with a variable IF in order to measure over a band of frequencies less than 1600 MHz wide. This mode allows for frequency conversion in the measurement system but not in the device under test (DUT). Single sideband operation and external filtering of the unwanted sideband are required. A typical DUT is an amplifier with a bandwidth of less than 1600 MHz. The system LO, an external filter and a mixer are required. Although the signal measured at the Noise Figure Meter INPUT is always in the range of 10 to 1600 MHz, the Noise Figure Meter uses the Excess Noise Ratio (ENR) of the noise source at the measurement frequency. All of the Measurement Modes can be set up to use many of the other capabilities of the Noise Figure Meter. For example, each mode can make either UNCORRECTED NOISE FIGURE or CORRECTED NOISE FIGURE AND GAIN measurements. Or, the measurement results for each mode can be displayed on an oscilloscope and output to a recorder or plotter. For an explanation and comparison of the ten Measurement Modes and instructions on how to choose the appropriate Measurement Mode and sideband operation, refer to the Measurement Modes Detailed Operating Instruction.

Requirements

The following minimum requirements are necessary for the Noise Figure Meter to act as a controller in Measurement Mode 1.2:

- a. The system local oscillator is connected to the Noise Figure Meter's SYSTEM INTERFACE BUS connector with an HP-IB cable.
- b. Special Function 48.0 active (Noise Figure Meter is controller on System Interface Bus; Special Function 48.0 is the default setting, after using Special Function 0.9).
- c. Special Function 46.0 active (Enable local oscillator on System Interface Bus; Special Function 46.0 is the default setting, after using Special Function 0.9).
- d. The address of the system local oscillator must match the system local oscillator address that is stored in the Noise Figure Meter. Use Special Function 40.1 (system local oscillator address) to display and change this address if necessary. The default address is 19, after using Special Function 0.9.
- e. The correct system local oscillator program must be active if the Noise Figure Meter is going to control the system local oscillator. The system local oscillator programs are listed below:
 - HP 8350B Sweep Oscillator; Special Function 41.0
 - HP 8671B/8672A Synthesized Signal Generators; Special Function 41.2
 - HP 8673B/C Synthesized Signal Generator; Special Function 41.3
 - HP 8340B/8341B Sweep Oscillator; Special Function 41.4
 - custom local oscillator; Special Function 41.5

Measurement Mode 1.2 (cont'd)

(Special Function 1.2)

Requirements (cont'd)

The custom local oscillator program will support local oscillators that may require a maximum of twenty-two characters for the frequency prefix and suffix and/or the output power prefix and suffix. The prefix and suffix define the command sequence that will set the frequency or output power.

Use Special Function 42 to define a new program for other system local oscillators.

Procedure

There are many possible measurement procedures. However, the following general procedure applies to all cases:

NOTE

High measurement system noise figure leads to high measurement uncertainty, when measuring low gain devices. A low noise preamplifier, between the device under test and the measurement system, can lower system noise figure and therefore reduce the measurement uncertainty. For more information on determining if a preamplifier is needed and selection of the preamplifier, refer to the Preamplifier Selection Detailed Operating Instruction.

- a. Select single sideband offset (use either Special Function 2.1, 2.2 or 2.3).
- b. Press 1 . 2 SPECIAL FUNCTION to set the Noise Figure Meter to Measurement Mode 1.2.
- c. Set frequency parameters (including the fixed frequency for the system LO, Special Function 3.1).
- d. Calibrate in Mode 1.2 (this is only required for a CORRECTED NOISE FIGURE AND GAIN measurement). External filtering is required during both the calibration and the measurement. If a preamplifier will be used during the measurement, the preamplifier must be used during the calibration.
- e. Insert DUT and measure.

NOTE

The following example assumes that the Noise Figure Meter is the controller, on the System Interface Bus. For information on using an external controller, refer to the Comments section at the end of this instruction.

Example

To make a swept CORRECTED NOISE FIGURE AND GAIN measurement of a wide-band amplifier in the 3.5 to 4.5 GHz range using 20 MHz steps and a fixed system LO of 5 GHz:

- a. Press PRESET (or send HP-IB code PR) to establish initial conditions.
- b. Press 2 . 1 SPECIAL FUNCTION (or send HP-IB code B1) to select a lower sideband measurement.


Measurement Mode 1.2 (cont'd) (Special Function 1.2)

**Example
(cont'd)**


NOTE

Measurement Mode 1.2 must be activated prior to entering the frequency parameters to avoid error E35 (entered value is out of range).

- c. Press 1 . 2 SPECIAL FUNCTION (or send HP-IB code E2) to activate Mode 1.2. Note that error E33 (IF will be out of range) is displayed. This error is cleared when the correct frequency parameters are entered in step d.
- d. Set the frequency parameters for both the calibration and measurement.



- e. To calibrate the Noise Figure Meter, set up the equipment as shown below.




- f. Calibrate the equipment in Measurement Mode 1.2 by pressing CALIBRATE twice (or sending HP-IB code CA).

Measurement Mode 1.2 (cont'd)

(Special Function 1.2)

Example (cont'd)

- g. To make the measurement, set up the equipment as shown below.



- h. Press **CORRECTED NOISE FIGURE AND GAIN** (or send HP-IB code M2).
- i. Press **SINGLE** (or send HP-IB code W2). The Noise Figure Meter will sweep from 1500 to 500 MHz in 20 MHz steps but will display the microwave measurement frequency of 3500 to 4500 MHz. After the single sweep is completed, the instrument halts.

Program Codes

HP-IB

The HP-IB code for Measurement Mode 1.2 is E2 (or 1.2SP).

Indications

The left display shows each frequency at which a measurement is made and the **EXT MIX** annunciator lights. The **INSERTION GAIN** display shows the gain of the DUT at the displayed frequency. The **NOISE FIGURE** display shows the noise figure of the DUT at the displayed frequency.

Comments

An external controller can be used to control the Noise Figure Meter and system local oscillator. The following general conditions must be observed when using an external controller:

- Connect the system local oscillator and the external controller to the HP-IB connector on the Noise Figure Meter.
- HP-IB code H1 must be active.
- Special Function 46.1 must be active.
- Special Function 4.0 (normal talker and listener) must be active. Note that there is no HP-IB code for this special function.
- Special Function 30.0 (free run) should be active (HP-IB code is T0).

Measurement Mode 1.2 (cont'd)

(Special Function 1.2)

Comments (cont'd)

- f. The correct measurement parameters (for example, Measurement Mode, frequencies, etc.) must be established. Refer to Table 3-9, Special Function to HP-IB Code Summary and Table 3-10, Front Panel Keys to HP-IB Code Summary, for applicable HP-IB codes.
- g. Set up for a calibration with the device under test (DUT) out of the measurement system (refer to the Calibrate Detailed Operating Instruction).
- h. Set the system local oscillator to the desired frequency. Refer to the local oscillator's operating manual for the required HP-IB codes. Allow sufficient time for the output of the local oscillator to stabilize.
- i. Send the command "RM 2EN RS CA." Wait for a serial poll to return a non-zero value, indicating calibration is complete.
- j. Insert the DUT into the measurement system.
- k. Special Function 30.1 (trigger hold) must be active (HP-IB code is T1).
- l. Set the Noise Figure Meter's SINGLE sweep on (HP-IB code is W2) or AUTO sweep on (HP-IB code is W1).
- m. Trigger a measurement using the HP-IB code T2. Do not use the alternate HP-IB code 30.2SP for Special Function 30.2 as it will reset the sweep.
- n. A method must be determined when to step to a new frequency and read the noise figure results. This read operation cannot be completed until the new data is ready. It is possible to write an SRQ interrupt routine on the Data Ready SRQ. Refer to Enabling the Service Request Condition, paragraph 3-30.
- o. Continue to loop through steps m and n. A method for determining when the measurements are complete must be programmed into the external controller. One method is to compare the frequency that was read from the Noise Figure Meter with the stop frequency programmed into the Noise Figure Meter and terminate the program after the measurement in which they are equal.

External filtering is necessary for single sideband measurements using Special Functions 2.1 through 2.3.

Related Sections

Calibrate
Controller Capability of the Noise Figure Meter
Fixed IF or LO Frequency Selection
Measurement Modes
Sideband Selection
Special Functions

Measurement Mode 1.3

(Special Function 1.3)

Description

Measurement Mode 1.3 provides a means of controlling the system LO to measure a frequency conversion device. This mode uses a fixed IF and allows for frequency conversion in the device under test (DUT). Although the signal measured at the Noise Figure Meter INPUT is always in the range of 10 to 1600 MHz, the Noise Figure Meter uses the Excess Noise Ratio (ENR) of the noise source at the measurement frequency. However, the correct 10 to 1600 MHz ENR is used during calibration. A typical DUT is a mixer or receiver. All of the Measurement Modes can be set to use many of the other capabilities of the Noise Figure Meter. For example, each mode can make either UNCORRECTED NOISE FIGURE or CORRECTED NOISE FIGURE AND GAIN measurements. Or, the measurement results for each mode can be displayed on an oscilloscope or output to a recorder or plotter. For an explanation and comparison of the ten Measurement Modes and instructions on how to choose the appropriate Measurement Mode and sideband operation, refer to the Measurement Modes Detailed Operating Instruction.

Requirements

The following minimum requirements are necessary for the Noise Figure Meter to act as a controller in Measurement Mode 1.3:

- a. The system local oscillator must be connected to the Noise Figure Meter's SYSTEM INTERFACE BUS connector with an HP-IB cable.
- b. Special Function 48.0 active (Noise Figure Meter is controller on System Interface Bus; Special Function 48.0 is the default setting, after using Special Function 0.9).
- c. Special Function 46.0 active (Enable local oscillator on System Interface Bus; Special Function 46.0 is the default setting, after using Special Function 0.9).
- d. The address of the system LO must match the system LO address that is stored in the Noise Figure Meter. Use Special Function 40.1 to display and change this address if necessary. The default address is 19, after using Special Function 0.9.
- e. The correct system local oscillator program must be active if the Noise Figure Meter is going to control the system local oscillator. The system local oscillator programs are listed below:

- HP 8350B Sweep Oscillator; Special Function 41.0
- HP 8671B/8672A Synthesized Signal Generators; Special Function 41.2
- HP 8673B/C Synthesized Signal Generator; Special Function 41.3
- HP 8340B/8341B Sweep Oscillator; Special Function 41.4
- custom local oscillator; Special Function 41.5

The custom local oscillator program will support local oscillators that may require a maximum of twenty-two characters for the frequency prefix and suffix and/or the output power prefix and suffix. The prefix and suffix define the command sequence that will set the frequency or output power.

Use Special Function 42 to define a new program for other system local oscillators.

Measurement Mode 1.3 (cont'd)

(Special Function 1.3)

Procedure

There are many possible measurement procedures. However, the following general procedure applies to all cases:

NOTE

High measurement system noise figure leads to high measurement uncertainty, when measuring low gain devices. A low noise preamplifier, between the device under test and the measurement system, can lower system noise figure and therefore reduce the measurement uncertainty. For more information on determining if a preamplifier is needed and selection of the preamplifier, refer to the Preamplifier Selection Detailed Operating Instruction.

- a. Verify that the minimum requirements specified under Requirements are satisfied.
- b. Press 1 . 3 SPECIAL FUNCTION to set the Noise Figure Meter to Measurement Mode 1.3.
- c. Set frequency parameters (including the fixed IF, Special Function 3.0).
- d. Calibrate in Mode 1.3. If a preamplifier will be used during the measurement, the preamplifier must be used during the calibration.
- e. Insert DUT and initiate sweep.

Example

To make a swept CORRECTED NOISE FIGURE AND GAIN measurement in the 3.0 to 4.5 GHz range in 20 MHz steps with a fixed IF of 70 MHz:

NOTE

This example assumes that the Noise Figure Meter is acting as a controller on the System Interface Bus and the minimum requirements specified under Requirements are satisfied. Refer to Comments for a brief description of using an external controller when in Measurement Mode 1.3.

- a. Press PRESET (or send HP-IB code PR) to establish initial conditions.


NOTE

Measurement Mode 1.3 must be activated prior to entering the frequency parameters to avoid error E35 (entered value is out of range).


- b. Press 1 . 3 SPECIAL FUNCTION to activate Measurement Mode 1.3.
- c. Set the frequency parameters for both the calibration and measurement.

Measurement Mode 1.3 (cont'd) (Special Function 1.3)

**Example
(cont'd)**




d. To calibrate the Noise Figure Meter, set up the equipment as shown below.



* IF THE PREAMPLIFIER IS USED DURING THE MEASUREMENT, IT MUST BE USED DURING THE CALIBRATION.

e. Calibrate the equipment in Measurement Mode 1.3 by pressing CALIBRATE twice.

f. To make the measurement, set up the equipment as shown below.



g. Press CORRECTED NOISE FIGURE AND GAIN.

h. Press SINGLE. The Noise Figure Meter will sweep the system LO from 3 GHz to 4.5 GHz in 20 MHz steps and halt.

Measurement Mode 1.3 (cont'd)

(Special Function 1.3)

Program Codes

HP-IB

Indications

The left display shows each frequency at which a measurement is made and the EXT MIX annunciator lights. The INSERTION GAIN display shows the gain of the DUT at the displayed frequency. The NOISE FIGURE display shows the noise figure of the DUT at the displayed frequency.

Comments

An external controller can be used in place of the Noise Figure Meter to control the system LO and the Noise Figure Meter in Measurement Mode 1.3. The following general conditions must be observed when using an external controller:

- a. The system local oscillator and the external controller must be connected to the HP-IB connector on the Noise Figure Meter.
- b. HP-IB code H1 must be active.
- c. Special Function 46.1 must be active.
- d. Special Function 4.0 (normal talker and listener) must be active. Note that there is no HP-IB code for this special function.
- e. Special Function 30.0 (free run) should be active (HP-IB code is T0).
- f. The correct measurement parameters (for example, Measurement Mode, frequencies, etc.) must be established. Refer to Table 3-9, Special Function to HP-IB Code Summary, and Table 3-10, Front Panel Keys to HP-IB Code Summary, for applicable HP-IB codes.
- g. Set up for a calibration with the DUT out of the measurement system (refer to the Calibrate Detailed Operating Instruction).
- h. Send the command "RM 2EN RS CA". Wait for a serial poll to return a non-zero value, indicating calibration is complete.
- i. Insert the DUT into the measurement system.
- j. Special Function 30.1 (trigger hold) must be active (HP-IB code is T1).
- k. Set the Noise Figure Meter's SINGLE sweep on (HP-IB code is W2) or AUTO sweep on (HP-IB code is W1).
- l. Set the system LO to the appropriate frequency. Refer to the LO's operating manual for the required HP-IB codes. Allow sufficient time for the output of the system LO to stabilize.
- m. Trigger a measurement using the HP-IB code T2. Do not use the alternate HP-IB code 30.2SP for Special Function 30.2 as it will reset the sweep.

Measurement Mode 1.3 (cont'd)

(Special Function 1.3)

Comments (cont'd)

n. A method must be determined when to step to a new frequency and read the noise figure results. This read operation cannot be completed until the new data is ready. It is possible to write an SRQ interrupt routine on the Data Ready SRQ. Refer to Enabling the Service Request Condition, paragraph 3-30.

o. Continue to loop through steps l, m, and n. A method for determining when the measurements are complete must be programmed into the external controller. One method is to compare the frequency that was read from the Noise Figure Meter with the stop frequency programmed into the Noise Figure Meter and terminate the program after the measurement in which they are equal.

External filtering is necessary for single sideband measurements, using Special Functions 2.1 through 2.3.

Related Sections

Calibrate
Controller Capability of the Noise Figure Meter
Fixed IF or LO Frequency Selection
HP-IB and System Interface Bus (SIB) Addresses
Sideband Selection
Special Functions
Trigger Selection

Measurement Mode 1.4

(Special Function 1.4)

Description

Measurement Mode 1.4 provides a means of using a fixed-frequency system LO and testing over a variable IF range. This mode allows for frequency conversion in the device under test (DUT). Although the signal measured at the Noise Figure Meter INPUT is always in the range of 10 to 1600 MHz, the Noise Figure Meter uses the Excess Noise Ratio (ENR) of the noise source at the measurement frequency. However, the correct 10 to 1600 MHz ENR is used during calibration. A typical DUT is a mixer or receiver. The system LO is required. All of the Measurement Modes can be set up to use many of the other capabilities of the Noise Figure Meter. For example, each mode can make either UNCORRECTED NOISE FIGURE or CORRECTED NOISE FIGURE AND GAIN measurements. Or, the measurement results for each mode can be displayed on an oscilloscope or output to a recorder or plotter. For an explanation and comparison of the ten Measurement Modes and instructions on how to choose the appropriate Measurement Mode and sideband operation, refer to the Measurement Modes Detailed Operating Instruction.

Requirements

The following minimum requirements are necessary for the Noise Figure Meter to act as a controller in Measurement Mode 1.4:

- a. The system local oscillator must be connected to the Noise Figure Meter's SYSTEM INTERFACE BUS connector with an HP-IB cable.
- b. Special Function 48.0 active (Noise Figure Meter is controller on System Interface Bus; Special Function 48.0 is the default setting, after using Special Function 0.9).
- c. Special Function 46.0 active (Enable local oscillator on System Interface Bus; Special Function 46.0 is the default setting, after using Special Function 0.9).
- d. The address of the system local oscillator must match the system local oscillator address that is stored in the Noise Figure Meter. Use Special Function 40.1 (system local oscillator address) to display and change this address if necessary. The default address is 19, after using Special Function 0.9.
- e. The correct system local oscillator program must be active if the Noise Figure Meter is going to control the system local oscillator. The system local oscillator programs are listed below:
 - HP 8350B Sweep Oscillator; Special Function 41.0
 - HP 8671B/8672A Synthesized Signal Generators; Special Function 41.2
 - HP 8673B/C Synthesized Signal Generator; Special Function 41.3
 - HP 8340B/8341B Sweep Oscillator; Special Function 41.4
 - custom local oscillator; Special Function 41.5

The custom local oscillator program will support local oscillators that may require a maximum of twenty-two characters for the frequency prefix and suffix and/or the output power prefix and suffix. The prefix and suffix define the command sequence that will set the frequency or output power.

Measurement Mode 1.4 (cont'd)

(Special Function 1.4)

Description (cont'd) Procedure

Use Special Function 42 to define a new program for other system local oscillators.

There are many possible measurement procedures. However, the following general procedure applies to all cases:

NOTE

High measurement system noise figure leads to high measurement uncertainty, when measuring low gain devices. A low noise preamplifier, between the device under test and the measurement system, can lower system noise figure and therefore reduce the measurement uncertainty. For more information on determining if a preamplifier is needed and selection of the preamplifier, refer to the Preamplifier Selection Detailed Operating Instruction.

- a. Set frequency parameters (including the fixed frequency for the system LO, Special Function 3.1).
- b. Press 1 . 4 SPECIAL FUNCTION to set the Noise Figure Meter to Measurement Mode 1.4.
- c. Calibrate in Mode 1.4 (this is only required for a CORRECTED NOISE FIGURE AND GAIN measurement). If a preamplifier will be used during the measurement, the preamplifier must be used during the calibration.
- d. Insert DUT and measure.
- e. The left display shows the swept IF.

Example

NOTE


The following example assumes that the Noise Figure Meter is the controller, on the System Interface Bus. For information on using an external controller, refer to the Comments section at the end of this instruction.

To make a swept CORRECTED NOISE FIGURE AND GAIN measurement over an IF of 10 MHz to 1 GHz using 20 MHz steps with a fixed system LO frequency of 10 GHz:

- a. Press PRESET (or send HP-IB code PR) to establish initial conditions.
- b. Set the frequency parameters for both the calibration and measurement.


Measurement Mode 1.4 (cont'd) (Special Function 1.4)

Example
(cont'd)




c. Press 1.4 SPECIAL FUNCTION (or send HP-IB code E4) to activate Measurement Mode 1.4.

d. To calibrate the Noise Figure Meter, set up the equipment as shown below.



e. Calibrate the equipment in Measurement Mode 1.4 by pressing CALIBRATE twice (or sending HP-IB code CA).

f. To make the measurement, set up the equipment as shown below.



Measurement Mode 1.4 (cont'd)

(Special Function 1.4)

Example (cont'd)

- g. Press CORRECTED NOISE FIGURE AND GAIN (or send HP-IB code M2).
- h. Press SINGLE (or send HP-IB code W2). The Noise Figure Meter will sweep from 10 to 1000 MHz in 20 MHz steps. After the single sweep is completed, the instrument halts.

Program Codes

◀ HP-IB ▶

The HP-IB code for Measurement Mode 1.4 is E4 (or 1.4SP).

Indications

The left display shows each IF frequency at which a measurement is made and the EXT MIX annunciator lights. The INSERTION GAIN display shows the gain of the DUT at the displayed frequency. The NOISE FIGURE display shows the noise figure of the DUT at the displayed frequency.

Comments

An external controller can be used to control the Noise Figure Meter and system local oscillator. The following general conditions must be observed when using an external controller:

- a. The system local oscillator and the external controller must be connected to the HP-IB connector on the Noise Figure Meter.
- b. HP-IB code H1 must be active.
- c. Special Function 46.1 must be active.
- d. Special Function 4.0 (normal talker and listener) must be active. Note that there is no HP-IB code for this special function.
- e. Special Function 30.0 (free run) should be active (HP-IB code is T0).
- f. The correct measurement parameters (for example, Measurement Mode, frequencies, etc.) must be established. Refer to Table 3-9, Special Function to HP-IB Code Summary and Table 3-10, Front Panel Keys to HP-IB Code Summary, for applicable HP-IB codes.
- g. Set up for a calibration with the device under test (DUT) out of the measurement system (refer to the Calibrate Detailed Operating Instruction).
- h. Send the command "RM 2EN RS CA." Wait for a serial poll to return a non-zero value, indicating calibration is complete.
- i. Insert the DUT into the measurement system.
- j. Special Function 30.1 (trigger hold) must be active (HP-IB code T1).
- k. Set the Noise Figure Meter's SINGLE sweep on (HP-IB code is W2) or AUTO sweep on (HP-IB code is W1).

Measurement Mode 1.4 (cont'd)

(Special Function 1.4)

Comments (cont'd)

l. Set the system local oscillator to the desired frequency. Refer to the local oscillator's operating manual for the required HP-IB codes. Allow sufficient time for the output of the system local oscillator to stabilize.

m. Trigger a measurement using the HP-IB code T2. Do not use the alternate HP-IB code 30.2SP for Special Function 30.2 as it will reset the sweep.

n. A method must be determined when to step to a new frequency and read the noise figure results. This read operation cannot be completed until the new data is ready. It is possible to write an SRQ interrupt routine on the Data Ready SRQ. Refer to Enabling the Service Request Condition, paragraph 3-30.

o. Continue to loop through steps m and n. A method for determining when the measurements are complete must be programmed into the external controller. One method is to compare the frequency that was read from the Noise Figure Meter with the stop frequency programmed into the Noise Figure Meter and terminate the program after the measurement in which they are equal.

External filtering is necessary for single sideband measurements, using Special Functions 2.1 through 2.3.

Related Sections

Calibrate
Controller Capability of the Noise Figure Meter
Fixed IF or LO Frequency Selection
Sideband Selection
Special Functions

Measurement Mode 1.5

(Special Function 1.5)

Description

NOTE

The HP 8971B Noise Figure Test Set and the system local oscillator are required when making a measurement using Measurement Mode 1.5.

Measurement Mode 1.5 provides direct noise figure and gain measurements in the frequency range of 10 to 18000 MHz. No external mixer or second local oscillator is needed. This measurement mode does not allow for down conversion in the device under test (DUT). All of the Measurement Modes can be set up to use many of the other capabilities of the Noise Figure Meter. For example, each mode can make either UNCORRECTED NOISE FIGURE or CORRECTED NOISE FIGURE AND GAIN measurements. In addition, the measurement results for each mode can be displayed on an oscilloscope or output to either a recorder or plotter. For explanation and comparison of the ten Measurement Modes and instructions on how to choose the appropriate Measurement Mode and sideband operation, refer to the Measurement Modes Detailed Operating Instructions.

Requirements

The following minimum requirements are necessary for the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and system local oscillator) to operate in Measurement Mode 1.5.

- a. The system local oscillator and the Noise Figure Test Set must be connected to the Noise Figure Meter's SYSTEM INTERFACE BUS connector with an HP-IB cable.
- b. Special Function 48.0 must be active (Noise Figure Meter is System controller on System Interface Bus; Special Function 48.0 is the default setting, after using Special Function 0.9).
- c. Special Function 45.0 must be active (Noise Figure Test Set enabled in measurement modes 1.5 through 1.9; Special Function 45.0 is the default setting, after using Special Function 0.9.) or Special Function 45.1 (Noise Figure Test Set enabled always) must be active.
- d. The address of the Noise Figure Test Set must match the Noise Figure Test Set address that is stored in the Noise Figure Meter. Use Special Function 40.2 (Noise Figure Test Set System Interface Bus address) to display and change this address if necessary. The default address for the Noise Figure Test Set is 10, after using Special Function 0.9.
- e. Special Function 46.0 must be active (Enable system local oscillator on System Interface Bus; Special Function 46.0 is the default setting, after using Special Function 0.9.)
- f. The address of the system local oscillator must match the address of the system local oscillator stored in the Noise Figure Meter. Use Special Function 40.1 (system local oscillator System Interface Bus address) to display and change this address if necessary. The default address is 19, after using Special Function 0.9.
- g. The correct system local oscillator program must be active if the Noise Figure Meter is going to control the system local oscillator. The system local oscillator programs are listed below:

Measurement Mode 1.5 (cont'd)

(Special Function 1.5)

- Requirements**
- HP 8671B/8672A Synthesized Signal Generators; Special Function 41.2
 - HP 8673B/C (Standard) Synthesized Signal Generator; Special Function 41.3
 - HP 8340B/8341B Sweep Oscillator; Special Function 41.4
 - Custom local oscillator; Special Function 41.5

The custom local oscillator program will support local oscillators that may require a maximum of twenty-two characters for the frequency prefix and suffix and/or the output power prefix and suffix. The prefix and suffix define the command sequence that will set the frequency or output power.

Use Special Function 42 to define a new program for other system local oscillators.

h. If a free-running (non-synthesized) source is being used as the system local oscillator, a Noise Figure Test Set Coarse Tuning Calibration should have been done when the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and system local oscillator) was put together. The coarse tuning is **ONLY** required when a free-running source is the system local oscillator or repairs have been made to the Noise Figure Test Set. For more information on the coarse tuning, refer to the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction.

Procedure There are many possible measurement procedures. However, the following general procedure applies to all cases:

NOTE

High measurement system noise figure leads to high measurement uncertainty, when measuring low gain devices. A low noise preamplifier, between the device under test and the measurement system, can lower system noise figure and therefore reduce the measurement uncertainty. For more information on determining if a preamplifier is needed and selection of the preamplifier, refer to the Preamplifier Selection Detailed Operating Instruction.

- a. Verify that the minimum requirements specified under Requirements are satisfied.
- b. Press PRESET.
- c. Press 1.5 SPECIAL FUNCTION to set the Noise Figure Meter to Measurement Mode 1.5.
- d. Set frequency parameters.
- e. Select sideband operation desired (Special Function 17).
- f. Select appropriate smoothing (Special Function 13).
- g. Perform a Noise Figure Test Set Fine Tuning Calibration. Refer to the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction.

Measurement Mode 1.5 (cont'd) (Special Function 1.5)

Procedure

h. Calibrate in Mode 1.5 (this is only required for a CORRECTED NOISE FIGURE AND GAIN measurement). If a preamplifier is required for the measurement, the preamplifier must be used in the calibration.

i. Insert device under test (DUT) and measure.

Example


To make a swept CORRECTED NOISE FIGURE AND GAIN single sideband measurement in the 3000 to 4000 MHz range in 10 MHz steps:

a. Press PRESET to establish initial conditions. Single sideband (Special Function 17.0) is active when PRESET is pressed.

b. Press 1.5 SPECIAL FUNCTION to set the Noise Figure Measurement System to Measurement Mode 1.5.

c. Set the frequency parameters for both the calibration and measurement.


d. Enter actual ENR for the Noise Source, if this has not previously been done.



e. To calibrate and perform a Noise Figure Test Set Fine Tuning Calibration, set up the equipment as shown below.

Measurement Mode 1.5 (cont'd) (Special Function 1.5)


**Example
(cont'd)**



* IF THE PREAMPLIFIER IS NEEDED FOR THE MEASUREMENT,
IT MUST BE USED DURING CALIBRATION.

f. Calibrate and fine tune in Measurement Mode 1.5 by pressing CALIBRATE twice (or send HP-IB code CA). PRESET enabled a fine tune (Special Function 36.0) to be done each time a calibration is done.

g. To make the measurement, set up the equipment as shown below.



NOTE

For the Noise Figure Measurement System specifications to be valid, the measurement must use the same START FREQ, STOP FREQ and STEP SIZE that was used for calibration. None of the calibrated points can be skipped. Also, the measurement must be done in the same direction as the calibration, for example, from start frequency to stop frequency.

h. Press CORRECTED NOISE FIGURE AND GAIN (or send HP-IB code M2).

i. Press SINGLE (or send HP-IB code W2). The Noise Figure Measurement System will sweep from 3000 MHz to 4000 MHz in 10 MHz steps and halt.

Measurement Mode 1.5 (cont'd)

(Special Function 1.5)

Program Codes



The HP-IB code for Measurement Mode 1.5 is E5 (or 1.5SP).

Indications

The left display shows each frequency at which a measurement is made. The INSERTION GAIN display shows the gain of the DUT at the displayed frequency. The NOISE FIGURE display shows the noise figure of the DUT at the displayed frequency.

Related Sections

Calibrate
Noise Figure Test Set YIG Filter Calibration
Measurement Modes
Sideband Selection
Special Functions

Measurement Mode 1.6

(Special Function 1.6)

Description

NOTES

If the IF into the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and system local oscillator) can be reduced below 1600 MHz, Measurement Mode 1.1 is a better choice than Measurement Mode 1.6. Measurement Mode 1.1 requires less equipment, less noise figure is contributed by the measurement system and a pre-amplifier may not be required for the measurement.

Measurement Mode 1.6 requires the use of the HP 8971B Noise Figure Test Set, a system local oscillator and a user controlled local oscillator.

Measurement Mode 1.6 uses two stages of frequency conversion. The user controlled local oscillator and an external mixer provide the first stage of conversion. The user controlled local oscillator is not controlled by the Noise Figure Meter; the user controlled local oscillator must be controlled by the user. The second stage of conversion is provided by the system local oscillator and the Noise Figure Test Set. The Noise Figure Meter does control the system local oscillator and the Noise Figure Test Set.

Measurement Mode 1.6 provides a means of increasing the frequency range of the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and system local oscillator) from 18000 MHz to 99999 MHz. This mode provides for a variable-frequency user controlled local oscillator and a fixed IF. If single sideband measurements are to be made, a filter is used with the user controlled local oscillator and mixer. Frequency conversion is not allowed for in the device under test (DUT). Although the signal measured at the Noise Figure Measurement System INPUT is always in the range of 10 to 18000 MHz, the Noise Figure Meter uses the Excess Noise Ratio (ENR) of the noise source at the measurement frequency. A typical DUT is an amplifier or transistor. All of the Measurement Modes can be set up to use many of the other capabilities of the Noise Figure Meter. For example, each mode can make either UNCORRECTED NOISE FIGURE or CORRECTED NOISE FIGURE AND GAIN measurements, plus the measurements can be displayed on an oscilloscope or output to a recorder or plotter. For an explanation and comparison of the ten Measurement Modes and instructions on how to choose the appropriate Measurement Mode and sideband operation, refer to the Measurement Modes Detailed Operating Instruction.

Requirements

The following minimum requirements are necessary for the Noise Figure Measurement System to operate in Measurement Mode 1.6.

- a. The Noise Figure Test Set and the system local oscillator must be connected to the Noise Figure Meter's SYSTEM INTERFACE BUS connector with an HP-IB cable.
- b. Special Function 48.0 must be active (Noise Figure Meter is the system controller on the system interface bus; Special Function 48.0 is the default setting, after using Special Function 0.9).
- c. Special Function 45.0 must be active (Noise Figure Test Set enabled in measurement modes 1.5 through 1.9; Special Function 45.0 is the default setting, after using Special Function 0.9.) or Special Function 45.1 (Noise Figure Test Set enabled always) must be active.

Measurement Mode 1.6 (cont'd)

(Special Function 1.6)

Requirements (cont'd)

d. The address of the Noise Figure Test Set must match the Noise Figure Test Set address that is stored in the Noise Figure Meter. Use Special Function 40.2 (Noise Figure Test Set address) to display and change the address if necessary. The default address of the Noise Figure Test Set is 10, after using Special Function 0.9.

e. Special Function 46.0 must be active (Enable system local oscillator on System Interface Bus; Special Function 46.0 is the default setting, after using Special Function 0.9).

f. The address of the system local oscillator must match the address of the system local oscillator stored in the Noise Figure Meter. Use Special Function 40.1 (system local oscillator System Interface Bus address) to display and change this address, if necessary. The default address is 19, after using Special Function 0.9.

g. The correct system local oscillator program must be active if the Noise Figure Meter is going to control the system local oscillator. The system local oscillator programs are listed below:

- HP 8671B/8672A Synthesized Signal Generators; Special Function 41.2
- HP 8673B/C (Standard) Synthesized Signal Generator; Special Function 41.3
- HP 8340B/8341B Sweep Oscillator; Special Function 41.4
- Custom local oscillator; Special Function 41.5

The custom local oscillator program will support local oscillators that may require a maximum of twenty-two characters for the frequency prefix and suffix and/or the output power prefix and suffix. The prefix and suffix define the command sequence that will set the frequency or output power.

Use Special Function 42 to define a new program for other system local oscillators.

h. If a free-running (non-synthesized) source is being used as the system local oscillator, a Noise Figure Test Set Coarse Tuning Calibration should have been done when the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and system local oscillator) was put together. The coarse tuning is **ONLY** required when a free-running source is the system local oscillator or repairs have been made to the Noise Figure Test Set. For more information on the coarse tuning, refer to the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction.

Procedure

NOTE

High measurement system noise figure leads to high measurement uncertainty, when measuring low gain devices. A low noise preamplifier, between the device under test and the measurement system, can lower system noise figure and therefore reduce the measurement uncertainty. For more information on determining if a preamplifier is needed and selection of the preamplifier, refer to the Preamplifier Selection Detailed Operating Instruction.

Measurement Mode 1.6 (cont'd)

(Special Function 1.6)

Procedure (cont'd)

- a. Verify that the minimum requirements specified under Requirements are satisfied.
- b. Press PRESET.
- c. Press 1.6 SPECIAL FUNCTION to set the Noise Figure Meter to Measurement Mode 1.6.
- d. Set frequency parameters (including the fixed IF, Special Function 3.0).
- e. Select sideband operation desired. (Special Function 2 and 17)
- f. Select appropriate smoothing (Special Function 13).
- g. Enter the ENR table of the noise source.
- h. Perform a Noise Figure Test Set fine tuning calibration. For more information, refer to the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction.
- i. Perform a triggered calibration of the Noise Figure Measurement System, with the device under test (DUT) out of the measurement system, in Mode 1.6 (this is only required for a CORRECTED NOISE FIGURE AND GAIN measurement). The user controlled local oscillator must be set up for each of the calibration points. If external filtering and a preamplifier are required for the measurement, external filtering and the preamplifier must be used during calibration.
- j. Insert the DUT into the measurement system and make a noise figure or noise figure and gain measurement.

Example

To make a swept single sideband CORRECTED NOISE FIGURE AND GAIN measurement in the 20 to 24 GHz range in 200 MHz steps with a fixed IF of 3.5 GHz.

NOTE

This example assumes that the Noise Figure Meter is acting as a controller and the minimum requirements specified under Requirements are satisfied. Refer to Comments for a brief description of using an external controller when in Measurement Mode 1.6.

- a. Press PRESET to establish initial conditions.

NOTE

Single sideband (Special Function 17.0) was enabled, for the Noise Figure Test Set, when PRESET was pressed.

Measurement Mode 1.6 must be activated prior to entering the frequency parameters to avoid error E35 (entered value is out of range).

- b. Press 1.6 SPECIAL FUNCTION to activate Measurement Mode 1.6.
- c. Set the frequency parameters for both the calibration and measurement.

Measurement Mode 1.6 (cont'd) (Special Function 1.6)


**Example
(cont'd)**

- d. Enter actual ENR for the noise source, if this has not previously been done.
- e. Press 2.1 SPECIAL FUNCTION to select a lower sideband measurement. Special Function 2.1 is used to select the sideband operation desired for the first frequency conversion, using the user controlled local oscillator and the external mixer.

NOTE

When a single sideband measurement is being made, the user must place a filter between the device under test and the external mixer to eliminate the unwanted sideband.


- f. Configure the user controlled local oscillator to produce a 3.5 GHz IF at the input of the Noise Figure Measurement System. The correct frequency to set the user controlled local oscillator to can be viewed by using Special Function 3.2.



- g. To calibrate the Noise Figure Measurement System and perform a Noise Figure Test Set Fine Tuning Calibration, set up the equipment as shown below.

Measurement Mode 1.6 (cont'd) (Special Function 1.6)

**Example
(cont'd)**




•IF THE PREAMPLIFIER AND FILTER ARE NEEDED DURING THE MEASUREMENT (THE FILTER IS ADDED IF A SINGLE SIDEBAND MEASUREMENT IS BEING MADE), THEY NEED TO BE USED DURING CALIBRATION.

NOTE

A Noise Figure Test Set Fine Tuning Calibration may need to be done separately from the measurement system calibration (step h). The separate fine tuning calibration is needed if a mixer is being used out in front of the Noise Figure Measurement System and a preamplifier is not being used. An Excess Noise Ratio (ENR) of 13 dB or greater is needed at the input to the Noise Figure Test Set during the fine tuning calibration.

h. Calibrate and fine tune in Measurement Mode 1.6 by performing a triggered calibration. The user controlled local oscillator frequency must be set up before the Noise Figure Meter is triggered. PRESET enabled a fine tune (Special Function 36.0) to be done each time a calibration is done. Enable the calibration and fine tune by pressing the CALIBRATE key twice.

i. To make the measurement, set up the equipment as shown below.



•THE FILTER IS ADDED IF A SINGLE SIDEBAND MEASUREMENT IS BEING MADE.

Measurement Mode 1.6 (cont'd)

(Special Function 1.6)

Example (cont'd)

NOTE

For the Noise Figure Measurement System specifications to be valid, the measurement must use the same START FREQ, STOP FREQ and STEP SIZE that was used for calibration. None of the calibrated points can be skipped. Also, the measurement must be done in the same direction as the calibration, for example, from start frequency to stop frequency.

j. Press CORRECTED NOISE FIGURE AND GAIN.

k. Perform a triggered sweep of the user controlled local oscillator and the Noise Figure Measurement System to gather the data.

Program Codes

HP-IB

The HP-IB code for Measurement Mode 1.6 is E6 (or 1.6SP). Refer to Comments for additional information on using HP-IB program codes in Measurement Mode 1.6.

Indications

The left display shows each frequency at which a measurement is made and the EXT MIX annunciator lights. The INSERTION GAIN display shows the gain of the DUT at the displayed frequency. The NOISE FIGURE display shows the noise figure of the DUT at the displayed frequency.

Comments

An external controller can be used to control the Noise Figure Measurement System and the user controlled local oscillator. The following general conditions must be observed when using an external controller:

a. The external controller and the user controlled local oscillator must be connected to the HP-IB connector on the Noise Figure Meter.

b. HP-IB code H1 must be active.

c. Special Function 4.0 (normal talker and listener) must be active. Note that there is no HP-IB code for this special function.

d. Special Function 30.1 (trigger hold) must be active (HP-IB code is T1).

e. The correct measurement parameters (for example, Measurement Mode, frequencies, etc.) must be established. Refer to Table 3-9, Special Function to HP-IB Code Summary and Table 3-10, Front Panel Keys to HP-IB Code Summary for applicable HP-IB codes.

f. Perform a triggered Noise Figure Test Set Fine Tuning Calibration and Noise Figure Measurement System Calibration with the DUT out of the measurement system (refer to the Calibrate Detailed Operating Instruction and the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction).

A Noise Figure Test Set Fine Tuning Calibration may need to be done separately from the measurement system calibration. The separate fine tuning calibration is needed if a mixer is being used out in front of the Noise Figure Measurement System and a preamplifier is not being used. An ENR (Excess Noise Ratio) of 13 dB or greater is needed at the input to the Noise Figure Test Set during the fine tuning calibration.

Measurement Mode 1.6 (cont'd) (Special Function 1.6)

Comments (cont'd)

- g. Set the Noise Figure Meter's calibrate function on (HP-IB code is CA).
- h. Set the user controlled local oscillator to the desired frequency, depending on the sideband selection. If double sideband was selected, the oscillator should be set to the measurement frequency. If lower sideband was selected, the oscillator should be set to the measurement frequency plus the IF. If upper sideband was selected, the oscillator should be set to the measurement frequency minus the IF. If sum (upconversion; Special Function 2.3) was selected, set the oscillator to the IF minus the measurement frequency. Refer to the user controlled local oscillator's operating manual for the required HP-IB codes. Allow sufficient time for the output of the user controlled local oscillator to stabilize.
- i. Trigger a measurement using the HP-IB code T2. Do not use the alternate HP-IB code 30.2SP for it will be ignored.
- j. A method must be determined when to step to a new frequency after reading the noise figure results. This read operation cannot be completed until the new data is ready. It is possible to write an SRQ interrupt routine on the Data Ready status bit. Refer to Enabling the Service Request Condition, paragraph 3-30.
- k. Continue to loop through steps h, i and j. A method for determining when the calibration will be completed must be programmed into the external controller. One method is to compare the frequency that is sent to the user LO with the stop frequency programmed into the Noise Figure Meter and terminate the program after the third measurement in which they are equal. It is also possible to write an SRQ interrupt routine on the Calibration Complete Status Bit. Refer to Enabling the Service Request Condition, paragraph 3-30.
- l. Insert the device under test (DUT) into the measurement system.
- m. Set the Noise Figure Meter's SINGLE sweep on (HP-IB code is W2) or AUTO sweep on (HP-IB code is W1).
- n. Repeat step h.
- o. Trigger a measurement using the HP-IB code T2. Do not use the alternate HP-IB code 30.2SP for Special Function 30.2 as it will reset the sweep.
- p. A method must be determined when to step to a new frequency after reading the noise figure results. This read operation cannot be completed until the new data is ready. It is possible to write an SRQ interrupt routine on the Data Ready Status Bit. Refer to Enabling the Service Request Condition, paragraph 3-30.
- q. Continue to loop through steps n, o and p. A method for determining when the measurements are complete must be programmed into the external controller. One method is to compare the measurement frequency read from the Noise Figure Meter with the stop frequency programmed into the Noise Figure Meter and terminate the program after the measurement in which they are equal.

Measurement Mode 1.6 (cont'd)

(Special Function 1.6)

Related Sections

Calibrate
Controller Capability of the Noise Figure Meter
Fixed IF Selection
Measurement Modes
Noise Figure Test Set YIG Filter Calibration
Sideband Selection
Special Functions
Trigger Selection

Measurement Mode 1.7

(Special Function 1.7)

Description

NOTE

A double sideband measurement can not be made when using Measurement Mode 1.7.

Measurement Mode 1.7 requires the use of the HP 8971B Noise Figure Test Set, a system local oscillator and a user controlled local oscillator.

Measurement Mode 1.7 uses two stages of frequency conversion. The user controlled local oscillator and an external mixer provide the first stage of conversion. The user controlled local oscillator is not controlled by the Noise Figure Meter; the user controlled local oscillator must be controlled by the user. The second stage of conversion is provided by the system local oscillator and the Noise Figure Test Set. The Noise Figure Meter does control the system local oscillator and the Noise Figure Test Set.

Measurement Mode 1.7 provides the means of increasing the frequency range of the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and system local oscillator) from 18000 to 99999 MHz. Also, this mode provides the means of using a fixed-frequency user controlled local oscillator with a variable IF in order to measure over a band of frequencies less than 18000 MHz wide. Frequency conversion is allowed for at the input to the Noise Figure Measurement System, but not in the device under test (DUT). Single sideband operation and external filtering of the unwanted sideband are required. A typical DUT is an amplifier with a bandwidth of less than 18000 MHz. Although the signal measured at the Noise Figure Measurement System INPUT is always in the range of 10 to 18000 MHz, the Noise Figure Meter uses the Excess Noise Ratio (ENR) of the noise source at the measurement frequency. All of the Measurement Modes can be set up to use many of the other capabilities of the Noise Figure Meter. For example, each mode can make either UNCORRECTED NOISE FIGURE or CORRECTED NOISE FIGURE AND GAIN measurements. Or, the measurement results for each mode can be displayed on an oscilloscope or output to a recorder or plotter. For an explanation and comparison of the ten Measurement Modes and instructions on how to choose the appropriate Measurement Mode and sideband operation, refer to the Measurement Modes Detailed Operating Instruction.

Requirements

The following minimum requirements are necessary for the Noise Figure Measurement System and the user controlled local oscillator to operate in Measurement Mode 1.7.

- a. The system local oscillator and the Noise Figure Test Set must be connected to the Noise Figure Meter's SYSTEM INTERFACE BUS connector with an HP-IB cable.
- b. Special Function 48.0 must be active (Noise Figure Meter is system controller on System Interface Bus; Special Function 48.0 is the default setting, after using Special Function 0.9.).
- c. Special Function 45.0 must be active (Noise Figure Test Set enabled in measurement modes 1.5 through 1.9; Special Function 45.0 is the default setting, after using Special Function 0.9.) or Special Function 45.1 (Noise Figure Test Set enabled always) must be active.

Measurement Mode 1.7 (cont'd)

(Special Function 1.7)

Requirements (cont'd)

d. The address of the Noise Figure Test Set must match the Noise Figure Test Set address that is stored in the Noise Figure Meter. Use Special Function 40.2 (Noise Figure Test Set System Interface Bus address) to display and change this address if necessary. The default address for the Noise Figure Test Set is 10, after using Special Function 0.9.

e. Special Function 46.0 must be active (Enable system local oscillator on System Interface Bus; Special Function 46.0 is the default setting, after using Special Function 0.9.).

f. The address of the system local oscillator must match the address of the system local oscillator stored in the Noise Figure Meter. Use Special Function 40.1 (system local oscillator System Interface Bus address) to display and change this address if necessary. The default address is 19, after using Special Function 0.9.

g. The correct system local oscillator program must be active if the Noise Figure Meter is going to control the system local oscillator. The system local oscillator programs are listed below:

- HP 8671B/8672A Synthesized Signal Generators; Special Function 41.2
- HP 8673B/C (Standard) Synthesized Signal Generator; Special Function 41.3
- HP 8340B/8341B Sweep Oscillator; Special Function 41.4
- Custom local oscillator; Special Function 41.5

The custom local oscillator program will support local oscillators that may require a maximum of twenty-two characters for the frequency prefix and suffix and/or the output power prefix and suffix. The prefix and suffix define the command sequence that will set the frequency or output power.

Use Special Function 42 to define a new program for other system local oscillators.

h. The user controlled local oscillator must be configured to produce the desired IF (10 to 18000 MHz). The user controlled local oscillator is not controlled by the Noise Figure Meter.

i. If a free-running (non-synthesized) source is being used as the system local oscillator, a Noise Figure Test Set Coarse Tuning Calibration should have been done when the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and system local oscillator) was put together. The coarse tuning is **ONLY** required when a free-running source is the system local oscillator or repairs have been made to the Noise Figure Test Set. For more information on a Noise Figure Test Set Coarse Tuning, refer to the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction.

Procedure

There are many possible measurement procedures. However, the following general procedure applies to all cases:

Measurement Mode 1.7 (cont'd)

(Special Function 1.7)

Procedure (cont'd)

NOTE

High measurement system noise figure leads to high measurement uncertainty, when measuring low gain devices. A low noise preamplifier, between the device under test and the measurement system, can lower system noise figure and therefore reduce the measurement uncertainty. For more information on determining if a preamplifier is needed and selection of the preamplifier, refer to the Preamplifier Selection Detailed Operating Instruction.

- a. Verify that the minimum requirements specified under Requirements are satisfied.
- b. Press PRESET.
- c. Press 1.7 SPECIAL FUNCTION to set the Noise Figure Meter to Measurement Mode 1.7.
- d. Set frequency parameters (including the fixed frequency for the user controlled local oscillator, Special Function 3.1).
- e. Select sideband operation desired (Special Functions 2.1 through 2.3 and 17; Special Function 2.1 is the default.)
- f. Select appropriate smoothing (Special Function 13).
- g. Enter the noise source ENR table.
- h. Set the user controlled local oscillator to the frequency specified by Special Function 3.1.
- i. Perform a Noise Figure Test Set Fine Tuning Calibration. For more information, refer to the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction.
- j. Calibrate the Noise Figure Measurement System in Mode 1.7 (this is only required for a CORRECTED NOISE FIGURE AND GAIN measurement). External filtering is required during both calibration and the measurement. If a preamplifier is required for the measurement, the preamplifier must be used in the calibration.
- k. Insert DUT and make a noise figure or noise figure and gain measurement.

Example

NOTE

The following example assumes that the Noise Figure Meter is the controller. An external controller can be used to control the Noise Figure Measurement System and the user controlled local oscillator. For more information on using an external controller, refer to Comments at the end of this instruction.

To make a swept CORRECTED NOISE FIGURE AND GAIN measurement of a wideband amplifier in the 20 to 30 GHz range using 200 MHz steps:

Measurement Mode 1.7 (cont'd)

(Special Function 1.7)

Example (cont'd)

a. Press PRESET (or send HP-IB code PR) to establish initial conditions. PRESET selects a single sideband measurement (Special Function 17.0) for the Noise Figure Test Set.

NOTE

Measurement Mode 1.7 must be activated prior to entering the frequency parameters to avoid error E35 (entered value is out of range).

b. Press 1.7 SPECIAL FUNCTION (or send HP-IB code E7) to activate Mode 1.7. Note that error E33 (IF will be out of range) is displayed. This error is cleared when the correct frequency parameters are entered in step d.

c. Press 2.1 SPECIAL FUNCTION (or send HP-IB code B1 or 2.1SP) to select a lower sideband measurement. Special Function 2.1 is used to select single sideband operation for the first frequency conversion, using the user controlled local oscillator and the external mixer.

NOTE

When a single sideband measurement is being made, the user must place a filter between the device under test and the external mixer to eliminate the unwanted sideband.


d. Set the frequency parameters for both the calibration and measurement.

e. Enter the noise source ENR table, if this has not already been done.


f. Set the user controlled local oscillator to the frequency specified by Special Function 3.1.

Measurement Mode 1.7 (cont'd) (Special Function 1.7)

Example
(cont'd)



g. To calibrate the Noise Figure Measurement System and perform a Noise Figure Test Set Fine Tuning Calibration, set up the equipment as shown below. Ensure the user controlled local oscillator frequency is set before calibration. PRESET enabled a fine tuning calibration (Special Function 36.0) each time the Noise Figure Measurement System is calibrated.



• IF THE PREAMPLIFIER AND FILTER ARE USED DURING THE MEASUREMENT (THE FILTER IS USED WHEN A SINGLE SIDEBAND MEASUREMENT IS BEING MADE), THEY MUST BE USED DURING CALIBRATION.

Measurement Mode 1.7 (cont'd)

(Special Function 1.7)


Example (cont'd)

NOTE

A Noise Figure Test Set Fine Tuning Calibration may need to be done separately from the measurement system calibration (step h). The separate fine tuning calibration is needed if a mixer is being used out in front of the Noise Figure Measurement System and a preamplifier is not being used. An Excess Noise Ratio (ENR) of 13 dB or greater is needed at the input to the Noise Figure Test Set during the fine tuning calibration.

h. Calibrate and fine tune the equipment in Measurement Mode 1.7 by pressing CALIBRATE twice (or sending HP-IB code CA).

i. To make the measurement, set up the equipment as shown below.



*THE FILTER IS NEEDED IF A SINGLE SIDEBAND MEASUREMENT IS BEING MADE.

NOTE

For the Noise Figure Measurement System specifications to be valid, the measurement must use the same START FREQ, STOP FREQ and STEP SIZE that was used for calibration. None of the calibrated points can be skipped. Also, the measurement must be done in the same direction as the calibration, for example, from start frequency to stop frequency.

This example assumes that the user controlled local oscillator is tuned to the specified frequency of 35 GHz.

j. Press CORRECTED NOISE FIGURE AND GAIN (or send HP-IB code M2).

k. Press SINGLE (or send HP-IB code W2). The Noise Figure Measurement System will sweep from 15000 to 5000 MHz in 200 MHz steps but will display the microwave measurement frequency of 20000 to 30000 MHz. After the single sweep is completed, the instrument halts.

Measurement Mode 1.7 (cont'd)

(Special Function 1.7)

Program Codes

HP-IB

The HP-IB code for Measurement Mode 1.7 is E7 (or 1.7SP). Additional HP-IB codes are given, in the Comments section, when using an external controller.

Indications

The left display shows each frequency at which a measurement is made and the EXT MIX annunciator lights. The INSERTION GAIN display shows the gain of the DUT at the displayed frequency. The NOISE FIGURE display shows the noise figure of the DUT at the displayed frequency.

Comments

An external controller can be used to control the Noise Figure Measurement System and the user controlled local oscillator in Measurement Mode 1.7. The following general conditions must be observed when using an external controller:

a. The external controller and the user controlled local oscillator must be connected to the HP-IB connector on the Noise Figure Meter.

b. HP-IB code H1 must be active.

c. Special Function 4.0 (normal talker and listener) must be active. Note that there is no HP-IB code for this special function.

d. Special Function 30.0 (free run) must be active (HP-IB code is T0).

e. The correct measurement parameters (for example, Measurement Mode, frequencies, etc.) must be established. Refer to Table 3-9, Special Function to HP-IB Code Summary, and Table 3-10, Front Panel Keys to HP-IB Code Summary, for applicable HP-IB codes.

f. Set the user controlled local oscillator to the appropriate frequency. Refer to the local oscillator's operating manual for the required HP-IB codes. Allow sufficient time for the output of the local oscillator to stabilize.

g. Perform a Noise Figure Test Set Fine Tuning Calibration and a Noise Figure Measurement System Calibration with the DUT out of the measurement system (refer to the Calibrate Detailed Operating Instruction and the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction).

A Noise Figure Test Set Fine Tuning Calibration may need to be done separately from the measurement system calibration. The separate fine tuning calibration is needed if a mixer is being used out in front of the Noise Figure Measurement System and a preamplifier is not being used. An Excess Noise Ratio (ENR) of 13 dB or greater is needed at the input to the Noise Figure Test Set during the fine tuning calibration.

h. Send the command "RM 2EN RS CA." Wait for a serial poll to return a non-zero value, indicating calibration is complete.

i. Insert the DUT into the measurement system.

j. Special Function 30.1 (trigger hold) must be active (HP-IB code is T1).

Measurement Mode 1.7 (cont'd)

(Special Function 1.7)

Comments (cont'd)

k. Set the Noise Figure Meter's SINGLE sweep on (HP-IB code is W2) or AUTO sweep on (HP-IB code is W1).

l. Trigger a measurement using the HP-IB code T2. Do not use the alternate HP-IB code 30.2SP for Special Function 30.2 as it will reset the sweep.

m. A method must be determined when to step to a new frequency after reading the noise figure results. This read operation cannot be completed until the new data is ready. It is possible to write an SRQ interrupt routine on the Data Ready Status Bit. Refer to Enabling the Service Request Condition, paragraph 3-30.

n. Continue to loop through steps l and m. A method for determining when the measurements are complete must be programmed into the external controller. One method is to compare the measurement frequency that is read from Noise Figure Meter with the stop frequency programmed into the Noise Figure Meter and terminate the program after the measurement in which they are equal.

Related Sections

Calibrate
Controller Capability of the Noise Figure Meter
Fixed IF or LO Frequency Selection
Measurement Modes
Noise Figure Test Set YIG Filter Calibration
Sideband Selection
Special Functions

Measurement Mode 1.8

(Special Function 1.8)

Description

NOTE

If the IF into the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and System Local Oscillator) can be reduced below 1600 MHz, Measurement Mode 1.3 is a better choice than Measurement Mode 1.8. Measurement Mode 1.3 requires less equipment, less noise figure is contributed by the measurement system and a pre-amplifier may not be required for the measurement.

The HP 8971B Noise Figure Test Set, a system local oscillator and a user controlled local oscillator are required for Measurement Mode 1.8.

Measurement Mode 1.8 uses two stages of frequency conversion. The user controlled local oscillator and the device under test provide the first stage of conversion. The user controlled local oscillator is not controlled by the Noise Figure Meter; the user controlled local oscillator must be controlled by the user. The second stage of conversion is provided by the system local oscillator and the Noise Figure Test Set. The Noise Figure Meter does control the system local oscillator and the Noise Figure Test Set.

Measurement Mode 1.8 provides the means of increasing the frequency range of the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and system local oscillator) from 18000 MHz to 99999 MHz. This mode uses a variable user controlled local oscillator and a fixed IF. Frequency conversion is allowed for in the device under test (DUT). Although the signal measured at the Noise Figure Measurement System INPUT is always in the range of 10 to 18000 MHz, the Noise Figure Meter uses the Excess Noise Ratio (ENR) of the noise source at the measurement frequency. However, the correct 10 to 18000 MHz ENR is used during calibration. A typical DUT is a mixer or receiver. All of the Measurement Modes can be set to use many of the other capabilities of the Noise Figure Meter. For example, each mode can make either UNCORRECTED NOISE FIGURE or CORRECTED NOISE FIGURE AND GAIN measurements. Or, the measurement results for each mode can be displayed on an oscilloscope or output to a recorder or plotter. For an explanation and comparison of the ten Measurement Modes and instructions on how to choose the appropriate Measurement Mode and sideband operation, refer to the Measurement Modes Detailed Operating Instructions.

Requirements

The following minimum requirements are necessary for the Noise Figure Measurement System and user controlled local oscillator to operate in Measurement Mode 1.8.

- a. The system local oscillator and the Noise Figure Test Set must be connected to the Noise Figure Meter's SYSTEM INTERFACE BUS connector with an HP-IB cable.
- b. Special Function 48.0 must be active (Noise Figure Meter is the controller on the system interface bus; Special Function 48.0 is the default setting, after using Special Function 0.9).
- c. Special Function 45.0 must be active (Noise Figure Test Set enabled in measurement modes 1.5 through 1.9; Special Function 45.0 is the default setting, after using Special Function 0.9.) or Special Function 45.1 (Noise Figure Test Set enabled always) must be active.

Measurement Mode 1.8 (cont'd)

(Special Function 1.8)

Requirements (cont'd)

d. The address of the Noise Figure Test Set must match the Noise Figure Test Set address that is stored in the Noise Figure Meter. Use Special Function 40.2 (Noise Figure Test Set address) to display and change the address if necessary. The default address of the Noise Figure Test Set is 10, after using Special Function 0.9.

e. Special Function 46.0 must be active (Enable system local oscillator on System Interface Bus; Special Function 46.0 is the default setting, after using Special Function 0.9).

f. The address of the system local oscillator must match the address of the system local oscillator stored in the Noise Figure Meter. Use Special Function 40.1 (system local oscillator System Interface Bus address) to display and change this address, if necessary. The default address is 19, after using Special Function 0.9.

g. The correct system local oscillator program must be active if the Noise Figure Meter is going to control the system local oscillator. The system local oscillator programs are listed below:

- HP 8671B/8672A Synthesized Signal Generator; Special Function 41.2
- HP 8673B/C (Standard) Synthesized Signal Generator; Special Function 41.3
- HP 8340B/8341B Sweep Oscillator; Special Function 41.4
- Custom local oscillator; Special Function 41.5

The custom local oscillator program will support local oscillators that may require a maximum of twenty-two characters for the frequency prefix and suffix and/or the output power prefix and suffix. The prefix and suffix define the command sequence that will set the frequency or output power.

Use Special Function 42 to define a new program for other system local oscillators.

h. Configure the user controlled local oscillator to produce the desired frequency.

i. If a free-running (non-synthesized) source is being used as the system local oscillator, a Noise Figure Test Set Coarse Tuning Calibration should have been done when the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and system local oscillator) was put together. The coarse tuning is **ONLY** required when a free-running source is the system local oscillator or repairs have been made to the Noise Figure Test Set. For more information on a Noise Figure Test Set Coarse Tuning, refer to the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction.

Procedure

There are many possible measurement procedures. However, the following general procedure applies to all cases:

NOTE

High measurement system noise figure leads to high measurement uncertainty, when measuring low gain devices. A low noise preamplifier, between the device under test and the measurement system, can

Measurement Mode 1.8 (cont'd)

(Special Function 1.8)

Procedure (cont'd)

lower system noise figure and therefore reduce the measurement uncertainty. For more information on determining if a preamplifier is needed and selection of the preamplifier, refer to the Preamplifier Selection Detailed Operating Instruction.

- a. Verify that the minimum requirements specified under Requirements are satisfied.
- b. Press PRESET.
- c. Press 1.8 SPECIAL FUNCTION to set the Noise Figure Meter to Measurement Mode 1.8.
- d. Set frequency parameters (including the fixed IF, Special Function 3.0).
- e. Enter the ENR table for calibration (Special Function 5.7) and the ENR table for the measurement (Special Function 5.8). Refer to the ENR Table Entry Detailed Operating Instruction for more information.
- f. Select appropriate smoothing (Special Function 13).
- g. Select sideband operation desired. (Special Function 2 and 17)
- h. Perform a Noise Figure Test Set Fine Tuning Calibration. Refer to the Noise Figure Test Set YIG Calibration Detailed Operating Instruction for more information.
- i. With the device under test (DUT) removed, perform a calibration of the Noise Figure Measurement System in Mode 1.8 (this is only required for a CORRECTED NOISE FIGURE AND GAIN measurement). If a preamplifier is required for the measurement, the preamplifier must be used in the calibration.
- j. Insert DUT and measure the noise figure or noise figure and gain of the DUT.

Example

To make a swept CORRECTED NOISE FIGURE AND GAIN single sideband measurement in the 30 to 45 GHz range in 200 MHz steps with a fixed IF of 4000 MHz.

NOTE

This example assumes that the Noise Figure Meter is acting as a controller and the minimum requirements specified under Requirements are satisfied. Refer to Comments for a brief description of using an external controller when in Measurement Mode 1.8.

- a. Press PRESET (or send HP-IB code PR) to establish initial conditions. PRESET selects a single sideband measurement (Special Function 17.0) for the Noise Figure Test Set.

NOTE

Measurement Mode 1.8 must be activated prior to entering the frequency parameters to avoid error E35 (entered value is out of range).

- b. Press 1.8 SPECIAL FUNCTION to activate Measurement Mode 1.8.

Measurement Mode 1.8 (cont'd) (Special Function 1.8)

**Example
(cont'd)**

c. Set the frequency parameters for both the calibration and measurement.

| | | | | |
|----------------------------------|--|-----------------------|-----------|----------|
| | Code | Function | Data | Function |
| LOCAL (keystrokes) | 1 . 8 | ● SPECIAL FUNCTION | | |
| | 2 . 1 | ● SPECIAL FUNCTION | | |
| | | START FREQ | 3 0 0 0 0 | ENTER |
| | | STOP FREQ | 4 5 0 0 0 | ENTER |
| | | STEP SIZE | 2 0 0 | ENTER |
| | 3 . 0 | ● SPECIAL FUNCTION | 4 0 0 0 | ENTER |
| HP-IB (program codes) | E8B11F4000MZFA30000MZFB45000MZSS200MZ | | | |
| | Code | | Function | |
| | Code | | Data | |
| | Code | | Code | |
| | Data | | Function | |
| | Function | | Data | |
| | Code | | Code | |
| | Data | | Function | |

d. Enter the calibration and measurement ENR tables, if this hasn't already been done (Special Functions 5.7 and 5.8).

e. Press 2.1 SPECIAL FUNCTION to enable a lower sideband measurement. Special Function 2.1 is used with the first frequency conversion, using the user controlled local oscillator and the device under test.

NOTE

When a single sideband measurement is being made, the user must place a filter between the noise source and the device under test to eliminate the unwanted sideband.


f. Configure the user controlled local oscillator to produce a 4 GHz IF at the input of the Noise Figure Measurement System. The correct frequency to set the user controlled local oscillator to can be viewed by using Special Function 3.2.

Measurement Mode 1.8 (cont'd)

(Special Function 1.8)

Example (cont'd)

g. To calibrate the Noise Figure Measurement System and perform a Noise Figure Test Set Fine Tuning calibration, set up the equipment as shown below.



NOTES

For a single sideband measurement, the external filter is not included during calibration. During calibration the Noise Figure Meter only accounts for loss after the device under test. Since the filter is before the device under test, the loss of the filter is not accounted for properly.

To account for the filter's conversion loss, enter the filter's loss (in dB) into the Noise Figure Meter using Special Function 34.2 (loss between the noise source and device under test). Also, enter the room temperature of the filter using Special Function 34.3. To turn loss compensation on, use Special Function 34.1.

h. Calibrate and fine tune in Measurement Mode 1.8 by pressing the CALIBRATE key twice. PRESET enabled a fine tune (Special Function 36.0) to be done each time a calibration is done.

Measurement Mode 1.8 (cont'd)

(Special Function 1.8)

Comments (cont'd)

- d. Special Function 30.0 (free run) should be active (HP-IB code is T0).
- e. The correct measurement parameters (for example, Measurement Mode, frequencies, etc.) must be established. Refer to Table 3-9, Special Function to HP-IB Code Summary and Table 3-10, Front Panel Keys to HP-IB Code Summary, for applicable HP-IB codes.
- f. Perform a Noise Figure Test Set Fine Tuning Calibration and a Noise Figure Measurement System Calibration with the DUT out of the measurement system (refer to the Calibrate Detailed Operating Instruction and the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction).
- g. Send the command "RM 2EN RS CA." Wait for a serial poll to return a non-zero value, indicating calibration is complete.
- h. Insert the DUT into the measurement system.
- i. Special Function 30.1 (trigger hold) must be active (HP-IB code is T1).
- j. Set the Noise Figure Meter's SINGLE sweep on (HP-IB code is W2) or AUTO sweep on (HP-IB code is W1).
- k. Set the user controlled local oscillator to the desired frequency, depending on the sideband selection. If double sideband was selected, the oscillator should be set to the measurement frequency. If lower sideband was selected, the oscillator should be set to the measurement frequency plus the IF. If upper sideband was selected, the oscillator should be set to the measurement frequency minus the IF. If sum (upconversion; Special Function 2.3) was selected, set the oscillator to the IF minus the measurement frequency. Refer to the user controlled local oscillator's operating manual for the required HP-IB codes. Allow sufficient time for the output of the user controlled local oscillator to stabilize.
- l. Trigger a measurement using the HP-IB code T2. Do not use the alternate HP-IB code 30.2SP for Special Function 30.2 as it will reset the sweep.
- m. A method must be determined when to step to a new frequency after reading the noise figure results. This read operation cannot be completed until the new data is ready. It is possible to write an SRQ interrupt routine on the Data Ready Status Bit. Refer to Enabling the Service Request Condition, paragraph 3-30.
- n. Continue to loop through steps k, l and m. A method for determining when the measurements are complete must be programmed into the external controller. One method is to compare the measurement frequency that is read from the Noise Figure Meter with the stop frequency programmed into the Noise Figure Meter and terminate the program after the measurement in which they are equal.

Related Sections

Calibrate
 Controller Capability of the Noise Figure Meter
 Fixed IF or LO Frequency Selection
 HP-IB Addresses
 Noise Figure Test Set YIG Filter Calibration
 Sideband Selection
 Special Functions
 System Interface Bus Control
 Trigger Selection

Measurement Mode 1.9

(Special Function 1.9)

Description

NOTE

The HP 8971B Noise Figure Test Set, a system local oscillator and a user controlled local oscillator are needed for Measurement Mode 1.9.

Measurement Mode 1.9 uses two stages of frequency conversion. The user controlled local oscillator and the device under test provide the first stage of conversion. The user controlled local oscillator is not controlled by the Noise Figure Meter; the user controlled local oscillator must be controlled by the user. The second stage of conversion is provided by the system local oscillator and the Noise Figure Test Set. The Noise Figure Meter does control the system local oscillator and the Noise Figure Test Set.

Measurement Mode 1.9 provides the means of increasing the frequency range of the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and system local oscillator) from 18000 to 99999 MHz. This mode provides for using a fixed-frequency user controlled local oscillator and a variable IF. Frequency conversion is allowed for in the device under test (DUT). Although the signal measured at the Noise Figure Measurement System INPUT is always in the range of 10 to 18000 MHz, the Noise Figure Meter uses the Excess Noise Ratio (ENR) of the noise source at the measurement frequency. However, the correct 10 to 18000 MHz ENR is used during calibration. A typical DUT is a mixer or receiver. All of the Measurement Modes can be set up to use many of the other capabilities of the Noise Figure Meter. For example, each mode can make either UNCORRECTED NOISE FIGURE or CORRECTED NOISE FIGURE AND GAIN measurements. Or, the measurement results for each mode can be displayed on an oscilloscope or output to a recorder or plotter. For an explanation and comparison of the ten Measurement Modes and instructions on how to choose the appropriate Measurement Mode and sideband operation, refer to the Measurement Modes Detailed Operating Instruction.

Requirements

The following minimum requirements are necessary for the Noise Figure Measurement System and the user controlled local oscillator to operate in Measurement Mode 1.9.

- a. The system local oscillator and the Noise Figure Test Set must be connected to the Noise Figure Meter's SYSTEM INTERFACE BUS connector with an HP-IB cable.
- b. Special Function 48.0 must be active (Noise Figure Meter is system controller on System Interface Bus; Special Function 48.0 is the default setting, after using Special Function 0.9).
- c. Special Function 45.0 must be active (Noise Figure Test Set enabled in measurement modes 1.5 through 1.9; Special Function 45.0 is the default setting, after using Special Function 0.9) or Special Function 45.1 (Noise Figure Test Set enabled always) must be active.
- d. The address of the Noise Figure Test Set must match the Noise Figure Test Set address that is stored in the Noise Figure Meter. Use Special Function 40.2 (Noise Figure Test Set System Interface Bus address) to display and change this address if necessary. The default address for the Noise Figure Test Set is 10, after using Special Function 0.9.

Measurement Mode 1.9 (cont'd)

(Special Function 1.9)

Requirements (cont'd)

e. Special Function 46.0 must be active (Enable system local oscillator on System Interface Bus; Special Function 46.0 is the default setting, after using Special Function 0.9).

f. The address of the system local oscillator must match the address of the system local oscillator stored in the Noise Figure Meter. Use Special Function 40.1 (system local oscillator System Interface Bus address) to display and change this address if necessary. The default address is 19, after using Special Function 0.9.

g. The correct system local oscillator program must be active if the Noise Figure Meter is going to control the system local oscillator. The system local oscillator programs are listed below:

- HP 8671B/8672A Synthesized Signal Generator; Special Function 41.2
- HP 8673B/C (Standard) Synthesized Signal Generator; Special Function 41.3
- HP 8340B/8341B Sweep Oscillator; Special Function 41.4
- Custom local oscillator; Special Function 41.5

The custom local oscillator program will support local oscillators that may require a maximum of twenty-two characters for the frequency prefix and suffix and/or the output power prefix and suffix. The prefix and suffix define the command sequence that will set the frequency or output power.

Use Special Function 42 to define a new program for other system local oscillators.

h. The user controlled local oscillator must be configured to produce the desired IF (10 to 18000 MHz).

i. If a free-running (non-synthesized) source is being used as the system local oscillator, a Noise Figure Test Set Coarse Tuning Calibration should have been done when the Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and system local oscillator) was put together. The coarse tuning is **ONLY** required when a free-running source is the system local oscillator or repairs have been made to the Noise Figure Test Set. For more information on a Noise Figure Test Set Coarse Tuning, refer to the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction.

Procedure

There are many possible measurement procedures. However, the following general procedure applies to all cases:

NOTE

High measurement system noise figure leads to high measurement uncertainty, when measuring low gain devices. A low noise preamplifier, between the device under test and the measurement system, can lower system noise figure and therefore reduce the measurement uncertainty. For more information on determining if a preamplifier is needed and selection of the preamplifier, refer to the Preamplifier Selection Detailed Operating Instruction.

Measurement Mode 1.9 (cont'd) (Special Function 1.9)

Procedure (cont'd)

- a. Verify that the minimum requirements specified under Requirements are satisfied.
- b. Press PRESET.
- c. Press 1.9 SPECIAL FUNCTION to set the Noise Figure Meter to Measurement Mode 1.9.
- d. Set frequency parameters (including the fixed frequency for the user controlled local oscillator, Special Function 3.1).
- e. Enter ENR tables for calibration and measurement (use Special Functions 5.7 and 5.8).
- f. Select sideband operation desired (Special Function 2 and 17).
- g. Set up the user controlled local oscillator to produce the desired output, as specified by Special Function 3.1.
- h. Perform a Noise Figure Test Set Fine Tuning Calibration. For more information, refer to the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction.
- i. Calibrate the Noise Figure Measurement System in Mode 1.9 (this is only required for a CORRECTED NOISE FIGURE AND GAIN measurement). If a preamplifier is required for the measurement, the preamplifier must be used in the calibration.
- j. Insert DUT into the measurement system and make a noise figure or noise figure and gain measurement.

Example

NOTE

The following example assumes that the Noise Figure Meter is the controller. An external controller can be used to control the Noise Figure Measurement System and the user controlled local oscillator. For more information on using an external controller, refer to Comments at the end of this instruction.

To make a swept CORRECTED NOISE FIGURE AND GAIN single sideband measurement over an IF of 10 to 12 GHz using 100 MHz steps with a fixed user controlled local oscillator frequency of 5 GHz.

- a. Press PRESET (or send HP-IB code PR) to establish initial conditions. PRESET selects a single sideband measurement (Special Function 17.0) for the Noise Figure Test Set.

NOTE


Measurement Mode 1.9 must be activated prior to entering the frequency parameters to avoid error E35 (entered value is out of range).

- b. Press 1.9 SPECIAL FUNCTION (or send HP-IB code E9) to activate Measurement Mode 1.9.

Measurement Mode 1.9 (cont'd) (Special Function 1.9)

**Example
(cont'd)**

c. Set the frequency parameters for both the calibration and measurement.



d. Enter the ENR tables for calibration (Special Function 5.7) and the measurement (Special Function 5.8), if this hasn't already been done. Refer to the ENR Table Entry Detailed Operating Instruction for more information.

e. Press 2.1 SPECIAL FUNCTION to select a lower sideband measurement. Special Function 2.1 is used to select the sideband operation desired for the first frequency conversion, using the user controlled local oscillator and the device under test.

NOTE

When a single sideband measurement is being made, the user must place a filter between the noise source and the device under test to eliminate the unwanted sideband.

f. To calibrate the Noise Figure Measurement System and perform a Noise Figure Test Set Fine Tuning Calibration, set up the equipment as shown below.


Measurement Mode 1.9 (cont'd) (Special Function 1.9)

**Example
(cont'd)**

NOTES

For a single sideband measurement, the external filter is not included during calibration. During calibration the Noise Figure Meter only accounts for loss after the device under test. Since the filter is before the device under test, the loss of the filter is not accounted for properly.


To account for the filter's conversion loss, enter the filter's loss (in dB) into the Noise Figure Meter using Special Function 34.2 (loss between the noise source and device under test). Also, enter the room temperature of the filter using Special Function 34.3. To turn loss compensation on, use Special Function 34.1.



• IF THE PREAMPLIFIER IS USED DURING THE MEASUREMENT, IT MUST BE USED DURING CALIBRATION.

g. Calibrate the Noise Figure Measurement System and fine tune the Noise Figure Test Set in Mode 1.9 by pressing CALIBRATE twice (or sending HP-IB code CA). PRESET enabled a fine tuning calibration (Special Function 36.0) each time the Noise Figure Measurement system is calibrated.

h. To make the measurement, set up the equipment as shown below.



• IF A SINGLE SIDEBAND MEASUREMENT IS BEING MADE, A FILTER MUST BE USED.

Measurement Mode 1.9 (cont'd)

(Special Function 1.9)

Example (cont'd)

NOTE

For the Noise Figure Measurement System specifications to be valid, the measurement must use the same START FREQ, STOP FREQ and STEP SIZE that was used for calibration. None of the calibrated points can be skipped. Also, the measurement must be done in the same direction as the calibration, for example, from start frequency to stop frequency.

This example assumes that the user controlled local oscillator is tuned to the specified frequency (5 GHz).

i. Press CORRECTED NOISE FIGURE AND GAIN (or send HP-IB code M2).

j. Press SINGLE (or send HP-IB code W2). The Noise Figure Measurement System will sweep from 10 to 12 GHz in 100 MHz steps. After the single sweep is completed, the system halts.

Program Codes



The HP-IB code for Measurement Mode 1.9 is E9 (or 1.9SP). The Comments section contains additional HP-IB codes, when using an external controller.

Indications

The left display shows each IF frequency at which a measurement is made and the EXT MIX annunciator lights. The INSERTION GAIN display shows the gain of the DUT at the displayed frequency. The NOISE FIGURE display shows the noise figure of the DUT at the displayed frequency.

Comments

An external controller can be used to control the Noise Figure Measurement System and the user controlled local oscillator in Measurement Mode 1.9. The following general conditions must be observed when using an external controller:

a. The external controller and the user controlled local oscillator must be connected to the HP-IB connector on the Noise Figure Meter.

b. HP-IB code H1 must be active.

c. Special Function 4.0 (normal talker and listener) must be active. Note that there is no HP-IB code for this special function.

d. Special Function 30.0 (free run) should be active (HP-IB code is T0).

e. The correct measurement parameters (for example, Measurement Mode, frequencies, etc.) must be established. Refer to Table 3-9, Special Function to HP-IB Code Summary, and Table 3-10, Front Panel Keys to HP-IB Code Summary, for applicable HP-IB codes.

f. Set the user controlled local oscillator to the appropriate frequency. Refer to the local oscillator's operating manual for the required HP-IB codes. Allow sufficient time for the output of the local oscillator to stabilize.

g. Perform a Noise Figure Test Set Fine Tuning Calibration and a Noise Figure Measurement System Calibration with the DUT out of the measurement system (refer to the Calibrate Detailed Operating Instruction and the Noise Figure Test Set YIG Filter Calibration Detailed Operating Instruction).

Measurement Mode 1.9 (cont'd)

(Special Function 1.9)

Comments (cont'd)

h. Send the command "RM 2EN RS CA." Wait for a serial poll to return a non-zero value, indicating calibration is complete.

i. Insert the DUT into the measurement system.

j. Special Function 30.1 (trigger hold) must be active (HP-IB code is T1).

k. Set the Noise Figure Meter's SINGLE sweep on (HP-IB code is W2) or AUTO sweep on (HP-IB code is W1).

l. Trigger a measurement using the HP-IB code T2. Do not use the alternate HP-IB code 30.2SP for Special Function 30.2 as it will reset the sweep.

m. A method must be determined when to step to a new frequency after reading the noise figure results. This read operation cannot be completed until the new data is ready. It is possible to write an SRQ interrupt routine on the Data Ready Status Bit. Refer to Enabling the Service Request Condition, paragraph 3-30.

n. Continue to loop through steps l and m. A method for determining when the measurements are complete must be programmed into the external controller. One method is to compare the measurement frequency that is read from the Noise Figure Meter with the stop frequency programmed into the Noise Figure Meter and terminate the program after the measurement in which they are equal.

Related Sections

Calibrate
Controller Capability of the Noise Figure Meter
ENR Table Entry
Fixed IF or LO Frequency Selection
Noise Figure Test Set YIG Filter Calibration
Sideband Selection
Special Functions
System Interface Bus Control

Noise Figure Test Set YIG Filter Calibration

(Special Functions 36 and 64)

Description

When the Noise Figure Meter, Noise Figure Test Set and system local oscillator are configured to form the Noise Figure Measurement System, the passbands of the Noise Figure Meter and the Noise Figure Test Set must be aligned.

The alignment process involves a Coarse Tuning Calibration (Special Function 64) and a Fine Tuning Calibration (Special Function 36).

Coarse Tuning Calibration (Special Function 64). The Coarse Tuning Calibration will be done at the factory and needs to be done when the Noise Figure Measurement System is first configured and the system local oscillator is a freerunning source or repairs are done to the Noise Figure Test Set.

NOTE

Sweepers are not recommended as the system local oscillator when the Noise Figure Test Set is operating in band SSB3. High local oscillator accuracy is needed by the Noise Figure Measurement System in this band. A better choice is a local oscillator that is a synthesizer.

The Coarse Tuning Calibration will align the passbands of the Noise Figure Meter and Noise Figure Test Set at the following frequencies: 2401 MHz, 3000 MHz, and every 500 MHz from 3500 MHz to 18000 MHz. At each of these frequencies, the Noise Figure Test Set preselector YIG filter is peaked at the frequency being calibrated. The entire calibration procedure will take about 15 minutes. The Coarse Tuning Calibration is not needed each time the Noise Figure Measurement System is powered up. Normally, the Coarse Tuning Calibration will only need to be done once or twice in the lifetime of a Noise Figure Test Set. The results of the Coarse Tuning Calibration will be saved in memory, in the Noise Figure Test Set.

Special Function 64.0 is used to enable a Coarse Tuning Calibration. The upper frequency limit of the Noise Figure Test Set can be changed using Special Function 64.1. The allowable range for Special Function 64.1 is 2400 to 30000 MHz. Special Function 64.1 is useful if the system local oscillator doesn't go to 18000 MHz. With Special Function 64.1, the Noise Figure Test Set can be calibrated to the nearest 500 MHz of the upper frequency limit desired.

NOTE

If the system local oscillator doesn't go to 18000 MHz, Special Function 64.1 MUST be used. If Special Function 64.1 isn't used, error code E19 (Noise Figure Test Set Calibration Failed) will be generated.

Fine Tuning Calibration (Special Function 36). Fine tuning calibration is used to align the passbands of the Noise Figure Meter and Noise Figure Test Set, at the measurement frequencies defined by START FREQ, STOP FREQ and STEP SIZE. Fine Tuning Calibration is required when the Noise Figure Test Set is in single sideband operation (Special Function 17.0) and the measurement frequency is greater than 2400 MHz (SSB3). There is no limit to the number of times that a Fine Tuning Calibration may be performed. The Noise Figure Measurement System will perform better the more frequently a Fine Tuning Calibration is done. However, once the Fine Tuning Calibration is done, a new Fine Tuning Calibration should not be required unless the Noise Figure

Noise Figure Test Set YIG Filter Calibration (cont'd)

(Special Functions 36 and 64)

Description (cont'd)

Test Set is turned off, the ambient air temperature around the Noise Figure Test Set changes by more than $\pm 5^{\circ}\text{C}$ since the last Fine Tuning Calibration or the START FREQ, STOP FREQ or STEP SIZE have been changed.

Fine Tuning Calibration is controlled by Special Functions 36.0 through 36.4.

The progress of the Coarse and Fine Tuning Calibrations may be viewed on an analog oscilloscope, using Special Functions 97.1 and 97.2. These special functions can be used to diagnose any measurement system setup problems. Special Functions 97.1 and 97.2 are described in the Example section of this instruction. Refer to Viewing a Coarse or Fine Tuning Calibration on an Oscilloscope.

The following discussion will help to give a better understanding of Special Functions 36.0 through 36.4, 64.0 and 64.1:

Special Function 36.0 will enable a Fine Tuning Calibration to be done just before the Noise Figure Measurement System is calibrated, when a CORRECTED NOISE FIGURE AND GAIN measurement is to be made. Also, error twenty-eight (E28) is enabled. Possible causes for error twenty-eight are given in the Comments section, at the end of this instruction. Error twenty-eight (E28) is a warning to the user and is not necessarily an indication of any hardware problem.

Special Function 36.1 will disable a Fine Tuning Calibration each time the Noise Figure Measurement System is calibrated. The user can perform a Fine Tuning Calibration using Special Function 36.3.

Special Function 36.2 disables a Fine Tuning Calibration each time the Noise Figure Measurement System is calibrated and also disables the error twenty-eight warning. The user can perform a Fine Tuning Calibration using Special Function 36.3. This special function is useful if the user is not concerned with absolute accuracy and understands the accuracy problems associated with not having the Noise Figure Test Set fine tuned. Possible causes of error twenty-eight are found in the Comments section at the end of this instruction. Even though the error is not displayed, a warning indication still exists in the Noise Figure Meter's extended status byte. Normally, using Special Function 36.2 is not a good idea because it removes the safeguard of the Noise Figure Measurement System checking to see if a Fine Tune Calibration is needed.

Special Function 36.3 will perform a Fine Tuning Calibration of the Noise Figure Test Set, immediately. Special Function 36.1 is enabled, since the Fine Tuning Calibration has been completed using Special Function 36.3. Additional Fine Tuning Calibrations are not needed unless the temperature inside the Noise Figure Test Set drifts five degrees centigrade or new frequency points are to be measured.

Special Function 36.4 allows the user to define additional Fine Tuning Calibration frequencies, between the frequencies set by START FREQ, STOP FREQ and STEP SIZE. The passbands are aligned for the frequency point added by Special Function 36.4, but the point added is not a calibrated point of the Noise Figure Measurement System. In other words, any noise contributed by the Noise Figure Measurement System has not been factored out at the frequency point added. Special Function 36.4 may be useful for an uncorrected noise figure measurement or as a way of re-fine tuning a single frequency point.

Noise Figure Test Set YIG Filter Calibration (cont'd)

(Special Functions 36 and 64)

Procedure

To select Special Functions 36.0 through 36.3 and 64.0, key in the special function code desired and press the SPECIAL FUNCTION key. To select Special Function 64.1, press 64.1 SPECIAL FUNCTION, select the frequency desired and press ENTER. To use Special Function 36.4, press the FREQUENCY key and select the frequency desired. Press ENTER. Then, press 36.4 SPECIAL FUNCTION.

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|---|------|-----------------------|--|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| Enable Fine Tuning Calibration before Noise Figure Measurement System Calibration is done. Error E28 is enabled. | 36.0 | FT | N | Y | Y | On | On | On |
| Disable Fine Tuning Calibration before Noise Figure Measurement System Calibration is done. | 36.1 | FD | N | Y | Y | Off | Off | Off |
| Disable Fine Tuning Calibration before Noise Figure Measurement System Calibration is done. Also, error twenty-eight is disabled. | 36.2 | FW | Y | Y | Y | Off | Off | Off |
| Perform a Fine Tuning Calibration from START FREQ to STOP FREQ and enable Special Function 36.1. | 36.3 | PF | N | N | N | Off | Off | Off |
| Enable a Fine Tuning Calibration at the current frequency. | 36.4 | FF | N | N | N | Off | Off | Off |
| Enable a Coarse Tuning Calibration. | 64.0 | CP | N | N | N | Off | Off | Off |
| Set the upper frequency limit of the Noise Figure Test Set. | 64.1 | CU | N | N | N | NC | 18000 | 18000 |

¹Table categories are explained in the Special Functions Detailed Operating Instruction.

Noise Figure Test Set YIG Filter Calibration (cont'd)

(Special Functions 36 and 64)

Example

To select a coarse tuning calibration:

| | |
|---|---|
| <p>LOCAL (keystrokes)</p> | <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Code</p> <div style="display: flex; gap: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">6</div> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">4</div> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">.</div> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">0</div> </div> </div> <div style="text-align: center;"> <p>Function</p> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"> <div style="width: 10px; height: 10px; background-color: black; border-radius: 50%; margin-right: 5px;"></div> <p>SPECIAL FUNCTION</p> </div> </div> </div> |
| <p>HP-IB (program codes)</p> | <p>CP</p> |

The following examples will describe how to perform a Coarse Tuning Calibration, Fine Tuning Calibration and how to view a Coarse or Fine Tuning Calibration on an oscilloscope.


Coarse Tuning Calibration. The following discussion will describe how to perform a Coarse Tuning Calibration:

NOTE

A Coarse Tuning Calibration should only be done when the Noise Figure Measurement System is first configured and a freerunning source is being used as the system local oscillator or repairs have been made to the Noise Figure Test Set.

The Excess Noise Ratio (ENR) of the noise source should be 12 to 13 dB or more from 2401 to 18000 MHz or a preamplifier may be required.

a. Connect the equipment as shown below.



b. Turn the equipment on and allow a twenty (20) minute warm up period, before performing the Coarse Tuning Calibration.

c. If the upper frequency limit of the Noise Figure Test Set is to be less than 18000 MHz, enter the upper limit using Special Function 64.1.

Noise Figure Test Set YIG Filter Calibration (cont'd)

(Special Functions 36 and 64)

Example (cont'd)

d. After the equipment has warmed up for twenty minutes, press 64.0 SPECIAL FUNCTION. The Coarse Tuning Calibration will take about fifteen (15) minutes.

NOTE

If data is read from the Noise Figure Meter, over the Hewlett-Packard Interface Bus, during a Coarse Tuning Calibration, the Noise Figure Meter will output a special HP-IB code for the NOISE FIGURE window. For more information on this HP-IB code, refer to the Error Messages and Recovery Detailed Operating Instruction.

e. To view the Coarse Tuning Calibration, refer to Viewing a Coarse or Fine Tuning Calibration on an Oscilloscope, at the end of the Example section.

Fine Tuning Calibration. The following discussion will describe how to perform a Fine Tuning Calibration:

NOTE

Fine Tuning Calibration is only required when single sideband operation (Special Function 17.0) has been selected on the Noise Figure Test Set and the measurement frequency is greater than 2400 MHz (SSB3).

There is no limit on the number of times that a Fine Tuning Calibration may be performed. But, a Fine Tuning Calibration is not needed each time a measurement is made.

a. Connect the equipment as shown below. The noise source should have a minimum ENR (Excess Noise Ratio) of 13 dB. The noise source should be placed as close as possible to the RF INPUT of the Noise Figure Test Set. If a preamplifier will be used in the measurement, the preamplifier may be placed between the noise source and the RF INPUT during the Fine Tuning Calibration. For Measurement Modes 1.6 and 1.7, when there is quite a bit of loss in the measurement setup, it is possible to do the Fine Tune Calibration by connecting the noise source directly to the Noise Figure Test Set RF INPUT. This will ensure that 13 dB of ENR is available for the Fine Tuning Calibration. In this case, the Fine Tuning Calibration can be performed using Special Function 36.3. In Measurement Modes 1.6 and 1.7, it is also possible to do a Fine Tuning Calibration with the external mixer in place and a preamplifier in the measurement system, to increase the available noise power at the Noise Figure Test Set RF INPUT. The preamplifier should be low noise or it may affect the Fine Tuning Calibration.


NOTE

Allow the equipment to warm up for twenty (20) minutes, before performing the Fine Tuning Calibration.

Noise Figure Test Set YIG Filter Calibration (cont'd)

(Special Functions 36 and 64)

Example (cont'd)



b. Select the start, stop and step size frequencies, using the START FREQ, STOP FREQ and STEP SIZE keys. Refer to the Sweep Detailed Operating Instruction for an explanation of START FREQ, STOP FREQ and STEP SIZE.

c. The Noise Figure Measurement System is now ready to perform a Fine Tuning Calibration. The Fine Tuning Calibration will be performed each time the Noise Figure Measurement System is calibrated, if Special Function 36.0 has been selected. Or, Special Function 36.3 can be selected to perform a Fine Tuning Calibration from the START FREQ to the STOP FREQ, immediately. The calibration will take from five to ten seconds per frequency point.

NOTE

When a Fine Tuning Calibration has been enabled and the decimal point is flashing in the NOISE FIGURE display, the Noise Figure Test Set is not at operating temperature. The calibration cannot be completed until the instrument is up to temperature. The Noise Figure Meter is waiting for the YIG filter temperature control loop, in the Noise Figure Test Set, to lock. The flashing decimal can also be caused by a power loss to the Noise Figure Test Set. The time needed for the temperature control loop to lock could be fifteen minutes, if the Noise Figure Test Set was cold or four to five minutes if the Noise Figure Test Set was warmed-up before it lost power. When the loop locks, the Fine Tuning Calibration will be completed.

It is normal for the system local oscillator to change frequency a number of times at each frequency point. This is part of the calibration process.

If data is read from the Noise Figure Meter, over the Hewlett-Packard Interface Bus, during a Fine Tuning Calibration, the Noise Figure Meter will output a special HP-IB code for the NOISE FIGURE window. For more information about this HP-IB code, refer to the Error Messages and Recovery Detailed Operating Instruction.

Noise Figure Test Set YIG Filter Calibration (cont'd)

(Special Functions 36 and 64)

Example (cont'd)

Measurement accuracy is dependent on the temperature inside the Noise Figure Test Set. If the temperature drifts approximately five degrees centigrade, since the last Fine Tuning Calibration, error twenty-eight (E28) will be generated. The Fine Tuning Calibration must be repeated using Special Function 36.3.

d. If a frequency not selected by START FREQ, STOP FREQ or STEP SIZE is desired, use Special Function 36.4. To select this frequency, press the FREQUENCY key and key in the frequency desired. Press ENTER. Then, press 36.4 SPECIAL FUNCTION, to start the Fine Tuning Calibration at the selected frequency.

NOTE

The passbands of the Noise Figure Meter and Noise Figure Test Set are aligned for the frequency fine tuned with Special Function 36.4. When the Noise Figure Measurement System is calibrated, for a CORRECTED NOISE FIGURE AND GAIN measurement, the noise contributed by the Noise Figure Measurement System is not factored out, at the frequency fine tuned by Special Function 36.4. Unless, the frequency fine tuned is a calibrated frequency point of the Noise Figure Measurement System.

e. To view the progress of the Fine Tuning Calibration, refer to Viewing a Coarse or Fine Tuning Calibration, at the end of the Example section.

Viewing a Coarse or Fine Tuning Calibration on an Oscilloscope. The following discussion will describe how to view a Coarse or Fine Tuning Calibration on an analog oscilloscope:

NOTE

An analog oscilloscope must be used with the Noise Figure Meter. A digital oscilloscope won't work with the Noise Figure Meter.

a. Connect the X-AXIS, Y-AXIS and Z-AXIS outputs on the rear panel of the Noise Figure Meter to the A, B and Z (or horizontal, vertical and Z) inputs of the oscilloscope. Select DC mode for all oscilloscope inputs.

b. Press 7.1 SPECIAL FUNCTION (or send HP-IB code A1) to display the test pattern on the oscilloscope screen.

c. Using the oscilloscope's position and gain controls, position the test pattern where desired.

d. Press 97.1 SPECIAL FUNCTION (or send HP-IB code Y9). The oscilloscope will now display the peaking (maximum power) at each frequency point for a Coarse or Fine Tuning Calibration, when enabled by Special Function 36 or 64.

NOTES

If a preamplifier is being used, the maximum and minimum oscilloscope display limits will need to be changed to view the noise peak at optimum scale. Special Function 97.1 sets the maximum limit to 500 and the minimum limit to 120.

Noise Figure Test Set YIG Filter Calibration (cont'd)

(Special Functions 36 and 64)

Example (cont'd)

To change the maximum limit and minimum limit, use the front panel keys of GAIN MAX (Special Function 8.4) and GAIN MIN (Special Function 8.3). The limits are entered by pressing the appropriate key, keying in the data and pressing ENTER.

e. When finished viewing the Coarse or Fine Tuning Calibration, press 97.2 SPECIAL FUNCTION (or send HP-IB code Y8). Special Function 97.2 disables the oscilloscope from displaying the Coarse or Fine Tuning Calibration and restores the GAIN MIN and GAIN MAX settings to where they were before Special Function 97.1 was enabled.

Program Codes

HP-IB

For HP-IB codes, refer to the Procedure above.

Indications

For a Coarse and Fine Tuning Calibration, the left display shows each Noise Figure Test Set input frequency at which a calibration is made. The INSERTION GAIN display shows "8971." The NOISE FIGURE display shows "CAL."

When viewing a Coarse Tuning Calibration, a noise peak will be drawn on the oscilloscope for each frequency point being coarse tuned.

When viewing a Fine Tuning Calibration, a first pass at finding the noise peak is drawn and then a reference power line is drawn. Finally, a dot is placed where the actual noise peak was found. These steps are repeated for each frequency point to be fine tuned.

For a Coarse or Fine Tuning Calibration, three attempts will be made at each frequency point, to find the noise peak. After three attempts, error code E19 will be generated.

Comments

The causes that generate an error twenty-eight (E28) are given below:

a. The YIG filter, in the Noise Figure Test Set, has not been fine tuned at the current frequency and coarse tune data is being used. The measurement may not be valid.

b. The current frequency of the Noise Figure Test Set YIG filter has been interpolated from the Fine Tuning Calibration data. The measurement may not be valid.

c. The Noise Figure Test Set has been fine tuned, but the temperature has drifted more than five degrees centigrade, since the last Fine Tuning Calibration. The YIG heater loop must be reset and new fine tuning data gathered. Use Special Function 36.3 to reset the heater loop and gather the new fine tune data.

Usually, the solution to error twenty-eight (E28) is to perform a Fine Tuning Calibration using Special Function 36.3.

Related Sections

Calibrate
Measurement Modes 1.0 through 1.9
Sweep

Noise Figure (Uncorrected) and Noise Figure and Gain (Corrected)

Description **UNCORRECTED NOISE FIGURE** measures the combined noise figure of the device under test and the measurement system (including the effect of the Noise Figure Test Set, local oscillator, mixer, cables, connectors and adapters).

CORRECTED NOISE FIGURE AND GAIN removes the measurement system noise contribution and allows only the noise figure and gain of the device under test to be displayed. The Noise Figure Meter must be calibrated in the measurement frequency range and measurement mode before a corrected noise figure and gain measurement can be made.


Procedure To measure uncorrected noise figure, press the **NOISE FIGURE** key.

To measure corrected noise figure and gain, press the **NOISE FIGURE AND GAIN** key. If the Noise Figure Meter is not correctly calibrated, error code E20 will be displayed.

| Front Panel Key | Program Code HP-IB | Stored in Continuous Memory ¹ | Can be Stored and Recalled | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|-----------------------------------|-----------------------|--|----------------------------|-------------------------------------|---------------------------------|
| NOISE FIGURE (UNCORRECTED) | M1 | N | N | Active | Active |
| NOISE FIGURE AND GAIN (CORRECTED) | M2 | N | N | Off | Off |

¹Table categories are explained in the Preset Conditions and Power-Up Sequence Detailed Operating Instruction.

Example To measure corrected noise figure and gain:

| | |
|-----------------------|--|
| LOCAL (keystrokes) | Measurement ● CORRECTED  |
| HP-IB (program codes) | M2 |

Program Codes



For HP-IB program codes, refer to Procedure above.

Indications

When the instrument is making uncorrected noise figure measurements, the **UNCORRECTED** LED above the **NOISE FIGURE** key is illuminated. The measurement result is displayed in the **NOISE FIGURE** display. In addition, the **INSERTION GAIN** display is blank.

Noise Figure (Uncorrected) and Noise Figure and Gain (Corrected) (cont'd)

| | |
|-----------------------------|--|
| Indications (cont'd) | When the instrument is making noise figure and gain measurements, the CORRECTED LED above the NOISE FIGURE AND GAIN key is illuminated. The gain of the device under test (DUT) appears in the INSERTION GAIN display and the noise figure of the DUT appears in the NOISE FIGURE display. |
| Comments | <p>For CORRECTED NOISE FIGURE AND GAIN measurements, it is necessary to calibrate the instrument each time there is a change in measurement modes, equipment (except the DUT), or frequency parameters (if the new frequency parameters are outside of the calibrated range).</p> <p>UNCORRECTED NOISE FIGURE and CORRECTED NOISE FIGURE AND GAIN measurements are always corrected for T_{cold} and ENR.</p> <p>Measured noise can be expressed in a variety of units: F, F dB, Y, Y dB, and T_e K. Refer to the Display Units Selection Detailed Operating Instruction for additional information.</p> <p>The noise figure measurement range is 0 to 30 dB. The gain measurement range (for total noise figures less than 30 dB) is -20 to at least +40 dB, for the Noise Figure Meter.</p> <p>High measurement system noise figure leads to high measurement uncertainty when measuring low gain devices. A low noise preamplifier, between the device under test and the measurement system, can lower system noise figure, and therefore reduce the measurement uncertainty. For more information, refer to the Preamplifier Selection Detailed Operating Instruction.</p> |
| Related Sections | <p>Calibrate</p> <p>Display Units Selection</p> <p>Preset Conditions and Power-Up Sequence</p> |

Power Measurements

(Special Function 9)

Description

Special Function 9 measures noise power density in dB relative to -174 dBm/Hz with the noise source on or off. Either an approximate or a calibrated measurement can be made. The value -174 dBm/Hz was chosen because this is the thermal noise at 290K in a 1 Hz bandwidth. This special function can be used to make absolute power density measurements or simply to verify that the measurement system setup is operating and the signal path is complete. To exit from Special Function 9, press either **UNCORRECTED NOISE FIGURE** or **CORRECTED NOISE FIGURE AND GAIN**.

Procedure

To select a power density measurement, key in the corresponding Special Function code and then press the **SPECIAL FUNCTION** key.

Special Functions 9.3 and 9.4 require that a calibration be performed prior to activating the special function. If the calibration has not been performed, error E20 (not calibrated) is displayed and the special function is not activated.

Since the power measurements can be performed from any Measurement Mode, refer to the applicable Detailed Operating Instruction for the correct calibration procedures.

| Special Function | | Program Code Code HP-IB | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|---------------------------|------|--------------------------------------|-----------------------------|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| SOURCE Off (uncalibrated) | 9.1 | N5 or 9.1SP | N | Y | Y | Off | Off | Off |
| SOURCE On (uncalibrated) | 9.2 | N6 or 9.2SP | N | Y | Y | Off | Off | Off |
| SOURCE Off (calibrated) | 9.3 | N7 or 9.3SP | N | Y | Y | Off | Off | Off |
| SOURCE On (calibrated) | 9.4 | N8 or 9.4SP | N | Y | Y | Off | Off | Off |

¹Table categories are explained in the Special Functions Detailed Operating Instruction.

Example

To select an uncalibrated power measurement with the noise source on:

| | |
|---------------------------------|----|
| LOCAL (keystrokes) | |
| HP-IB (program codes) | N6 |

Power Measurements (cont'd)

(Special Function 9)

Program Codes

For HP-IB codes, refer to Procedure above.

HP-IB

Indications

The NOISE FIGURE display shows the selected power measurement result in dB.

Comments

Special Functions 9.3 and 9.4 measure the power density delivered from the DUT. The rest of the measurement system setup is corrected for by the calibration (second stage correction).

The units shown in the NOISE FIGURE display are dB referenced to 290K (-174 dBm/Hz). The equation is:

$$\text{Power displayed} = 10 \log \frac{\text{unknown power density}}{290} \text{ dB}$$

Special Functions 9.1 and 9.2 are similar to 9.3 and 9.4 except that they are not calibrated and they use nominal values for noise figure. These Special Functions are primarily used to verify that the measurement system is operating.

Special Functions 9.1 and 9.2 do not correct for the RF attenuators. There can be an error for very low power when the lowest RF attenuation is selected.

Related Sections

Calibrate
Measurement Modes 1.1 through 1.9
Special Functions

Preamplifier Selection

Description

Measurement system noise figure directly affects measurement uncertainty (as the measurement system noise figure increases, measurement uncertainty increases—see figure). The measurement system is defined as those components that are included when the measurement system is calibrated. When the measurement system noise figure is reduced to a specific level, its effect on measurement uncertainty is minimal.

The effect of measurement system noise figure on measurement uncertainty can be reduced to this specific level with a preamplifier. The preamplifier is placed between the device under test (DUT) and the measurement system. The preamplifier is part of the measurement system when it is calibrated.

When measuring low noise figure/gain devices, it may not be possible to minimize the inaccuracy effect of the measurement system. In these cases, it is best to reduce measurement system noise figure as much as possible (2 or 3 dB is possible), and thus, reduce its effect on measurement uncertainty.

This discussion will cover the following topics:

- Determining the measurement system noise figure that minimizes measurement uncertainty.
- Selecting the preamplifier

Procedure


Determining Measurement System Noise Figure

The first step is to determine the measurement system noise figure that minimizes measurement uncertainty. First, add the DUT noise figure and gain dB values. If that number is greater than 17 dB, use the following equation to determine the measurement system noise figure that minimizes measurement uncertainty:

$$NF_{\min} = NF_{\text{dut}} + G_{\text{dut}} - 15 \text{ dB}$$

NOTE

If the noise figure and gain of the DUT is less than 17 dB, you will only be able to reduce the measurement system noise figure effect on uncertainty, not minimize it. By reducing measurement system noise figure to 2 or 3 dB using a preamplifier, you will significantly reduce its effect on



Noise Figure Measurement Uncertainty versus Measurement System Noise Figure

This is a graph of overall noise figure measurement uncertainty versus measurement system noise figure. "DUT F + G" is the device under test noise figure plus gain in dB. The curves are based on typical values of noise figure instrumentation uncertainty (0.1 dB), gain instrumentation uncertainty (0.15 dB), noise source ENR uncertainty (0.1 dB), measurement system SWR (1.7), noise source SWR (1.15), DUT input SWR (1.5) and DUT output SWR (1.9).

Preamplifier Selection (cont'd)

Procedure (cont'd)

measurement uncertainty. For DUTs with noise figure and gain less than 17 dB, use 2 or 3 dB, for $F_{amp/sys}$ in the "Selecting the Preamplifier" section.

- NF_{min} is the measurement system noise figure that minimizes measurement uncertainty. NF_{min} is in dB.
- NF_{dut} is the estimated noise figure of the device under test. NF_{dut} is in dB.
- G_{dut} is the estimated gain of the device under test. G_{dut} is in dB.
- 15 dB is a fixed amount that is subtracted from the total of NF_{dut} and G_{dut} . The value of 15 dB was derived from a number of measurement uncertainty versus measurement system noise figure curves. The points at which the curves flattened out were observed. The flattened portion of the curve is when changing measurement system noise figure no longer affects measurement uncertainty.

Selecting the Preamplifier

Once the measurement system noise figure [NF_{min}] is determined, the preamplifier is selected. The noise figure of the preamplifier must be less than NF_{min} .

From the cascade gain equation, the following equation is used to determine the preamplifier needed:

NOTE

The terms of the equation were in dB and have been converted to linear terms (ratios). There are no units associated with the linear terms (ratios).

$$G_{preamp} = \frac{F_{no\ amp/sys} - 1}{F_{amp/sys} - F_{amp}}$$

- G_{preamp} is the gain of the preamplifier (in linear terms) needed to produce NF_{min} .
- $F_{no\ amp/sys}$ is the noise figure of the measurement system, before the preamplifier is added.
- $F_{amp/sys}$ is the noise figure of the preamplifier and the measurement system. $F_{amp/sys}$ is the linear ratio of NF_{min} .
- F_{amp} is the noise figure of the preamplifier. F_{amp} must be less than $F_{amp/sys}$.

The equation will determine the gain of the preamplifier (in linear terms) needed to produce NF_{min} . To convert the linear gain of the preamplifier to a gain in dB, use the following equation:

$$10 \log_{10}(\text{preamplifier linear gain}) = \text{gain in dB}$$

Preamplifier Selection (cont'd)

Example

In the following example the measurement system noise figure that will minimize measurement uncertainty will be determined and the gain of the preamplifier will be calculated.

NOTE

It is assumed that NF_{dut} is 15 dB and G_{dut} is 10 dB.

Using the equation, a measurement system noise figure is arrived at:

$$NF_{min} = NF_{dut} + G_{dut} - 15 \text{ dB}$$

$$NF_{min} = 15 \text{ dB} + 10 \text{ dB} - 15 \text{ dB}$$

$$NF_{min} = 10 \text{ dB}$$

Using the second equation, the gain of the preamplifier (in linear terms) is arrived at:

NF_{min} must be converted to linear terms. NF_{min} is then substituted in the equation below as $F_{amp/sys}$. $F_{amp/sys}$ is then 10. The value used for $F_{no \text{ amp/sys}}$ is a typical measurement system value of 20 dB (100 linear). If we use a preamplifier with a noise figure of 6 dB (4 linear), the minimum gain of the preamplifier can be calculated using the following equation:

$$G_{preamp} = \frac{F_{no \text{ amp/sys}} - 1}{F_{amp/sys} - F_{amp}}$$

$$G_{preamp} = \frac{100 - 1}{10 - 4}$$

$$G_{preamp} = \frac{99}{6}$$

$$G_{preamp} = 16.5 \text{ (linear)} \\ = 24.3 \text{ dB}$$

A preamplifier with 24.3 dB or greater of gain and 6 dB or less of noise figure will be needed to reduce the measurement system noise figure to a level where it minimizes measurement uncertainty.

Preset Conditions and Power-Up Sequence

(Includes Special Functions 0.0 and 0.9)

Description

Power-Up. When first turned on, the Noise Figure Meter performs a sequence of internal checks after which the instrument is ready to make measurements. During the power-up sequence, all front panel indicators light for approximately two seconds to allow the operator to determine if any are defective. Then, "Ctrl" appears in the INSERTION GAIN display and "on" or "OFF" appears in the NOISE FIGURE display. If the Noise Figure Meter is the System Interface Bus controller (Special Function 48.0) "on" will be displayed. If the Noise Figure Meter is not the System Interface Bus controller (Special Function 48.1) "OFF" will be displayed. Next, "Fr" appears in the INSERTION GAIN display and "CAL" appears in the NOISE FIGURE display for approximately five seconds while the Noise Figure Meter performs a frequency calibration. When the frequency calibration is completed, the Noise Figure Meter restores the same configuration it had before the power was removed. Except that:

- a. Sweep is always off.
- b. The measurement is always UNCORRECTED NOISE FIGURE.
- c. The instrument always turns on in local mode (instead of HP-IB remote).
- d. Calibration data is not retained when power is removed.
- e. Special Functions 25, 30 through 32, 35.1, 43, 44, 49.2 through 49.4 and 60 through 72 are not remembered when power is removed.

Preset Functions. The Noise Figure Meter has three levels of preset: Special Function 0.9, PRESET and Special Function 0.0. Special Function 0.9 is the upper level of preset; Special Function 0.9 sets all conditions set by PRESET and Special Function 0.0 and sets default values for some special functions, not set by PRESET. Special Function 0.9 does not reset the ENR (Excess Noise Ratio) tables and does not clear the IF calibration data. PRESET is the second level of preset; PRESET sets all conditions set by Special Function 0.0 and sets the default values for some of the special functions. Special Function 0.0 is the lowest level of preset. More detail is given for Special Function 0.9, PRESET and Special Function 0.0 in the following text.

Special Function 0.9 and PRESET. Special Function 0.9 and the PRESET key set the Noise Figure Meter to a known state. The front panel is set to the conditions listed in the "Special Function 0.9, Preset and HP-IB Clear Conditions" column in Table 3-12, Front Panel Summary. Table 3-13 lists the default data values that are set, by Special Function 0.9 and PRESET, for some of the special functions. Table 3-14, Special Functions Summary, in the Special Functions Detailed Operating Instruction provides a complete list of Special Function 0.9 and PRESET conditions for special functions.

In the "Program Code" column in Table 3-12, program codes that are equivalent to front panel keystrokes are listed. HP-IB codes control the Noise Figure Meter's functions over the HP-IB.

The "Stored in Continuous Memory" column in Table 3-12 indicates whether or not the status of a front panel key is retained when the Noise Figure Meter is turned off.

The "Can Be Stored and Recalled" column in Table 3-12 indicates whether or not the status of a front panel key can be stored in an internal storage register for recall at a later time.

Preset Conditions and Power-Up Sequence (cont'd)

(Includes Special Functions 0.0 and 0.9)

Table 3-12. Front Panel Summary

| Front Panel Key | Program Code HP-IB | Stored In Continuous Memory | Can be Stored and Recalled | Special Function 0.9 and Preset (and HP-IB Clear) Conditions | References and Comments |
|---|-----------------------|-----------------------------|----------------------------|--|--|
| AUTO Sweep | W1 | N | N | Off | Sweep |
| CALIBRATE | CA | N | N | Off | Calibrate |
| DECREASE | DE | Y | N | 1 | Smoothing |
| ENTER | EN | — | — | — | General Operating Instructions |
| ENR | NR | Y | N | NC | ENR Table Entry |
| FREQ INCR | FN | Y | Y | 20 MHz | Fixed Frequency Increment |
| ▼ | DN | — | — | — | Fixed Frequency Increment |
| ▲ | UP | — | — | — | Fixed Frequency Increment |
| FREQUENCY | FR | Y | Y | 30 MHz | Fixed Frequency Tuning |
| INCREASE | IN | Y | N | 1 | Smoothing |
| NOISE FIGURE (UNCORRECTED) | M1 | N | N | Active | Noise Figure (Uncorrected) and Noise Figure and Gain (Corrected) |
| NOISE FIGURE AND GAIN (CORRECTED) | M2 | N | N | Off | Noise Figure (Uncorrected) and Noise Figure and Gain (Corrected) |
| PRESET | PR | — | — | — | Preset Conditions and Power-Up Sequence |
| RECALL | RC | — | — | — | Store and Recall |
| GRAPHIC SCALE | | | | | |
| Noise Min | NL | Y | Y | 0 dB | Data Output to Oscilloscopes, Recorders and Plotters. |
| Noise Max | NU | Y | Y | 8 dB | Data Output to Oscilloscopes, Recorders and Plotters. |
| Gain Min | GL | Y | Y | 0 dB | Data Output to Oscilloscopes, Recorders and Plotters. |
| Gain Max | GU | Y | Y | 40 dB | Data Output to Oscilloscopes, Recorders and Plotters. |
| SEQ | SQ | — | — | — | Sequence |
| SINGLE Sweep | W2 | N | N | Off | Sweep |
| SPECIAL FUNCTION | SP | — | — | — | Special Functions |
| START FREQ | FA | Y | Y | 10 MHz | Sweep |
| STEP SIZE | SS | Y | Y | 20 MHz | Sweep |
| STOP FREQ | FB | Y | Y | 1600 MHz | Sweep |
| STORE | ST | — | — | — | Store and Recall |
| Sweep and Calibrate Off (must be used to turn these functions off over the HP-IB) | W0 | — | — | — | Sweep |

Y = Yes, N = No, NC = No Change, — = Not Applicable

Preset Conditions and Power-Up Sequence (cont'd)

(Includes Special Functions 0.0 and 0.9)

Table 3-13. Special Function 0.9 and Preset Default Values for Special Functions

| Special Function | | Preset Default Value | Special Function 0.9 Default Value |
|---|------|--|--|
| Description | Code | | |
| Addresses (HP-IB and SIB) | | | |
| Noise Figure Meter | 40.0 | | 8 |
| System Local Oscillator | 40.1 | | 19 |
| Noise Figure Test Set | 40.2 | | 10 |
| Plotter | 40.3 | | 5 |
| System Interface Bus | 40.4 | | 8 |
| Pass Control | 40.5 | | 16 |
| IF | 3.0 | 30 MHz (Modes 1.1 and 1.3) 3500 MHz (Modes 1.6 and 1.8) | 30 MHz (Modes 1.1 and 1.3) 3500 MHz (Modes 1.6 and 1.8) |
| LO Frequency | 3.1 | 10000 MHz (Modes 1.2 and 1.4) 44000 MHz (Modes 1.7 and 1.9) | 10000 MHz (Modes 1.2 and 1.4) 44000 MHz (Modes 1.7 and 1.9) |
| Loss Compensation | | | |
| Before DUT | 34.2 | 0 dB | 0 dB |
| Temperature of Losses | 34.3 | OK | OK |
| After DUT | 34.4 | 0 dB | 0 dB |
| Measurement Mode 1.1, Measurement Mode 1.2, and Measurement Mode 1.3 | | | |
| Start Frequency | 1.1 | 8000 MHz | 8000 MHz |
| Stop Frequency | 1.2 | 12000 MHz | 12000 MHz |
| Step Size | 1.3 | 200 MHz | 200 MHz |
| Noise Figure Measurement System Internal IF | | | |
| SSB2 IF | 19.2 | 700 MHz | 700 MHz |
| SSB3 IF | 19.3 | 450 MHz | 450 MHz |
| DSB IF | 19.4 | 25 MHz | 25 MHz |
| Oscilloscope Limits | | | |
| Noise Figure Lower Limit | 8.1 | 0 | 0 |
| Noise Figure Upper Limit | 8.2 | 8 | 8 |
| Gain Lower Limit | 8.3 | 0 | 0 |
| Gain Upper Limit | 8.4 | 40 | 40 |
| Plotter Functions | | | |
| Noise Pen | 25.3 | 1 | 1 |
| Gain Pen | 25.4 | 2 | 2 |
| Plot Title | 25.5 | HP 8970B Noise Figure Meter | HP 8970B Noise Figure Meter |
| Programming the System | | | |
| Local Oscillator | | | |
| Power Level | 42.5 | 6 dBm | 6 dBm |
| Set Sequence | 35.2 | 1-9 | 1-9 |
| Smoothing Factor | 13.2 | 1 | 1 |
| Spot ENR | 5.3 | 15.2 dB | 15.2 dB |
| System Local Oscillator Sideband Crossover frequency; Measurement Modes 1.5 through 1.9 | 17.2 | 16 GHz | 16 GHz |
| T _{cold} | 6.0 | 296.5K | 296.5K |
| Spot T _{hot} | 5.4 | 9893K | 9893K |

Preset Conditions and Power-Up Sequence (cont'd)

(Includes Special Functions 0.0 and 0.9)

Description (cont'd)

Special Functions are off or set to their zero-suffix mode. The exception is Service Request, which is set to enable an HP-IB code error to cause an SRQ (Special Function 44.3). In addition, default data values are set for the special functions listed in Table 3-13.

Special Function 0.0. Special Function 0.0 initializes selected special functions. It is similar to PRESET except that default data values are not set. Existing values do not change. Refer to Table 3-14, Special Function Summary, in the Special Functions Detailed Operating Instruction for a complete list of Special Function 0.0 conditions.

Procedure

To set the Noise Figure Meter to a known state, press the PRESET key or key in 0.9 and press the SPECIAL FUNCTION key.

To initialize selected special functions, key in 0.0, then press the SPECIAL FUNCTION key.

Example

To initialize selected special functions:

| | |
|-----------------------|----|
| LOCAL (keystrokes) | |
| (program codes) | CS |

Program Codes



| Parameter | Program Code |
|----------------------|------------------|
| Special Function 0.9 | 0.9SP |
| PRESET | PR |
| Special Function 0.0 | CS |

Indications

After entering Special Function 0.9 or pressing PRESET, the INSERTION GAIN display shows "Fr" and the NOISE FIGURE display shows "CAL" while a frequency calibration is performed. After approximately five seconds, the left display shows 30 MHz, the INSERTION GAIN display is blank, and the NOISE FIGURE display shows noise figure in units of F dB. Also, the UNCORRECTED NOISE FIGURE LED is illuminated.

When Special Function 0.0 is executed, the SPECIAL FUNCTION key LED turns off if it was on.

Comments

Special Function 0.0 does not affect any data entered by special functions or front panel keys.

PRESET is identical to the Device Clear command over the HP-IB.

Preset Conditions and Power-Up Sequence (cont'd)

(Includes Special Functions 0.0 and 0.9)

**Comments
(cont'd)**

PRESET does not effect calibration data or information in the ENR table.

Special Function 0.9, PRESET and Special Function 0.0 do not modify any data in the internal storage registers.

When using HP-IB code 0.9SP to issue Special Function 0.9, allow ten seconds to pass before giving the next command.

**Related
Sections**

Calibration, Frequency
Special Functions

Programming The System LO (Special Function 42)

Description

Special Function 42 can be used to modify the predefined system local oscillator programs for the HP 8340B/8341B Sweep Oscillator (Special Function 41.4), HP 8350B Sweep Oscillator (Special Function 41.0), the HP 8671B/8672A Synthesized Signal Generators (Special Function 41.2), the HP 8673B/C Synthesized Signal Generator (Special Function 41.3) or a custom local oscillator (Special Function 41.5). Special Function 42 can also be used to define a new program for other system local oscillators provided the local oscillator is HP-IB compatible. However, a thorough understanding of the HP-IB program requirements and restrictions that apply to the system local oscillator is required.

The custom local oscillator program is different from the other predefined system LO programs. The other programs will only support a frequency prefix or suffix of two characters, maximum. The same is true for the power prefix or suffix. The custom local oscillator program will support a system LO that could require a maximum of twenty-two characters in the prefix and suffix. This is true for frequency and power.

The five predefined system LO programs are stored in permanent memory (ROM). Activating Special Function 41.0, 41.2, 41.3, 41.4 or 41.5 loads the corresponding predefined program from permanent memory into temporary memory (RAM). The programs stored in the permanent memory are never changed; only the program in temporary memory can be modified. Special Function 42 can change the program data that is stored in the temporary memory. One of the predefined programs or the last modified program is always present in the temporary memory. And, only the program in temporary memory can control the system LO.

Detailed examples will be used to explain the use of Special Function 42. However, a brief definition of the purpose of the individual parts of the program that can be changed using Special Function 42 will make the programs easier to understand:

a. Special Function 42.0 is used to display and change the auxiliary commands. The purpose of the auxiliary commands are to set the system LO to continuous wave (CW) operation.

b. Special Function 42.1 is used to display and change the CW prefix and suffix. The purpose of the prefix and suffix is to correctly format the frequency commands from the Noise Figure Meter to the system LO. The format is different for different LOs. Frequency data of up to five digits is located between the prefix and suffix. The frequency information is determined by the frequency parameters entered into the Noise Figure Meter during the measurement setup and by the measurement mode in which the instrument is operating. The custom local oscillator program (Special Function 41.5) overrides Special Function 42.1. Refer to Special Function 42.7.

c. Special Function 42.2 is used to display and change the settling time (in ms). The purpose of the settling time is to ensure that the Noise Figure Meter waits a sufficient amount of time after issuing the frequency command and the auxiliary commands to allow the system LO output to stabilize.

d. Special Functions 42.3 and 42.4 are used to display and change the minimum and maximum frequencies that the program will accept. These entries are in MHz. In most cases, they will represent the frequency capability of the system LO. However, they do not affect the system LO but are only used by the Noise Figure Meter to determine if a requested frequency parameter will be accepted. If an attempt to enter an out-of-range frequency is made, the Noise Figure Meter displays one of the invalid frequency entry error messages.

Programming The System LO (cont'd)

(Special Function 42)

Description (cont'd)

e. Special Function 42.5 is used to display and set the output signal power level of the system local oscillator. The allowable range is 0 to 30 dBm. If a level less than zero or greater than thirty is desired, the auxiliary commands (Special Function 42.0) need to be used to set the level. Do not use Special Function 42.5 to exceed the minimum or maximum output signal power level limits of the local oscillator being used. For Special Functions 41.0 through 41.4, Special Function 42.5 sets the command sequence (prefix and suffix) automatically as the power level (0 to 30 dBm) is entered. Special Function 41.5 (custom local oscillator program) requires that Special Function 42.6 be used with Special Function 42.5. The order is Special Function 42.6 then Special Function 42.5.

f. Special Function 42.6 is used only when the custom local oscillator (Special Function 41.5) program has been selected. Special Function 42.6 is used to properly format the command sequence that will set the output signal power level. Special Function 42.6 is used to set the power prefix and suffix in place of Special Function 42.0. The prefix and suffix are set much like Special Function 42.1 sets the frequency prefix and suffix. Once Special Function 42.6 is set up, Special Function 42.5 is used to set the power level. With Special Function 42.6 the prefix and suffix can total as many as twenty-four (24) characters. The twenty-four characters include the count character for the prefix, the prefix characters, the count character for the suffix and the characters for the suffix. The count characters indicate the number of characters that are in the prefix or suffix.

g. Special Function 42.7 is used only when the custom local oscillator (Special Function 41.5) program has been selected. Special Function 42.7 is used to properly format the command sequence that will set the output frequency. Special Function 42.7 is similar to Special Function 42.1 (prefix and suffix). With Special Function 42.1 the prefix and suffix, used to format the output frequency, is limited to four (4) ASCII characters. With Special Function 42.7 the prefix and suffix can total as many as twenty-four (24) characters. The twenty-four characters include the count character for the prefix, the prefix characters, the count character for the suffix and the characters for the suffix. The count characters indicate the number of characters in the prefix or suffix.

Predefined Program Listings

The listings for the five predefined programs are shown below. Each listing shows the data that is stored in permanent memory. Also shown are the system LO Commands (Special Functions 42.0 through 42.7) and the data that can be modified by each special function.

The following conventions are used in the program listings:

HP-IB

a. All HP-IB program codes consist of ASCII characters. The numbers and letters shown before the parentheses (in Special Functions 42.0, 42.1 and 42.5 through 42.7) are the ASCII characters that make up valid HP-IB program codes.

There is one exception, the custom local oscillator program. "Count" is not ASCII. Count is used to show the position in the program where the prefix and suffix count characters are to be placed. The count character indicates the number of characters in the prefix or suffix.

Programming The System LO (cont'd)

(Special Function 42)

Predefined Program Listings (cont'd)

System LO Predefined Program Listings

| System LO Commands (Special Function 42) | HP8340B/8341B (41.4) or HP 8350B (41.0) Program | HP 8671B/8672A Program (41.2) | HP 8673B/C Program (41.3) | Custom Local Oscillator Program (41.5) |
|---|--|----------------------------------|------------------------------|--|
| 42.0 Auxiliary Commands | (0) | M(77) } AM off | R (82) } RF on | M (77) } |
| | (0) | 0(48) } | 1 (49) } | O (79) } |
| | (0) | N(78) } FM off | D (68) } | D (68) } |
| | (0) | 7(55) } | 0 (48) } | : (58) } |
| | (0) | (0) | A (65) } | S (83) } |
| | (0) | (0) | 0 (48) } | T (84) } |
| | (0) | (0) | P (80) } | A (65) } |
| | (0) | (0) | 0 (48) } | T (84) } |
| | (0) | (0) | | Space (32) |
| | (0) | (0) | (0) | O (79) |
| | (0) | (0) | (0) | F (70) |
| | (0) | (0) | (0) | F (70) |
| | (0) | (0) | (0) | (0) |
| | (0) | (0) | (0) | (0) |
| 42.1 Prefix Suffix | C(67) | P(80) | F (70) | Special Function 42.1 is not used with Special Function 41.5. Refer to Special Function 42.7. |
| | W(87) | (255) | R (82) | |
| | M(77) | Z(90) | M (77) | |
| | Z(90) | 0(48) | Z (90) | |
| 42.2 Settling Time | 60 ms | 20 ms | 30 ms | 30 ms |
| 42.3 Minimum Frequency | 2000 MHz | 2000 MHz | 2000 MHz | 10 MHz |
| 42.4 Maximum Frequency | 18000 MHz | 18000 MHz | 26500 MHz | 60000 MHz |
| 42.5 Output Signal Power Level | 6 dBm | 7 dBm | 8 dBm | 8 dBm |
| 42.6 Power Prefix Power Suffix | | | | Count (4) P (80) O (79) W (87) Space (32) |
| | | | | Count (5) Space (32) D (68) B (66) M (77) ; (59) |
| 42.7 Frequency Prefix | | | | Count (5) F (70) R (82) E (69) Q (81) Space (32) |

Programming The System LO (cont'd)

(Special Function 42)

Predefined Program Listings (cont'd)

External LO Predefined Program Listings (cont'd)

| System LO Commands (Special Function 42) | HP8340B/8341B (41.4) or HP 8350B (41.0) Program | HP 8671B/8672A Program (41.2) | HP 8673B/C Program (41.3) | Custom Local Oscillator Program (41.5) |
|---|--|----------------------------------|------------------------------|---|
| Frequency Suffix | | | | Count (5) Space (32) M (77) H (72) Z (90) ; (59) |

b. The numbers shown within parentheses are the decimal equivalent of the required ASCII or count character. (It is this decimal value that is entered into the Noise Figure Meter) For example, in the first line of the listing for the HP 8671B/8672A program, the entry is M(77). The M is the first ASCII character of a valid HP-IB program code for the HP 8671B/8672A. The 77 is the decimal equivalent of the letter M.

The two exceptions to this rule are (0) in the HP 8340B/8341B/8350B program and (255) in the HP 8671B/8672A program. The (0) entry is used as a placeholder. It is ignored by the Noise Figure Meter and is not transmitted on the HP-IB. In the HP 8340B/8341B/8350B program (Special Functions 41.0 and 41.4), there are no preset auxiliary commands. This area contains zeros because no single program can control all possible HP 8340B/8341B/8350B configurations. This portion of the program must be correctly entered by the user to match the configuration of the HP 8340B/8341B/8350B used with the Noise Figure Meter. The (255) in the HP 8671B/8672A program is used by the Noise Figure Meter to establish that, when controlling the HP 8671B/8672A, leading zeros must be sent if they are required to complete five digits of frequency data.

c. The numbers shown without parentheses (in Special Functions 42.2, 42.3, and 42.4) are the actual values used for that function. For example, the "60 ms" shown as the settling time for the HP 8340B/8341B/8350B program is the actual settling time allowed by that program.

d. The comments following the brackets, such as in the HP 8671B/8672A program, are the functions performed by each HP-IB code. Note that many two-character HP-IB codes use the first character to establish the instrument function and the second character to establish the setting of that function.

In all the programs, a maximum five digits of frequency information are sent between the prefix and the suffix. This information is generated by the front panel settings of frequency parameters on the Noise Figure Meter.

Procedure

To activate a specific programming function, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.

Programming The System LO (cont'd) (Special Function 42)

**Procedure
(con't)**

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Con- tinuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|--|------|-----------------------|---|----------------------------------|----------------------------------|------------------------------------|--|------------------------------------|
| Description | Code | | | | | | | |
| Auxiliary Commands | 42.0 | AC or 42.0SP | N | Y | Y | NC | NC | 0 |
| CW Prefix and Suffix | 42.1 | PS or 42.1SP | N | Y | N | NC | NC | CW;MZ |
| Settling Time in ms | 42.2 | TM or 42.2SP | N | Y | N | NC | NC | 60 |
| Minimum Frequency in MHz | 42.3 | MN or 42.3SP | N | Y | N | NC | NC | 2000 |
| Maximum Frequency in MHz | 42.4 | MX or 42.4SP | N | Y | N | NC | NC | 18000 |
| Output Signal Power Level | 42.5 | PL or 42.5SP | N | Y | Y | NC | NC | 6.0 dBm |
| Power Prefix and Suffix (Special Function 41.5) | 42.6 | PC or 42.6SP | N | Y | N | NC | NC | POW DBM; |
| Frequency Prefix and Suffix (Special Function 41.5) | 42.7 | FC or 42.7SP | N | Y | N | NC | NC | FREQ MHZ; |

¹ Table categories are explained in the Special Functions Detailed Operating Instruction.

Entering Data

Special Function 42.0 allows for modification of the auxiliary commands of the program stored in temporary memory. If one of the predefined system LO programs is to be modified, Special Function 41.0 through 41.5 should be activated first to ensure that the correct program is in the temporary memory.



An auxiliary command is simply an HP-IB program code required to control one function of the system LO. Each program code consists of one or more ASCII character. The decimal equivalent of each ASCII character is stored in one of the fifteen data locations available for auxiliary commands.

The general procedure for entering data using Special Function 42.0 is as follows:

- a. Determine what system LO functions are to be controlled by the Noise Figure Meter.
- b. Use the system LO's manual to look up the HP-IB program codes for the above functions.
- c. Use Table 3-11, located in Remote Operation near the front of this section, to look up the decimal equivalent for each of the ASCII characters used for the program codes.
- d. On the Noise Figure Meter, press 42.0 SPECIAL FUNCTION to display the current number stored in the first of the fifteen data locations. Enter the decimal equivalent of the desired ASCII character from the front panel of the Noise Figure Meter. The allowable range of decimal values is 0 to 255.
- e. Press the ENTER key on the Noise Figure Meter's front panel. The next data location available for modification will appear in the Noise Figure Meter's left display. If no change to the existing data is desired, press ENTER to advance to the next data location.

Programming The System LO (cont'd)

(Special Function 42)

Procedure (cont'd)

f. Continue stepping through the data locations until all fifteen have been filled. If all of the auxiliary command data locations are not used in a specific application, always enter zeros in the remaining locations to avoid possible HP-IB command errors.

After all fifteen locations are displayed, the Noise Figure Meter returns to the previous front panel setup the next time ENTER is pressed. It is also possible to exit Special Function 42.0 at any time by pressing FREQUENCY (and still retain the data).

HP-IB

Special Function 42.1 allows for modification of the CW prefix and suffix commands (Special Functions 41.0 through 41.4 ONLY) for the system local oscillator program. The prefix is the system LO's HP-IB program code for CW. The suffix is the system LO's program code for MHz. The CW prefix and suffix commands are entered in a manner similar to the auxiliary commands (that is, the decimal equivalent of each ASCII character is entered into the Noise Figure Meter). However, the prefix and suffix HP-IB program codes must each be two ASCII characters or less because only four data locations are available for this Special Function. Enter zeros in any data locations that are not used. The allowable range of decimal values is 0 to 255.

For Special Functions 42.2 through 42.5, the decimal value is entered directly into the Noise Figure Meter. The settling time is entered in ms. The allowable range is 0 to 65530 ms. Frequency is entered in MHz. The allowable range is 0 to 99999 MHz.

The output power is entered in dBm. The allowable range is 0 to 30 dBm.

Special Function 42.6 is ONLY used with the custom local oscillator program (Special Function 41.5). Special Function 42.6 is used to properly format the command sequence that is used to set the output signal power level. Special Function 42.6 allows entry of the prefix and suffix for the output signal power level. The count character for the prefix, the prefix characters, the count character for the suffix and the suffix characters can be a maximum of twenty-four (24) characters. The prefix, suffix and count characters are entered in a manner similar to the auxiliary commands (that is, the decimal equivalent of each ASCII character is entered into the Noise Figure Meter. Since the count characters are decimal, they are entered as they are.) Once the prefix and suffix have been entered, Special Function 42.5 is used to enter the actual power level (0 to 30 dBm). For an example of using the custom local oscillator program and Special Function 42.6, refer to Example two (2) at the end of this instruction. With the other local oscillator programs (Special Functions 41.0 through 41.4), Special Function 42.5 sets the power level and the prefix and suffix for the output signal power level.

Special Function 42.7 is used with the custom local oscillator program (Special Function 41.5) ONLY. Special Function 42.7 is used to properly format the command sequence that is used to set the output frequency. Special Function 42.7 allows entry of the prefix and suffix for the output frequency. The count character for the prefix, the prefix characters, the count character for the suffix and the suffix characters can be a maximum of twenty-four (24) characters. The prefix, suffix and count characters are entered in a manner similar to the auxiliary commands (that is, the decimal equivalent of each ASCII character is entered into the Noise Figure Meter. Since the count characters are in decimal, they are entered as they are.) For an example of using the custom local oscillator program and Special Function 42.7, refer to Example two (2) at the end of this instruction.

Programming The System LO (cont'd)

(Special Function 42)

Procedure (cont'd)

Modified data can be entered in any order. For example, the settling time can be modified prior to changing the frequency prefix and suffix.

Running the System LO Program

Before the program can be run, several conditions must be met:

- a. The system local oscillator must be connected to the Noise Figure Meter's SYSTEM INTERFACE BUS connector with an HP-IB cable.
- b. Special Function 48.0 active (Noise Figure Meter is the system controller on System Interface Bus; Special Function 48.0 is the default setting, after using Special Function 0.9.).
- c. Special Function 46.0 active (Enable local oscillator on System Interface Bus; Special Function 46.0 is the default setting, after using Special Function 0.9.).
- d. The address of the system local oscillator must match the system local oscillator address that is stored in the Noise Figure Meter. Use Special Function 40.1 (system local oscillator address) to display and change the address, if necessary.
- e. Select the proper measurement mode, 1.1 through 1.9.
- f. The internal sweep of the system LO (if one exists) should be off.

Once the above conditions are met, the system LO program stored in the Noise Figure Meter's temporary memory runs whenever a frequency value is entered from the front panel of the Noise Figure Meter and the system LO is required. The program is also triggered each time an auxiliary command is changed when a system LO is connected.

When the program is running the following sequence occurs:

- a. A frequency command is given.
- b. The power level is set.
- c. The auxiliary commands are given.
- d. The Noise Figure Meter waits for the programmed settling time and then makes a measurement.

This sequence is repeated until all of the frequencies required by the measurement setup have been sent and the measurement results obtained.

HP-IB

Each time the frequency is changed the Noise Figure Meter issues an HP-IB command string. The Noise Figure Meter sends the following HP-IB commands to the system LO in the order indicated:

- a. REN and ATN are both set true.
- b. the LO's listen address is sent.
- c. ATN is released (that is, set false).
- d. the frequency command is sent.
- e. the power command is sent.
- f. the auxiliary commands are sent.
- g. carriage return (CR) and line feed (LF) are sent.

Programming The System LO (cont'd)

(Special Function 42)

Procedure (cont'd)

Because the frequency command precedes the auxiliary commands, a Preset or Initialize command cannot be used in the auxiliary commands. These type of commands will prevent the system LO from tuning to the required frequencies because after the LO tunes to the requested frequency, it will be reset to its original frequency.

Examples

Example 1—Modifying the Output Power Level for a Predefined Program

In example 1, the HP 8671B/8672A program is modified for different output power levels. Modifying the output power level will probably be the most frequent change made to this predefined program.

NOTE

The actual power level command is not contained in the predefined program. The power level is entered with a separate Special Function.

a. On the Noise Figure Meter, press 41.2 SPECIAL FUNCTION to load the HP 8671B/8672A program from permanent memory to temporary memory.

b. Changing the output power level is a simple procedure. Press 42.5 SPECIAL FUNCTION and key in the level desired (0 to 30 dBm). Press ENTER. Be sure not to exceed the limits of the system LO being used. For a power level less than 0 dBm or greater than 30 dBm, the auxiliary commands can be used.

c. Each time the power level is changed, step b is repeated.

Example 2—Using the Custom Local Oscillator Program

The Custom Local Oscillator (Special Function 41.5) Program is meant to be used with local oscillators that require anywhere from two (2) to twenty-two (22) ASCII characters to define the command sequence that sets the output frequency or output power. Special Functions 42.0 (Auxiliary Commands), 42.2 (Settling Time), 42.3 (Minimum Frequency), 42.4 (Maximum Frequency) and 42.5 (Output Signal Power Level) are still valid when using the Custom Local Oscillator Program. Special Function 42.1 is not valid with the Custom Local Oscillator Program.

The following procedure outlines the steps to be followed when using the Custom Local Oscillator Program:

a. Press 46.1 SPECIAL FUNCTION. This disables the system local oscillator commands on the System Interface Bus.

b. Press 41.5 SPECIAL FUNCTION. This brings the Custom Local Oscillator Program from permanent memory (ROM) to temporary memory (RAM).

NOTE

Once the parameters for Special Function 41.5 have been selected, enabling Special Function 41.5 again will set the default conditions.

c. Press 42.0 SPECIAL FUNCTION. Modify the auxiliary commands, if desired, as described earlier under Entering Data.

Programming The System LO (cont'd)

(Special Function 42)

Examples (cont'd)

d. Press 42.2 SPECIAL FUNCTION. Enter the settling time of the local oscillator being used.

e. Press 42.3 SPECIAL FUNCTION. Enter the minimum frequency of the local oscillator being used.

f. Press 42.4 SPECIAL FUNCTION. Enter the maximum frequency of the local oscillator being used.

g. Press 42.6 SPECIAL FUNCTION. Enter the count character for the prefix, the prefix characters, the count character for the suffix and the suffix characters for the output signal power level. The prefix and suffix can be found in the local oscillator's operating manual. The prefix and suffix are used to format the command sequence that sets the power level. The prefix, suffix, count character for the prefix and count character for the suffix can be a maximum of twenty-four (24) characters. The count character indicates the number of ASCII characters in the prefix or suffix. The prefix and suffix should be entered using the following format:

CPPPPCSSSS

C equals the decimal count character. P equals the prefix ASCII characters. S equals the suffix ASCII characters.

Use the front panel to enter the ASCII characters using their decimal equivalents. Since the count characters are in decimal, they are entered as they are. Press ENTER each time a decimal number is keyed in.

h. Press 42.5 SPECIAL FUNCTION. Enter the power level (0 to 30 dBm) using the front panel keys. Press ENTER.

i. Press 42.7 SPECIAL FUNCTION. Enter the count character for the prefix, the prefix characters, the count character for the suffix and the suffix characters for the output frequency. The prefix and suffix can be found in the local oscillator's operating manual. The prefix and suffix are used to format the command sequence that sets the output frequency. The prefix, suffix, count character for the prefix and count character for the suffix can be a maximum of twenty-four (24) characters. The count characters indicate the number of ASCII characters in the prefix or suffix. The prefix and suffix should be entered using the following format:

CPPPPCSSSS

C equals the decimal count character. P equals the prefix ASCII characters. S equals the suffix ASCII characters.

Use the front panel to enter the ASCII characters using their decimal equivalents. Since the count characters are in decimal, they are entered as they are. Press ENTER each time a decimal number is keyed in.

j. Press 46.0 SPECIAL FUNCTION. This enables the system local oscillator on the System Interface Bus.

Programs Available to Control The System LO

(Special Function 41)

Description

Special Function 41 selects predefined programs to control the system LO. Special Function 41.0 selects the program for the HP 8350B Sweep Oscillator, Special Function 41.2 selects the program for the HP 8671B/8672A Synthesized Signal Generators, Special Function 41.3 selects the program for the HP 8673B/C Synthesized Signal Generator, Special Function 41.4 selects the program for the HP 8340B/8341B Sweep Oscillator and Special Function 41.5 selects the program for the custom local oscillator. A listing of these programs is contained in the Comments section of this instruction.

The programs are activated when Special Function 46.0 (enable system local oscillator on the System Interface Bus), a Measurement Mode (1.1 through 1.4 or 1.6 through 1.9), and the correct predefined program has been selected. The programs can be modified using Special Function 42 (System Local Oscillator Commands). Refer to the Programming the System Local Oscillator Detailed Operating Instruction for additional information on how to modify these programs.

Procedure


To select one of the predefined programs key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.

| Special Function | | Program Code HP-IB | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|--|------|-----------------------|-----------------------------|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| HP 8350B Sweep Oscillator Program | 41.0 | J0 or 41.0SP | N | Y | N | NC | NC | On |
| HP 8671B/8672A Synthesized Signal Generator Program | 41.2 | J2 or 41.2SP | N | Y | N | NC | NC | Off |
| HP 8673B/C Synthesized Signal Generator Program ² | 41.3 | J3 or 41.3SP | N | Y | N | NC | NC | Off |
| HP 8340B/8341B Sweep Oscillator Program | 41.4 | J4 or 41.4SP | N | Y | N | NC | NC | Off |
| Custom Local Oscillator Program | 41.5 | J5 or 41.5SP | N | Y | N | NC | NC | Off |

¹ Table categories are explained in the Special Functions Detailed Operating Instruction.
² If the HP 8673B Option 008 or HP 8673D Synthesized Signal Generator is used as the system local oscillator, the auxiliary commands for the predefined program (Special Function 41.3) will need to be modified. For additional information, refer to the Comments section at the end of this instruction.

Example

To select the predefined program to control the HP 8671B/8672A:



Programs Available to Control The System LO (cont'd)

(Special Function 41)

Program Codes

HP-IB

Comments

For HP-IB codes, refer to Procedure.

A listing of the predefined programs is provided here for a quick reference. A complete explanation of these programs and instructions on how to modify them are contained in the Programming the System LO Detailed Operating Instruction.

System LO Predefined Program Listings

| System LO Commands (Special Function 42) | HP8340B/8341B (41.4) or HP 8350B (41.0) Program | HP 8671B/8672A Program (41.2) | HP 8673B/C Program (41.3) | Custom Local Oscillator Program (41.5) |
|--|---|--|---|--|
| 42.0 Auxiliary Commands | (0) (0) (0) (0) (0) (0) (0) (0) (0) (0) (0) (0) (0) | M(77) } AM off O(48) } N(78) } FM off 7(55) } (0) (0) (0) (0) (0) (0) (0) (0) | R (82) } RF on 1 (49) } D (68) } 0 (48) } Mod- A (65) } ulation 0 (48) } off P (80) 0 (48) | M (77) } O (79) } D (68) } : (58) } S (83) } T (84) } Mod- A (65) } ulation T (84) } off Space(32) O (79) F (70) F (70) |
| 42.1 Prefix Suffix | C(67) W(87) M(77) Z(90) | P(80) (255) Z(90) O(48) | F (70) R (82) M (77) Z (90) | Special Function 42.1 is not used with Special Function 41.5. Refer to Special Function 42.7. |
| 42.2 Settling Time | 60 ms | 20 ms | 30 ms | 30 ms |
| 42.3 Minimum Frequency | 2000 MHz | 2000 MHz | 2000 MHz | 10 MHz |
| 42.4 Maximum Frequency | 18000 MHz | 18000 MHz | 26500 MHz | 60000 MHz |
| 42.5 Output Signal Power Level | 6 dBm | 7 dBm | 8 dBm | 8 dBm |
| 42.6 Power Prefix Power Suffix | | | | P (80) O (79) W (87) Space (32) Space (32) D (68) B (66) M (77) ; (59) |

Programs Available to Control The System LO (cont'd) (Special Function 41)

**Comments
(cont'd)**

System LO Predefined Program Listings (cont'd)

| System LO Commands (Special Function 42) | HP8340B/8341B (41.4) or HP 8350B (41.0) Program | HP 8671B/8672A Program (41.2) | HP 8673B/C Program (41.3) | Custom Local Oscillator Program (41.5) |
|---|--|----------------------------------|------------------------------|--|
| 42.7 Frequency Prefix | | | | F (70) R (82) E (69) Q (81) Space (32) |
| Frequency Suffix | | | | Space (32) M (77) H (72) Z (90) ; (59) |

The HP 8673B Option 008 and HP 8673D Synthesized Signal Generators use K-band amplifiers. The amplifier is used when the output signal is greater than or equal to 16 GHz. If either signal generator is being used as the system local oscillator and the output signal is greater than or equal to 16 GHz, the K-band amplifier must be removed from the output signal path. If the K-band amplifier is not removed from the signal path, the Noise Figure Meter or Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and system local oscillator) will not operate properly.

Taking the K-band amplifier out of the signal path involves modifying the auxiliary commands (Special Function 42.0) for Special Function 41.3. The following HP-IB program code needs to be added to the auxiliary commands: 9SV. The decimal equivalent of each ASCII character (9SV) is entered into the Noise Figure Meter. The decimal equivalents of the ASCII characters are as follows: 9 (57), S (83) and V (86). Modifying the auxiliary commands is described in the Entering Data section of the Programming the System LO Detailed Operating Instruction.

After the K-band amplifier is removed, the local oscillator must be able to supply a leveled +8 dBm over the oscillator's complete bandwidth. If the local oscillator can't supply the leveled +8 dBm, another local oscillator will have to be selected.

**Related
Sections**

Controller Capability of the Noise Figure Meter
Measurement Modes 1.1 through 1.9
Programming the System LO
Special Functions

RF Attenuation Selection

(Special Functions 60, 61, and 62)

Description

RF attenuation selection, display, and hold are available in all measurement modes. It should be noted, however, that only the hold capability (Special Function 62.0) is normally used by most operators. The hold is required during manual measurements (refer to the Manual Measurements Detailed Operating Instruction for additional information). The selection and display of specific RF attenuation settings are more likely to be used during adjustment procedures, performance tests, or troubleshooting procedures. In some specialized applications these capabilities can be helpful, but care must be exercised when using them. It is possible to introduce some very subtle errors in the measurements that the Noise Figure Meter may not be able to guard against. Additional information on how to use and interpret these Special Functions is contained in Section VIII, Service.¹

Procedure

To select a specific RF attenuation setting, display, or hold, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.

| Special Function | | Program Code HP-IB | Lights Special? Function Key | Stored in Con- tinuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|--|------|-----------------------|---------------------------------|----------------------------------|-------------------------------|------------------------------------|--|------------------------------------|
| Description | Code | | | | | | | |
| RF Attenuation Selection | | | | | | | | |
| Auto | 60.0 | R0 or 60.0SP | N | N | N | On | On | On |
| +20 dB | 60.1 | R1 or 60.1SP | Y | N | N | Off | Off | Off |
| +10 dB | 60.2 | R2 or 60.2SP | Y | N | N | Off | Off | Off |
| 0 dB | 60.3 | R3 or 60.3SP | Y | N | N | Off | Off | Off |
| -10 dB | 60.4 | R4 or 60.4SP | Y | N | N | Off | Off | Off |
| -20 dB | 60.5 | R5 or 60.5SP | Y | N | N | Off | Off | Off |
| -30 dB | 60.6 | R6 or 60.6SP | Y | N | N | Off | Off | Off |
| Display RF Attenuator Settings | | | | | | | | |
| Display RF Attenuator | 61.0 | SR or 61.0SP | N | N | N | Off | Off | Off |
| RF Attenuator Hold | | | | | | | | |
| RF Attenuator Hold | 62.0 | RH or 62.0SP | Y | N | N | Off | Off | Off |
| ² Table categories are explained in the Special Functions Detailed Operating Instruction. | | | | | | | | |


¹ Section VIII, Service, is in the Service Manual. The part number of the Service Manual is on the title page of this manual.

RF Attenuation Selection (cont'd)

(Special Functions 60, 61, and 62)

Example

To select the RF attenuator hold function:



Program Codes



For HP-IB codes, refer to Procedure.

Indications

When Special Function 61 is implemented, four digits appear in the left display. The digits are either "1" (yes) or "0" (no) to indicate whether or not the corresponding 10 dB pads and 20 dB amplifier are switched into the Input Assembly circuits (see Service Sheet 1 in Section VIII, Service¹). The first, third, and fourth digits each represent -10 dB (10 dB Pad No. 1, 10 dB Pad No. 2, and 10 dB Pad No. 3, respectively). The second digit represents +20 dB (20 dB Input Gain Amplifier). To obtain the RF attenuator setting, add the attenuation that is represented by each digit in the display. For example, a display of "1 1 1 0" indicates an RF attenuation setting of 0 dB.

The following table lists the RF attenuation available (Special Functions 60.1 through 60.6) and the ones (1) and zeros (0) that are displayed, using Special Function 61.0.

| Attenuation [dB] | Special Function | Attenuator or Amplifier | | | |
|------------------|------------------|-------------------------|--------|--------|--------|
| | | -10 dB | +20 dB | -10 dB | -10 dB |
| +20 | 60.1 | 0 | 1 | 0 | 0 |
| +10 | 60.2 | 0 | 1 | 1 | 0 |
| 0 | 60.3 | 1 | 1 | 1 | 0 |
| -10 | 60.4 | 1 | 0 | 0 | 0 |
| -20 | 60.5 | 1 | 0 | 1 | 0 |
| -30 | 60.6 | 1 | 0 | 1 | 1 |

Comments

If any of the 60 or 70 series of Special Functions (except 60.0 and 70.0) are active, the calibration sequence does not override them. Therefore, to calibrate on one range only, use any of these Special Functions except 60.0 or 70.0. It is also true that if any of these Special Functions are inadvertently active, the calibration sequence will not cover the expected gain range.

Related Sections

- Calibrate
- IF Attenuation Selection
- Manual Measurements
- Special Functions

¹ Section VIII, Service, is in the Service Manual. The part number of the Service Manual is on the title page of this manual.

Sequence

(Includes Special Function 35)

Description

The sequence feature allows the user to predetermine the recall order of the storage registers. Manual sequence (recall of registers one at a time) or automatic sequence (continuous recall of registers) can be selected.

Nine digits are used in a sequence. Any combination of registers 1 through 9 is allowed. Zeros used within a sequence are ignored.

Procedure

To set the sequence (that is, the recall order), key in 35.2 SPECIAL FUNCTION. The register to be recalled at each step of the sequence is displayed in turn in the left display. If a change is desired, enter the new register number and press ENTER. If no change is desired, press ENTER to advance to the next step of the sequence. After all nine registers have been displayed, the Noise Figure Meter returns to normal measurement. Pressing the FREQUENCY key at any time terminates setting the sequence.

To select the manual sequence mode, key in 35.0 SPECIAL FUNCTION. The instrument steps through the defined sequence one step at a time each time the SEQ key is pressed. When the end of a sequence is reached, it starts over.

To select the automatic sequence mode, key in 35.1 SPECIAL FUNCTION. Press the SEQ key to start automatic sequencing. The instrument starts a continuous recall of registers in the predetermined sequence. To stop an automatic sequence, press the SEQ key again.

To clear the sequence (that is, set the sequence to 000 000 000), key in 35.3 SPECIAL FUNCTION.

To set the sequence to 1 through 9 in order, press PRESET.

| Special Function | | Program Code ◀ HP-IB ▶ | Lights Special ¹ Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|--------------------|------|---------------------------|--|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| Manual Sequence | 35.0 | QM or 35.0SP | N | N | N | On | On | On |
| Automatic Sequence | 35.1 | QA or 35.1 SP | N | N* | N | Off | Off | Off |
| Set Sequence | 35.2 | QS or 35.2SP | N | Y | N | NC | 1-9 | 1-9 |
| Clear Sequence | 35.3 | QC or 35.3SP | N | N | N | Off | Off | Off |

* Enables Special Function key LED to light when SEQ is pressed.
¹ Table categories are explained in the Special Functions Detailed Operating Instruction.

Sequence (cont'd) (Special Function 35)

Example

To set the register recall sequence to 1, 2, 7, 2 and 5:

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------------------|--|----------|------|----------|------|----------|------|----------|------|----------|------|----------|------|----------|------|----------|------|----------|------|----------|------|----------|------|----------|------|----------|---|---|---|---|---|------|------|----------|------|----------|------|----------|------|----------|------|----------|------|----------|------|----------|------|----------|------|----------|------|----------|------|----------|------|----------|------|----------|
| LOCAL (keystrokes) | <div style="display: flex; justify-content: center; align-items: center; gap: 10px;"> <div style="border: 1px solid black; padding: 2px 5px;">Code</div> <div style="border: 1px solid black; padding: 2px 5px;">Function</div> <div style="border: 1px solid black; padding: 2px 5px;">Data</div> <div style="border: 1px solid black; padding: 2px 5px;">Function</div> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 10px; margin-top: 5px;"> <div style="border: 1px solid black; padding: 2px 5px;">3</div> <div style="border: 1px solid black; padding: 2px 5px;">5</div> <div style="border: 1px solid black; padding: 2px 5px;">.</div> <div style="border: 1px solid black; padding: 2px 5px;">2</div> <div style="border: 1px solid black; padding: 2px 5px; margin-left: 20px;">● SPECIAL FUNCTION</div> <div style="border: 1px solid black; padding: 2px 5px;">1</div> <div style="border: 1px solid black; padding: 2px 5px; margin-left: 5px;">ENTER</div> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 10px; margin-top: 5px;"> <div style="border: 1px solid black; padding: 2px 5px;">2</div> <div style="border: 1px solid black; padding: 2px 5px; margin-left: 5px;">ENTER</div> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 10px; margin-top: 5px;"> <div style="border: 1px solid black; padding: 2px 5px;">7</div> <div style="border: 1px solid black; padding: 2px 5px; margin-left: 5px;">ENTER</div> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 10px; margin-top: 5px;"> <div style="border: 1px solid black; padding: 2px 5px;">2</div> <div style="border: 1px solid black; padding: 2px 5px; margin-left: 5px;">ENTER</div> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 10px; margin-top: 5px;"> <div style="border: 1px solid black; padding: 2px 5px;">5</div> <div style="border: 1px solid black; padding: 2px 5px; margin-left: 5px;">ENTER</div> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 10px; margin-top: 5px;"> <div style="border: 1px solid black; padding: 2px 5px;">0</div> <div style="border: 1px solid black; padding: 2px 5px; margin-left: 5px;">ENTER</div> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 10px; margin-top: 5px;"> <div style="border: 1px solid black; padding: 2px 5px;">0</div> <div style="border: 1px solid black; padding: 2px 5px; margin-left: 5px;">ENTER</div> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 10px; margin-top: 5px;"> <div style="border: 1px solid black; padding: 2px 5px;">0</div> <div style="border: 1px solid black; padding: 2px 5px; margin-left: 5px;">ENTER</div> </div> <div style="display: flex; justify-content: center; align-items: center; gap: 10px; margin-top: 5px;"> <div style="border: 1px solid black; padding: 2px 5px;">0</div> <div style="border: 1px solid black; padding: 2px 5px; margin-left: 5px;">ENTER</div> </div> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| HP-IB (program codes) | <table style="margin: auto; border-collapse: collapse;"> <tr> <td></td> <td>Q</td> <td>S</td> <td>1</td> <td>E</td> <td>N</td> <td>2</td> <td>E</td> <td>N</td> <td>7</td> <td>E</td> <td>N</td> <td>2</td> <td>E</td> <td>N</td> <td>5</td> <td>E</td> <td>N</td> <td>0</td> <td>E</td> <td>N</td> <td>0</td> <td>E</td> <td>N</td> <td>0</td> <td>E</td> <td>N</td> <td>0</td> <td>E</td> <td>N</td> </tr> <tr> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Code</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Data</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Function</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Data</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Function</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Data</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Function</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Data</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Function</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Data</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Function</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Data</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Function</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Data</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Function</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Data</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Function</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Data</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Function</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Data</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Function</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Data</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Function</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Data</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Function</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Data</td> <td style="writing-mode: vertical-rl; transform: rotate(180deg);">Function</td> </tr> </table> | | Q | S | 1 | E | N | 2 | E | N | 7 | E | N | 2 | E | N | 5 | E | N | 0 | E | N | 0 | E | N | 0 | E | N | 0 | E | N | Code | Data | Function |
| | Q | S | 1 | E | N | 2 | E | N | 7 | E | N | 2 | E | N | 5 | E | N | 0 | E | N | 0 | E | N | 0 | E | N | 0 | E | N | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Code | Data | Function | Data | Function | Data | Function | Data | Function | Data | Function | Data | Function | Data | Function | Data | Function | Data | Function | Data | Function | Data | Function | Data | Function | Data | Function | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

Program Codes

The program code for the SEQ key is SQ. The program code for the ENTER key is EN. Refer to Procedure, above, for HP-IB program codes for Special Function 35.



Indications

When the Noise Figure Meter is in the manual sequence mode, pressing the SEQ key causes the storage register being recalled to appear in the left display while the key is depressed.

When the Noise Figure Meter is in the automatic sequence mode, the SPECIAL FUNCTION key LED lights. Register numbers are not displayed during automatic sequencing.

Comments

Register numbers can be repeated in a sequence string.

If fewer than nine register numbers are used for a sequence string, zeros should be entered so that the sequence always has nine digits in it.

For a list of front panel functions that can or cannot be stored and recalled (therefore, can or cannot be used in a sequence), refer to Table 3-12, Front Panel Summary, in the Preset Conditions and Power-Up Sequence Detailed Operating Instruction. For a list of special functions that can and cannot be stored and recalled, refer to Table 3-14, Special Function Summary, in the Special Functions Detailed Operating Instruction.

Related Sections

Preset Conditions and Power-Up Sequence
Special Functions
Store and Recall

Sideband Selection

(Special Functions 2 and 17)

Description

Special Functions 2.0 through 2.2 are used when external down conversion is used with the Noise Figure Meter or Noise Figure Measurement System (Noise Figure Meter, Noise Figure Test Set and system local oscillator). Special Functions 2.0 through 2.2 convey to the Noise Figure Meter the sideband operation (double sideband, upper sideband or lower sideband) being used with the external down conversion. Special Function 2.3 is used when up-conversion is employed with the Noise Figure Meter or Noise Figure Measurement System.

Special Function 2 is used in Measurement Modes 1.1 through 1.4, 1.7 and 1.9. Special Function 2 is optional with Measurement Modes 1.6 or 1.8. Since the user controlled local oscillator, used in Measurement Modes 1.6 and 1.8, produces a fixed IF and is not controlled by the Noise Figure Measurement System, Special Function 2 is optional. However, if Special Function 3.2 (display user controlled local oscillator frequency in Measurement Modes 1.6 through 1.9) is desired, Special Function 2 will have to be used.

In Measurement Modes 1.2 or 1.7, one of the single sideband special functions must be selected or else an error code (E34) is displayed. The reason a double sideband measurement cannot be made in Modes 1.2 or 1.7 is that the frequency at which the measurement is being made is ambiguous. Therefore, one of the two single sideband special functions must be selected and the other sideband must be filtered out after the device under test (DUT) for a meaningful sweep. This eliminates any noise that is added by the DUT that may fall in the undesired sideband.

It is in Measurement Modes 1.1, 1.3, 1.4, 1.6, 1.8 and 1.9 that the choice between single or double sideband becomes necessary. The following brief description will help clarify the choices available:

a. Special Function 2.0 selects a double sideband measurement. The measured result is an average of the noise figure at two frequencies; in Measurement Modes 1.1 through 1.4, the system local oscillator frequency plus the IF and the system local oscillator minus the IF; in Measurement Modes 1.6 through 1.9, the user controlled local oscillator frequency plus the IF and the user controlled local oscillator frequency minus the IF.

b. Special Function 2.1 offsets the measurement frequency to the system local oscillator frequency minus the IF, in Measurement Modes 1.1 through 1.4. Special Function 2.1 offsets the measurement frequency to the user controlled local oscillator frequency minus the IF, in Measurement Modes 1.6 through 1.9. The Noise Figure Meter uses the ENR (Excess Noise Ratio) value of the offset measurement frequency. When using Special Function 2.1 an external filter is needed to eliminate the unwanted sideband.

c. Special Function 2.2 offsets the measurement frequency to the system local oscillator frequency plus the IF, in Measurement Modes 1.1 through 1.4. Special Function 2.2 offsets the measurement frequency to the user controlled local oscillator frequency plus the IF, in Measurement Modes 1.6 through 1.9. The Noise Figure Meter uses the ENR value of the offset measurement frequency. When using Special Function 2.2 an external filter is needed to eliminate the unwanted sideband.

d. Special Function 2.3 offsets the measurement frequency to the IF frequency minus the system local oscillator frequency, in Measurement Modes 1.1 through 1.4. Special Function 2.3 offsets the measurement frequency to the IF frequency minus the user controlled local oscillator frequency, in Measurement Modes 1.6 through 1.9. The Noise

Sideband Selection (cont'd)

(Special Functions 2 and 17)

Description (cont'd)

Figure Meter uses the ENR value of the offset measurement frequency. Special Function 2.3 is useful for frequency upconversion characterization.

Special Function 17 is only used in Measurement Modes 1.5 through 1.9. With the exception of Measurement Mode 1.5, the measurement signal is converted twice. The first conversion is done using an external mixer and the user controlled local oscillator. The second conversion is done using the Noise Figure Test Set and the system local oscillator. Special Function 17 selects a single sideband (SSB) or a double sideband (DBS) measurement, for the second conversion (or the first conversion, in the case of Measurement Mode 1.5). The sideband selection for the first conversion (Special Function 2) does not have to be the same as the sideband selection for the second conversion. And the sideband selection for the second conversion does not have to be the same as the sideband selection for the first conversion.

For measurement signals from 10 to 2400 MHz, single sideband operation is all that is available. For measurement signals greater than 2400 MHz, single and double sideband operation are available.

Normally, there is no need to change Special Function 17. Special Function 17.0 (single sideband) is the default. Special Function 17.0 has been chosen for best system performance.

The following descriptions will help to clarify Special Function 17:

a. Special Function 17.0 selects single sideband operation, for the Noise Figure Measurement System, when the Noise Figure Test Set input frequency is greater than 2400 MHz. Step c describes how to set the single sideband operation to either lower or upper sideband. The measurement frequency is offset from the system local oscillator frequency plus or minus the IF, depending upon how Special Function 17.2 has been set up.

The IF into the Noise Figure Meter (the difference between the Noise Figure Test Set input frequency and the system local oscillator frequency) is a fixed value of 450 MHz, set by the Noise Figure Measurement System. The IF can be changed using Special Function 19.3. For more information on Special Function 19.3, refer to the Fixed IF or LO Frequency Selection Detailed Operating Instruction. Normally, there is no reason to change Special Function 19.3.

b. Special Function 17.1 selects double sideband operation, for the Noise Figure Measurement System, when the Noise Figure Test Set input frequency is greater than 2400 MHz. The measured result is an average of the noise figure at two frequencies; the system local oscillator plus the IF, into the Noise Figure Meter and the system local oscillator minus the IF, into the Noise Figure Meter.

The IF (the difference between the Noise Figure Test Set input frequency and the system local oscillator frequency) is a fixed value of 25 MHz, set by the Noise Figure Measurement System. The IF can be changed using Special Function 19.4. For more information on Special Function 19.4, refer to the Fixed IF or LO Frequency Selection Detailed Operating Instruction. Normally, there is no need to change Special Function 19.4.

c. Special Function 17.2 is used with Special Function 17.0. Special Function 17.0 selects single sideband operation, for the Noise Figure Measurement System; Special

Sideband Selection (cont'd) (Special Functions 2 and 17)

**Description
(cont'd)**

Function 17.2 selects either lower or upper single sideband operation. Special Function 17.2 is used to enter a value from 2400 to 30000 MHz. Once the value is entered, a Noise Figure Test Set input frequency at or below the entered value will be a lower sideband measurement and a Noise Figure Test Set input frequency above the entered value will be an upper sideband measurement.

The procedure is to press 17.2 SPECIAL FUNCTION; key in the data (2400 to 30000 MHz) and press ENTER. Once Special Function 17.2 is set up, Special Function 17.0 may be keyed in, if desired. After PRESET, 2401 to 16000 MHz is lower sideband and 16000 to 18000 MHz is upper sideband.

Procedure

To select Special Function 2 or Special Function 17, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key. In the case of Special Function 17.2, the SPECIAL FUNCTION key is pressed then data is keyed in and the ENTER key is pressed.

| Special Function | | Program Code HP-IB | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|---|------|-----------------------|-----------------------------|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| Double Sideband (no frequency offset) | 2.0 | B0 or 2.0SP | N | Y | Y | On | On | On |
| Lower Single Sideband (measurement frequency less than LO frequency) | 2.1 | B1 or 2.1 SP | Y | Y | Y | Off | Off | Off |
| Upper Single Sideband (measurement frequency greater than LO frequency) | 2.2 | B2 or 2.2SP | Y | Y | Y | Off | Off | Off |
| Signal Up Conversion IF = F _{signal} plus F _{LO} | 2.3 | B3 or 2.3SP | Y | Y | Y | Off | Off | Off |
| Single Sideband measurement for Noise Figure Test Set input frequencies >2400 MHz | 17.0 | B4 or 17.0SP | N | Y | Y | On | On | On |
| Double Sideband measurement for Noise Figure Test Set input frequencies >2400 MHz | 17.1 | B5 or 17.1SP | N | Y | Y | Off | Off | Off |
| Lower and Upper sideband cross-over frequency | 17.2 | CF or 17.2SP | N | Y | Y | NC | 16 GHz | 16 GHz |

¹ Table categories are explained in the Special Functions Detailed Operating Instruction.

Sideband Selection (cont'd)

(Special Functions 2 and 17)

Example

To select lower single sideband frequency offset:

| | |
|--|--|
| <p>LOCAL (keystrokes)</p> | <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Code</p> <div style="display: flex; justify-content: center; gap: 10px;"> <div style="border: 1px solid black; padding: 2px 5px; border-radius: 3px;">2</div> <div style="border: 1px solid black; padding: 2px 5px; border-radius: 3px;">.</div> <div style="border: 1px solid black; padding: 2px 5px; border-radius: 3px;">1</div> </div> </div> <div style="text-align: center;"> <p>Function</p> <div style="border: 1px solid black; padding: 2px 5px; border-radius: 3px; display: flex; align-items: center; gap: 5px;"> • <p>SPECIAL FUNCTION</p> </div> </div> </div> |
| <p style="text-align: center;">HP-IB</p> <p>(program codes)</p> | <p style="font-size: 1.5em;">B1</p> |

Program Codes

For HP-IB codes, refer to Procedure.



Indications

For indications, refer to the "Lights Special Function Key" column in the table in Procedure above.

Related Sections

Measurement Modes
 Measurement Modes 1.1 through 1.9
 Special Functions

Smoothing (Averaging)

(Includes Special Function 13)

Description

The purpose of smoothing is to reduce jitter in both the NOISE FIGURE and INSERTION GAIN displays. Numbers that are sent to both of these displays are averaged before being displayed.

The Noise Figure Meter has two modes of smoothing: exponential and arithmetic (straight averaging). The equation for exponential smoothing is:

$$\text{new display} = \frac{\text{new measurement}}{n} + \frac{n-1}{n} (\text{previous display})$$

where n is the smoothing factor.

The equation for arithmetic is:

$$\text{new display} = \frac{n \text{ measurements}}{n}$$

where n is the smoothing factor.

The smoothing factor can range from 1 to 512 in factors of two. Each time the INCREASE key is pressed, the smoothing factor is doubled (until the smoothing factor is 512). Each time the DECREASE key is pressed, the smoothing factor is halved (until the smoothing factor is 1). A stable display can usually be obtained by increasing the smoothing factor.

When exponential smoothing is used for a fixed frequency measurement, the display is updated approximately five times per second for all smoothing factors. However, when a large smoothing factor is used, the Noise Figure Meter is slow to respond to changes in the noise measurement when tuning from one fixed frequency to another.

Arithmetic smoothing makes the number of measurements indicated by the smoothing factor and averages them before the result is displayed. The display is updated each time n measurements are made, where n is the smoothing factor. With a smoothing factor of 1, sixteen measurement updates are made each second. With a smoothing factor of 512, the measurement update interval is typically forty seconds to one minute.

Calibration and swept measurements always use arithmetic smoothing automatically. Either exponential or arithmetic smoothing can be selected for fixed frequency measurements.

Procedure

To display the smoothing factor, key in 13.2 SPECIAL FUNCTION. If a change is desired, key in the new smoothing factor and then press the ENTER key.

The smoothing factor can also be changed from the front panel. Press INCREASE for more smoothing or press DECREASE for less smoothing. Each time one of these keys is pressed the smoothing factor changes by a factor of two.

To select exponential or arithmetic smoothing for fixed frequency measurements only, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.

Smoothing (Averaging) (cont'd)

(Includes Special Function 13)

**Procedure
(cont'd)**

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Con- tinuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|---|------|-----------------------|---|----------------------------------|-------------------------------|------------------------------------|--|------------------------------------|
| Description | Code | | | | | | | |
| Exponential smoothing mode for fixed frequency measurements | 13.0 | V0 or 13.0SP | N | Y | N | On | On | On |
| Arithmetic smoothing mode for fixed frequency measurements | 13.1 | V1 or 13.1SP | N | Y | N | Off | Off | Off |
| Displays and allows entry of smoothing factor | 13.2 | AF or 13.2SP | N | Y | N | NC | 1 | 1 |

¹ Table categories are explained in the Special Functions Detailed Operating Instruction.

Example

To select exponential smoothing and a smoothing factor of 4:

| | | | | |
|--------------------------|---|--|--------------------------------|------------------------------------|
| LOCAL (keystrokes) | Code | Function | Data | Function |
| | <input type="text" value="1"/> <input type="text" value="3"/> <input type="text" value="."/> <input type="text" value="0"/> | <input checked="" type="radio"/> SPECIAL FUNCTION | | |
| | <input type="text" value="1"/> <input type="text" value="3"/> <input type="text" value="."/> <input type="text" value="2"/> | <input checked="" type="radio"/> SPECIAL FUNCTION | <input type="text" value="4"/> | <input type="text" value="ENTER"/> |
| HP-IB (program codes) | V0F2 | | | |

**Program Codes
HP-IB**

| Parameter | Program Code HP-IB |
|------------------------|-----------------------|
| INCREASE | IN |
| DECREASE | DE |
| Smoothing Factor = 1 | F0 or AF1EN |
| Smoothing Factor = 2 | F1 or AF2EN |
| Smoothing Factor = 4 | F2 or AF4EN |
| Smoothing Factor = 8 | F3 or AF8EN |
| Smoothing Factor = 16 | F4 or AF16EN |
| Smoothing Factor = 32 | F5 or AF32EN |
| Smoothing Factor = 64 | F6 or AF64EN |
| Smoothing Factor = 128 | F7 or AF128EN |
| Smoothing Factor = 256 | F8 or AF256EN |
| Smoothing Factor = 512 | F9 or AF512EN |

For HP-IB codes for Special Function 13, refer to Procedure above.

Smoothing (Averaging) (cont'd)

(Includes Special Function 13)

| | |
|-------------------------|--|
| Indications | The current smoothing factor is displayed in the left display whenever the INCREASE key or the DECREASE key is depressed. |
| Comments | <p>The smoothing factor can be changed while swept measurements are in progress. However, the smoothing factor cannot be changed during calibration.</p> <p>For fixed frequency measurements, arithmetic smoothing is mainly useful in HP-IB systems. Exponential smoothing is best for reading measurement results on the front panel display or on an oscilloscope.</p> <p>When using exponential smoothing, any time the fixed frequency changes, a number of measurements equal to the smoothing factor is made before any results are displayed. During this time the NOISE FIGURE display shows four dashes (— — — —).</p> <p>In exponential smoothing, to reduce the settling time after a large measurement change, press the FREQUENCY key to reset the display to the current measurement value.</p> |
| Related Sections | <ul style="list-style-type: none">CalibrateFixed Frequency TuningSpecial FunctionsSweep |

Special Function Catalog (Special Function 50)

Description

Special Function 50 displays the contents of the eight line special functions catalog either sequentially or by individual line. The catalog can be used to quickly determine the present status of many of the special functions. For a concise explanation of the special function catalog, refer to the Special Function Catalog Summary shown below.

Special Function 50.N displays the Special Function Catalog. 50.0 SP sequences through 8 catalog lines. 50.1 through 50.8 SP display the specified catalog line. For example:

5
0
.
1
•
 Displays the N = 1 line.

The first displayed digit (N) is the catalog line number. Each of the digits is the suffix of a specific Special Function as shown in the table below.



SP Code suffixes

This display indicates the following Special Functions:
1.4, 2.2, 4.0, 5.0

| N | 1 | 2 | 3 | 4 |
|----------|---------------------------|-----------------|-----------------|--------------|
| LINE NO. | SPECIAL FUNCTION PREFIXES | | | |
| 1 | 1 | 2 | 4 | 5 |
| 2 | 10/9 ¹ | 11 | 12 ² | 13 |
| 3 | 16 | 14 | 15 | ³ |
| 4 | 30 | 31 | 32 | 34 |
| 5 | 35 | 41 ⁴ | 43 | 17 |
| 6 | 60 ⁵ | 70 | ⁶ | 92 |
| 7 | 45 | 46 | 47 | 48 |
| 8 | 49 | N/A | 36 | N/A |

¹0—4 = 10.0 through 10.4SP; 5 = 9.1SP; 6 = 9.2SP; 7 = 9.3SP; 8 = 9.4SP.
²3 = 12.1SP ;and 12.2SP selected.
³ Indicates selected analog output; 0—3 = 7.0 through 7.3SP; 4 = 22.0SP; 5 = 23.0SP; 6 = 24.0SP; 7 = 82.0SP.
⁴ Indicates selected System LO program: 0 = 41.0SP (HP 8350B); 2 = 41.2SP (HP 8671B/8672A); 3 = 41.3SP (HP 8673B); 4 = 41.4SP (HP 8340B); 5 = 41.5SP (Custom LO program)
⁵ 0—6 = 60.0 through 60.6 SP; 9 = 63.0SP through 63.5SP.
⁶ 0 = Normal display; 1 = 80.0SP (Voltmeter Mode, Noise Source Off); 2 = 81.0SP (Voltmeter Mode, Noise Source On).

Special Function Catalog (cont'd) (Special Function 50)

Procedure


To select a specific special function catalog display, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.

| Special Function | | Program Code Code HP-IB | Lights Special ¹ Function Key | Stored in Con- tinuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|--|------|-------------------------------|---|----------------------------------|-------------------------------|------------------------------------|--|------------------------------------|
| Description | Code | | | | | | | |
| Sequence through all eight lines at once | 50.0 | G0 or 50.0SP | N | N | N | Off | Off | Off |
| Display Line 1 | 50.1 | G1 or 50.1SP | N | N | N | Off | Off | Off |
| Display Line 2 | 50.2 | G2 or 50.2SP | N | N | N | Off | Off | Off |
| Display Line 3 | 50.3 | G3 or 50.3SP | N | N | N | Off | Off | Off |
| Display Line 4 | 50.4 | G4 or 50.4SP | N | N | N | Off | Off | Off |
| Display Line 5 | 50.5 | G5 or 50.5SP | N | N | N | Off | Off | Off |
| Display Line 6 | 50.6 | G6 or 50.6SP | N | N | N | Off | Off | Off |
| Display Line 7 | 50.7 | G7 or 50.7SP | N | N | N | Off | Off | Off |
| Display Line 8 | 50.8 | G8 or 50.8SP | N | N | N | Off | Off | Off |

¹ Table categories are explained in the Special Functions Detailed Operating Instruction.

Example

To display line 2 of the special function catalog:



Program Codes



For HP-IB codes, refer to Procedure above.

Indications

When Special Function 50.0 is selected, the Noise Figure Meter automatically sequences through all eight lines, showing the status of each line for approximately one second in the left display.

When Special Functions 50.1 through 50.8 are selected, the status of the corresponding line is displayed in the left display until another function is selected.

Under the left display are reference characters N, 1, 2, 3, and 4. N refers to the line number and 1, 2, 3, and 4 refer to digit positions in the display.

Comments

To read the special function catalog information via HP-IB, use Special Functions 50.1 through 50.8 and read one line at a time. The HP-IB output format must be set to output all three displays (HP-IB code H1 or 43.1SP).

Related Sections

Special Functions

Special Functions

Description

General Information. Special Functions extend user control of the instrument beyond that normally available from dedicated front panel keys. They are accessed via keyboard entry of the appropriate numeric code terminated by the SPECIAL FUNCTION key. The codes consist of a prefix, decimal, and suffix. Special Functions are grouped by their prefixes into five categories as follows:

Prefix 0

This initializes selected Special Functions. Refer to Table 3-14, Special Function Summary, for a complete listing of initialized Special Function conditions.

Prefixes 1 to 49

These are User Special Functions which are used during normal instrument operation when a special configuration, a special measurement, or special information is required. These Special Functions are described in the Special Function Summary, Table 3-14.

Prefixes 50 to 59

These are Catalog Special Functions and are used to display the status of Special Function settings. Refer to the Special Function Catalog Detailed Operating Instruction for additional information.

Prefixes 60 to 79

These are Auxiliary Special Functions which are normally used for servicing the Noise Figure Meter. However, some of these Special Functions must be used for manual measurements (HOT and COLD). Refer to Section VIII (Service¹), and the IF Attenuation Selection and RF Attenuation Selection Detailed Operating Instructions for additional information.

Prefixes 80 to 99

These are the Service Special Functions used to assist in troubleshooting an instrument fault. The functions available are quite diverse — special internal measurements, software control, and special service tests and configurations. These Special Functions are discussed in detail in Section VIII, Service.¹

Special Function Summary Table. A summary of User, Catalog, and Auxiliary Special Functions is given in Table 3-14. Most of the Special Functions are explained in more detail in other operating instructions.

The “Lights Special Function Key” column indicates which Special Functions, when active, light the SPECIAL FUNCTION key LED on the front panel.

The “Stored in Continuous Memory” column indicates whether or not the status of a Special Function can be retained when power is removed from the Noise Figure Meter.

The “Can Be Stored and Recalled” column indicates whether or not the status of a Special Function can be stored in an internal storage register for recall at a later time.

The “Special Function 0.0 Conditions” column indicates the status of each Special Function (that is, on, off, or no change) when Special Function 0.0 is selected.

¹ Section VIII, Service, is in the Service Manual. The part number of the Service Manual is on the title page of this manual.

Special Functions (cont'd)

Description (cont'd)

The "Preset (and HP-IB Clear) Conditions" column indicates the status of each Special Function when the front panel PRESET key is pressed (or HP-IB code PR is sent). In addition, this column indicates default data values that are set for some Special Functions.

The "Special Function 0.9 Conditions" column indicates the status of each Special Function when Special Function 0.9 is selected. In addition, this column indicates default data values that are set for some Special Functions. Special Function 0.9 is the highest level of preset that the Noise Figure Meter has. Special Function 0.9 sets up everything that is set by PRESET or Special Function 0.0 and more. When Special Function 0.9 is selected it doesn't have any effect on the ENR tables or the IF calibration data. Special Function 0.9 does set the defaults for all Hewlett-Packard Interface Bus (HP-IB) and System Interface Bus (SIB) addresses and the system local oscillator programs.

Procedure

To use a Special Function, key in the corresponding code, then press the SPECIAL FUNCTION key.

Example

To select Measurement Mode 1.1 (Special Function 1.1):

| | |
|---|--|
| <p>LOCAL (keystrokes)</p> | <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Code</p> <div style="display: flex; gap: 10px;"> <div style="border: 1px solid black; padding: 2px 10px; border-radius: 5px;">1</div> <div style="border: 1px solid black; padding: 2px 10px; border-radius: 5px;">.</div> <div style="border: 1px solid black; padding: 2px 10px; border-radius: 5px;">1</div> </div> </div> <div style="text-align: center;"> <p>Function</p> <div style="border: 1px solid black; padding: 5px; border-radius: 5px; display: inline-block;"> ● SPECIAL FUNCTION </div> </div> </div> |
| <p>HP-IB (program codes)</p> | <p>E1</p> |

Indications

The numeric code appears in the left display as it is being entered. Pressing the SPECIAL FUNCTION key activates the selected Special Function. Refer to the "Lights Special Function Key" column in Table 3-14 for a list of Special Functions that light the key LED.

Related Sections

- Calibration, Frequency
- Calibration, IF Attenuators
- Calibration, Input Gain Selection
- Controller Capability of the Noise Figure Meter
- Data Output to Oscilloscopes, Recorders and Plotters
- Display Control
- Display Resolution
- Display Units Selection
- Fixed IF or LO Frequency Selection
- HP-IB and System Interface Bus (SIB) Addresses
- IF Attenuation Selection
- Loss Compensation
- Manual Measurement Functions
- Measurement Mode 1.0
- Measurement Mode 1.1
- Measurement Mode 1.2
- Measurement Mode 1.3
- Measurement Mode 1.4

Special Functions (cont'd)

Related Sections (cont'd)

Measurement Mode 1.5
Measurement Mode 1.6
Measurement Mode 1.7
Measurement Mode 1.8
Measurement Mode 1.9
Noise Figure Test Set YIG Filter Calibration
Power Measurements
Preamplifier Selection
Preset Conditions and Power-Up Sequence
Programming the System LO
Programs Available to Control the System LO
RF Attenuation Selection
Sequence
Sideband Selection
Smoothing
Special Function Catalog
Spot ENR, T_{hot} , T_{cold} and ENR Table Selection
System Interface Bus Control
Temperature Units Selection
Trigger Selection



Table 3-14. Special Function Summary (1 of 15)

| Special Function | | Program Code HP-IB | Description | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions | References and Comments |
|--|-------|-----------------------|--|-----------------------------|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|---|
| Name | Code* | | | | | | | | | |
| Initialize Special Functions | 0.0 | CS | Initializes many Special Functions | N | — | — | — | | | Preset Conditions and Power Up Sequence |
| | 0.9 | — | Initializes or sets defaults for all Special Functions | N | N | N | — | — | — | |
| Measurement Mode Selection (Noise Figure Meter) | 1.0 | E0 | Mode 1.0 (10–1600 MHz measurement) | N | Y | Y | On | On | On | Measurement Mode 1.0 |
| | 1.1 | E1 | Mode 1.1 (fixed IF; variable freq. sys. LO) | N | Y | Y | Off | Off | Off | Measurement Mode 1.1 |
| | 1.2 | E2 | Mode 1.2 (variable IF; fixed freq. sys. LO; SSB) | N | Y | Y | Off | Off | Off | Measurement Mode 1.2 |
| | 1.3 | E3 | Mode 1.3 (fixed IF; variable freq. sys. LO; mixer is DUT) | N | Y | Y | Off | Off | Off | Measurement Mode 1.3 |
| | 1.4 | E4 | Mode 1.4 (variable IF; fixed freq. sys. LO; mixer is DUT) | N | Y | Y | Off | Off | Off | Measurement Mode 1.4 |
| Measurement Mode Selection (Noise Figure Measurement System) | 1.5 | E5 | Mode 1.5 (10 to 18000 MHz) | N | Y | Y | Off | Off | Off | Measurement Mode 1.5 |
| | 1.6 | E6 | Mode 1.6 (fixed IF; variable user controlled LO) | N | Y | Y | Off | Off | Off | Measurement Mode 1.6 |
| | 1.7 | E7 | Mode 1.7 (variable IF; fixed freq. user controlled LO; SSB) | N | Y | Y | Off | Off | Off | Measurement Mode 1.7 |
| | 1.8 | E8 | Mode 1.8 (fixed IF; variable user controlled LO; mixer in DUT) | N | Y | Y | Off | Off | Off | Measurement Mode 1.8 |
| | 1.9 | E9 | Mode 1.9 (variable IF; fixed user controlled LO; mixer in DUT.) | N | Y | Y | Off | Off | Off | Measurement Mode 1.9 |
| Sideband Frequency Offset | 2.0 | B0 | Double Sideband (no offset) | N | Y | Y | On | On | On | Sideband Selection |
| | 2.1 | B1 | Lower Single Sideband ($F_{\text{signal}} < F_{\text{LO}}$) | Y | Y | Y | Off | Off | Off | |
| | 2.2 | B2 | Upper Single Sideband ($F_{\text{signal}} > F_{\text{LO}}$) | Y | Y | Y | Off | Off | Off | |
| | 2.3 | B3 | Signal Up Conversion $IF = F_{\text{signal}} + F_{\text{LO}}$ | Y | Y | Y | Off | Off | Off | |

*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code.
N = No; Y = Yes; NC = No Change; — = Not Applicable

Table 3-14. Special Function Summary (2 of 15)

| Special Function | | Program Code HP-IB | Description | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Functions 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions | References and Comments |
|--|------------------|--------------------------------------|---|-----------------------------|-----------------------------|----------------------------|----------------------------------|-------------------------------------|---------------------------------|--|
| Name | Code* | | | | | | | | | |
| Enter IF and LO Frequencies | 3.0 | IF | IF (for Modes 1.1 & 1.3) (for Modes 1.6 & 1.8) | N | Y | Y | NC | 30 MHz 3 500 MHz | 30 MHz 3 500 MHz | Fixed IF or LO Frequency Selection |
| | 3.1 | LF | LO (for Modes 1.2 & 1.4) (for Modes 1.7 & 1.9) | N | Y | Y | NC | 10 000 MHz 44 000 MHz | 10 000 MHz 44 000 MHz | |
| | 3.2 | UL | Display the User Controlled LO Frequency in Measurement Modes 1.6 through 1.9 | N | N | N | Off | Off | Off | |
| Control Function Selection | 4.0 | none | Normal Talker and Listener | N | Y | N | NC | NC | On | Controller Capability of the Noise Figure Meter |
| | 4.1 ¹ | — | | — | — | — | — | — | — | |
| | 4.2 | none | Talk Only | N | Y | N | NC | NC | Off | |
| ENR, THOT Settings and ENR Table Selection | 5.0 | S0 | Use ENR Table | N | Y | Y | On | On | On | Spot ENR, T _{HOT} , T _{COLD} and ENR Table Selection |
| | 5.1 | S1 | Use Spot ENR | Y | Y | Y | Off | Off | Off | |
| | 5.2 | SE | Display Current ENR in dB | N | N | N | Off | Off | Off | |
| | 5.3 | NR | Enter and Use Spot ENR | N | Y | Y | NC | 15.2 dB | 15.2 dB | |
| | 5.4 | TH | Enter and Use THOT | N | Y | Y | NC | 9893K | 9893K | |
| | 5.5 | SN | Enter Noise Source Identifier | N | Y | N | NC | NC | NC | |
| | 5.6 | NS | Noise Source catalog | N | N | N | NC | NC | NC | |
| | 5.7 | EC | ENR table number for calibration | N | Y | Y | NC | 0 | 0 | |
| 5.8 | EM | ENR table number for the measurement | N | Y | Y | NC | 0 | 0 | | |
| TCOLD Setting | 6.0 | TC | Enter TCOLD | N | Y | Y | NC | 296.5K | 296.5K | Spot ENR, T _{HOT} , T _{COLD} and ENR Table Selection |
| Output to Oscilloscope | 7.0 | A0 | Noise Figure and Gain | N | Y | N | On | On | On | Data Output to Oscilloscopes, Recorders and Plotters |
| | 7.1 | A1 | Test Pattern | N | Y | N | Off | Off | Off | |
| | 7.2 | A2 | Noise Figure Only | N | Y | N | Off | Off | Off | |
| | 7.3 | A3 | Gain Only | N | Y | N | Off | Off | Off | |
| | 7.4 | A8 | Cursor enabled for oscilloscope display | N | Y | N | On | On | On | |
| | 7.5 | A9 | Cursor disabled for oscilloscope display | N | Y | N | Off | Off | Off | |
| <p>*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code. N = No; Y = Yes; NC = No Change; — = Not Applicable</p> | | | | | | | | | | |

¹Special Function 4.1 is no longer used. Refer to Special Function 46.

Table 3-14. Special Function Summary (3 of 15)

| Special Function | | Program Code HP-IB | Description | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Functions 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions | References and Comments |
|---|-------|-----------------------|---------------------------|-----------------------------|-----------------------------|----------------------------|----------------------------------|-------------------------------------|---------------------------------|--|
| Name | Code* | | | | | | | | | |
| Enter Oscilloscope Limits | 8.1 | NL | Noise Figure Lower Limit | N | Y | Y | NC | 0 | 0 | Data Output to Oscilloscopes, Recorders and Plotters |
| | 8.2 | NU | Noise Figure Upper Limit | N | Y | Y | NC | 8 | 8 | |
| | 8.3 | GL | Gain Lower Limit | N | Y | Y | NC | 0 | 0 | |
| | 8.4 | GU | Gain Upper Limit | N | Y | Y | NC | 40 | 40 | |
| Power Measurements | 9.1 | N5 | SOURCE Off (uncal) | N | Y | Y | Off | Off | Off | Power Measurements |
| | 9.2 | N6 | SOURCE On (uncal) | N | Y | Y | Off | Off | Off | |
| | 9.3 | N7 | SOURCE Off (cal) | N | Y | Y | Off | Off | Off | |
| | 9.4 | N8 | SOURCE On (cal) | N | Y | Y | Off | Off | Off | |
| Noise Figure Display Units | 10.0 | N0 | F dB | N | Y | Y | On | On | On | Display Units Selection |
| | 10.1 | N1 | F | N | Y | Y | Off | Off | Off | |
| | 10.2 | N2 | Y dB | N | Y | Y | Off | Off | Off | |
| | 10.3 | N3 | Y | N | Y | Y | Off | Off | Off | |
| | 10.4 | N4 | TeK | N | Y | Y | Off | Off | Off | |
| Select Noise Source Temp. Units for Data Input | 11.0 | D0 | K | N | Y | Y | On | On | On | Temperature Units Selection (Also see Special Functions 5.4, 6.0 and 34.3) |
| | 11.1 | D1 | °C | N | Y | Y | Off | Off | Off | |
| | 11.2 | D2 | °F | N | Y | Y | Off | Off | Off | |
| Display Resolution | 12.0 | X0 | Maximum Resolution | N | Y | N | On | On | On | Display Resolution |
| | 12.1 | X1 | Less Res. on Noise Figure | N | Y | N | Off | Off | Off | |
| | 12.2 | X2 | Less Res. on Gain | N | Y | N | Off | Off | Off | |
| Smoothing (Averaging) | 13.0 | V0 | Exponential Smoothing | N | Y | N | On | On | On | Smoothing (Averaging) |
| | 13.1 | V1 | Arithmetic Averaging | N | Y | N | Off | Off | Off | |
| | 13.2 | AF | Smoothing Factor | N | Y | N | NC | 1 | 1 | |
| <p>*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code. N = No; Y = Yes; NC = No Change; — = Not Applicable</p> | | | | | | | | | | |

Table 3-14. Special Function Summary (4 of 15)

| Special Function | | Program Code HP-IB | Description | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Functions 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions | References and Comments |
|---|-------|------------------------------|---|-----------------------------|-----------------------------|----------------------------|----------------------------------|-------------------------------------|---------------------------------|------------------------------------|
| Name | Code* | | | | | | | | | |
| Manual Measurement Functions | 14.1 | MC | Cold Measurement (SOURCE-off) | N | Y | Y | Off | Off | Off | Manual Measurement Functions |
| | 14.2 | MH | Hot Measurement (SOURCE-on) | N | Y | Y | Off | Off | Off | |
| | 14.3 | CC | Cold Calibration (SOURCE-off) | N | Y | Y | Off | Off | Off | |
| | 14.4 | CH | Hot Calibration (SOURCE-on) | N | Y | Y | Off | Off | Off | |
| | 15.0 | P0 | Display Current Measurement | N | N | Y | On | On | On | |
| | 15.1 | P1 | Display Manual Measurement Results | Y | N | Y | Off | Off | Off | |
| Display Control | 16.0 | DF | Measurement frequency is displayed in left window. | N | Y | Y | On | On | On | Display Control |
| | 16.1 | DI | Input to Noise Figure Meter (Modes 1.0 through 1.4) or Noise Figure Test Set (Modes 1.5 through 1.9) displayed. | N | Y | Y | Off | Off | Off | |
| | 16.2 | BF | Frequency display is blanked. | N | Y | Y | Off | Off | Off | |
| | 16.3 | BD | All displays are blanked. | N | Y | Y | Off | Off | Off | |
| Sideband Frequency Offset | 17.0 | B4 | Single Sideband Operation (Modes 1.5 through 1.9) | N | Y | Y | On | On | On | Sideband Selection |
| | 17.1 | B5 | Double Sideband Operation (Modes 1.5 through 1.9) | N | Y | Y | Off | Off | Off | |
| | 17.2 | CF | Upper and Lower sideband crossover frequency selection | N | Y | Y | NC | 16 GHz | 16 GHz | |
| Noise Figure Measurement System Internal IF | 19.2 | S2 | Internal IF for SSB2 | N | Y | Y | NC | 700 MHz | 700 MHz | Fixed IF or LO Frequency Selection |
| | 19.3 | S3 | Internal IF for SSB3 | N | Y | Y | NC | 450 MHz | 450 MHz | |
| | 19.4 | S4 | Internal IF for DSB | N | Y | Y | NC | 25 MHz | 25 MHz | |
| | 19.5 | S5 | Display Noise Figure Meter input frequency | N | N | N | NC | NC | NC | |

*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code.
N = No; Y = Yes; NC = No Change; -- = Not Applicable

Table 3-14. Special Function Summary (5 of 15)

| Special Function | | Program Code HP-IB | Description | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Functions 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions | References and Comments |
|------------------------|-------|------------------------------|--|-----------------------------|-----------------------------|----------------------------|----------------------------------|-------------------------------------|---------------------------------|--|
| Name | Code* | | | | | | | | | |
| Recorder Functions | 20.0 | LL | Go to Lower Left | N | N | N | Off | Off | Off | Data Output to Oscilloscopes, Recorders and Plotters |
| | 21.0 | UR | Go to Upper Right | N | N | N | Off | Off | Off | |
| | 22.0 | A4 | Plot Noise Figure | N | Y | N | Off | Off | Off | |
| | 23.0 | A5 | Plot Gain | N | Y | N | Off | Off | Off | |
| | 24.0 | A6 | X-AXIS Output is Noise Figure and Y-AXIS Output is Gain (Strip Chart mode) | N | Y | N | Off | Off | Off | |
| Plotter Functions | 25.0 | PA | Plot grid and data | N | N | N | Off | Off | Off | Data Output to Oscilloscopes, Recorders and Plotters |
| | 25.1 | PG | Plot grid and axes labels | N | N | N | Off | Off | Off | |
| | 25.2 | PD | Plot data only | N | N | N | Off | Off | Off | |
| | 25.3 | NP | Select noise pen number | N | N | N | NC | 1 | 1 | |
| | 25.4 | GP | Select gain pen number | N | N | N | NC | 2 | 2 | |
| | 25.5 | WT | Select plot name | N | N | N | NC | HP 8970B Noise Figure Meter | HP 8970B Noise Figure Meter | |
| Trigger Selection | 30.0 | T0 | Free Run | N | N | N | On | On | On | Trigger Selection |
| | 30.1 | T1 | Hold | N | N | N | Off | Off | Off | |
| | 30.2 | T2 | Execute | N | N | N | Off | Off | Off | |
| Frequency Calibration | 31.0 | Y0 | Automatic | N | N | N | On | On | On | Calibration, Frequency |
| | 31.1 | Y1 | Display Frequency Cal | N | N | N | Off | Off | Off | |
| | 31.2 | Y2 | Perform 1 Frequency Cal | N | N | N | Off | Off | Off | |
| Input Gain Calibration | 32.0 | C0 | 20, 10 and 0 dB | N | N | N | On | On | On | Calibration, Input Gain Selection |
| | 32.1 | C1 | 10, 0 and -10 dB | Y | N | N | Off | Off | Off | |
| | 32.2 | C2 | 0, -10 and -20 dB | Y | N | N | Off | Off | Off | |
| | 32.3 | C3 | -10, -20 and -30 dB | Y | N | N | Off | Off | Off | |

*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code.
 N = No; Y = Yes; NC = No Change; -- = Not Applicable

Table 3-14. Special Function Summary (6 of 15)

| Special Function | | Program Code Code HP-IB | Description | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Functions 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions | References and Comments |
|--|---------------------------------|---|---|-----------------------------|-----------------------------|----------------------------|----------------------------------|-------------------------------------|---------------------------------|---|
| Name | Code* | | | | | | | | | |
| IF Attenuators Calibration | See footnote below ¹ | | Calibrate IF Attenuators | N | Y | N | Off | Off | Off | Calibration, IF Attenuators |
| Loss Compensation | 34.0 | L0 | Off | N | Y | N | On | On | On | Loss Compensation |
| | 34.1 | L1 | On | Y | Y | N | Off | Off | Off | |
| | 34.2 | LA | Enter Loss before DUT in dB | N | Y | N | NC | 0 dB | 0 dB | |
| | 34.3 | LT | Enter Temperature of Losses | N | Y | N | NC | 0K | 0K | |
| 34.4 | LB | Enter Loss after DUT in dB | N | Y | N | NC | 0 dB | 0 dB | | |
| Sequence Functions | 35.0 | QM | Manual | N | N | N | On | On | On | Sequence ² Enables Special Function Key LED to light when SEQ is pressed. |
| | 35.1 | QA | Automatic | N ² | N | N | Off | Off | Off | |
| | 35.2 | QS | Set | N | Y | N | NC | 1-9 | 1-9 | |
| | 35.3 | QC | Clear | N | N | N | Off | Off | Off | |
| Noise Figure Test Set YIG Filter Fine Tuning Calibration | 36.0 | FT | Enable Fine Tuning Calibration before Noise Figure Measurement System Cal. (Error E28 enabled.) | N | Y | Y | On | On | On | Noise Figure Test Set YIG Filter Calibration |
| | 36.1 | FD | Disable Fine Tuning Calibration before Noise Figure Measurement System Calibration is done. | N | Y | Y | Off | Off | Off | |
| | 36.2 | FW | Disable Fine Tuning Calibration before Noise Figure Measurement System Calibration is done. Also, error twenty-eight is disabled. | Y | Y | Y | Off | Off | Off | |
| | 36.3 | PF | Perform a Fine Tuning Calibration from START FREQ to STOP FREQ and enable Special Function 36.1. | N | N | N | Off | Off | Off | |
| 36.4 | FF | Enable a Fine Tuning Calibration at the current frequency | N | N | N | Off | Off | Off | | |
| <p>*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code. N = No; Y = Yes; NC = No Change; - = Not Applicable</p> | | | | | | | | | | |

¹IF Attenuators Calibration; Special Function 33.1 (HP-IB Code CI). IF Special Function 33.1 is used, the gain accuracy specification will be degraded from 0.15 dB to a typical value of 0.25 dB. For more information, refer to the Calibration, IF Attenuators Detailed Operating Instruction.

Table 3-14. Special Function Summary (7 of 15)

| Special Function | | Program Code HP-IB | Description | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions | References and Comments |
|--|-------|-----------------------|--|-----------------------------|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|---|
| Name | Code* | | | | | | | | | |
| Interpolated Measurements | 39.0 | DG | Disables interpolated measurements in Measurement Modes 1.5 to 1.9 | N | Y | Y | NC | On | On | Calibration |
| | 39.1 | EG | Enables interpolated measurements in Measurement Modes 1.5 to 1.9 | N | Y | Y | NC | Off | Off | |
| HP-IB and SIB Addresses | 40.0 | none | Display and Enter Noise Figure Meter Address | N | Y | N | NC | NC | 8 | HP-IB and SIB Addresses |
| | 40.1 | EA | Display and Enter Sys. LO Address | N | Y | N | NC | NC | 19 | |
| | 40.2 | HT | Display and Enter Noise Figure Test Set Address | N | Y | N | NC | NC | 10 | |
| | 40.3 | HP | Display and Enter Plotter Address | N | Y | N | NC | NC | 5 | |
| | 40.4 | HS | Display and Enter System Interface Bus Address | N | Y | N | NC | NC | 8 | |
| | 40.5 | HC | Display and Enter the Pass Control Address | N | Y | N | NC | NC | 16 | |
| | 40.6 | PT | Display and Enter the Address of the Pass Through Device on the System Interface Bus | N | Y | N | NC | 0 ¹ | 0 ¹ | |
| | 40.7 | VP | Display the Pass Through Address of the Noise Figure Meter | N | N | N | NC | NC | NC | |
| System LO Programs | 41.0 | J0 | HP 8350B Sweep Oscillator | N | Y | N | NC | NC | On | Programs Available to Control the System LO |
| | 41.2 | J2 | HP 8671B/8672A Syn. Signal Generator | N | Y | N | NC | NC | Off | |
| | 41.3 | J3 | HP 8673B/C Syn. Signal Generator | N | Y | N | NC | NC | Off | |
| | 41.4 | J4 | HP 8340B/8341B Sweep Oscillator | N | Y | N | Off | Off | Off | |
| | 41.5 | J5 | Custom Local Oscillator | N | Y | N | Off | Off | Off | |
| <p>*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code. N = No; Y = Yes; NC = No Change; — = Not Applicable</p> | | | | | | | | | | |

¹Also, Pass Through Mode is disabled.

Table 3-14. Special Function Summary (8 of 15)

| Special Function | | Program Code HP-IB | Description | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Functions 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions | References and Comments |
|-----------------------------|-------|-----------------------|--|-----------------------------|-----------------------------|----------------------------|----------------------------------|-------------------------------------|---------------------------------|---|
| Name | Code* | | | | | | | | | |
| System LO Commands | 42.0 | AC | Auxilliary Commands | N | Y | Y | NC | NC | 0 | Programming the System LO |
| | 42.1 | PS | CW Prefix and Suffix | N | Y | N | NC | NC | CW,MZ | |
| | 42.2 | TM | Settling Time in ms | N | Y | N | NC | NC | 60 | |
| | 42.3 | MN | Min Frequency in MHz | N | Y | N | NC | NC | 2 000 | |
| | 42.4 | MX | Max Frequency in MHz | N | Y | N | NC | NC | 18 000 | |
| | 42.5 | PL | Power level in dBm | N | Y | Y | NC | NC | 6 dBm | |
| | 42.6 | PC | Power Prefix and Suffix (Special Function 41.5) | N | Y | N | NC | NC | NC | |
| | 42.7 | FC | Frequency Prefix and Suffix (Special Function 41.5) | N | Y | N | NC | NC | NC | |
| HP-IB Data Output Selection | 43.0 | H0 | NOISE FIGURE Only | N | N | N | On | On | On | Refer to Remote Operation, Hewlett-Packard Interface Bus |
| | 43.1 | H1 | Frequency (left display), INSERTION GAIN, NOISE FIGURE | N | N | N | Off | Off | Off | |
| | 43.2 | H2 | Send gain reference and second stage temperature, while calibrating. | N | N | N | Off | Off | Off | |
| Service Request | 44.0 | Q0 | Disable SRQ Capability (clears all enabled conditions) | N | N | N | Off | Off | Off | Refer to Remote Operations, Hewlett-Packard Interface Bus |
| | 44.1 | Q1 | Enable Data Ready to cause an SRQ | N | N | N | Off | Off | Off | |
| | 44.2 | Q2 | Enable Cal Complete to cause an SRQ | N | N | N | Off | Off | Off | |
| | 44.3 | Q3 | Enable HP-IB Code Error to cause an SRQ | N | N | N | On | On | On | |
| | 44.4 | Q4 | Enable SRQ on the System Interface Bus | N | N | N | Off | Off | Off | |
| | 44.5 | Q5 | Enable System Interface Bus control active | N | N | N | Off | Off | Off | |
| | 44.6 | Q6 | Enable Instrument Error to cause an SRQ | N | N | N | Off | Off | Off | |
| | 44.7 | RM | Set Status Byte Mask | N | N | N | 4 | 4 | 4 | |

*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code.
N = No; Y = Yes; NC = No Change; -- = Not Applicable

Table 3-14. Special Function Summary (9 of 15)

| Special Function | | Program Code HP-IB | Description | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Functions 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions | References and Comments |
|---|-------|-----------------------|---|-----------------------------|-----------------------------|----------------------------|----------------------------------|-------------------------------------|---------------------------------|---|
| Name | Code* | | | | | | | | | |
| Service Request (cont'd) | 44.8 | Q8 | Enable Extended Status Byte | N | N | N | Off | Off | Off | |
| | 44.9 | RE | Set Extended Status Byte Mask | N | N | N | 0 | 0 | 0 | |
| Noise Figure Test Set Control | 45.0 | TE | Enable Noise Figure Test Set in Modes 1.5 through 1.9 | N | Y | N | NC | NC | On | System Interface Control |
| | 45.1 | TS | Enable Noise Figure Test Set on the System Interface Bus in all Modes | N | Y | N | NC | NC | Off | |
| | 45.2 | TD | Disable Noise Figure Test Set on the System Interface Bus | N | Y | N | NC | NC | Off | |
| System Local Oscillator Control | 46.0 | LE | Enable LO on the System Interface Bus | N | Y | N | NC | NC | On | System Interface Bus Control |
| | 46.1 | LD | Disable LO on the System Interface Bus | N | Y | N | NC | NC | Off | |
| Plotter Control on System Interface Bus | 47.0 | PI | Plotter is on the System Interface Bus | N | Y | N | NC | NC | On | Data Output to Oscilloscopes, Recorders and Plotters and System Interface Bus Control |
| | 47.1 | PM | Enable plot data to be read on HP-IB | N | Y | N | NC | NC | Off | |
| System Interface Bus Controller | 48.0 | SC | Noise Figure Meter is the System Controller on the System Interface Bus | N | Y | N | NC | NC | On | System Interface Bus Control |
| | 48.1 | NC | Noise Figure Meter is not the System Controller on the System Interface Bus | N | Y | N | NC | NC | Off | |
| | 48.2 | DC | Disable controller collision, on the System Interface Bus, error (E48) | N | Y | N | NC | Off | Off | |
| <p>*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code. N = No; Y = Yes; NC = No Change; -- = Not Applicable</p> | | | | | | | | | | |

Table 3-14. Special Function Summary (10 of 15)

| Special Function | | Program Code HP-IB | Description | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Functions 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions | References and Comments |
|--|-------|-----------------------|---|-----------------------------|-----------------------------|----------------------------|----------------------------------|-------------------------------------|---------------------------------|--------------------------|
| Name | Code* | | | | | | | | | |
| Sharing Control on the System Interface Bus | 49.0 | DP | Disable Auto Pass Control on the System Interface Bus | N | Y | N | NC | NC | On | System Interface Control |
| | 49.1 | EP | Enable Auto Pass Control on the System Interface Bus | N | Y | N | NC | NC | Off | |
| | 49.2 | CR | Noise Figure Meter releases control of the System Interface Bus | N | N | N | NC | NC | Off | |
| | 49.3 | CT | Noise Figure Meter takes control of the System Interface Bus | N | N | N | NC | NC | Off | |
| | 49.4 | SB | Noise Figure Meter does a serial poll on the System Interface Bus | N | N | N | NC | NC | Off | |
| | 49.5 | DD | Enable a selective device clear of the Pass Through Device on the System Interface Bus | N | N | N | Off | Off | Off | |
| | 49.6 | DS | Enable a device clear on the System Interface Bus, if the Noise Figure Meter is the active controller | N | N | N | Off | Off | Off | |
| | 49.7 | IS | Enable an interface clear on the System Interface Bus, if the Noise Figure Meter is the system controller | N | N | N | Off | Off | Off | |
| Special Function Catalog | 50.0 | G0 | Scan Special Function Catalog Lines | N | N | N | Off | Off | Off | Special Function Catalog |
| | 50.1 | G1 | Line 1 Status | N | N | N | Off | Off | Off | |
| | 50.2 | G2 | Line 2 Status | N | N | N | Off | Off | Off | |
| | 50.3 | G3 | Line 3 Status | N | N | N | Off | Off | Off | |
| | 50.4 | G4 | Line 4 Status | N | N | N | Off | Off | Off | |
| | 50.5 | G5 | Line 5 Status | N | N | N | Off | Off | Off | |
| <p>*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code. N = No; Y = Yes; NC = No Change; — = Not Applicable</p> | | | | | | | | | | |

Table 3-14. Special Function Summary (11 of 15)

| Special Function | | Program Code HP-IB | Description | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Functions 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions | References and Comments |
|---|-------|------------------------------|--|-----------------------------|-----------------------------|----------------------------|----------------------------------|-------------------------------------|---------------------------------|--|
| Name | Code* | | | | | | | | | |
| Special Function Catalog (cont'd) | 50.6 | G6 | Line 6 Status | N | N | N | Off | Off | Off | |
| | 50.7 | G7 | Line 7 Status | N | N | N | Off | Off | Off | |
| | 50.8 | G8 | Line 8 Status | N | N | N | Off | Off | Off | |
| RF Attenuation Selection | 60.0 | R0 | Auto | N | N | N | On | On | On | RF Attenuation Selection |
| | 60.1 | R1 | +20 dB | Y | N | N | Off | Off | Off | |
| | 60.2 | R2 | +10 dB | Y | N | N | Off | Off | Off | |
| | 60.3 | R3 | 0 dB | Y | N | N | Off | Off | Off | |
| | 60.4 | R4 | -10 dB | Y | N | N | Off | Off | Off | |
| | 60.5 | R5 | -20 dB | Y | N | N | Off | Off | Off | |
| | 60.6 | R6 | -30 dB | Y | N | N | Off | Off | Off | |
| Display RF Attenuator Settings | 61.0 | SR | Display RF Attenuators | N | N | N | Off | Off | Off | RF Attenuation Selection |
| RF Attenuator Hold | 62.0 | RH | RF Attenuators are held in the configuration that exists when Special Function 62.0 is activated | Y | N | N | Off | Off | Off | RF Attenuation Selection |
| Individual RF Attenuator Selection | 63.0 | Z0 | Select RF through Path | Y | N | N | Off | Off | Off | RF Attenuation Selection Refer to Section VIII, Service ¹ |
| | 63.1 | Z1 | Select 10 dB Pad Number 1 | Y | N | N | Off | Off | Off | |
| | 63.2 | Z2 | Select 20 dB Input Amplifier | Y | N | N | Off | Off | Off | |
| | 63.4 | Z4 | Select 10 dB Pad Number 2 | Y | N | N | Off | Off | Off | |
| | 63.5 | Z5 | Select 10 dB Pad Number 3 | Y | N | N | Off | Off | Off | |
| <p>*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code. N = No; Y = Yes; NC = No Change; -- = Not Applicable</p> | | | | | | | | | | |

¹Section VIII, Service, is in the Service Manual. The part number of the Service Manual is on the title page of this manual.

Table 3-14. Special Function Summary (12 of 15)

| Special Function | | Program Code HP-IB | Description | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Functions 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions | References and Comments |
|--|-------|-----------------------|--|-----------------------------|-----------------------------|----------------------------|----------------------------------|-------------------------------------|---------------------------------|--|
| Name | Code* | | | | | | | | | |
| Noise Figure Test Set YIG Filter Coarse Calibration | 64.0 | CP | Enable a coarse calibration of the Noise Figure Test Set | N | N | N | NC | NC | Off | Noise Figure Test Set YIG Filter Calibration |
| | 64.1 | CU | Selects the upper frequency of the Noise Figure Test Set | N | N | N | NC | NC | Off | |
| IF Attenuation Selection | 70.0 | I0 | Auto | N | N | N | On | On | On | IF Attenuation Selection |
| | 70.1 | I1 | 0 db | Y | N | N | Off | Off | Off | |
| | 70.2 | I2 | 5 db | Y | N | N | Off | Off | Off | |
| | 70.3 | I3 | 10 db | Y | N | N | Off | Off | Off | |
| | 70.4 | I4 | 15 db | Y | N | N | Off | Off | Off | |
| | 70.5 | I5 | 20 db | Y | N | N | Off | Off | Off | |
| | 70.6 | I6 | 25 db | Y | N | N | Off | Off | Off | |
| | 70.7 | I7 | 30 db | Y | N | N | Off | Off | Off | |
| 70.8 | I8 | 35 db | Y | N | N | Off | Off | Off | | |
| Display IF Attenuator Settings | 71.0 | SI | Display IF Attenuators | N | N | N | Off | Off | Off | IF Attenuation Selection |
| IF Attenuator Hold | 72.0 | IH | IF Attenuators are held in the configuration that exists when Special Function 72.0 is activated | Y | N | N | Off | Off | Off | IF Attenuation Selection |
| Voltmeter Mode | 80.0 | VC | Noise Source Off | N | Y | Y | Off | Off | Off | Refer to Section VIII, Service ¹ |
| | 81.0 | VH | Noise Source On | N | Y | Y | Off | Off | Off | |
| Recorder Test Functions | 82.0 | A7 | Enable Recorder Test | N | N | N | Off | Off | Off | Refer to Section VIII, Service ¹ |
| | 82.1 | XV | X-Axis Test | N | N | N | NC | 0 | 0 | |
| | 82.2 | YV | Y-Axis Test | N | N | N | NC | 0 | 0 | |
| <p>*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code. N = No; Y = Yes; NC = No Change; — = Not Applicable</p> | | | | | | | | | | |

¹Section VIII, Service, is in the Service Manual. The part number of the Service Manual is on the title page of this manual.

Table 3-14. Special Function Summary (13 of 15)

| Special Function | | Program Code HP-IB | Description | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Functions 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions | References and Comments |
|---|-------|-----------------------|--|-----------------------------|-----------------------------|----------------------------|----------------------------------|-------------------------------------|---------------------------------|---|
| Name | Code* | | | | | | | | | |
| Keyboard Test | 90.0 | KY | Display Key Codes | N | N | N | Off | Off | Off | Refer to Section VIII, Service ¹ |
| | 90.1 | K1 | Key Test—Row 1 | N | N | N | Off | Off | Off | |
| | 90.2 | K2 | Key Test—Row 2 | N | N | N | Off | Off | Off | |
| | 90.3 | K3 | Key Test—Row 3 | N | N | N | Off | Off | Off | |
| | 90.4 | K4 | Key Test—Row 4 | N | N | N | Off | Off | Off | |
| | 90.5 | K5 | Key Test—Row 5 | N | N | N | Off | Off | Off | |
| | 90.6 | K6 | Key Test—Row 6 | N | N | N | Off | Off | Off | |
| | 90.7 | K7 | Key Test—Row 7 | N | N | N | Off | Off | Off | |
| | 90.8 | K8 | Key Test—Row 8 | N | N | N | Off | Off | Off | |
| Display Test | 91.0 | DT | Enable Display Test | N | N | N | Off | Off | Off | Refer to Section VIII, Service ¹ |
| 0 MHz Hold | 92.0 | U0 | Off | N | N | N | On | On | On | Refer to Section VIII, Service ¹ |
| | 92.1 | U1 | On | Y | N | N | Off | Off | Off | |
| RAM Inspection/Modification or ROM Inspection Utilities | 93.0 | AI | Sets the address for modification or inspection and enables auto-increment mode | N | N | N | NC | Cal Data | Cal Data | Refer to Section VIII, Service ¹ |
| | 93.1 | AD | Sets the address for modification or inspection and disables auto-increment mode | N | N | N | NC | Cal Data | Cal Data | |
| | 93.2 | MB | Selects modification or inspection of a byte in RAM or inspection of a byte in ROM | N | N | N | Off | Off | Off | |
| | 93.3 | MW | Selects modification or inspection of a word in RAM or inspection of a word in ROM | N | N | N | Off | Off | Off | |
| | 93.4 | MF | Selects modification or inspection of a floating point value in RAM or inspection of a floating point value in ROM | N | N | N | Off | Off | Off | |

*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code.
N = No; Y = Yes; NC = No Change; — = Not Applicable

¹Section VIII, Service, is in the Service Manual. The part number of the Service Manual is on the title page of this manual.

Table 3-14. Special Function Summary (14 of 15)

| Special Function | | Program Code HP-IB | Description | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Functions 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions | References and Comments |
|--|-------|-----------------------|--|-----------------------------|-----------------------------|----------------------------|----------------------------------|-------------------------------------|---------------------------------|---|
| Name | Code* | | | | | | | | | |
| Noise Figure Meter YIG Filter Tuning Functions | 94.1 | — | Disable hysteresis calibration when frequency is changed | N | N | N | Off | Off | Off | Refer to Section VIII, Service ¹ |
| | 94.2 | EH | Enable hysteresis calibration when frequency is changed | N | N | N | On | On | On | |
| | 94.3 | — | YIG DAC is not updated when frequency is changed | N | N | N | Off | Off | Off | |
| | 94.4 | UY | YIG DAC is updated when frequency is changed | N | N | N | On | On | On | |
| Default ENR | 95.6 | ND | Sets all ENR values to 15.20 dB and Noise Source ID No. to 00000 | N | N | N | Off | Off | Off | Refer to Section VIII, Service ¹ |
| Debug Oscilloscope Plots | 97.1 | Y9 | Enables debug oscilloscope plots | N | N | N | NC | Off | Off | Refer to Section VIII, Service ¹ |
| | 97.2 | Y8 | Disable debug oscilloscope plots | N | N | N | NC | On | On | |
| Noise Figure Test Set Functions | 97.3 | DA | Disable auto-sweep abort, error E102. | N | Y | Y | Off | Off | Off | Refer to Section VIII, Service ¹ |
| | 97.4 | — | Reset Noise Figure Test Set YIG Filter Heater. | N | N | N | Off | Off | Off | Refer to Section VIII, Service ¹ |
| <p>*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code. N = No; Y = Yes; NC = No Change; — = Not Applicable</p> | | | | | | | | | | |

¹Section VIII, Service, is in the Service Manual. The part number of the Service Manual is on the title page of this manual.

Table 3-14. Special Function Summary (15 of 15)

| Special Function | | Program Code HP-IB | Description | Lights Special Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Functions 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions | References and Comments |
|---|-------|-----------------------|---|-----------------------------|-----------------------------|----------------------------|----------------------------------|-------------------------------------|---------------------------------|---|
| Name | Code* | | | | | | | | | |
| Hewlett-Packard Interface Bus and System Interface Bus Test | 98.1 | — | Enable HP-IB and SIB test | N | N | N | Off | Off | Off | Refer to Section VIII, Service ¹ |
| Noise Figure Meter RAM Test | 98.2 | — | Enable RAM test. | N | N | N | Off | Off | Off | Refer to Section VIII, Service ¹ |
| Noise Figure Test Set Self Test | 98.7 | — | Enable Noise Figure Test Set Self Test | N | N | N | Off | Off | Off | Refer to Section VIII, Service ¹ |
| Last Error | 99.1 | ER | Recall last error issued | N | N | N | Off | Off | Off | Refer to Section VIII, Service ¹ |
| Noise Figure Test Set Software Day-code | 99.7 | — | Display Noise Figure Test Set Software Day-code | N | N | N | Off | Off | Off | Refer to Section VIII, Service ¹ |
| Software Date | 99.9 | SD | Display Software Date | N | N | N | Off | Off | Off | Refer to Section VIII, Service ¹ |

*Most Special Functions can be programmed using either the code number followed by SP or the HP-IB Code.
N = No; Y = Yes; NC = No Change; — = Not Applicable

¹Section VIII, Service, is in the Service Manual. The part number of the Service Manual is on the title page of this manual.

Spot ENR, T_{hot} , T_{cold} and ENR Table Selection (Special Functions 5 and 6)

Description

Special Functions 5 and 6 perform the following functions:

a. Special Function 5.0 enables use of the ENR (Excess Noise Ratio) data that was previously entered (refer to the ENR Table Entry Detailed Operating Instruction). This function disables spot ENR. (Spot ENR can be re-enabled using Special Function 5.1).

b. Special Function 5.1 enables use of the previously entered spot ENR value (refer to Special Function 5.3). The ENR table is disabled and the single spot ENR value will be used at all frequencies. (The ENR table can be re-enabled using Special Function 5.0).

c. Special Function 5.2 enables the current value of ENR being used by the instrument to be displayed.

d. Special Function 5.3 enables entry and use of a spot ENR value. The allowable values for spot ENR range from -7 to $+17$ dB.

e. Special Function 5.4 enables entry and use of T_{hot} . Some noise sources are specified in terms of T_{hot} instead of ENR. The allowable values for T_{hot} (in Kelvins) range from 0 to 14824. The equation to convert T_{hot} (in Kelvins) to ENR is:

$$ENR = 10 \log (T_{hot}/290 - 1)$$

f. Special Function 5.5 enables display and entry of the noise source identifier. Up to five digits, within the range of 0 to 60000 can be used to identify the noise source. For example, the serial number of the noise source for which the ENR table data was entered can be used.

g. Special Function 5.6 enables display of the noise source catalog. The noise source catalog special function allows the user to examine each of the ENR tables; the user is able to see how many entries are in each table.

h. Special Function 5.7 allows display and entry of the ENR table that will be used for calibration. Tables 0 through 4 can be selected for a calibration. Special Function 5.7 is useful in Measurement Modes 1.3, 1.4, 1.8 and 1.9, where two noise sources may be required.

i. Special Function 5.8 allows display and entry of the ENR table that will be used for a measurement. Tables 0 through 4 can be selected for the measurement.

j. Special Function 6.0 enables entry of a value for T_{cold} . T_{hot} and T_{cold} are used for hot/cold manual measurements. The allowable values for T_{cold} (in Kelvins) range from 0 to 9999.

Procedure

To enable use of the ENR table data or spot ENR data, or to display the current ENR or noise source catalog, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.

To display and enable entry of spot ENR, T_{hot} , T_{cold} , the noise source identifier, the ENR table number for calibration or the ENR table number for a measurement, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key. Next, enter the appropriate value using the DATA keys and press ENTER.

Spot ENR, T_{hot} , T_{cold} and ENR Table Selection (cont'd)

(Special Functions 5 and 6)


**Procedure
(cont'd)**

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Con- tinuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|----------------------------------|------|------------------------------|---|----------------------------------|-------------------------------|------------------------------------|--|------------------------------------|
| Description | Code | | | | | | | |
| Use ENR Table Data | 5.0 | S0 or 5.0SP | N | Y | Y | On | On | On |
| Use Spot ENR Data | 5.1 | S1 or 5.1 SP | Y | Y | Y | Off | Off | Off |
| Display Current ENR in dB | 5.2 | SE or 5.2SP | N | N | N | Off | Off | Off |
| Enter and Use Spot ENR | 5.3 | NE or 5.3SP | N | Y | Y | NC | 15.2 dB | 15.2 dB |
| Enter and Use T_{hot} | 5.4 | TH or 5.4SP | N | Y | Y | NC | 9893K | 9893K |
| Enter Noise Source Identifier | 5.5 | SN or 5.5SP | N | Y | N | NC | NC | NC |
| Noise Source Catalog | 5.6 | NS or 5.6SP | N | N | N | NC | NC | NC |
| ENR Table for Calibration | 5.7 | EC or 5.7SP | N | Y | Y | NC | 0 | 0 |
| ENR Table for Measurement | 5.8 | EM or 5.8SP | N | Y | Y | NC | 0 | 0 |
| Enter T_{cold} | 6.0 | TC or 6.0SP | N | Y | Y | NC | 296.5K | 296.5K |

¹Table categories are explained in the Special Functions Detailed Operating Instruction.

Example

To enter and use a value of 9800K for T_{hot} (assuming Special Function 11.0 is active).



Program Codes



For HP-IB codes for Special Functions 5 and 6, refer to Procedure above. The program code for ENTER is EN.

Indications

When Special Function 5.2 or 5.3 is active, the current ENR or spot ENR is shown in the left display in units of dB. If a new spot ENR value is entered, it appears in the left display for as long as the ENTER key is depressed.

When Special Function 5.4 or 6.0 is active, T_{hot} or T_{cold} is shown in the left display in the temperature unit selected by Special Function 11. If a new value is entered for either T_{hot} or T_{cold} , it appears in the left display for as long as the ENTER key is depressed.

Spot ENR, T_{hot} , T_{cold} and ENR Table Selection (cont'd)

(Special Functions 5 and 6)

Indications (cont'd)

When Special Function 5.5 is active, the left display shows five digits. No units are displayed.

When Special Function 5.6 is active, the left display shows the ENR identification number of one of the ENR tables. The right display shows the ENR table number and the number of entries in the table.

When Special Function 5.7 or 5.8 is active, the left display shows the number of the table that is currently being used for calibration or measurement. If a new table number is entered for calibration or measurement, it appears in the left display for as long as the ENTER key is depressed.

Related Sections

ENR Table Entry
Manual Measurement Functions
Special Functions
Temperature Units Selection

Store and Recall

Description Up to ten instrument configurations can be stored in the Noise Figure Meter's storage registers. Front panel settings that are stored and recalled are FREQUENCY, FREQ INCR, START FREQ, STOP FREQ, and STEP SIZE. Table 3-14, Special Function Summary, in the Special Functions Detailed Operating Instruction has a complete listing of special functions that can and cannot be stored and recalled.

Procedure Press STORE and a Data key (a single digit 0-9 to identify the storage register).
 Press RECALL and a Data key (a single digit 0-9 to identify the storage register).

Example To recall an instrument configuration that has been stored in register 2:

| | | |
|--|---|---|
| LOCAL (keystrokes) | Function  | Data  |
|  (program codes) | RC2 Code ———┐┌———— Data | |

Program Codes



| Key | Program Code  |
|-----------------|---|
| STORE RECALL | ST RC |

Indications When the stored contents of a register are recalled, the instrument configuration changes to the recalled parameter values.

Comments If any key other than a digit is pressed after STORE or RECALL, the store or recall entry will be rejected.

The data in the storage registers is not affected by PRESET or Special Function 0.0.

When the Noise Figure Meter is turned off, data stored in the registers is retained.

Related Sections Preset Conditions and Power-Up Sequence
 Sequence
 Special Functions

Sweep

Description

The Noise Figure Meter (Noise Figure Measurement System) can sweep the measurement frequency from START FREQ to STOP FREQ. The frequency changes in discrete steps (as set by STEP SIZE) rather than in a continuous analog manner.

The allowable sweep range depends on the measurement mode selected.

| Measurement Mode | Range of Sweep | Conditions |
|------------------|------------------|--|
| 1.0 | 10 to 1600 MHz | |
| 1.1 | 1 to 99999 MHz | Depends on the frequency range of the system LO and the noise source. |
| 1.2 | >10 to <1600 MHz | System LO must be set up so that variable IF sweeps 10 to 1600 MHz. |
| 1.3 | 1 to 99999 MHz | Depends on the frequency range of the system LO and the noise source. |
| 1.4 | 10 to 1600 MHz | IF port response of mixer is being measured. Left display shows IF. |
| 1.5 | 10 to 18000 MHz | |
| 1.6 | 1 to 99999 MHz | Depends on frequency range of user controlled local oscillator and the noise source. |
| 1.7 | 10 to 18000 MHz | User controlled local oscillator must be set up so that variable IF sweeps 10 to 18000 MHz |
| 1.8 | 1 to 99999 MHz | Depends on frequency range of user controlled local oscillator and the noise source. |
| 1.9 | 10 to 18000 MHz | IF port response of mixer is being measured. Left display shows IF. |

Depending on the Measurement Mode selected, the START FREQ, STOP FREQ and STEP SIZE default to different values. The following table lists the default frequencies for the Measurement Modes.

| Measurement Modes | START FREQ | STOP FREQ | STEP SIZE |
|-------------------|------------|-----------|-----------|
| 1.0 and 1.4 | 10 MHz | 1600 MHz | 20 MHz |
| 1.1, 1.2 and 1.3 | 8000 MHz | 12000 MHz | 200 MHz |
| 1.5 and 1.9 | 10 MHz | 18000 MHz | 250 MHz |
| 1.6, 1.7 and 1.8 | 45000 MHz | 50000 MHz | 500 MHz |

Sweep (cont'd)

**Description
(cont'd)**

As shown in the table, the Measurement Modes have been placed into four groups. When the start, stop and step size frequencies are changed for one measurement mode, the start, stop and step size frequencies are changed for all the measurement modes of the group. When selecting a new Measurement Mode, the Noise Figure Meter automatically saves the start, stop and step size frequencies from the previous measurement mode.

The minimum step size is 1 MHz. The maximum number of frequency points allowable in one sweep is

$$\frac{\text{STOP FREQ} - \text{START FREQ}}{\text{STEP SIZE}} + 1$$

If the fractional part of

$$\frac{\text{STOP FREQ} - \text{START FREQ}}{\text{STEP SIZE}} + 1$$

does not equal 0, then add 1.

However, the maximum number of frequency points that should be used when the sweep is displayed on an oscilloscope is 251. If more points are swept, multiple readings could occur at some points. Other limitations may be caused by the system LO.

Two sweep modes are available: Auto and Single. Each mode uses the sweep parameters that were previously set. Auto mode executes a repetitive sweep, restarting at the end of each sweep. Single mode executes one sweep only. At the end of a single sweep, the instrument remains tuned to the stop frequency.

Procedure

Sweep Range Selection. The START FREQ and STOP FREQ keys set the starting and stopping points of the frequency sweep. STEP SIZE sets the frequency increment. Sweep parameters are selected in a Function - Data - ENTER format. Note that all frequency inputs from the front panel are in MHz.

Sweep Mode Selection. Press the desired mode key (AUTO or SINGLE) to initiate a sweep. To turn a sweep off, press the active sweep mode key a second time.


| Front Panel Key | Program Code | Stored in Continuous Memory | Can be Stored and Recalled | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|-----------------|--------------|-----------------------------|----------------------------|-------------------------------------|---------------------------------|
| | HP-IB | | | | |
| AUTO | W1 | N | N | Off | Off |
| SINGLE | W2 | N | N | Off | Off |
| START FREQ | FA | Y | Y | 10 MHz | 10 MHz |
| STEP SIZE | SS | Y | Y | 20 MHz | 20 MHz |
| STOP FREQ | FB | Y | Y | 1600 MHz | 1600 MHz |

*Table categories are explained in the Preset Conditions and Power-Up Sequence Detailed Operating Instruction.

Sweep (cont'd)

Example

To sweep from 100 MHz to 400 MHz in 50 MHz steps once only:



Program Codes

HP-IB

| Parameter | Program Code |
|-----------|--------------|
| Hz | HZ |
| MHz | MZ |
| Sweep Off | W0 |

For additional HP-IB program codes, refer to Procedure above.

Indications

When the START FREQ or STOP FREQ key is pressed, the left display shows the currently programmed start or stop frequency. The instrument tunes to that frequency and continues measuring there. As a new start or stop frequency is entered, it appears in the left display. When the STEP SIZE key is pressed, the left display shows the step size only for as long as the key is held down. A newly entered value is displayed for as long as the ENTER key is held down.

When the AUTO or SINGLE key is pressed, the LED within the corresponding key lights to indicate that the instrument is in the sweep mode.

Comments

If the stop frequency is less than the start frequency, the instrument sweeps downward. The sweep is slower when it operates in this manner. However, calibration and plotting to an X/Y recorder must be performed in ascending frequency order only.

Pressing the AUTO key starts a sweep at the current frequency if the current frequency is not outside the start-stop range. If the current frequency is outside the start-stop range, the auto sweep starts at the programmed start frequency. To assure that an auto sweep starts at the programmed start frequency, press START FREQ, then AUTO.

Sweep (cont'd)

Comments (cont'd)

AUTO and SINGLE are toggle keys, and they stop the sweep when pressed a second time. However, program codes W1 and W2 do not toggle over the HP-IB. Use program code W0 to stop a sweep over the HP-IB.

Any front panel key except LOCAL, DECREASE, INCREASE, SPECIAL FUNCTION, NOISE FIGURE, and NOISE FIGURE AND .GAIN stop the sweep when pressed.

All HP-IB codes except DE (DECREASE Smoothing), IN (INCREASE Smoothing), M1 (UNCORRECTED NOISE FIGURE), M2 (CORRECTED NOISE FIGURE and GAIN) and PT (Pass Through Mode) stop the sweep when given.

START FREQ, STOP FREQ, and STEP SIZE set the calibration parameters. During calibration, the maximum number of frequency points allowed in a sweep is 181.

If the last step of a sweep causes the frequency to exceed the programmed stop frequency, the Noise Figure Meter tunes a partial step to reach the programmed stop frequency.

HP-IB code W2 (single sweep) should be the last code given before a single sweep is triggered.

Related Sections

Calibrate
Measurement Modes 1.0 through 1.9

System Interface Bus Control

(Special Functions 45 through 49)

Description

The Noise Figure Meter has two IEEE 488.1 connectors, the Hewlett-Packard Interface Bus (HP-IB) and System Interface Bus (SIB). The System Interface Bus is actually an HP-IB port that the Noise Figure Meter uses to control such instruments as the system local oscillator, a plotter and the Noise Figure Test Set. All instruments that the Noise Figure Meter can control are connected to the SIB connector. The external computer, used to control the Noise Figure Meter, is connected to the HP-IB connector. Also, connected to the HP-IB connector are any other instruments that the external computer needs to control, such as, the user controlled local oscillator or other HP-IB devices.

When an instrument is connected to the SIB, a special function is used to enable or disable the Noise Figure Meter from sending that instruments commands, on the SIB. Special Functions 45 through 47 are used to control the HP 8971B Noise Figure Test Set (Special Function 45), system local oscillator (Special Function 46) or the plotter (Special Function 47).

The Noise Figure Meter has the capability of sharing control responsibilities with another instrument on the System Interface Bus. Special Function 49 deals with passing control between controllers on the System Interface Bus and control of the System Interface Bus. The Noise Figure Meter can be configured to the following Special Function 49 conditions:

- Special Function 49.0; do not pass control automatically.
- Special Function 49.1; pass control automatically.
- Special Function 49.2; release control of the SIB.
- Special Function 49.3; take control of the SIB.
- Special Function 49.4; perform a serial poll on the SIB.
- Special Function 49.5; perform a selective device clear of the pass through device.
- Special Function 49.6; perform a device clear on the SIB, if the Noise Figure Meter is the active controller.
- Special Function 49.7; perform an interface clear on the SIB, if the Noise Figure Meter is the system controller.

The structure of the System Interface Bus requires that one and ONLY one instrument be the system controller on the SIB. As called out in the IEEE 488.1 specification, "The system controller is defined as the device that controls the REN and IFC lines on an IEEE 488.1 interface." Special Function 48 conveys to the Noise Figure Meter if it will be the system controller (Special Function 48.0) or if the Noise Figure Meter will not be the system controller (Special Function 48.1).

Finally, the Noise Figure Meter has the capability of allowing an external computer, on the Hewlett-Packard Interface Bus, to gain control of an instrument on the System Interface Bus. The mode used is called Pass Through Mode. Pass Through Mode is described in the Example section of this instruction.

System Interface Bus Control (cont'd)

(Special Functions 45 through 49)

Description (cont'd)

The following descriptions will give a better understanding of Special Functions 45 through 49:

a. Special Function 45.0 enables the commands for the Noise Figure Test Set to be sent on the SIB in Measurement Modes 1.5 through 1.9.

b. Special Function 45.1 enables the commands for the Noise Figure Test Set to be sent on the SIB in Measurement Modes 1.0 through 1.9. When Special Function 45.1 is active, the Noise Figure Test Set is set to bypass mode (SSB1) in Measurement Modes 1.0 through 1.4. This means that the measurement signal is passed straight through the Noise Figure Test Set, with only a 3 dB loss.

c. Special Function 45.2 disables the commands for the Noise Figure Test Set.

d. Special Function 46.0 enables the commands for the System Local Oscillator to be sent on the SIB in Measurement Modes 1.1 through 1.9.

e. Special Function 46.1 disables the commands for the System Local Oscillator in Measurement Modes 1.1 through 1.9.

f. Special Function 47.0 conveys to the Noise Figure Meter that the plotter is on the System Interface Bus. The use of Special Function 47.0 is described in the Data Output to Oscilloscopes, Recorders and Plotters Detailed Operating Instruction.

g. Special Function 47.1 conveys to the Noise Figure Meter that the plot data is to be read on the Hewlett-Packard Interface Bus (HP-IB). The use of Special Function 47.1 is described in the Data Output to Oscilloscopes, Recorders and Plotters Detailed Operating Instruction.

h. Special Function 48.0 enables the Noise Figure Meter to be the system controller on the System Interface Bus. Error forty-eight (E48) is generated if another controller has been enabled as controller on the System Interface Bus and Special Function 48 is active.

i. Special Function 48.1 conveys to the Noise Figure Meter that it is not the system controller on the System Interface Bus. This special function is useful if another controller is to share the System Interface Bus with the Noise Figure Meter.

j. Special Function 48.2 disables error forty-eight (E48). Error forty-eight occurs when the Noise Figure Meter has been told that it will be the controller on the System Interface Bus (Special Function 48.0) and the Noise Figure Meter detects another controller on the System Interface Bus. If this special function is to be used, ensure that the error condition does not exist. Check cabling carefully.

k. Special Function 49.0 disables auto-pass control. For instruments with auto-pass control capabilities, control is not automatically passed between the Noise Figure Meter and another controller.

l. Special Function 49.1 enables auto-pass control. For instruments with auto-pass control capabilities, control is automatically passed between the Noise Figure Meter and another controller.

System Interface Bus Control (cont'd)

(Special Functions 45 through 49)

Description (cont'd)

m. Special Function 49.2 tells the Noise Figure Meter to release active control of the System Interface Bus. This special function is useful if control of the System Interface Bus is to be shared. Special Function 49.2 should be used before another controller is told to take control.

n. Special Function 49.3 tells the Noise Figure Meter to take active control of the System Interface Bus. Special Function 49.3 is only useful if there are more than two controllers on the System Interface Bus and control of the System Interface Bus is to be shared. This special function should be used after all other controllers have been told to release control of the System Interface Bus.

o. Special Function 49.4 tells the Noise Figure Meter to do a serial poll on the System Interface Bus. The request is usually given by an external computer over the Hewlett-Packard Interface Bus, using the HP-IB code SB. For a serial poll program example, refer to the Comments section, at the end of this instruction.

p. Special Function 49.5 performs a selective device clear of the "pass through device" on the System Interface Bus. This task will be done before the next HP-IB read of the Noise Figure Meter can be done.

q. Special Function 49.6 performs a device clear on the System Interface Bus, if the Noise Figure Meter is the active controller. This task will be done before the next HP-IB read of the Noise Figure Meter can be done.

r. Special Function 49.7 performs an interface clear on the System Interface Bus, if the Noise Figure Meter is the system controller. All instruments on the System Interface Bus are unaddressed to listen or talk. This task will be done before the next HP-IB read of the Noise Figure Meter can be done.

Procedure

To select one of the System Interface Bus Control special functions, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.

| Special Function | | Program Code | Lights Special ¹ Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|---|------|--------------|--|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | HP-IB | | | | | | |
| Enable Noise Figure Test Set in Measurement Modes 1.5 through 1.9 | 45.0 | TE | N | Y | N | NC | NC | On |
| Enable Noise Figure Test Set in all Measurement Modes | 45.1 | TS | N | Y | N | NC | NC | Off |
| Disable Noise Figure Test Set in all Measurement Modes | 45.2 | TD | N | Y | N | NC | NC | Off |

¹Table categories are explained in the Special Functions Detailed Operating Instruction.

System Interface Bus Control (cont'd)

(Special Functions 45 through 49)

Procedure
(cont'd)

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Con- tinuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|---|------|------------------------------|---|----------------------------------|-------------------------------|------------------------------------|--|------------------------------------|
| Description | Code | | | | | | | |
| Enable System Local Oscillator on the System Interface Bus | 46.0 | LE | N | Y | N | NC | NC | On |
| Disable System Local Oscillator on the System Interface Bus | 46.1 | LD | N | Y | N | NC | NC | Off |
| Plotter is on the System Interface Bus | 47.0 | PI | N | Y | N | NC | NC | On |
| Enable plot data to be on the Hewlett-Packard Interface Bus | 47.1 | PM | N | Y | N | NC | NC | Off |
| Enable Noise Figure Meter to be the system controller on the System Interface Bus | 48.0 | SC | N | Y | N | NC | NC | On |
| Disable Noise Figure Meter as the system controller on the System Interface Bus | 48.1 | NC | N | Y | N | NC | NC | Off |
| Disable error 48 (E48) | 48.2 | DC | N | N | N | NC | Off | Off |
| Disable auto-pass control | 49.0 | DP | N | Y | N | NC | NC | On |
| Enable auto-pass control | 49.1 | EP | N | Y | N | NC | NC | Off |
| Noise Figure Meter releases active control of the System Interface Bus | 49.2 | CR | N | N | N | NC | NC | Off |
| Noise Figure Meter takes active control of the System Interface Bus | 49.3 | CT | N | N | N | NC | NC | Off |
| Noise Figure Meter performs a serial poll on the System Interface Bus | 49.4 | SB | N | N | N | NC | NC | Off |
| Perform a selective device clear of the pass through device on the System Interface Bus | 49.5 | DD | N | N | N | Off | Off | Off |

¹Table categories are explained in the Special Functions Detailed Operating Instruction.

System Interface Bus Control (cont'd)

(Special Functions 45 through 49)


Procedure (cont'd)

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|--|------|------------------------------|--|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| Perform a device clear on the System Interface Bus, if the Noise Figure Meter is the active controller | 49.6 | DS | N | N | N | Off | Off | Off |
| Perform an interface clear on the System Interface Bus, if the Noise Figure Meter is the system controller | 49.7 | IS | N | N | N | Off | Off | Off |

¹Table categories are explained in the Special Functions Detailed Operating Instruction.

Example

To select the Noise Figure Meter as the controller on the System Interface Bus:



The following examples will illustrate how the Noise Figure Meter can share control of the System Interface Bus (SIB) with another instrument on the SIB and how the Noise Figure Meter can be configured to pass commands from a computer on the Hewlett-Packard Interface Bus (HP-IB) to an instrument on the SIB.

Pass Through Mode

Pass Through Mode will allow commands to be “passed through” the Noise Figure Meter from an external computer, on the Hewlett-Packard Interface Bus (HP-IB), to an instrument on the System Interface Bus (SIB). The instrument on the SIB can be a listener or a talker. An SRQ (Service Request) on the SIB can trigger an SRQ on the HP-IB. Special Function 49.4 can be used to do a serial poll of an instrument on the SIB. Parallel poll will not be supported.

System Interface Bus Control (cont'd)

(Special Functions 45 through 49)

Example (cont'd)

NOTE

When in Pass Through Mode the rate at which data is sent or received is slowed down. Typically data is sent at a rate of 0.5 ms/byte and received at a rate of 1.6 ms/byte. This is five and eight times, respectively, slower than if the instrument were connected directly to the external computer.

Pass Through Mode is set up as follows:

a. When the external computer wants to communicate with an instrument on the SIB, it sends the command PTdEN; d is the address of the instrument, on the SIB, that the computer wants to communicate with. The Noise Figure Meter will also accept the command PTd (carriage return; line feed) to be compatible with the HP 8757A Scalar Network Analyzer.

NOTE

The command PTdEN does not have to be sent each time a command is sent to the instrument on the SIB. The instrument on the SIB needs only to be specified once.

b. The external computer can now send commands to the instrument on the SIB. After Pass Through Mode is set up using PTdEN, the Noise Figure Meter has two addresses, it's address and the pass through address. The pass through address is one greater than the Noise Figure Meter's address if it is even and one less than the Noise Figure Meter's address if it is odd. So, if the address of the Noise Figure Meter is eight (8) then the pass through address would be nine (9). If the address of the Noise Figure Meter is seven (7) then the pass through address would be six (6).

NOTE

The pass through address can be displayed by pressing 40.7 SPECIAL FUNCTION.

In Pass Through Mode two addresses are used up on the Hewlett-Packard Interface Bus (HP-IB). Ensure that an address is not used twice.

c. The external computer can send commands to a device on the SIB by using the Noise Figure Meter's pass through address. Commands can be sent to the Noise Figure Meter by using the Noise Figure Meter's HP-IB address.

For example, if the external computer wanted to control the local oscillator on the SIB (at address 19) and the Noise Figure Meter's address is eight (8), the external computer may send the following commands:

| | |
|-------------------------|---|
| OUTPUT 708; "PT19EN" ↵ | !This sets up the pass through !device address. |
| OUTPUT 709; "FR10000MZ" | !This command is sent to the !pass through address and then !to the local oscillator. |

System Interface Bus Control (cont'd)

(Special Functions 45 through 49)

Example (cont'd)

To get out of Pass Through Mode, simply, address the Noise Figure Meter or press the LOCAL key. Once the Noise Figure Meter is addressed, it is out of Pass Through Mode until the next time an output is done to the pass through address.

NOTE

Error 46 (E46) is generated if the instrument on the SIB is not found or the address of the instrument is incorrect.

If the Noise Figure Meter is addressed, all the instruments on the SIB are re-initialized to the state they were in before Pass Through Mode was enabled. To avoid the instruments from being re-initialized, Special Function 45.2 (disable Noise Figure Test Set) and Special Function 46.1 (disable local oscillator) can be used before Pass Through Mode is enabled (PTdEN). When finished with Pass Through Mode, the appropriate special functions for the Noise Figure Test Set and local oscillator should be enabled.

Passing Control On The System Interface Bus

The Noise Figure Meter has the capability of passing control to another instrument on the System Interface Bus. An external computer, on the Hewlett-Packard Interface Bus, determines which instrument will have control.

Instrument Configuration. The following minimum requirements are necessary for the Noise Figure Meter to be able to pass control on the System Interface Bus:

NOTE

The following steps must be done in the order given.

- a. Set the Noise Figure Meter's System Interface Bus address using Special Function 40.4. The default address of the System Interface Bus is eight (8).
- b. Set the address of the Noise Figure Meter using Special Function 40.0. The default address of the Noise Figure Meter is eight (8).
- c. Set the address of the other controller on the System Interface Bus.
- d. Decide if the Noise Figure Meter or the other instrument will be the system controller. If the other instrument can be enabled or disabled as system controller, either instrument can initially be system controller. If the other instrument can only be enabled as system controller, the other instrument will initially have to be the system controller and Special Function 48.1 (Noise Figure Meter is not the system controller on the System Interface Bus.) will have to be active.

NOTE

Error forty-eight (E48) is generated if the Noise Figure Meter detects another controller on the System Interface Bus and the Noise Figure Meter has been told it would be the controller.

System Interface Bus Control (cont'd)

(Special Functions 45 through 49)

Example (cont'd)

e. Special Function 48.0 will enable the Noise Figure Meter as system controller. Special Function 48.1 will disable the Noise Figure Meter as system controller. Use the appropriate commands to enable or disable the other controller.

NOTE

The Noise Figure Meter is set up to be the system controller when shipped from the factory, after memory (RAM) loss or when Special Function 0.9 is used.

f. Connect the Noise Figure Meter, external computer and the second instrument controller to the Hewlett-Packard Interface Bus (HP-IB).

g. Connect the Noise Figure Meter, second instrument controller, the local oscillator, plotter and any other instruments to be controlled to the System Interface Bus (SIB).

Computer Control. The following discussion will describe how the computer will pass control between the Noise Figure Meter and the other controller.

If the Noise Figure Meter has control of the System Interface Bus and the other controller needs to have control, the computer will send 49.2SP or the HP-IB code CR. This will convey to the Noise Figure Meter to release control of the System Interface Bus. The other controller will be told to take control, using the appropriate code for that instrument.

The other controller will now have control of the System Interface Bus and the Noise Figure Meter will display the message "Ctrl OFF."

When the Noise Figure Meter needs to be controller, the computer must tell the other controller to release control, using the appropriate code for that instrument. The Noise Figure Meter is then told to take control, using 49.3SP or the HP-IB code CT. Once the Noise Figure Meter is the controller, it will no longer display the message "Ctrl OFF."

Program Codes



Indications

For HP-IB codes, refer to the Procedure above.

As a special function code is entered it appears in the left display. The code remains there until the SPECIAL FUNCTION key is pressed.

When the Noise Figure Meter is not the System Interface Bus controller, "Ctrl" appears in the INSERTION GAIN display and "OFF" appears in the NOISE FIGURE display.

When the Noise Figure Meter is in Pass Through Mode, "PASS" appears in the INSERTION GAIN display and "thru" appears in the NOISE FIGURE display.

When the Noise Figure Meter is doing a plot, "Plot" appears in the INSERTION GAIN display.

System Interface Bus Control (cont'd)

(Special Functions 45 through 49)

Comments

The following program example shows how an external controller would request that the Noise Figure Meter perform a serial poll of a device on the System Interface Bus (SIB):

NOTE

The following example assumes that the address of the Noise Figure Meter is 708 and the address of the device on the SIB, to be polled, is 19.

This program was written in BASIC language 3.0 using the HP 9000 Series 200 Model 236 computer.

```

10 Spoll:                                !Serial poll of device on the Noise Figure
                                        !Meter System Interface Bus.
20 Addr=19                                !Address of device on SIB to be polled.
30 OUTPUT 708;"SB";Addr;"EN"            !Tell Noise Figure Meter
                                        !to poll device on SIB.
40 OUTPUT 708;"H1"                        !Output frequency, insertion
                                        !gain and noise figure windows.
50 OUTPUT 708;"SB"                        !Show serial poll return value.
60 Error=0                                !Clear subroutine error code.
70 Wait_poll:                             !Wait for the serial poll to finish.
80 ENTER 708;V,W2,W3                      !Get Noise Figure Meter frequency window.
90 !The value returned will be 2000 plus 19 until the
100 !poll is completed or it is aborted due to an error,
110 !such as, the device is not present or is off.
120 !
130 IF V≥2000 THEN GOTO Wait_poll         !Wait for the serial poll to be complete.
140 !
150 !At this point, the poll is complete or is in error.
160 !We find out which is the case in the next statement.
170 !If the value is 1000 plus 19, there has been an error,
180 !the device was not found or it was off. If the device
190 !was present and the serial poll worked, the value will
200 !be 0 through 255, for the serial poll value.
210 !
220 IF V≥1000 THEN                        !An error has occurred
230 Error=1                                !Indicate error to program
240 END IF
250 !
260 !The subroutine will return V=serial poll value
270 !and Error=0, if the serial poll is valid, or Error <> 0,
280 !if the serial poll failed.
290 !
300 IF Error <> 0 THEN
310 PRINT "SERIAL POLL FAILED"
320 ELSE
330 PRINT "SERIAL POLL VALUE = ";V
340 END IF
350 END

```

Related Sections

Measurement Modes 1.0 through 1.9

Temperature Units Selection (Special Function 11)

Description Temperature units are used when loss temperature, T_{hot} , or T_{cold} data is entered into the instrument. The instrument can accept temperature data entries in three different measurement units: Kelvins (K), Fahrenheit ($^{\circ}F$), or Celsius ($^{\circ}C$).

Procedure To select a temperature unit, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored In Con- tinuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|------------------|------|-----------------------|---|----------------------------------|-------------------------------|------------------------------------|--|------------------------------------|
| Description | Code | | | | | | | |
| K | 11.0 | D0 or 11.0SP | N | Y | Y | On | On | On |
| $^{\circ}C$ | 11.1 | D1 or 11.1SP | N | Y | Y | Off | Off | Off |
| $^{\circ}F$ | 11.2 | D2 or 11.2SP | N | Y | Y | Off | Off | Off |

¹Table categories are explained in the Special Functions Detailed Operating Instruction.

It is not necessary to select temperature units each time temperature data is entered. Once a temperature unit has been selected, all temperature data are entered and displayed in the same unit until that unit is changed (either by Special Function 0.9, PRESET, Special Function 0.0, or by another temperature unit selection).

After a temperature unit has been selected, one of the special functions listed below must be active before temperature data can be entered.


| Description | Special Function Code | Range of Values | | |
|-----------------------------|-----------------------|-----------------|------------------|-----------------|
| | | K | $^{\circ}C$ | $^{\circ}F$ |
| Enter and Use T_{hot} | 5.4 | 0 to 14824 | -273.2 to 14551 | -459.7 to 26224 |
| Enter T_{cold} | 6.0 | 0 to 9999 | -273.2 to 9725.9 | -459.7 to 17539 |
| Enter Temperature of Losses | 34.3 | 0 to 9999 | -273.2 to 9725.9 | -459.7 to 17539 |

Next, key in a value for temperature (within the specified range) and press the ENTER key. Up to five digits are allowed for temperature entries. If a minus sign is used, only four digits are allowed. The maximum resolution is to three places to the right of the decimal point.

Temperature Units Selection (cont'd)

(Special Function 11)

Example To enter a value of 75 °F for T_{cold} :



Program Codes For HP-IB codes, refer to Procedure above.



Indications When temperature data has been entered correctly, the selected unit appears in the left display.

Comments The equations used to convert from one temperature unit to another are:
 $K = °C + 273.15$
 $°F = (9/5)°C + 32$

Related Sections
 ENR Table Entry
 Loss Compensation
 Special Functions
 Spot ENR, T_{hot} , T_{cold} and ENR Table Selection

Trigger Selection

(Special Function 30)

Description Special Function 30.0 selects free run triggering for continuous measurements.

Special Function 30.1 selects trigger hold to prevent continuous measurements. When trigger hold is active, the frequency and results of the last measurement are held and displayed. No additional measurements are made and the displayed data can be read over the HP-IB as many times as required. Trigger hold is useful when the measurement setup must be reconfigured before making the next measurement.

Special Function 30.2 triggers one measurement and then returns to the previously selected trigger mode. Normally, this trigger execute command is used in conjunction with the trigger hold mode. Once the measurement is complete, the results are displayed and are available via the HP-IB. The measurement results are also output to an oscilloscope or recorder if one is connected to the rear panel X, Y and Z connectors. If a smoothing factor other than one has been selected, the Noise Figure Meter makes the number of measurements required by the selected smoothing factor before the smoothed measurement is displayed or available via the HP-IB.

Procedure To select a specific triggering mode, key in the corresponding Special Function code and then press the SPECIAL FUNCTION key.

| Special Function | | Program Code HP-IB | Lights Special ¹ Function Key | Stored in Continuous Memory | Can be Stored and Recalled | Special Function 0.0 Conditions | Preset (and HP-IB Clear) Conditions | Special Function 0.9 Conditions |
|------------------|------|-----------------------|--|-----------------------------|----------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Description | Code | | | | | | | |
| Free Run | 30.0 | T0 or 30.0SP | N | N | N | On | On | On |
| Hold | 30.1 | T1 or 30.1 SP | N | N | N | Off | Off | Off |
| Execute | 30.2 | T2 or 30.2SP | N | N | N | Off | Off | Off |

¹ Table categories are explained in the Special Functions Detailed Operating Instruction.

Example To select trigger hold and then execute a single measurement and return to trigger hold:

| | | | | | | |
|--------------------------|--------------------------------|--------------------------------|--------------------------------|--------------------------------|----------------------------------|------------------|
| LOCAL (keystrokes) | Code | | | | Function | |
| | <input type="text" value="3"/> | <input type="text" value="0"/> | <input type="text" value="."/> | <input type="text" value="1"/> | <input checked="" type="radio"/> | SPECIAL FUNCTION |
| | <input type="text" value="3"/> | <input type="text" value="0"/> | <input type="text" value="."/> | <input type="text" value="2"/> | <input checked="" type="radio"/> | SPECIAL FUNCTION |
| HP-IB (program codes) | T1T2 | | | | | |

Trigger Selection (cont'd)

(Special Function 30)

Program Codes**HP-IB**

For HP-IB codes, refer to Procedure.

Indications

When Special Function 30.0 is active, the front panel displays update continuously. When Special Function 30.1 is active, the front panel displays do not change. When Special Function 30.2 is active, the Noise Figure Meter makes one measurement and then returns to the last selected trigger mode.

Comments

When performing a triggered calibration, only the HP-IB mnemonic code T2 can be used. The Noise Figure Meter does not respond to the alternate 30.2SP code.

Related Sections

Calibrate
Measurement Modes 1.0 through 1.9
Smoothing
Special Functions

SECTION IV PERFORMANCE TESTS

4-1. INTRODUCTION

The procedures in this section test the HP 8970B's electrical performance using the specifications of Table 1-1 as the performance standards. All tests can be performed without access to the interior of the instrument.

These tests, in conjunction with the performance tests of the HP 8971B Noise Figure Test Set, System Local Oscillator and Noise Source, verify the performance of the HP 8970S Noise Figure Measurement System.

NOTES

Unless otherwise noted, no warm-up period is required for the tests.

Line voltage must be within +5% and -10% of nominal, if the performance tests are to be considered valid.

4-2. EQUIPMENT REQUIRED

Equipment required for the performance tests is listed in Table 1-5, Recommended Test Equipment

in Section I. Any equipment that satisfies the critical specifications given in the table may be substituted for the recommended model(s).

4-3. TEST RECORD

Results of the performance tests may be tabulated on the Test Record at the end of the procedures. The Test Record lists all of the tested specifications and their acceptable limits. The results, recorded at incoming inspection, can be used for comparison in periodic maintenance and troubleshooting and after repairs or adjustments.

System performance is guaranteed if each instrument in the system is calibrated.

4-4. CALIBRATION CYCLE

This instrument requires periodic verification of performance. Depending on the use and environmental conditions, the instrument should be checked using the following performance tests at least once every year.

The instruments that are part of the HP 8970S Noise Figure Measurement System should be calibrated once a year.

PERFORMANCE TESTS

4-5. TUNING ACCURACY PERFORMANCE TEST

Specification TUNING ACCURACY: (from 10° to 40°C) $\pm(1 \text{ MHz} + 1\% \text{ of frequency})$, $\pm 6 \text{ MHz}$ maximum.

Description The Noise Figure Meter is tuned to the frequency where accuracy is to be tested. The point of maximum IF signal level is found by stepping the signal source through the passband while monitoring the level at the internal noise power detector. A power reference is set, and the 3-dB passband frequencies are determined. The tuned center frequency of the Noise Figure Meter is then found as the average of the 3-dB frequencies. This tuned frequency is compared to limits derived from the specifications above.

Equipment: Signal Generator HP 8340B

- Procedure**
1. Connect the signal generator RF output to the Noise Figure Meter INPUT.
 2. Turn on the equipment and allow it to warm up for one half hour. Set the signal generator output level to -30 dBm .
 3. On the Noise Figure Meter, key in 31.2 SPECIAL FUNCTION to execute a frequency calibration, then key in 31.1 SPECIAL FUNCTION to inhibit any further frequency calibrations. Key in 10.2 SPECIAL FUNCTION to set the display units to read Y-Factor in dB.
 4. Tune both the Noise Figure Meter and the signal generator to 10 MHz.
 5. On the Noise Figure Meter, key in 80.0 SPECIAL FUNCTION to display the noise power detector output in volts. Key in 62.0 SPECIAL FUNCTION to hold the RF attenuators. Key in 72.0 SPECIAL FUNCTION to hold the IF attenuators.
 6. Tune the signal generator up and down in 100 kHz steps until the maximum voltage display on the Noise Figure Meter is located. The 3-dB point should be within approximately 4 MHz of center frequency.
 7. On the Noise Figure Meter, key in 14.1 SPECIAL FUNCTION to activate the manual measurement mode and make a cold measurement. Key in 14.2 SPECIAL FUNCTION to exit the cold measurement mode (and store that value) and to make hot measurements. Finally, key in 15.1 SPECIAL FUNCTION to set the Noise Figure Meter to actively display the ratio of hot to cold values. The NOISE FIGURE display should now indicate 0.00 dB.
 8. Tune the signal generator up and down to find the 3-dB frequencies to within 100 kHz. Find the center frequency by summing the 3-dB frequencies and dividing by two. The center frequency should be within the limits in the table in step 9.

PERFORMANCE TESTS

TUNING ACCURACY PERFORMANCE TEST (cont'd)

Procedure (cont'd)

9. Repeat steps 5 through 8 for each of the frequencies in the table below.

| Nominal Tuned Frequency (MHz) | Lower 3-dB Frequency (MHz) | Upper 3-dB Frequency (MHz) | Center Frequency (MHz) | | |
|-------------------------------|----------------------------|----------------------------|------------------------|--------|------|
| | | | Min. | Actual | Max. |
| 10 | _____ | _____ | 8.9 | _____ | 11.1 |
| 100 | _____ | _____ | 98 | _____ | 102 |
| 300 | _____ | _____ | 296 | _____ | 304 |
| 500 | _____ | _____ | 494 | _____ | 506 |
| 1000 | _____ | _____ | 994 | _____ | 1006 |
| 1300 | _____ | _____ | 1294 | _____ | 1306 |
| 1600 | _____ | _____ | 1594 | _____ | 1606 |

PERFORMANCE TESTS

4-6. INPUT SWR PERFORMANCE TEST

Specification INPUT SWR (reflection coefficient): <1.7 (0.26); 50 ohms reference impedance.

Description The frequency range of the Noise Figure Meter is scanned for frequencies where the return loss is near specification limits. Then, each high point is checked individually against the specification. This is done for several input gain settings.

Equipment

| | |
|-------------------------|---------------------|
| Attenuator, 10 dB | HP 8491A Option 010 |
| Power Meter | HP 436A |
| Power Sensor | HP 8484A |
| Signal Generator | HP 8340B |
| SWR Bridge | Wiltron 60N50 |




Figure 4-1. Input SWR Test Setup

Procedure

1. Connect equipment as shown in Figure 4-1. Note that the power sensor is connected to the test port of the SWR bridge.
2. Set the Signal Generator for a 10 MHz continuous wave output. Set the Signal Generator power level to -23 dBm at the test port of the SWR bridge as read on the power meter. Signal Generator power should be approximately -6 dBm.
3. On the Noise Figure Meter, key in 0.0 SPECIAL FUNCTION to initialize most Special Functions and 60.1 SPECIAL FUNCTION to set the input gain to $+20$ dB.
4. Tune the Signal Generator to 1600 MHz. Connect the power sensor to the reflected output port of the SWR bridge. Set a relative reference on the power meter.
5. Connect the test port of the SWR bridge to the Noise Figure Meter INPUT. Slowly tune the Signal Generator in 10 MHz steps down in frequency to 10 MHz. While tuning, note each frequency at which the power meter reading peaks at less than 12.5 dB below the 0 dB reference set in step 4. For example, if the power meter display showed -11.0 dB, then the frequency should be noted. However, a reading of -13.0 dB indicates a return loss well within specifications.
6. For each frequency noted in step 5, tune the Signal Generator and the Noise Figure Meter to that frequency. Disconnect the SWR bridge from the Noise Figure Meter INPUT, and set a power meter reference. Reconnect the SWR bridge to the Noise Figure Meter INPUT. The power meter should read greater than 11.73 dB below the reference.

PERFORMANCE TESTS

INPUT SWR PERFORMANCE TEST (cont'd)

**Procedure
(cont'd)**

| INPUT SWR PERFORMANCE TEST | Min. | Actual | Max. |
|----------------------------|------|--------|-----------|
| +20 dB Input Gain Setting | | | |
| Frequency | | | |
| _____ MHz | | _____ | -11.73 dB |
| _____ MHz | | _____ | -11.73 dB |
| _____ MHz | | _____ | -11.73 dB |
| +10 dB Input Gain Setting | | | |
| Frequency | | | |
| _____ MHz | | _____ | -11.73 dB |
| _____ MHz | | _____ | -11.73 dB |
| _____ MHz | | _____ | -11.73 dB |
| 0 dB Input Gain Setting | | | |
| Frequency | | | |
| _____ MHz | | _____ | -11.73 dB |
| _____ MHz | | _____ | -11.73 dB |
| _____ MHz | | _____ | -11.73 dB |

7. On the Noise Figure Meter, key in 60.2 SPECIAL FUNCTION to set the input gain to +10 dB. Repeat steps 4 through 6.
8. On the Noise Figure Meter, key in 60.3 SPECIAL FUNCTION to set the input gain to 0 dB. Repeat steps 4 through 6.

PERFORMANCE TESTS

4-7. NOISE FIGURE RANGE AND ACCURACY PERFORMANCE TEST

Specification NOISE FIGURE MEASUREMENT CHARACTERISTICS Range: 0.0 to 30 dB. Instrumentation Uncertainty: ± 0.1 dB for a noise source in a 0 to 55°C in a 300K environment with a noise source ENR of 14 to 16 dB.

Description Level ratios of -0.1 dB, -1 dB, -5 dB, -10 dB, -15 dB, and -20 dB are generated. The levels are measured on the power meter, and linear power ratios are computed. The levels are simultaneously measured on the Noise Figure Meter, and linear voltage ratios are computed. The voltage ratios are squared and then subtracted from the linear power ratios to compute the Y-Factor error. This error is compared to accuracy limits derived from the 0.1 dB noise figure accuracy specification. (A 15 dB ENR value is assumed.) The reading at -20 dB and the reading at -5 dB are used to compute a second 15 dB ratio. This ratio is also checked for accuracy.

NOTES

This test is difficult to perform. Passing the test requires minimum drift in both the measurement equipment and the Noise Figure Meter. The more rapidly the test is performed, the more closely the test results will indicate the actual performance of the instrument. If the instrument fails by a narrow margin, performing the test more quickly will probably allow the instrument to pass.

Since the Noise Figure Meter is highly sensitive to RF signals at its input, spurious transmissions or noise can adversely affect performance test results. Use short well shielded cables and a minimum of adapters when performing this test.

| | | |
|------------------|-----------------------------|-------------------|
| Equipment | Attenuator, 6 dB | HP 8491A Opt. 006 |
| | Attenuator, 1 dB Step. | HP 8494A Opt. 001 |
| | Calculator | HP 41C |
| | Digital Voltmeter | HP 3456A |
| | Filter, Low-Pass | HP 360B |
| | Power Meter | HP 436A |
| | Power Sensor | HP 8484A |
| | Power Splitter | HP 11667A |
| | Signal Generator | HP 8340B |

Procedure

1. Connect equipment as shown in Figure 4-2, except do not connect the power sensor to the step attenuator.
2. Turn on all equipment and allow it to warm up for one hour.
3. Set the signal generator for a 50 MHz continuous wave output at -17 dBm.
4. On the Noise Figure Meter, set FREQUENCY to 50 MHz. Key in 80.0 SPECIAL FUNCTION to display the noise power detector output in volts (voltmeter mode). Key in 31.1 SPECIAL FUNCTION to inhibit frequency calibrations. Key in 60.5 SPECIAL FUNCTION to set the input gain to -20 dB. Key in 70.6 SPECIAL FUNCTION to set the IF attenuation to -25 dB. Set the smoothing factor to 4 using the INCREASE and DECREASE keys.
5. Zero the power meter and set the 1 dB step attenuator to 10 dB. Connect the power sensor to the 1 dB step attenuator as shown in Figure 4-2.

PERFORMANCE TESTS

NOISE FIGURE RANGE AND ACCURACY PERFORMANCE TEST (cont'd)

Procedure (cont'd)




Figure 4-2. Noise Figure Instrumentation Accuracy Test Setup

6. Peak the Noise Figure Meter display reading by tuning the signal generator up and down in frequency in 10 kHz increments.
7. Increase the signal generator power in 0.1 dB steps until the combined INSERTION GAIN and NOISE FIGURE displays on the Noise Figure Meter indicate as close as possible to 1.00000 volts. The signal generator power should be near -14.7 dBm. Note this power level as indicated on the signal generator.
 _____ dBm
8. Set the step attenuator for a power meter reading as close as possible to 1.000 μW.
9. Set the digital voltmeter to read dc volts on the high resolution setting. Using the manual trigger control, trigger several readings then stop on a typical reading. Note this reading using full resolution.
 _____ Vdc
10. Note the voltmeter mode reading on the Noise Figure Meter also using full resolution.
 _____ Vdc
11. Decrease the signal generator power by 0.1 dB.
12. Using the same technique as in step 9, take a voltmeter reading.
 _____ Vdc
13. Note the new voltmeter mode reading on the Noise Figure Meter.
 _____ Vdc
14. Decrease the signal generator output power to 1 dB below that set in step 7.

PERFORMANCE TESTS

NOISE FIGURE RANGE AND ACCURACY PERFORMANCE TEST (cont'd)

- Procedure (cont'd)**
15. Using the same technique as in step 9, take a voltmeter reading. _____ Vdc
 16. Note the new voltmeter mode reading on the Noise Figure Meter. _____ Vdc
 17. Decrease the signal generator output power to 5 dB below that set in step 7.
 18. Using the same technique as in step 9, take a voltmeter reading. _____ Vdc
 19. Note the new voltmeter mode reading on the Noise Figure Meter. _____ Vdc
 20. Decrease the signal generator output power to 10 dB below that set in step 7.
 21. Using the same technique as in step 9, take a voltmeter reading. (Note that the power meter may change ranges for this reading. If it does, the voltmeter reading taken must be decreased by a factor of 10.) _____ Vdc
 22. Note the new voltmeter mode reading on the Noise Figure Meter. _____ Vdc
 23. Decrease the signal generator output power to 15 dB below that set in step 7.
 24. Using the same technique as in step 9, take a voltmeter reading. (Remember to decrease this reading by a factor of 10.) _____ Vdc
 25. Note the new voltmeter mode reading on the Noise Figure Meter. _____ Vdc
 26. Decrease the signal generator output power to 20 dB below that set in step 7.
 27. Using the same technique as in step 9, take a voltmeter reading. (Note that the power meter may change ranges again. If so this voltmeter reading must be decreased by a factor of 100.) _____ Vdc
 28. Note the new voltmeter mode reading on the Noise Figure Meter. _____ Vdc
-

PERFORMANCE TESTS

NOISE FIGURE RANGE AND ACCURACY PERFORMANCE TEST (cont'd)

Procedure (cont'd)

29. Fill in the table below using the readings from the appropriate steps above. For the column on the far right, square the readings in the previous column.

| Voltmeter Readings (Vdc) | | Noise Figure Meter Readings | | |
|--------------------------|-------|-----------------------------|-------|--------------------|
| | | | Vdc | (Vdc) ² |
| Step 9 | _____ | Step 10 | _____ | _____ |
| Step 12 | _____ | Step 13 | _____ | _____ |
| Step 15 | _____ | Step 16 | _____ | _____ |
| Step 18 | _____ | Step 19 | _____ | _____ |
| Step 21 | _____ | Step 22 | _____ | _____ |
| Step 24 | _____ | Step 25 | _____ | _____ |
| Step 27 | _____ | Step 28 | _____ | _____ |

30. Fill in the table below by computing the indicated ratios (Y-Factors). The ratios of the second set of columns should be computed from the squared voltages from the previous table. Subtract the ratios of the second set of columns from those of the first set to yield the net error (difference). The result should be within the indicated limits.

| Ratios (Y-Factors) | | | | Difference | | |
|--------------------|-------|-----------|-------|------------|--------|----------|
| | | | | Min. | Actual | Max. |
| (Step 9) | | (Step 10) | | | | |
| _____ | | _____ | | | | |
| (Step 12) | _____ | (Step 13) | _____ | -0.00053 | _____ | +0.00054 |
| (Step 9) | | (Step 10) | | | | |
| _____ | | _____ | | | | |
| (Step 15) | _____ | (Step 16) | _____ | -0.00589 | _____ | +0.00603 |
| (Step 9) | | (Step 10) | | | | |
| _____ | | _____ | | | | |
| (Step 18) | _____ | (Step 19) | _____ | -0.04922 | _____ | +0.05037 |
| (Step 9) | | (Step 10) | | | | |
| _____ | | _____ | | | | |
| (Step 21) | _____ | (Step 22) | _____ | -0.20487 | _____ | +0.20964 |
| (Step 9) | | (Step 10) | | | | |
| _____ | | _____ | | | | |
| (Step 24) | _____ | (Step 25) | _____ | -0.69706 | _____ | +0.71330 |
| (Step 9) | | (Step 10) | | | | |
| _____ | | _____ | | | | |
| (Step 18) | | (Step 19) | | | | |
| _____ | | _____ | | | | |
| (Step 27) | _____ | (Step 28) | _____ | -0.69706 | _____ | +0.71330 |

PERFORMANCE TESTS

4-8. GAIN MEASUREMENT UNCERTAINTY PERFORMANCE TEST

Specification **GAIN MEASUREMENT CHARACTERISTICS** Range: -20 to > +40 dB. Instrumentation Uncertainty: ± 0.15 dB.

Description The Noise Figure Meter uses internal IF attenuator values for measuring gain. Prior to performing the Gain Measurement Uncertainty Performance Test, the IF attenuators are calibrated to ensure valid gain measurements.

For the IF attenuator calibration the IF attenuators are measured by taking a reference power reading, switching in an attenuator and then taking another power measurement. The relative power change is equal to the IF attenuator value. The power change is calculated using a voltmeter to measure the change in voltage from the Recorder Output of the power meter.

The attenuator values are computed as the ratio of measured voltages (linear units) rather than in decibels (logarithmic units). The linear value of the 15 dB attenuator is calculated by multiplying the linear value for the 10 dB attenuator and the linear value for the 5 dB power change observed when the attenuators change from 10 to 15 dB. The 25 dB attenuator is calculated in the same way, using the 20 dB instead of the 10 dB attenuator value. The calibrated IF attenuator values are recorded in Table 4-1 and entered into the Noise Figure Meter.

For the Gain Measurement Uncertainty Performance Test, net gain is generated by removing attenuation from a high gain setup. The net gain is alternately measured first by a power meter and then by the Noise Figure Meter. The two measurements should compare to within 0.15 dB.

NOTES

This test is difficult to perform. Passing the test requires minimum drift in both the measurement equipment and the Noise Figure Meter. The more rapidly the test is performed, the more closely the test results will indicate the actual performance of the instrument. If the instrument fails by a narrow margin, performing the test more quickly will probably allow the instrument to pass.

Since the Noise Figure Meter is highly sensitive to RF signals at its input, spurious transmissions or noise can adversely affect performance test results. Use short well shielded cables and a minimum of adapters when performing this test.

| | | |
|------------------|--------------------------------------|-------------------|
| Equipment | Attenuator, 10 dB (2 required) | HP 8491A Opt. 010 |
| | Attenuator, 20 dB | HP 8491A Opt. 020 |
| | Attenuator, 1 dB Step | HP 8494A Opt. 001 |
| | Attenuator, 10 dB Step | HP 8495A Opt. 001 |
| | Filter, Low-Pass. | HP 360B |
| | Noise Source | HP 346B Opt. 001 |
| | Power Meter | HP 436A |
| | Power Sensor | HP 8484A |
| | Power Splitter | HP 11667A |
| | Wideband Amplifier I | HP 8447D Opt. 010 |
| | Wideband Amplifier II | HP 8447F Opt. 010 |
| | Digital Voltmeter | HP 3456A |

PERFORMANCE TESTS

GAIN MEASUREMENT UNCERTAINTY PERFORMANCE TEST (cont'd)

Procedure

IF Attenuator Calibration

1. Connect the noise source to the Noise Figure Meter's NOISE SOURCE DRIVE OUTPUT.
2. Turn on all equipment and allow it to warm up for a half hour.
3. Zero and calibrate the power meter and sensor.
4. Set the 10 dB step attenuator to 70 dB and connect the equipment as shown in Figure 4-3.




Figure 4-3. IF Attenuator Calibration Setup

5. On the Noise Figure Meter press
 - 70.1 SPECIAL FUNCTION to set the IF attenuators to 0 dB
 - 60.1 SPECIAL FUNCTION to set the RF attenuators to +20 dB.
6. Put the power meter in range 3. Do not allow the power meter to autorange. (For the HP 436A Power Meter, adjust the 10 dB and the 1 dB step attenuators until the power meter reads -45 dBm. Press RANGE HOLD to set the power meter to RANGE 3.)
7. Adjust the step attenuators for a voltmeter reading as close to 1 volt as possible. On the voltmeter, select single triggering. If the voltmeter has filtering, turn it on. Take 10 voltmeter readings. Using at least four digits to the right of the decimal point, calculate the average of the readings.

(On the HP 3456A Digital Voltmeter, press FILTER on to enable the analog filter, 10 STORE 6 to store 10 readings per trigger, SINGLE to select the single trigger mode, MATH 2 to turn on the statistical math mode and SINGLE to trigger 10 voltmeter readings. When the voltmeter has finished taking the 10 readings, press RECALL 0 to recall the average of the readings.)

PERFORMANCE TESTS

GAIN MEASUREMENT UNCERTAINTY PERFORMANCE TEST (cont'd)

Procedure (cont'd) Record the average of the voltmeter readings. This is the reference voltage for the 5 dB and 10 dB attenuator calculations.

_____ Vref1

NOTE

When using the HP 3456A Digital Voltmeter's statistical math mode to calculate an average, be sure to clear the math register before triggering the set of readings to be averaged. Press MATH 0 to clear the register and then MATH 2 to enable math mode.

8. On the Noise Figure Meter press 70.2 SPECIAL FUNCTION to switch in the internal 5 dB attenuator. Take 10 voltmeter readings. Using at least four digits to the right of the decimal point, calculate the average of the voltmeter readings.

(On the HP 3456A Digital Voltmeter, press MATH 0 to clear the math registers by turning math mode off, MATH 2 to enable the statistical math mode and SINGLE to trigger 10 voltmeter readings. When the voltmeter has finished taking the 10 readings, press RECALL 0 to recall the average of the readings.)

Record the average of the voltmeter readings.

_____ Vavg (5 dB)

NOTE

The limits for each attenuator are shown in linear units, that is, as the ratio of measured voltages. If an attenuator is outside its limits, it may be defective. Refer to Section VIII in the Service Manual for troubleshooting information.

9. Compute the 5 dB attenuator value as shown:

$$V_{\text{ref1}}/V_{\text{avg}} (5 \text{ dB}) = \text{_____} (>2.661; <3.758 \text{ for } 5 \text{ dB attenuator})$$

(For example, $V_{\text{ref1}} = 0.986622$ volts and $V_{\text{avg}} (5 \text{ dB}) = 0.312579$ volts. $0.986622 \text{ volts}/0.312579 \text{ volts} = 3.15639$. This value is within the stated limits.)

10. On the Noise Figure Meter press 70.3 SPECIAL FUNCTION to switch in the internal 10 dB attenuator. Take 10 voltmeter readings. Using at least four digits to the right of the decimal point, calculate and record the average of the readings.

_____ Vavg (10 dB)

11. Compute the 10 dB attenuator value as shown:

$$V_{\text{ref1}}/V_{\text{avg}} (10 \text{ dB}) = \text{_____} (>8.414; <11.885 \text{ for } 10 \text{ dB attenuator})$$

12. On the voltmeter, select internal triggering. If the voltmeter has filtering, turn it off. Reduce the 10 dB step attenuator by 10 dB, and adjust the 1 dB step attenuator until the voltmeter reads as close to 1 volt as possible. Select single triggering on the voltmeter. If the voltmeter has filtering, turn it on. Take 10 voltmeter readings.
-

PERFORMANCE TESTS

GAIN MEASUREMENT UNCERTAINTY PERFORMANCE TEST (cont'd)**Procedure
(cont'd)**

Using at least four digits to the right of the decimal point, calculate and record the average of the readings. This is the reference voltage for the 15 dB and 20 dB attenuator calculations.

_____ Vref2

13. On the Noise Figure Meter press 70.4 SPECIAL FUNCTION to switch in the internal 15 dB attenuator. Take 10 voltmeter readings. Then, calculate and record the average of those readings.

_____ Vavg (15 dB)

14. Compute the 15 dB attenuator value as shown:

(Result from step 11) * Vref2/Vavg (15 dB) = _____ (>26.607; <37.584 for 15 dB attenuator)

15. On the Noise Figure Meter press 70.5 SPECIAL FUNCTION to switch in the internal 20 dB attenuator. Take 10 voltmeter readings. Then, calculate and record the average of the readings.

_____ Vavg (20 dB)

16. Compute the 20 dB attenuator value as shown:

(Result from step 11) * Vref2/Vavg (20 dB) = _____ (>84.140; <118.850 for 20 dB attenuator)

17. On the voltmeter, select internal triggering. If the voltmeter has filtering, turn it off. Reduce the 10 dB step attenuator by 10 dB and adjust the 1 dB step attenuator until the voltmeter reads as close to 1 volt as possible. On the voltmeter, select single triggering. If the voltmeter has filtering, turn it on. Take 10 voltmeter readings. Using at least four digits to the right of the decimal point, calculate and record the average of the readings. This is a reference voltage used in the 25 dB and 30 dB attenuator calculations.

_____ Vref3

18. On the Noise Figure Meter press 70.6 SPECIAL FUNCTION to switch in the internal 25 dB attenuator. Take 10 voltmeter readings. Then, calculate and record the average of the readings.

_____ Vavg (25 dB)

19. Compute the 25 dB attenuator value as shown:

(Result from step 16) * Vref3/Vavg (25 dB) = _____ (>266.07; <376.84 for 25 dB attenuator)

20. On the Noise Figure Meter press 70.7 SPECIAL FUNCTION to switch in the internal 30 dB attenuator. Take 10 voltmeter readings. Then, calculate and record the average of the readings.

_____ Vavg (30 dB)

21. Compute the 30 dB attenuator value as shown:

(Result from step 16) * Vref3/Vavg (30 dB) = _____ (>841.4; <1188.5 for 30 dB attenuator)

PERFORMANCE TESTS

GAIN MEASUREMENT UNCERTAINTY PERFORMANCE TEST (cont'd)**Procedure
(cont'd)**

22. On the voltmeter, select internal triggering. If the voltmeter has filtering, turn it off. Reduce the 10 dB step attenuator by 10 dB and adjust the 1 dB step attenuator until the voltmeter reads as close to 1 volt as possible. On the voltmeter, select single triggering. If the voltmeter has filtering, turn it on. Take 10 voltmeter readings. Using at least four digits to the right of the decimal point, calculate and record the average of the readings. This is the reference voltage for the 35 dB attenuator calculation.
- _____ Vref4
23. On the Noise Figure Meter press 70.8 SPECIAL FUNCTION to switch in the internal 35 dB attenuator. Take 10 voltmeter readings, and then calculate the average of those readings. Record the average.
- _____ Vavg (35 dB)
24. Compute the 35 dB attenuator value as shown:
(Result from step 21) * Vref4/Vavg (35 dB) = _____ (>2660.7; <3758.4 for 35 dB attenuator)
25. Enter the measured attenuator values in Table 4-1.

Table 4-1. IF Attenuator Values

| Date: _____ | | |
|---------------|--------------|----------------|
| Nominal Value | | Measured Value |
| Log Units | Linear Units | Linear Units |
| 5 dB | 3.162 | <u>3.180</u> |
| 10 dB | 10.000 | <u>10.046</u> |
| 15 dB | 31.623 | <u>31.983</u> |
| 20 dB | 100.000 | <u>101.99</u> |
| 25 dB | 316.23 | <u>324.41</u> |
| 30 dB | 1000.0 | <u>1024.9</u> |
| 35 dB | 3162.3 | <u>3142.7</u> |

Entering IF Attenuator Values

26. Enter the measured attenuator values recorded in Table 4-1 into the Noise Figure Meter:

NOTE

It is not necessary to perform steps 26a through h if you only want to read the IF attenuator values and record them in Table 4-1.

PERFORMANCE TESTS

GAIN MEASUREMENT UNCERTAINTY PERFORMANCE TEST (cont'd)**Procedure
(cont'd)**

- a. Key in 93.1 SPECIAL FUNCTION. (This enables you to enter a RAM address.)
 - b. Key in 65452 and then press ENTER. (This is the RAM location where you will find the address of the memory protection word. The memory protection word must be modified before you can change the IF attenuator values stored in RAM.)
 - c. Key in 93.3 SPECIAL FUNCTION. (This displays the address of the memory protection word.)
 - d. Record the address of the memory protection word, which is shown in the left display of the Noise Figure Meter. 1176
 - e. Key in 93.1 SPECIAL FUNCTION.
 - f. Key in the memory protection word address recorded in step d and then press ENTER.
 - g. Key in 93.3 SPECIAL FUNCTION.
 - h. Key in 20299 and then press ENTER. (The value 20299 disables the memory protection and allows you to change the IF attenuator values. Turning the instrument off and then on turns memory protection back on.)
 - i. Key in 93.1 SPECIAL FUNCTION.
 - j. Key in 65460 and then press ENTER. (This is the RAM location where you will find the start address of the IF attenuator calibration table.)
 - k. Key in 93.3 SPECIAL FUNCTION. (This displays the start address of the IF attenuator calibration table.) 6992
 - l. Add 1 to the least significant digit shown in the left display of the Noise Figure Meter and record the value. 6993 (Address of the first attenuator data in calibration table.)
 - m. Key in 93.0 SPECIAL FUNCTION. (This enables you to enter the RAM address of the first attenuator data in the calibration table. It also automatically increments the address after pressing ENTER so that you can step through the calibration table.)
 - n. Enter the number from step l and press ENTER. 6993
 - o. Key in 93.4 SPECIAL FUNCTION. (This enables you to read and/or modify the 5 dB attenuator value in RAM.) 3,180
 - p. The number shown in the left display is the 5 dB attenuator value (in linear units). Key in the new 5 dB attenuator value and press ENTER. (To leave the value shown in the left display unchanged, press ENTER without keying in a new value.)
-

PERFORMANCE TESTS

GAIN MEASUREMENT UNCERTAINTY PERFORMANCE TEST (cont'd)

Procedure (cont'd)

- q. Press 93.4 SPECIAL FUNCTION to view the next attenuator value. Enter the new value and press ENTER. *12, 0%*
- r. Repeat step q for each subsequent attenuator value until all values have been entered.
- s. Press FREQUENCY to return to normal operation.

NOTE

Error code E26 (internal IF attenuators not calibrated) will occur after E80 (continuous memory failure). To clear E26, first enter the IF attenuator values by following the procedure in step 26. Then, perform the following:

1. Key in 93.0 SPECIAL FUNCTION.
2. Subtract 1 from the value recorded in step 26l. Enter this value into the Noise Figure Meter and then press ENTER.
3. Key in 93.2 SPECIAL FUNCTION. Then, key in 128 and press ENTER.
4. Press FREQUENCY to return to normal operation.

Gain Measurement Uncertainty Performance Test

27. On the Noise Figure Meter, press PRESET.

NOTE

This procedure relies critically upon the proper setup of the power meter. If readings yield results that are out of specification, check that the calibration adjustment and zero setting of the power meter are valid. Always disconnect the power sensor from the test setup when zeroing.

28. Connect the equipment as shown in Figure 4-4.




Figure 4-4. Gain Measurement Uncertainty Test Setup

PERFORMANCE TESTS

GAIN MEASUREMENT UNCERTAINTY PERFORMANCE TEST (cont'd)**Procedure
(cont'd)**

29. On the Noise Figure Meter, press the ENR key to access the working ENR table with in the Noise Figure Meter. Using the DATA keys and the ENTER key, modify the 10, 100, 1000 and 2000 MHz ENR entries to correspond to the noise source ENR chart. Exit the ENR table entry mode by pressing the FREQUENCY key.
 30. On the Noise Figure Meter, set START FREQ, STOP FREQ, and FREQUENCY all to 1000 MHz.
 31. Set the 10 dB step attenuator for 40 dB of attenuation. Set the 1 dB step attenuator for a power level no greater than -48 dBm as read on the power meter.
 32. On the Noise Figure Meter, press INCREASE to set the smoothing factor to 8. Press CALIBRATE twice.
 33. When calibration is complete, key in 81.0 SPECIAL FUNCTION to turn on the noise source and display the noise power detector output in volts (voltmeter mode). Press STORE 1 to store this setting in the instrument memory.
 34. Set a relative reference on the power meter. (Press dBREL key on HP 436A. Press NF and GAIN keys.)
 35. Set the step attenuator for 30 dB of attenuation. Note the power meter reading.
(Power Meter \approx 10 dB Gain) _____ dB
 36. On the Noise Figure Meter, press NOISE FIGURE AND GAIN. Note the Insertion Gain reading.
(Noise Figure Meter \approx 10 dB Gain) _____ dB
 37. On the Noise Figure Meter, press RECALL 1.
 38. Set the step attenuator for 20 dB of attenuation. Note the power meter reading.
(Power Meter \approx 20 dB Gain) _____ dB
 39. On the Noise Figure Meter, press NOISE FIGURE AND GAIN. Note the Insertion Gain reading.
(Noise Figure Meter \approx 20 dB Gain) _____ dB
 40. Insert a 20 dB attenuator into the setup at the input to the power sensor.
 41. On the Noise Figure Meter, press RECALL 1.
 42. Note the power meter reading. (Power Meter Reference) _____ dB
 43. On the Noise Figure Meter, press NOISE FIGURE AND GAIN. Note the Insertion Gain Reading.
(Noise Figure Meter Reference) _____ dB
 44. On the Noise Figure Meter, press RECALL 1.
-

PERFORMANCE TESTS

GAIN MEASUREMENT UNCERTAINTY PERFORMANCE TEST (cont'd)

**Procedure
(cont'd)**

- 45. Set the step attenuator for 10 dB of attenuation. Note the power meter reading.
(Power Meter \approx 30 dB Gain) _____ dB
- 46. On the Noise Figure Meter, press NOISE FIGURE AND GAIN. Note the Insertion Gain reading.
(Noise Figure Meter \approx 30 dB Gain) _____ dB
- 47. On the Noise Figure Meter, press RECALL 1.
- 48. Set the step attenuator for 0 dB of attenuation. Note the power meter reading.
(Power Meter \approx 40 dB Gain) _____ dB
- 49. On the Noise Figure Meter, press NOISE FIGURE AND GAIN. Note the Insertion Gain reading.
(Noise Figure Meter \approx 40 dB Gain) _____ dB
- 50. Subtract the reading of step 42 from that of step 38. This is the value of the 20 dB attenuator as seen by the power meter.
(20 dB Attenuator) _____ dB
- 51. Subtract the reading of step 43 from that of step 39. This is the Noise Figure Meter reference correction factor.
(Noise Figure Meter Correction Factor) _____ dB
- 52. Fill appropriate values into the following table, then subtract the values for the Noise Figure Meter from the power meter readings above them to yield the net error. The error should be within ± 0.15 dB.

| | | | | |
|-----------------------------------|----------|----------|-------------------------|-------------------------|
| Power Meter | Step 35 | Step 38 | Step 45 + Step 50 | Step 48 + Step 50 |
| | _____ dB | _____ dB | _____ dB | _____ dB |
| Noise Figure Meter | Step 36 | Step 39 | Step 46 + Step 51 | Step 49 + Step 51 |
| | _____ dB | _____ dB | _____ dB | _____ dB |
| Error | _____ dB | _____ dB | _____ dB | _____ dB |

PERFORMANCE TESTS

4-9. INSTRUMENT NOISE FIGURE PERFORMANCE TEST

Specification INSTRUMENT NOISE FIGURE: <7 dB + 0.003 dB per MHz on the most sensitive input range.

Description A noise source is connected to the Noise Figure Meter INPUT, and the instrument measures its own noise figure in the UNCORRECTED mode.

Equipment Noise Source HP 346B Opt. 001

- Procedure**
1. Connect the noise source between the SOURCE output and the INPUT of the Noise Figure Meter. Turn on the Noise Figure Meter, then press PRESET. Set FREQ INCR to 100 MHz.
 2. Press the ENR key to access the working ENR table within the Noise Figure Meter. Using the DATA keys and the ENTER key, modify the 10, 100, 1000, and 2000 MHz ENR entries to correspond to the noise source ENR chart. Exit the ENR table entry mode by pressing the FREQUENCY key.
 3. Use the INCREASE key to set the smoothing factor to 4. Select UNCORRECTED NOISE FIGURE.
 4. Note the NOISE FIGURE display reading at each frequency, while using the step up key (up arrow) to tune the Noise Figure Meter through its tuning range. The Noise Figure measurement results should be less than those shown in the table below.

| Frequency (MHz) | Noise Figure (dB) | | Frequency (MHz) | Noise Figure (dB) | |
|-----------------|-------------------|---------|-----------------|-------------------|---------|
| | Actual | Maximum | | Actual | Maximum |
| 10 | _____ | 7.03 | 810 | _____ | 9.43 |
| 110 | _____ | 7.33 | 910 | _____ | 9.73 |
| 210 | _____ | 7.63 | 1010 | _____ | 10.03 |
| 310 | _____ | 7.93 | 1110 | _____ | 10.33 |
| 410 | _____ | 8.23 | 1210 | _____ | 10.63 |
| 510 | _____ | 8.53 | 1310 | _____ | 10.93 |
| 610 | _____ | 8.83 | 1410 | _____ | 11.23 |
| 710 | _____ | 9.13 | 1510 | _____ | 11.53 |

PERFORMANCE TESTS

4-10. SPURIOUS RESPONSE PERFORMANCE TEST

Specification SPURIOUS RESPONSE: Change in noise figure < 0.03 dB for spurious levels below -45 dBm in the 10 to 2100 MHz range and -15 dBm in the 2.1 to 18 GHz range.

Description The signal generator power level is adjusted to give the desired power out of the directional coupler. Noise figure readings are taken at several frequencies with the signal generator power on and off. The difference between the two readings should be less than 0.03 dB.

Equipment

| | |
|---------------------------|-------------------|
| Attenuator, 10 dB | HP 8491A Opt. 010 |
| Directional Coupler | HP 778D |
| Noise Source | HP 346B Opt. 001 |
| Power Meter | HP 436A |
| Power Sensor | HP 8484A |
| Signal Generator | HP 8614A |




Figure 4-5. Spurious Response Test Setup

- Procedure**
1. Set the signal generator frequency to 1380 MHz.
 2. On the Noise Figure Meter press PRESET, then key in 13.1 SPECIAL FUNCTION, 13.2 SPECIAL FUNCTION and 32 ENTER to set the arithmetic smoothing factor to 32.
 3. On the Noise Figure Meter, set FREQUENCY to 500 MHz.
 4. Connect the equipment as shown in Figure 4-5.
 5. On the Noise Figure Meter, key in 80.0 SPECIAL FUNCTION to turn the noise source off.
 6. Adjust the signal generator output power to give a reading of -55 dBm on the power meter.

PERFORMANCE TESTS

SPURIOUS RESPONSE PERFORMANCE TEST (cont'd)

- | | | |
|-------------------------------|--|----------|
| Procedure (cont'd) | 7. Connect the input of the directional coupler to the INPUT connector of the Noise Figure Meter, then press NOISE FIGURE. | |
| | 8. Note the noise figure reading with the signal generator power off. | _____ dB |
| | 9. Note the noise figure reading with the signal generator power on. | _____ dB |
| | 10. Subtract step 9 from step 8. The difference should be less than 0.03 dB. | _____ dB |
| | 11. On the Noise Figure Meter, set FREQUENCY to 1400 MHz. | |
| | 12. Note the noise figure reading with the signal generator power off. | _____ dB |
| | 13. Note the noise figure reading with the signal generator power on. | _____ dB |
| | 14. Subtract step 13 from step 12. The difference should be less than 0.03 dB. | _____ dB |
| | 15. Set the signal generator frequency to 1420 MHz. | |
| | 16. Note the noise figure reading with the signal generator power off. | _____ dB |
| | 17. Note the noise figure reading with the signal generator power on. | _____ dB |
| | 18. Subtract step 17 from step 16. The difference should be less than 0.03 dB. | _____ dB |
| | 19. Set the signal generator frequency to 2050 MHz. Repeat steps 4 through 7. | |
| | 20. Note the noise figure reading with the signal generator power off. | _____ dB |
| | 21. Note the noise figure reading with the signal generator power on. | _____ dB |
| | 22. Subtract step 21 from step 20. The difference should be less than 0.03 dB. | _____ dB |
| | 23. Set the signal generator frequency to 2300 MHz. | |
| | 24. Repeat steps 4 through 7, but adjust the signal generator output to give a reading of -25 dBm on the power meter. | |
| | 25. Note the noise figure reading with the signal generator power off. | _____ dB |
| | 26. Note the noise figure reading with the signal generator power on. | _____ dB |
| | 27. Subtract step 26 from step 25. The difference should be less than 0.03 dB. | _____ dB |
-

PERFORMANCE TESTS

4-11. JITTER PERFORMANCE TEST

Specification JITTER: Peak-to-peak¹ Y-factor variation < 0.15 dB with minimum smoothing; peak-to-peak¹ Y-factor variation < 0.02 dB with increased smoothing (for smoothing set to 64).

¹Peak-to-peak is defined as five times the standard deviation of a statistically valid set of readings. Five standard deviations about the mean includes 99% of the readings for a Gaussian distribution.

Description The Noise Figure Meter is set to read Y-factor in dB. A large number of noise figure readings are taken with the noise source connected directly to the Noise Figure Meter's INPUT connector. Measurement hold and trigger are used to allow data to be recorded manually. Data is then examined to determine compliance with the specification.

NOTES

This procedure is very time consuming. If you have an HP 9826/36 controller, you can use the program listed at the end of this procedure to test this specification automatically.

This specification is statistical in nature. The truly correct way to make the measurement would be to take several hundred measurements to ensure a statistically valid sample has been gathered.

Equipment Noise SourceHP 346B Opt. 001

- Procedure**
1. Turn on the Noise Figure Meter and allow a 1 hour warm-up.
 2. Press PRESET to set the instrument to standard conditions. Connect the noise source directly to the INPUT connector.
 3. Key in 10.2 SPECIAL FUNCTION to set the instrument to read Y-factor in dB.
 4. Key in 30.1 SPECIAL FUNCTION to set the instrument to trigger hold.
 5. Execute 30.2 SPECIAL FUNCTION 100 times to get 100 separate readings. Record the readings. If you are using a computer or a calculator with statistical computation capabilities (that is, standard deviation), enter the data points as they are read from the Noise Figure Meter.
 6. Find the standard deviation. If you are using a calculator that does not have the standard deviation function, first calculate the mean.

Mean = (Total of all data points)/Number of readings

Mean _____

PERFORMANCE TESTS

JITTER PERFORMANCE TEST (cont'd)**Procedure
(cont'd)**

Then compute the standard deviation.

$$\sqrt{\sum_{i=1}^N \frac{(X_i - \text{mean})^2}{N - 1}} \text{ for } N = 100$$

Standard Deviation _____

7. Multiply the standard deviation by 5. The result should be <0.15 dB. If the result is >0.15 dB, perform steps 5 and 6 using a larger number of points. Also, make sure the noise source is properly connected to the INPUT connector. _____ dB
8. Set the smoothing to 64 by pressing the SMOOTHING INCREASE key until 64 appears in the left display.
9. Repeat steps 5 and 6, but allow 10 seconds after triggering the reading before recording the data.
10. Multiply the standard deviation by 5. The result should be <0.02 dB. If the result is >0.02 dB, perform steps 5 and 6 using a larger number of points. Also, make sure the noise source is properly connected to the INPUT connector. _____ dB

Automated Jitter Performance Test for HP 9826/36 with BASIC 2.0

```

10  PRINTER IS 701          ! Direct output to printer
20  PRINT "SPEC. LIMIT      HP 8970B JITTER"
30  DIM Point(100)
40  OUTPUT 708;"PR 13.1SP 13.2SP 1EN 10.2 SP FR100MZ"
50  !
60  !*****
70  ! Set HP 8970B for arithmetic smoothing with N=1, display Y factor *
80  ! in dB, set frequency to 100 MHz *
90  !*****
100 !
110 N=100                   ! Set number of samples for avg
120 Spec=.150               ! Spec limit with smoothing=1
130 Starttest:             !
140 Quantity=0              ! Initialize variables
150 Total=0
160 !
170 !*****
180 FOR I=1 TO N             !
190   ENTER 708;Reading      ! Read noise figure into Reading *
200   Point(I)=Reading      ! Fill Point array *
210   Total=Total+Reading   ! Build total to get average *
220   DISP I;" OF ";N      ! Shows no. of readings completed *
230 NEXT I                  !
240 !*****
250 !
260 Average=Total/N        ! Perform statistical analysis
270 FOR I=1 TO N
280   Quantity=(Point(I)-Average)^2+Quantity
290 NEXT I
300 Jitter=5*SQR(Quantity/(N-1)) ! Jitter = 5 x standard deviation
310 !
320 !*****
330 !
340 IF Jitter>Spec THEN     ! Format the output
350   Fail_sym$="xx FAIL xx"
360 ELSE
370   Fail_sym$="xx PASS xx"
380 END IF
390 PRINT "   ";Spec;"      ";
400 PRINT USING 410;Jitter;"   ";Fail_sym$
410 IMAGE Z.DDD,K,K
420 !
430 !*****
440 !
450 IF Spec=.02 THEN 510    ! check for end condition
460 !
470 Spec=.020              ! Set variables to test spec with
480 DISP "PLEASE WAIT"     ! smoothing of 64
490 OUTPUT 708;"13.2SP 64EN"
500 GOTO Starttest
510 PRINTER IS 1           ! Direct output back to terminal
520 END

```

Table 4-2. Performance Test Record (1 of 3)

| Hewlett-Packard Company Model HP 8970B Noise Figure Meter Serial Number _____ | | Tested by _____ Date _____ | | |
|--|--|--|--|---|
| Para. No. | Test | Results | | |
| | | Min. | Actual | Max. |
| 4-5 | TUNING ACCURACY PERFORMANCE TEST Tuned Frequency 10 MHz 100 MHz 300 MHz 500 MHz 1000 MHz 1300 MHz 1600 MHz | 8.9 MHz 98 MHz 296 MHz 494 MHz 994 MHz 1294 MHz 1594 MHz | _____ _____ _____ _____ _____ _____ _____ | 11.1 MHz 102 MHz 304 MHz 506 MHz 1006 MHz 1306 MHz 1606 MHz |
| 4-6 | INPUT SWR PERFORMANCE TEST +20 dB Input Gain Setting Frequency _____ MHz _____ MHz _____ MHz +10 dB Input Gain Setting Frequency _____ MHz _____ MHz _____ MHz 0 dB Input Gain Setting Frequency _____ MHz _____ MHz _____ MHz | | _____ _____ _____ _____ _____ _____ _____ _____ _____ | -11.73 dB -11.73 dB -11.73 dB -11.73 dB -11.73 dB -11.73 dB -11.73 dB -11.73 dB -11.73 dB |
| 4-7 | NOISE FIGURE RANGE AND ACCURACY PERFORMANCE TEST Step 9 - Step 10 ² Step 12 - Step 13 ² Step 9 - Step 10 ² Step 15 - Step 16 ² Step 9 - Step 10 ² Step 18 - Step 19 ² Step 9 - Step 10 ² Step 21 - Step 22 ² Step 9 - Step 10 ² Step 24 - Step 25 ² Step 18 - Step 19 ² Step 27 - Step 28 ² | -0.00053 -0.00589 -0.04922 -0.20487 -0.69706 -0.69706 | _____ _____ _____ _____ _____ _____ _____ _____ _____ _____ | Difference +0.00054 +0.00603 +0.05037 +0.20964 +0.71330 +0.71330 |

Table 4-2. Performance Test Record (2 of 3)

| Para. No. | Test | Results | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|--|------------------------------------|-----------------------------------|-----------------------------------|----------|---------|----------|----------|--|----------|---|----------|----------|---------|---|---------|--|----------|---|----------|----------|---------|---|---------|--|--|--|--|
| | | Min. | Actual | Max. | | | | | | | | | | | | | | | | | | | | | | | | |
| 4-8 | GAIN MEASUREMENT UNCERTAINTY PERFORMANCE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table style="width:100%; border:none;"> <tr> <td style="text-align:center;">Power Meter Reading</td> <td style="width:20px;"></td> <td style="text-align:center;">Noise Figure Meter Reading</td> <td></td> </tr> <tr> <td style="text-align:center;">Step 35</td> <td style="text-align:center;">-</td> <td style="text-align:center;">Step 36</td> <td></td> </tr> <tr> <td style="text-align:center;">_____ dB</td> <td></td> <td style="text-align:center;">_____ dB</td> <td style="text-align:center;">-0.15 dB</td> </tr> <tr> <td style="text-align:center;">Step 38</td> <td style="text-align:center;">-</td> <td style="text-align:center;">Step 39</td> <td></td> </tr> <tr> <td style="text-align:center;">_____ dB</td> <td></td> <td style="text-align:center;">_____ dB</td> <td style="text-align:center;">-0.15 dB</td> </tr> </table> | Power Meter Reading | | Noise Figure Meter Reading | | Step 35 | - | Step 36 | | _____ dB | | _____ dB | -0.15 dB | Step 38 | - | Step 39 | | _____ dB | | _____ dB | -0.15 dB | | | | | | | |
| | Power Meter Reading | | Noise Figure Meter Reading | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Step 35 | - | Step 36 | | | | | | | | | | | | | | | | | | | | | | | | | |
| _____ dB | | _____ dB | -0.15 dB | | | | | | | | | | | | | | | | | | | | | | | | | |
| Step 38 | - | Step 39 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| _____ dB | | _____ dB | -0.15 dB | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table style="width:100%; border:none;"> <tr> <td style="text-align:center;">Step 45 + Step 50</td> <td style="width:20px;"></td> <td style="text-align:center;">Step 46 + Step 51</td> <td></td> </tr> <tr> <td style="text-align:center;">_____ dB</td> <td style="text-align:center;">-</td> <td style="text-align:center;">_____ dB</td> <td style="text-align:center;">-0.15 dB</td> </tr> </table> | Step 45 + Step 50 | | Step 46 + Step 51 | | _____ dB | - | _____ dB | -0.15 dB | | | | | | | | | | | | | | | | | | | | |
| Step 45 + Step 50 | | Step 46 + Step 51 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| _____ dB | - | _____ dB | -0.15 dB | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table style="width:100%; border:none;"> <tr> <td style="text-align:center;">Step 48 + Step 50</td> <td style="width:20px;"></td> <td style="text-align:center;">Step 49 + Step 51</td> <td></td> </tr> <tr> <td style="text-align:center;">_____ dB</td> <td style="text-align:center;">-</td> <td style="text-align:center;">_____ dB</td> <td style="text-align:center;">-0.15 dB</td> </tr> </table> | Step 48 + Step 50 | | Step 49 + Step 51 | | _____ dB | - | _____ dB | -0.15 dB | | | | | | | | | | | | | | | | | | | | |
| Step 48 + Step 50 | | Step 49 + Step 51 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| _____ dB | - | _____ dB | -0.15 dB | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4-9 | INSTRUMENT NOISE FIGURE PERFORMANCE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Frequency | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 10 MHz | | _____ | 7.03 FdB | | | | | | | | | | | | | | | | | | | | | | | | |
| | 110 MHz | | _____ | 7.33 FdB | | | | | | | | | | | | | | | | | | | | | | | | |
| | 210 MHz | | _____ | 7.63 FdB | | | | | | | | | | | | | | | | | | | | | | | | |
| | 310 MHz | | _____ | 7.93 FdB | | | | | | | | | | | | | | | | | | | | | | | | |
| | 410 MHz | | _____ | 8.23 FdB | | | | | | | | | | | | | | | | | | | | | | | | |
| | 510 MHz | | _____ | 8.53 FdB | | | | | | | | | | | | | | | | | | | | | | | | |
| | 610 MHz | | _____ | 8.83 FdB | | | | | | | | | | | | | | | | | | | | | | | | |
| | 710 MHz | | _____ | 9.13 FdB | | | | | | | | | | | | | | | | | | | | | | | | |
| | 810 MHz | | _____ | 9.43 FdB | | | | | | | | | | | | | | | | | | | | | | | | |
| | 910 MHz | | _____ | 9.73 FdB | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1010 MHz | | _____ | 10.03 FdB | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1110 MHz | | _____ | 10.33 FdB | | | | | | | | | | | | | | | | | | | | | | | | |
| 1210 MHz | | _____ | 10.63 FdB | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1310 MHz | | _____ | 10.93 FdB | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1410 MHz | | _____ | 11.23 FdB | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1510 MHz | | _____ | 11.53 FdB | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4-10 | SPURIOUS RESPONSE PERFORMANCE TEST | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <table style="width:100%; border:none;"> <tr> <td style="text-align:center;">Noise Figure (Sig. Gen. Power Off)</td> <td style="width:20px;"></td> <td style="text-align:center;">Noise Figure (Sig. Gen. Power On)</td> <td></td> </tr> <tr> <td style="text-align:center;">Step 9</td> <td style="text-align:center;">-</td> <td style="text-align:center;">Step 8</td> <td></td> </tr> <tr> <td style="text-align:center;">Step 13</td> <td style="text-align:center;">-</td> <td style="text-align:center;">Step 12</td> <td></td> </tr> <tr> <td style="text-align:center;">Step 17</td> <td style="text-align:center;">-</td> <td style="text-align:center;">Step 16</td> <td></td> </tr> <tr> <td style="text-align:center;">Step 21</td> <td style="text-align:center;">-</td> <td style="text-align:center;">Step 20</td> <td></td> </tr> <tr> <td style="text-align:center;">Step 26</td> <td style="text-align:center;">-</td> <td style="text-align:center;">Step 27</td> <td></td> </tr> </table> | Noise Figure (Sig. Gen. Power Off) | | Noise Figure (Sig. Gen. Power On) | | Step 9 | - | Step 8 | | Step 13 | - | Step 12 | | Step 17 | - | Step 16 | | Step 21 | - | Step 20 | | Step 26 | - | Step 27 | | | | |
| | Noise Figure (Sig. Gen. Power Off) | | Noise Figure (Sig. Gen. Power On) | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Step 9 | - | Step 8 | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Step 13 | - | Step 12 | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Step 17 | - | Step 16 | | | | | | | | | | | | | | | | | | | | | | | | | |
| Step 21 | - | Step 20 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Step 26 | - | Step 27 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | _____ | 0.03 dB | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | _____ | 0.03 dB | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | _____ | 0.03 dB | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | _____ | 0.03 dB | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | _____ | 0.03 dB | | | | | | | | | | | | | | | | | | | | | | | | | |

Table 4-2. Performance Test Record (3 of 3)

| Para. No. | Test | Results | | |
|-----------|--|---------|--------|---------|
| | | Min. | Actual | Max. |
| 4-11 | JITTER PERFORMANCE TEST Minimum Smoothing 5 X Standard Deviation | | _____ | 0.15 dB |
| | Increased Smoothing 5 X Standard Deviation | | _____ | 0.02 dB |

