

Edition 1

HP Part No. 86205-90001
Printed in USA January 1992



Operating and Service Manual

HP 86205A Directional Bridge

SERIAL NUMBERS

This manual applies to HP 86205A bridges with serial number 3140A00101 and above. For additional information concerning serial numbers, see "Instruments Covered by this Manual" in "General Information."

©Copyright 1991, Hewlett-Packard Company, 1400 Fountainingrove Parkway, Santa Rosa, California 95403-1799 U.S.A.

Certification

Hewlett-Packard Company certifies that this product met its published specifications at the time of shipment from the factory. Hewlett-Packard further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology (NIST, formerly NBS), to the extent allowed by the institute's calibration facility, and to the calibration facilities of other International Standards Organization members.

Warranty

This Hewlett-Packard instrument product is warranted against defects in material and workmanship for a period of one year from date of delivery. During the warranty period, Hewlett-Packard Company will, at its option, either repair or replace products which prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by HP. Buyer shall pay shipping charges to HP and HP shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to HP from another country.

HP warrants that its software and firmware designated by HP for use with an instrument will execute its programming instructions when properly installed on that instrument. HP does not warrant that the operation of the instrument, or software, or firmware will be uninterrupted or error free.

LIMITATION OF WARRANTY

The foregoing warranty shall not apply to defects resulting from improper maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

NO OTHER WARRANTY IS EXPRESSED OR IMPLIED. HP SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OR MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. EXCLUSIVE REMEDIES

THE REMEDIES PROVIDED HEREIN ARE BUYER'S SOLE AND EXCLUSIVE REMEDIES, HP SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

Assistance

Product maintenance agreements and other customer assistance agreements are available for Hewlett-Packard Products.

For any assistance, contact your nearest Hewlett-Packard Sales and Service Office. Addresses are provided at the back of this manual.

General Information

Manual Overview

This manual contains information for operating, testing, and servicing the HP 86205A bridge.

Product Description

The HP 86205A is a high performance 50Ω directional bridge designed for high quality reflection measurements and external source leveling applications over an RF frequency range of 300 KHz to 6 GHz. The bridge achieves a low through loss of 1.5 dB and a high coupling factor of 16 dB. These characteristics make it useful in applications requiring directional couplers, such as power monitoring and closed-loop leveling applications.

Instruments Covered By This Manual

Each bridge has a unique serial number. The contents of this manual apply directly to bridges with serial numbers listed on the title page.

Accessories

Table 5-1 lists accessories available for use with these bridges.

Specifications & Supplemental Characteristics

Table 1-1 lists bridge specifications, which are the performance standards or limits against which you can test the device. Table 1-2 lists supplemental (typical, non-warranted) bridge characteristics.




1 Recession refers to a female type-N connector center conductor dimension relative to 0.207 nominal offset.
 2 Before you performance test an HP 86205A bridge, gage all the connectors and enter the results in the test record at the end of "Performance Tests." For descriptive illustrations defining connector tolerances, see the *Microwave Connector Care Manual* (HP part number 08510-90064).

Max Input Power: +25 dBm Max Input Voltage: port 1 or port 2 30 VDC 0 VDC Max Input Current: 1 amp DC Connector Rejection: 1 0.204 in to 0.207 in ² Weight: net 0.57 kg (1.3 lbs) 1.80 kg (4.0 lbs) shipping Dimensions: 160W x 93H x 23D (mm) 6.3W x 3.7H x 1D (in)	Nominal Through Loss: 1.5 dB +0.1 dB/GHz Through Loss Deviation: ±0.2 dB from nominal Nominal Coupling Factor: 16 dB +0.15 dB/GHz 1 MHz to 3 GHz 16.5 dB -0.2 dB/GHz 3 GHz to 6 GHz Coupling Factor Deviation: ±0.2 dB from nominal 1 MHz to 3 GHz ±0.4 dB from nominal 3 GHz to 6 GHz
---	---

Table 1-2. HP 86205A Supplemental Characteristics

Connector: 50Ω Precision Type-N female Frequency Range: 300 kHz to 6 GHz Directivity: 25 ±5°C >30 dB 300 kHz to 5 MHz >18 dB typical 3 to 5 GHz >40 dB 5 MHz to 2 GHz >16 dB typical 5 to 6 GHz >30 dB 2 GHz to 3 GHz >20 dB typical 2 to 3 GHz >23 dB 300 kHz to 2 GHz Port Match:	>16 dB typical 5 to 6 GHz >20 dB typical 3 to 5 GHz
--	--

Table 1-1. HP 86205A Specifications



Initial Inspection

1. Check the shipping container and packaging material for damage.

2. Check the shipment for completeness.
3. Check the connectors and bridge body for mechanical damage.
4. Check the bridge electrically.

Refer to the "Performance Tests" chapter for procedures that check the bridge electrically.

If any of the following conditions exist, notify your nearest Hewlett-Packard office:

- incomplete shipment

- mechanical damage or defect

- failed electrical test

If you find damage or signs of stress to the shipping container or the cushioning material, keep them for the carrier's inspection. Hewlett-Packard does not wait for a claim settlement before arranging for repair or replacement.

Bridge Operation

Table 2-1 and Figure 2-1 illustrate the bridge operation. The table shows the port orientation in a reflection measurement and in a power monitoring or leveling configuration. The figure identifies the paths and ports of the bridge and shows the electrical characteristics of each path.

Table 2-1.
Port Orientation
with Corresponding Application

Port Number	Application	
	1	Test Port
2	Input Port	Output
3	Coupled	Coupled
	Reflection Measurement	Power Monitoring/Leveling

Operation

Overview

This chapter includes the following information on the HP 86205A directional bridge:

- bridge operation
- bridge features
- operating precautions
- measurement configurations

Bridge Features

- frequency range from 300 kHz to 6 GHz
- high directivity
- insertion loss of 1.5 dB (nominal)
- coupled arm flatness of ± 0.2 dB from nominal

The HP 86205A operates over an RF frequency range of 300 kHz to 6 GHz and has excellent directivity for high quality reflection measurements. Additionally, the bridge has a very low insertion loss of 1.5 dB which means more power to the device under test; this is especially important in the measurement of high power solid state amplifiers and TWTs. The bridge also features a ± 0.2 dB flatness from the nominal 16 dB coupled arm. This capability is valuable in external leveling applications where a power meter or diode detector is used to level the power remotely from the source. Power variations are then minimized, which is important when measuring input-sensitive devices.

DC bias may be applied to a DUT through the main arm of the bridge. (**DO NOT** apply bias to the coupled port of the bridge.) Threaded mounting holes (3.5 mm x 0.5 mm) are located under prepunched holes in the model number label, as shown in




Figure 2-1. HP 86205A Bridge Ports and Measurement Paths




Figure 2-2. Location of Threaded Mounting Holes

Figure 2-2. Since the bridge package is brass, appropriate caution must be taken to avoid damaging the threaded holes.

Operating Precautions

- Read and observe all cautions.
- Tighten the bridge connectors with fingers only.
- If you must use a wrench, use a torque wrench set at 9.2 cm-k_g (12 lb-in).

Cautions



Electrostatic discharge (ESD) can damage the highly sensitive microcircuits in this device; an ESD as low as 1000V can destroy your bridge.

ESD damage occurs most often as you connect or disconnect a device. Use the bridge at a static-safe workstation and wear a grounding strap. *Never* touch the input connector center contacts, or the contact pins of a connecting cable.

Do *not* apply more than +25 dBm RF CW power, or more than 1 amp DC or 0 VDC to port 3 or 30 VDC to port 1 or 2 of the bridge. Higher current/power/voltage can electrically damage the bridge.

Before you connect a cable to the bridge, always discharge the cable's center conductor static electricity to instrument-ground.

Do not drop the bridge or subject it to mechanical shock.

Measurement Configurations

- remote reflection measurement using the HP 8711 network analyzer
- vector impedance measurement using two bridges and the HP 8753 network analyzer
- external power leveling with or without a controller
- reflection measurement using a spectrum analyzer and tracking generator

You can use remote sensing in applications where your DUT is not easily accessible. For example: when measuring the reflection coefficient of an antenna that is located on a tower.

Remote Reflection Measurement Configuration

To Set Up the Measurement

1. Connect the equipment as shown in Figure 2-3.

The cable length from the analyzer source to the bridge does not affect directivity, but may affect source match. However, you may put an attenuator between the cable and bridge to improve source match.

Connect the DUT either directly to the bridge or as close as possible.





Figure 2-3. Remote Directivity Measurement Setup

Figure 2-4. Vector Impedance Measurement Setup



Vector Impedance Measurement Configuration



Note

You may connect the analyzer input signal to either the A or B input port. Use an A/R or B/R ratio measurement to improve the source match.

1. Connect the equipment as shown in Figure 2-4

To Set Up the Measurement

This configuration provides a low-cost custom test system when full 2-port measurements are not needed.

2. Set the parameters on the analyzer to measure with an external detector by pressing:
 - CHAN 1** **Det Options** **Broadband External Y/R***
3. With nothing connected to the bridge, make a normalization of the measurement setup by pressing:
 - CAL** **Normalize**
4. Connect the DUT to the bridge and adjust the scale/division under the **DISPLAY** key.

2. Choose the following parameters on the analyzer:
 - PRESET**
 - MEAS** **A/R** (or **B/R**) If you connected the analyzer input signal to the B input port)
 - MENU** **POWER** then enter the power value and press **[X1]**
 - NUMBER OF POINTS** then enter the desired number
 - START** then enter the start frequency and press **[X1]**
 - STOP** then enter the stop frequency and press **[X1]**
3. Make a measurement calibration by pressing one of the following key sequences:
 - CAL**
 - Cal Kit N 500
 - Return Calibrate menu
 - RESPONSE** connect either an open or short calibration device to the reference plane and press the corresponding **OPEN (F)** or **SHORT (F)** key.
 - or
 - CAL** Calibrate Menu
 - (for A/R) **S11 1-PORT**
 - (for B/R) **S22 1-PORT**
4. Connect the DUT to the reference plane and adjust the scale/division under the **SCALE REF** key.
 - Connect an open, short, and load calibration device to the reference plane while pressing the corresponding key for measurement.

The 16 dB coupling factor is partially compensated by the through loss (1.5 dB) to give a 14.5 dB effective coupling factor (relative to the bridge output port).
The bridge coupling flatness has as good as 0.1 dB/GHz power level roll-off with ± 0.2 dB error.



Note

11. Set the coupling factor by pressing:
 - Coupling Factor** **-14.5** **dB(m)**
10. On the HP 8360, press:
 - ALC Leveling Point Extdr**

The power produced at the point where the power meter/sensor was disconnected is now calibrated at the frequencies and power level specified above.
9. When a message is displayed, indicating the operation is complete, apply the flatness correction array to your measurement setup by pressing:
 - FLTNSS ON/OFF** (the amber LED should be on)

The power produced at the point where the power meter/sensor was disconnected is now calibrated at the frequencies and power level specified above.
8. Set the power meter under synthesizer control to perform the sequence of steps necessary to generate the correction information at each frequency point by pressing:
 - Mtr Meas Menu** **Measure Corr All**


Set the power meter under synthesizer control to perform the sequence of steps necessary to generate the correction information at each frequency point by pressing:

 - Auto Fill Start** and enter the desired start frequency
 - Auto Fill Stop** and enter the desired stop frequency
 - Auto Fill Incr** and enter the desired increment frequency value
7. Set up the user flatness correction by pressing:
 - MENU** **Fitness Menu**
 - Delete Menu** **Delete All**
 - PRIOR**
 - START** then enter the desired start frequency
 - STOP** then enter the desired stop frequency

7. Press **(MKR)** and position the marker with the front panel knob to measure the return loss at the frequency of interest.
 - Terminate the second port of a two-port DUT.
 6. Measure the DUT by connecting it to port 1 of the bridge.
- The normalized trace or flat line represents 0 dB return loss.
- BLANK B MORE 1 OF 3 NORMALIZE ON**
- TRACE B CLEAR WRITE B**
- (TRACE)**
5. Normalize the trace by pressing:
 4. Replace the DUT with a short circuit.
 3. Set the desired center frequency and span to view the DUT.

- TRACK GEN SRC PWR ON**
- (AUX CTRL)**
2. On the tracking generator, press:

Figure 2-6. Reflection Measurement Setup



1. Connect the equipment as shown in Figure 2-6.

To Set Up the Measurement

This configuration is for portable reflection measurement applications.

Reflection Measurement Configuration