

KENWOOD

Amateur Radio Division

Subject: Miscellaneous Connectors**Date:** January 26, 1999


This information is provided "as is," and is subject to change without notice. Kenwood Service Corporation makes no warranty of any kind with regard to this information, including, but not limited to, the implied warranties of merchant ability and fitness for a particular purpose. Kenwood Service Corporation shall not be liable for any error or for incidental or consequential damage in connection with the furnishing, performance, or use of this information.

Microphone Connectors Pin Numbers Usually Imprinted in Insulator

4 Pin Microphone Plug

TR-7200A/7400A/7500


TS-120S/130S/180S/511S/520/530/600/700/820/830



- Pin 1 Microphone**
- Pin 2 Push To Talk**
- Pin 3 Chassis Ground**
- Pin 4 Microphone Ground**

5 Pin Microphone Plug


TR-7600/7625



- Pin 1 Microphone**
- Pin 2 Push To Talk**
- Pin 3 No Connection**
- Pin 4 Chassis Ground**
- Pin 5 Microphone Ground**


6 Pin Microphone Plug

TR-7730/7800/7850/7930/7950/8400/9000/9130/9500



- Pin 1 Microphone**
- Pin 2 Push To Talk**
- Pin 3 Down**
- Pin 4 Up**
- Pin 5 8VDC (150ma Max) Or N.C.**
- Pin 6 Chassis Ground**


8 Pin Microphone Plug



TM-201A/201B/211/221/231/241/321/331
 TM-401A/401B/421/431/441/521/531/541
 TM-621/631/701/721/731/2530/2550/2570
 TR-50/751/851
 TS-50/60/140/430/440/450/570/660/670/680
 TS-690/711/780/811/850/870/930/940/950
 TW-4000/4100

Pin 1 Microphone
Pin 2 Push To Talk
Pin 3 Down
Pin 4 Up
Pin 5 8VDC (150ma Max)
Pin 6 RX Audio (Some Models)
Pin 7 Microphone Ground
Pin 8 Chassis Ground


8 Pin Modular Microphone Plug



TM-251/255/261/451/455/461/641
 TM-642/732/733/741/742/941/942
 TM-G707/V7A

Pin 1 Up
Pin 2 8VDC (150ma Max)
Pin 3 Chassis Ground
Pin 4 Push-To-Talk
Pin 5 Microphone Ground
Pin 6 Microphone
Pin 7 RX Audio (Some Models)
Pin 8 Down

Speaker/Microphone Connection



TH-21AT/21BT/22/25/26/27/28/31AT/31BT
 TH-41AT/41BT/42/45/46/47/48/55/75/77
 TH-78/79/D7/G71/205/215/225/235/315/415

2.5mm Plug


1 Tip
2 Sleeve
Speaker
Speaker & PTT
Ground

3.5mm Plug

1 Tip
2 Ring
3 Sleeve
No Connection
Microphone
PTT

6 Pin Data Plug


TM-251/451/G707/V7



Pin 1 Data Input (Microphone)
Pin 2 Ground (Mic Ground)
Pin 3 Packet Standby (PTT)
Pin 4 9600bps RX Audio Output
Pin 5 1200bps RX Audio Output
Pin 6 Squelch Control Output
Shell Earth (Ground)

6 Pin ACC Plug

TS-450/690/570/850/870/950




Pin 1 GND Signal Ground
Pin 2 TXD Transmit Data
Pin 3 RXD Receive Data
Pin 4 CTS Transmit Enable
Pin 5 RTS Receive Enable
Pin 6 No Connection
Shell Earth (Ground)


7 Pin Remote Plug

TS-120/130/140/180/430/440/450/530/570

TS-680/690/830/850/870/940/950



Pin 1 Speaker Output
Pin 2 Relay Common (Ground)
Pin 3 PTT for Footswitch
Pin 4 Relay Close On Transmit
Pin 5 Relay Open On Transmit
Pin 6 ALC Input
Pin 7 12VDC On Transmit
(10ma Max)
Shell Earth (Ground)

13 Pin ACC 2 Plug

(Rear Panel view)

TS-140/440/450/680/690/570/711/790/811/850
TS-870/940/950

- Pin 1** N/C
- Pin 2** N/C
- Pin 3** RX Audio Output
- Pin 4** Shield For Pin 3
- Pin 5** Squelch Control Or N/C
- Pin 6** S-Meter Output Or N/C
- Pin 7** N/C
- Pin 8** Chassis Ground
- Pin 9** PTT (Standard Mic
Input is Muted)
- Pin 10** N/C
- Pin 11** Microphone Input
- Pin 12** Shield for Pin 11
- Pin 13** PTT (Standard Mic
Input is Active)
- Shell Earth (Ground)**




VC-H1 Wire Connections Using Optional Cable E30-3352-08

Color	Orange	Orange	Yellow	Yellow	White	White	Gray	Gray	Pink	Pink	Shield
Markings	Red	Black	Red	Black	Red	Black	Red	Black	Red	Black	Shield
Pin No.	4	5	6	7	8	9	11	13	14	15	16

Note: Pins 1, 2 and 10 are not connected. Pins 3 and 12 are jumpered.

Pin 1 is indicated by a triangle




VC-H1 Connections for SSTV and speaker microphone		
Wire Color	VCH1 Pin No.	
Orange/Red	4	→ Chassis Ground
Shield	16	
Yellow/Black	7	→ PTT
Gray/Red	11	
Pink/Red	14	→ Audio Input (Microphone)
White/Black	9	→ Audio Output **
Gray/Black	13	

VC-H1 Connections for SSTV		
Wire Color	VCH1 Pin No.	
Orange/Red	4	→ Chassis Ground
Shield	16	
Yellow/Black	7	→ PTT
White/Red	8	→ Audio Input (Microphone)
White/Black	9	→ Audio Output **

VC-H1 Connections for TS-570/TS-870		
Wire Color	VCH1 Pin No.	
Orange/Red	4	→ 8 Chassis Ground
Yellow/Black	7	→ 9 PTT
Yellow/Red	8	→ 11 Audio Input
White/Black	9	→ 3 Audio Output
Shield	16	→ 12 Shield 4


** A 47uf 16v capacitor may be needed to avoid audio distortion

Specialized Connections and CablesTH-D7AGPS Connection2.5mm Plug


1 Tip	To RXD on GPS
2 Ring	To TXD on GPS
3 Sleeve	Ground

PC Connection2.5mm Plug


1 Tip	To RXD on PC
2 Ring	To TXD on PC
3 Sleeve	Ground

Supplied Cable Part No E30-3374-05

1 White	RXD On GPS
2 Red	TXD On GPS
3 Shield	GND On GPS

VC-H1Video Output Plug2.5mm Plug

1 Tip	Video Signal
2 Sleeve	Ground

Video Input Plug3.5mm Plug

1 Tip	N/C (For VC-H1 Camera ONLY)
2 Ring	Video Signal
3 Sleeve	Ground

Com Jack Connection2.5mm Plug

1 Tip	To RXD on PC
2 Ring	To TXD on PC
3 Sleeve	Ground

