



ROHDE & SCHWARZ

Test and Measurement
Division

Service Manual

Handheld Spectrum Analyzer

R&S[®] FSH

1145.5850.03

1145.5850.06

1145.5850.13

1145.5850.23

1145.5850.26

Dear Customer,

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG.
Trade names are trademarks of the owners.

Contents

Safety Instructions

Certificate of Quality

Spare Parts Express Service

List of R&S Representatives

Contents of Manuals for Spectrum Analyzer R&S FSH
Service and Repair

1 Performance Test	1.1
Test Instructions	1.1
Measuring Equipment and Accessories	1.1
Performance Test	1.2
Checking the frequency accuracy.....	1.2
Checking the level accuracy and the frequency response.....	1.3
Checking the accuracy of the RF attenuator	1.5
Checking the accuracy of the IF gain setting.....	1.6
Checking the displayed average noise floor	1.7
Checking the phase noise.....	1.8
Checking the display linearity.....	1.9
Performance Test Tracking Generator	1.11
Checking output level / frequency response	1.11
Performance Test Report	1.12
Performance Test Report Tracking Generator	1.19

2 Adjustment	2.1
Quick Verification	2.1
Measurement Equipment and Accessories for Quick Verification	2.2
Verifying on/off functionality	2.2
Verifying power and AF connections	2.2
Verifying the display	2.3
Verifying the level and noise	2.3
Verify the tracking generator output level	2.4
Adjustment functions.....	2.4
Adjustment	2.5
Adjustment Instructions	2.5
Measurement Equipment and Accessories	2.6
Adjusting the reference frequency accuracy.....	2.6
Adjusting the level accuracy	2.7
Frequency Response Correction	2.8

3 Repair	3.1
Instrument Design and Functional Description	3.1
Description of the block diagram	3.2
Attenuator	3.2
RF to IF conversion.....	3.2
Tracking generator (Model 1145.5850.13/23/26 only)	3.4
RF/IF control	3.4
Mainboard	3.4
Power and battery management.....	3.4
Processing of measured data detectors	3.5
Resolution bandwidths (RBW).....	3.5
Video bandwidths (VBW).....	3.5
Detectors.....	3.6
Keypad control	3.6
Serial optical interface.....	3.6
Power sensor	3.6
Color LCD module	3.6
Module Replacement	3.7
Overview of the modules	3.9
Opening the instrument.....	3.10
Closing the instrument	3.10
Replacing the battery	3.11
Replacing the housing	3.12
Replacing the front unit for R&S FSH	3.13
Replacing the Color LCD Module	3.14
Replacing the RF/IF module	3.15
Replacing the mainboard.....	3.16
Replacing the N connector.....	3.17
Replacing the binder and BNC connector block	3.18
Replacing the power/audio connections	3.19
Replacing a cable from the cable set.....	3.20
Troubleshooting	3.21
Overview of errors, causes, and possible corrective actions.....	3.22
Troubleshooting problems in switching on the instrument	3.22

4 Software Updates / Installing Options4.1

Installing New R&S FSH Software4.1

Installing the Options.....4.1

5 Documents5.1

Shipping of Instrument and Ordering of Spare Parts5.1

 Shipping of instrument5.1

 Shipping of a module5.1

 Ordering spare parts.....5.2

 Refurbished modules5.2

 Return of defective replaced modules5.2



Spare Parts5.3

Safety Instructions

This unit has been designed and tested in accordance with the EC Certificate of Conformity and has left the manufacturer's plant in a condition fully complying with safety standards.

To maintain this condition and to ensure safe operation, the user must observe all instructions and warnings given in this operating manual.

Safety-related symbols used on equipment and documentation from R&S:

							
Observe operating instructions	Weight indication for units >18 kg	PE terminal	Ground terminal	Danger! Shock hazard	Warning! Hot surfaces	Ground	Attention! Electrostatic sensitive devices require special care

- The unit may be used only in the operating conditions and positions specified by the manufacturer. Unless otherwise agreed, the following applies to R&S products:
IP degree of protection 2X, pollution severity 2 overvoltage category 2, only for indoor use, altitude max. 2000 m.
The unit may be operated only from supply networks fused with max. 16 A.
Unless specified otherwise in the data sheet, a tolerance of $\pm 10\%$ shall apply to the nominal voltage and of $\pm 5\%$ to the nominal frequency.
- For measurements in circuits with voltages $V_{\text{rms}} > 30 \text{ V}$, suitable measures should be taken to avoid any hazards.
(using, for example, appropriate measuring equipment, fusing, current limiting, electrical separation, insulation).
- For permanently installed units without built-in fuses, circuit breakers or similar protective devices, the supply circuit must be fused such as to provide suitable protection for the users and equipment.
- Prior to switching on the unit, it must be ensured that the nominal voltage set on the unit matches the nominal voltage of the AC supply network.
If a different voltage is to be set, the power fuse of the unit may have to be changed accordingly.
- If the unit has no power switch for disconnection from the AC supply, the plug of the connecting cable is regarded as the disconnecting device. In such cases it must be ensured that the power plug is easily reachable and accessible at all times (length of connecting cable approx. 2 m). Functional or electronic switches are not suitable for providing disconnection from the AC supply.
If units without power switches are integrated in racks or systems, a disconnecting device must be provided at system level.
- Applicable local or national safety regulations and rules for the prevention of accidents must be observed in all work performed.
Prior to performing any work on the unit or opening the unit, the latter must be disconnected from the supply network.
Any adjustments, replacements of parts, maintenance or repair may be carried out only by authorized R&S technical personnel.
Only original parts may be used for replacing parts relevant to safety (eg power switches, power transformers, fuses). A safety test must be performed after each replacement of parts relevant to safety.
(visual inspection, PE conductor test, insulation-resistance, leakage-current measurement, functional test).
- Ensure that the connections with information technology equipment comply with IEC950 / EN60950.
- NiMH batteries must not be exposed to high temperatures or fire.
Keep batteries away from children.
If the battery is replaced improperly, there is danger of explosion. Only replace the battery by R&S type (see spare part list).
NiMH batteries are suitable for environmentally-friendly disposal or specialized recycling. Dispose them into appropriate containers, only.
Do not short-circuit the battery.
- Equipment returned or sent in for repair must be packed in the original packing or in packing with electrostatic and mechanical protection.
- Electrostatics via the connectors may damage the equipment. For the safe handling and operation of the equipment, appropriate measures against electrostatics should be implemented.

Safety Instructions

11. The outside of the instrument is suitably cleaned using a soft, lint-free dustcloth. Never use solvents such as thinners, acetone and similar things, as they may damage the front panel labeling or plastic parts.
12. Any additional safety instructions given in this manual are also to be observed.



Qualitätszertifikat

Sehr geehrter Kunde,

Sie haben sich für den Kauf eines Rohde & Schwarz-Produktes entschieden. Hiermit erhalten Sie ein nach modernsten Fertigungsmethoden hergestelltes Produkt. Es wurde nach den Regeln unseres Qualitätsmanagementsystems entwickelt, gefertigt und geprüft. Das Rohde & Schwarz-Qualitätsmanagementsystem ist u.a. nach ISO 9001 und ISO 14001 zertifiziert.

Certificate of quality

Dear Customer,

You have decided to buy a Rohde & Schwarz product. You are thus assured of receiving a product that is manufactured using the most modern methods available. This product was developed, manufactured and tested in compliance with our quality management system standards. The Rohde & Schwarz quality management system is certified according to standards such as ISO 9001 and ISO 14001.

Certificat de qualité

Cher client,

Vous avez choisi d'acheter un produit Rohde & Schwarz. Vous disposez donc d'un produit fabriqué d'après les méthodes les plus avancées. Le développement, la fabrication et les tests respectent nos normes de gestion qualité. Le système de gestion qualité de Rohde & Schwarz a été homologué, entre autres, conformément aux normes ISO 9001 et ISO 14001.



ROHDE & SCHWARZ

Spare Parts Express Service

Phone: +49 89 4129 - 12465

Fax: +49 89 41 29 - 13306

E-mail: werner.breidling@rsd.rohde-schwarz.com

In case of urgent spare parts requirements for this Rohde & Schwarz unit, please contact our spare parts express service.

Outside business hours, please leave us a message or send a fax or e-mail. We shall contact you promptly.

FIRMENSITZ/HEADQUARTERS

	Phone	
	Fax	
	E-mail	
Rohde & Schwarz GmbH & Co. KG	+49 (89) 41 29-0	
Mühlhofstraße 15 · D-81671 München	+49 89 4129-121 64	
Postfach 80 14 69 · D-81614 München	-	

WERKE/PLANTS

Rohde & Schwarz Messgerätebau GmbH	+49 (8331) 108-0	
Riedbachstraße 58 · D-87700 Memmingen	+49 (8331) 108-11 24	
Postfach 1652 · D-87686 Memmingen	-	

Rohde & Schwarz GmbH & Co. KG	+49 (9923) 857-0	
Werk Teisnach	+49 (9923) 857-11 74	
Kaikenrieder Straße 27 · D-94244 Teisnach	-	
Postfach 1149 · D-94240 Teisnach		

Rohde & Schwarz GmbH & Co. KG	+49 (2203) 49-0	
Dienstleistungszentrum Köln	+49 (2203) 49 51-308	
Graf-Zeppelin-Straße 18 · D-51147 Köln	info@rsdc.rohde-schwarz.com	
Postfach 98 02 60 · D-51130 Köln	service@rsdc.rohde-schwarz.com	

TOCHTERUNTERNEHMEN/

Rohde & Schwarz Vertriebs-GmbH	+49 (89) 41 29-137 74	
Mühlhofstraße 15 · D-81671 München	+49 (89) 41 29-137 77	
Postfach 80 14 69 · D-81614 München	-	

Rohde & Schwarz International GmbH	+49 (89) 41 29-129 84	
Mühlhofstraße 15 · D-81671 München	+49 (89) 41 29-120 50	
Postfach 80 14 60 · D-81614 München	-	

Rohde & Schwarz Engineering and Sales GmbH	+49 (89) 41 29-137 11	
Mühlhofstraße 15 · D-81671 München	+49 (89) 41 29-137 23	
Postfach 80 14 29 · D-81614 München	-	

R&S BICK Mobilfunk GmbH	+49 (5042) 998-0	
Fritz-Hahne-Str. 7 · D-31848 Bad Münder	+49 (5042) 998-105	
Postfach 2062 · D-31844 Bad Münder	-	

Rohde & Schwarz FTK GmbH	+49 (30) 658 91-122	
Wendenschlossstraße 168, Haus 28	+49 (30) 655 50-221	
D-12557 Berlin	-	

Rohde & Schwarz SIT GmbH	+49 (30) 658 84-0	
Agastraße 3	+49 (30) 658 84-183	
D-12489 Berlin		

ADRESSEN DEUTSCHLAND/ ADDRESSES GERMANY

Rohde & Schwarz Vertriebs-GmbH	+49 89 4129-133 74	
Mühlhofstraße 15 · D-81671 München	+4989 4129-133 77	
Postfach 80 14 69 · D-81614 München	-	

Zweigniederlassungen der Rohde & Schwarz Vertriebs-GmbH/Branch offices of Rohde & Schwarz Vertriebs-GmbH

Zweigniederlassung Nord, Geschäftsstelle Berlin	+49 (30) 34 79 48-0	
Ernst-Reuter-Platz 10 · D-10587 Berlin	+49 (30) 34 79 48 48	
Postfach 100620 · D-10566 Berlin	-	

Zweigniederlassung Büro Bonn	+49 (228) 918 90-0	
Josef-Wirmer-Straße 1-3 · D-53123 Bonn	+49 (228) 25 50 87	
Postfach 140264 · D-53057 Bonn	-	

Zweigniederlassung Nord, Geschäftsstelle Hamburg	+49 (40) 63 29 00-0	
Steilshooper Alle 47 · D-22309 Hamburg	+49 (40) 630 78 70	
Postfach 60 22 40 · D-22232 Hamburg	-	

Zweigniederlassung Mitte, Geschäftsstelle Köln	+49 (2203) 807-0	
Niederlassener Straße 33 · D-51147 Köln	+49 (2203) 807-650	
Postfach 900 149 · D-51111 Köln	-	

Zweigniederlassung Süd, Geschäftsstelle München	+49 (89) 41 86 95-0	
Mühlhofstraße 15 · D-81671 München	+49 (89) 40 47 64	
Postfach 80 14 69 · D-81614 München	-	

Zweigniederlassung Süd, Geschäftsstelle Nürnberg	+49 (911) 642 03-0	
Donaustraße 36	+49 (911) 642 03-33	
D-90451 Nürnberg	-	

Zweigniederlassung Mitte, Geschäftsstelle Neu-Isenburg	+49 (6102) 20 07-0	
Siemensstraße 20	+49 (6102) 20 07 12	
D-63263 Neu-Isenburg	-	

ADRESSEN WELTWEIT/ ADDRESSES WORLDWIDE

Albania siehe / see Austria

Algeria	ROHDE & SCHWARZ	+213 (21) 48 20 18
	Bureau d'Alger	+213 (21) 69 46 08
	5B Place de Laperrine	
	16035 Hydra-Alger	

Argentina	PRECISION ELECTRONICA S.R.L.	+541 (14) 331 41 99
	Av. Pde Julio A. Roca 710 - 6° Piso	+541 (14) 334 51 11
	(C1067ABP) Buenos Aires	alberto_lombardi@prec-elec.com.ar

Australia	ROHDE & SCHWARZ (AUSTRALIA) Pty. Ltd.	+61 (2) 88 45 41 00
	Sales Support	+61 (2) 96 38 39 88
	Unit 6	lyndell.james@rsaus.rohde-
	2-8 South Street	schwarz.com
	Rydalmere, N.S.W. 2116	

Austria	ROHDE & SCHWARZ-ÖSTERREICH	+43 (1) 602 61 41-0
	Ges.m.b.H.	+43 (1) 602 61 41-14
		rs-austria@rsoe.rohde-schwarz.com

Am Euro Platz 3
Gebäude B
1120 Wien

Azerbaijan	ROHDE & SCHWARZ Azerbaijan	+994 (12) 93 31 38
	Liaison Office Baku	+994 (12) 93 03 14
	ISR Plaza	RS-Azerbaijan@RUS.Rohde-
	340 Nizami Str.	Schwarz.com
	370000 Baku	

Baltic Countries siehe / see Denmark

Bangladesh	BIL Consortium Ltd.	+880 (2) 881 06 53
	Corporate Office	+880 (2) 882 82 91
	House-33, Road-4, Block-F	
	Banani	
	Dhaka-1213	

Belgium	ROHDE & SCHWARZ BELGIUM N.V.	+32 (2) 721 50 02
	Excelsiorlaan 31 Bus 1	+32 (2) 725 09 36
	1930 Zaventem	info@rsb.rohde-schwarz.com

Brazil	ROHDE & SCHWARZ DO BRASIL LTDA.	+55 (11) 56 44 86 11 (general)
	Av. Alfredo Egidio de Souza Aranha n° 177,	+55 (11) 56 44 86 25 (sales)
	1° andar - Santo Amaro	+55 (11) 56 44 86 36
	04726-170 Sao Paulo - SP	sales-brazil@rsdb.rohde-
		schwarz.com

Brunei	GKL Equipment PTE Ltd.	+65 (6) 276 06 26
	#11-01 BP Tower	+65 (6) 276 06 29
	396 Alexandra Road	gkleqpt@singnet.com.sg
	Singapore 119954	

Bulgaria	ROHDE & SCHWARZ ÖSTERREICH	+359 (2) 963 43 34
	Representation Office Bulgaria	+359 (2) 963 21 97
	39, Fridtjof Nansen Blvd.	rohdebg@rsoe.rohde-schwarz.com
	1000 Sofia	

Bosnia-Herzegovina siehe / see Slovenia

Canada	ROHDE & SCHWARZ CANADA Inc. 555 March Rd. Kanata, Ontario K2K 2M5	+1 (613) 592 80 00 +1 (613) 592 80 09 cgirwarnauth@rscanada.ca	Denmark	ROHDE & SCHWARZ DANMARK A/S Ejby Industrivej 40 2600 Glostrup	+45 (43) 43 66 99 +45 (43) 43 77 44
Canada	TEKTRONIX CANADA Inc. Test and Measurement 4929 Place Olivia Saint-Laurent, Pq Montreal H4R 2V6	+1 (514) 331 43 34 +1 (514) 331 59 91	Ecuador	REPRESENTACIONES MANFRED WEINZIERL Vía Láctea No. 4 y Vía Sta. Inés P.O.Box 17-22-20309 1722 Cumbayá-Quito	+593 (22) 89 65 97 +593 (22) 89 65 97 mweinzierl@plus.net.ec
Chile	DYMEQ Ltda. Av. Larrain 6666 Santiago	+56 (2) 339 20 00 +56 (2) 339 20 10 dymeq@dymeq.com	Egypt	U.A.S. Universal Advanced Systems 31 Manshiet El-Bakry Street Heliopolis 11341 Cairo	+20 (2) 455 67 44 +20 (2) 256 17 40 an_uas@link.net
China	ROHDE & SCHWARZ China Ltd. Representative Office Shanghai Central Plaza 227 Huangpi North Road RM 807/809 Shanghai 200003	+86 (21) 63 75 00 18 +86 (21) 63 75 91 70	El Salvador	siehe / see Mexico	
China	ROHDE & SCHWARZ China Ltd. Representative Office Beijing Room 602, Parkview Center 2 Jiangtai Road Chao Yang District Beijing 100016	+86 (10) 64 31 28 28 +86 (10) 64 37 98 88 info.rschina@rsbp.rohde- schwarz.com	Estonia	ROHDE & SCHWARZ DANMARK A/S Estonian Branch Office Narva mnt. 13 10151 Tallinn	+372 (6) 14 31 23 +372 (6) 14 31 21 margo.fingling@rsdk.rohde- schwarz.com
China	ROHDE & SCHWARZ China Ltd. Representative Office Guangzhou Room 2903, Metro Plaza 183 Tianhe North Road Guangzhou 510075	+86 (20) 87 55 47 58 +86 (20) 87 55 47 59	Finland	Orbis Oy P.O.Box 15 00421 Helsinki 42	+358 (9) 47 88 30 +358 (9) 53 16 04 info@orbis.fi
China	ROHDE & SCHWARZ China Ltd. Representative Office Chengdu Unit G, 28/F, First City Plaza 308 Shuncheng Avenue Chengdu 610017	+86 (28) 86 52 76 05 to 09 +86 (28) 86 52 76 10 rsbpc@mail.sc.cninfo.net	France	ROHDE & SCHWARZ FRANCE Immeuble "Le Newton" 9-11, rue Jeanne Braconnier 92366 Meudon La Forêt Cédex	+33 (1) 41 36 10 00 +33 (1) 41 36 11 73 contact@rsf.rohde-schwarz.com
China	ROHDE & SCHWARZ China Ltd. Representative Office Hongkong 31/F Entertainment Building 30 Queen's Road Central Hongkong	+85 (2) 21 68 06 70 +85 (2) 21 68 08 99	France	Niederlassung/Subsidiary Rennes 37 Rue du Bignon Bât. A F-35510 Cesson Sevigne	+33 (0) 299 51 97 00 +33 (0) 299 51 98 77 -
China	ROHDE & SCHWARZ China Ltd. Representative Office Xi'an Room 10125, Jianguo Hotel Xi'an No. 2, Huzhu Road Xi'an 710048	+86 (29) 321 82 33 +86 (29) 329 60 15 sherry.yu@rsbp.rohde-schwarz.com	France	Niederlassung/Subsidiary Toulouse Technoparc 3 B.P. 501 F-31674 Labège Cédex	+33 (0) 561 39 10 69 +33 (0) 561 39 99 10 -
China	ROHDE & SCHWARZ China Ltd. Representative Office Shenzhen No. 2002 Jiabin Road Luohu District Shenzhen 518001	+86 (755) 25 18 50 18 +86 (755) 25 18 50 18 jessica.lia@rsbp.rohde-schwarz.com	France	Aix-en-Provence	+33 (0) 494 07 39 94 +33 (0) 494 07 55 11 -
China	Shanghai ROHDE & SCHWARZ Communication Technology Co.Ltd.		France	Office Lyon	+33 (0) 478 29 88 10 +33 (0) 478 79 18 57
China	Beijing ROHDE & SCHWARZ Communication Technology Co.Ltd. Room 106, Parkview Centre No. 2, Jiangtai Road Chao Yang District Beijing 100016	+86 (10) 64 38 80 80 +86 (10) 64 38 97 06	France	Office Nancy	+33 (0) 383 54 51 29 +33 (0) 383 54 82 09
Croatia	siehe / see Slovenia		Ghana	KOP Engineering Ltd. P.O. Box 11012 3rd Floor Akai House, Osu Accra North	+233 (21) 77 89 13 +233 (21) 701 06 20
Cyprus	HINIS TELECAST LTD. Agiou Thoma 18 Kiti Larnaca 7550	+357 (24) 42 51 78 +357 (24) 42 46 21 hinis@logos.cy.net	Greece	MERCURY S.A. 6, Loukianou Str. 10675 Athens	+302 (10) 722 92 13 +302 (10) 721 51 98 mercury@hol.gr
Czech Republic	ROHDE & SCHWARZ - Praha s.r.o. Hadovka Office Park Evropská 33c 16000 Praha 6	+420 (2) 24 31 12 32 +420 (2) 24 31 70 43 office@rscz.rohde-schwarz.com	Guatemala	siehe / see Mexico	
			Honduras	siehe / see Mexico	
			Hong Kong	Electronic Scientific Engineering 9/F North Somerset House Taikoo Place 979 King's Road Hong Kong	+852 (25) 07 03 33 +852 (25) 07 09 25 stephenchau@ese.com.hk
			Hungary	ROHDE & SCHWARZ Budapesti Iroda Váci út 169 1138 Budapest	+36 (1) 412 44 60 +36 (1) 412 44 61 RS-Hungary@rshu.rohde- schwarz.com
			Iceland	siehe / see Denmark	

India	ROHDE & SCHWARZ India Pvt. Ltd. Bangalore Office No. 24, Service Road, Domlur 2nd Stage Extension Bangalore - 560 071	+91 (80) 535 23 62 +91 (80) 535 03 61 rsindiab@rsnl.net	Kazakhstan	ROHDE & SCHWARZ Kazakhstan Representative Office Almaty Pl. Respubliki 15 480013 Almaty	+7 (32) 72 63 55 55 +7 (32) 72 63 46 33 RS-Kazakhstan@RUS-Rohde-Schwarz.com
India	ROHDE & SCHWARZ India Pvt. Ltd. Hyderabad Office 302 & 303, Millenium Centre 6-3-1099/1100, Somajiguda Hyderabad - 500 016	+91 (40) 23 32 24 16 +91 (40) 23 32 27 32 rsindiah@nd2.dot.net.in	Kenya	Excel Enterprises Ltd Dunga Road P.O.Box 42 788 Nairobi	+254 (2) 55 80 88 +254 (2) 54 46 79
India	ROHDE & SCHWARZ India Pvt. Ltd. 244, Okhla Industrial Estate, Phase-III New Delhi 110020	+91 (11) 26 32 63 81 +91 (11) 26 32 63 73 sales@rsindia.rohde-schwarz services@rsindia.rohde-schwarz.com	Korea	ROHDE & SCHWARZ Korea Ltd. 83-29 Nonhyun-Dong, Kangnam-Ku Seoul 135-010	+82 (2) 514 45 46 +82 (2) 514 45 49 sales@rskor.rohde-schwarz.com service@rskor.rohde-schwarz.com
India	ROHDE & SCHWARZ India Pvt. Ltd. RS India Mumbai Office B-603, Remi Bizcourt, Shah Industrial Estate, Off Veera Desai Road Mumbai - 400 058	+91 (22) 26 30 18 10 +91 (22) 26 73 20 81 rsindiam@rsnl.net	Kuwait	Group Five Trading & Contracting Co. Mezanine Floor Al-Bana Towers Ahmad Al Jaber Street Sharq	+965 (244) 91 72/73/74 +965 (244) 95 28 jk_agarwal@yahoo.com
Indonesia	PT ROHDE & SCHWARZ Indonesia Graha Paramita 5th Floor Jln. Denpasar Raya Blok D-2 Jakarta 12940	+62 (21) 252 36 08 +62 (21) 252 36 07 sales@rsbj.rohde-schwarz.com services@rsbj.rohde-schwarz.com	Latvia	ROHDE & SCHWARZ DANMARK A/S Latvian Branch Office Merkela iela 21-301 1050 Riga	+371 (7) 50 23 55 +371 (7) 50 23 60 rsdk@rsdk.rohde-schwarz.com
Iran	ROHDE & SCHWARZ IRAN Groundfloor No. 1, 14th Street Khaled Eslamboli (Vozara) Ave. 15117 Tehran	+98 (21) 872 42 96 +98 (21) 871 90 12 rs-tehran@neda.net	Lebanon	ROHDE & SCHWARZ Liaison Office Riyadh P.O.Box 361 Riyadh 11411	+966 (1) 465 64 28 Ext. 303 +966 (1) 465 64 28 Ext. 229 chris.porzky@rsd.rohde-schwarz.com
Ireland	siehe / see United Kingdom		Lebanon	Netcom P.O.Box 55199 Op. Ex-Presidential Palace Horsh Tabet Beirut	+961-1-48 69 99 +961-1-49 05 11 netcom@inco.com.lb
Israel	EASTRONICS LTD. Messtechnik / T&M Equipment 11 Rozanis St. P.O.Box 39300 Tel Aviv 61392	+972 (3) 645 87 77 +972 (3) 645 86 66 david_hasky@easx.co.il	Liechtenstein	siehe / see Switzerland	
Israel	J.M. Moss (Engineering) Ltd. Kommunikationstechnik/ Communications Equipment 9 Oded Street P.O.Box 967 52109 Ramat Gan	+972 (3) 631 20 57 +972 (3) 631 40 58 jmoss@zahav.net.il	Lithuania	ROHDE & SCHWARZ DANMARK A/S Lithuanian Office Lukiskiu 5-228 2600 Vilnius	+370 (5) 239 50 10 +370 (5) 239 50 11
Italy	ROHDE & SCHWARZ ITALIA S.p.a. Centro Direzionale Lombardo Via Roma 108 20060 Cassina de Pecchi (MI)	+39 (02) 95 70 42 03 +39 (02) 95 30 27 72 ornella.crippa@rsi.rohde-schwarz.com	Luxembourg	siehe / see Belgium	
Italy	ROHDE & SCHWARZ ITALIA S.p.a. Via Tiburtina 1182 00156 Roma	+39 (06) 41 59 82 18 +39 (06) 41 59 82 70	Macedonia	siehe / see Slovenia	
Japan	Rohde & Schwarz Support Center Japan K.K. 711 bldg., Room 501 (5th floor) 7-11-18 Nishi-Shinjuku Shinjuku-ku Tokyo 160-0023	+81 (3) 59 25 12 88 +81 (3) 59 25 12 90 Akihiko Yoshimura/RSJP@RSJP	Malaysia	DAGANG TEKNIK SDN. BHD. No. 9, Jalan SS 4D/2 Selangor Darul Ehsan 47301 Petaling Jaya	+60 (3) 27 03 55 68 +60 (3) 27 03 34 39 maryanne@danik.com.my
Japan	ADVANTEST Sales Promotion Department Shinjuku-NS bldg. 2-4-1, Nishi-Shinjuku Shinjuku-ku Tokyo 160-0880	+81 (3) 33 42 75 52 +81 (3) 53 22 72 70 mkoyama@ns.advantest.co.jp	Malta	ITEC International Technology Ltd B'Kara Road San Gwann SGN 08	+356 (21) 37 43 00 or 37 43 29 +356 (21) 37 43 53 sales@itec.com.mt
Jordan	Jordan Crown Engineering & Trading Co. Jabal Amman, Second Circle Youssef Ezzideen Street P.O.Box 830414 Amman, 11183	+962 (6) 462 17 29 +962 (6) 465 96 72 jocrown@go.com.jo	Mexico	Rohde & Schwarz de Mexico (RSMX) S. de R.L. de C.V. German Centre Oficina 4-2-2 Av. Santa Fé 170 Col. Lomas de Santa Fé 01210 Mexico D.F.	+52 (55) 85 03 99 13 +52 (55) 85 03 99 16 latinoamerica@rsd.rohde-schwarz.com
			Mexico	Rohde & Schwarz de Mexico (RSMX) Av. Prol. Americas No. 1600, 2° Piso Col. Country Club Guadalajara, Jal. Mexico CP, 44610	+52 (33) 36 78 91 70 +52 (33) 36 78 92 00
			Moldavia	siehe / see Romania	
			Nepal	ICTC Pvt. Ltd. Hattisar, Post Box No. 660 Kathmandu	+977 (1) 443 48 95 +977 (1) 443 49 37 ictc@mos.com.np
			Netherlands	RÖHDE & SCHWARZ NEDERLAND B.V. Perkinsbaan 1 3439 ND Nieuwegein	+31 (30) 600 17 00 +31 (30) 600 17 99 info@rsn.rohde-schwarz.com

New Zealand	Nichecom 1 Lincoln Ave. Tawa, Wellington	+64 (4) 232 32 33 +64 (4) 232 32 30 rob@nichecom.co.nz	Singapore	ROHDE & SCHWARZ Support Centre Asia PTE Ltd. 1 Kaki Bukit View #04-05/07 Techview Singapore 415 941	+65 68 46 37 10 +65 67 49 17 91 rsca@rssg.rohde-schwarz.com
Nicaragua	siehe / see Mexico		Slovak Republic	Speciálne systémy a software, a.s. Svrčia ul. 841 04 Bratislava	+421 (2) 65 42 24 88 +421 (2) 65 42 07 68 stefan.lozek@special.sk
Nigeria	Ferrostaal Abuja Plot 3323, Barada Close P.O.Box 8513, Wuse Off Amazon Street Maitama, Abuja	+234 (9) 413 52 51 +234 (9) 413 52 50 fsabuja@rosecom.net	Slovenia	ROHDE & SCHWARZ Representation Ljubljana Tbilisijska 89 1000 Ljubljana	+386 (1) 423 46 51 +386 (1) 423 46 11 rohdesi@rsoe.rohde-schwarz.com
Norway	ROHDE & SCHWARZ NORGE AS Enebakkeveien 302 B 1188 Oslo	+47 (23) 38 66 00 +47 (23) 38 66 01	South Africa	Protea Data Systems (Pty.) Ltd. Communications and Measurement Division Private Bag X19 Bramley 2018	+27 (11) 719 57 00 +27 (11) 786 58 91 unicm@protea.co.za
Oman	Mustafa Sultan Science & Industry Co.LLC. For Test & Measurement ONLY Way No. 3503 Building No. 241 Postal Code 112 Al Khuwair, Muscat	+968 636 0000 +968 607 0666 m-aziz@mustafasultan.com	South Africa	Protea Data Systems (Pty.) Ltd. Cape Town Branch Unit G9, Centurion Business Park Bosmandam Road Milnerton Cape Town, 7441	+27 (21) 555 36 32 +27 (21) 555 42 67 unicm@protea.co.za
Pakistan	Siemens Pakistan 23, West Jinnah Avenue Islamabad	+92 (51) 227 22 00 +92 (51) 227 54 98 reza.bokhary@siemens.com.pk	Spain	ROHDE & SCHWARZ ESPANA S.A. Salcedo, 11 28034 Madrid	+34 (91) 334 10 70 +34 (91) 329 05 06 rses@rses-rohde-schwarz.com
Panama	siehe / see Mexico		Sri Lanka	Dynatel Communications (PTE) Ltd. 451/A Kandy Road Kelaniya	+94 (1) 90 80 01 +94 (1) 91 04 69 dyna-svc@sltnet.lk
Papua New Guinea	siehe / see Australia		Sudan	SolarMan Co. Ltd. P.O.Box 11 545 North of Fraouq Cementry 6/7/9 Bldg. 16 Karthoum	+249 (11) 47 31 08 +249 (11) 47 31 38 solarman29@hotmail.com
Philippines	Rohde & Schwarz (Philippines) Ltd. PBCom Tower Ayala Ave. cor. Herrera Sts. Makati City/ Philippines	+63 (2) +63 (2)	Sweden	ROHDE & SCHWARZ SVERIGE AB Marketing Div. Flygfältsgatan 15 128 30 Skarpnäck	+46 (8) 605 19 00 +46 (8) 605 19 80 info@rss.se
Poland	ROHDE & SCHWARZ Österreich SP.z o.o. Przedstawicielstwo w Polsce ul. Stawki 2, Pietro 28 00-193 Warszawa	+48 (22) 860 64 94 +48 (22) 860 64 99 rohdepl@rsoe.rohde-schwarz.com	Switzerland	Roschi Rohde & Schwarz AG Mühlestr. 7 3063 Ittigen	+41 (31) 922 15 22 +41 (31) 921 81 01 sales@roschi.rohde-schwarz.com
Portugal	Rohde & Schwarz Portugal, Lda. Alameda Antonio Sergio 7-R/C - Sala A 2795-023 Linda-a-Velha	+351 (21) 415 57 00 +351 (21) 415 57 10 info@rspt.rohde-schwarz.com	Syria	Electro Scientific Office Baghdad Street Dawara Clinical Lab. Bldg P.O.Box 8162 Damascus	+963 (11) 231 59 74 +963 (11) 231 88 75 memo@hamshointl.com
Romania	ROHDE & SCHWARZ Representation Office Bucharest Str. Uranus 98 Sc. 2, Et. 5, Ap. 36 76102 Bucuresti, Sector 5	+40 (21) 410 68 46 +40 (21) 411 20 13 rohdero@rsoe.rohde-schwarz.com	Taiwan	Rohde & Schwarz Taiwan Ltd. 14F, No. 13, Sec. 2, Pei-Tou Road Taipei	+886 (2) 28 93 10 88 +886 (2) 28 91 72 60 alice.chen@rstw.rohde-schwarz.com
Russian Federation	ROHDE & SCHWARZ Representative Office Moscow 119180, Yakimanskaya nab., 2 Moscow	+7 (095) 745 88 50 to 53 +7 (095) 745 88 54 rs-russia@rsru.rohde-schwarz.com	Tanzania	SSTL Group P.O. Box 7512 Dunga Street Plot 343/345 Dar es Salaam	+255 (22) 276 00 37 +255 (22) 276 02 93 sstl@ud.co.tz
Saudi Arabia	Rohde & Schwarz Liaison Office Riyadh c/o Haji Abdullah Alireza Co. Ltd. P.O.Box 361 Riyadh 11411	+966 (1) 465 64 28 Ext. 303 +966 (1) 465 6428 Ext. 229 chris.porzky@rsd.rohde-schwarz.com	Thailand	Schmidt Electronics (Thailand) Ltd. 63 Government Housing Bank Bldg. Tower II, 19th floor, Rama 9 Rd. Huaykwang, Bangkok Bangkok 10320	+66 (2) 643 13 30 to 39 +66 (2) 643 13 40 kamthoninthuyot@schmidtthailand.com
Saudi Arabia	GENTEC Haji Abdullah Alireza & Co. Ltd. P.O.Box 43054 Riyadh	+966 (1) 465 64 28 +966 (1) 465-64 28 akanbar@gentec.com.sa	Thailand	TPP Operation Co., Ltd. 41/5 Mooban Tarinee Boromrajchonnee Road Talingchan, Bangkok 10170	+66 (2) 880 93 47 +66 (2) 880 93 47 thipsukon@tpp-operation.com
Serbia-Montenegro	Representative Office Belgrade Tose Jovanovica 7 11030 Beograd	+381 (11) 305 50 25 +381 (11) 305 50 24			
Singapore	INFOTEL TECHNOLOGIES Ltd. 19 Tai Seng Drive #02-01 HeShe Building Singapore 535227	+65 65 80 77 77 +65 62 87 65 77 general@infotel.com.sg			

Trinidad & Tobago	siehe / see Mexico		
Tunisia	TELETEK 71, Rue Alain Savary Residence Alain Savary (C64) 1003 Tunis		
Turkey	ROHDE & SCHWARZ International GmbH Liaison Office Istanbul Bagdad Cad. 191/3, Arda Apt. B-Blok 81030 Selamicesme-Istanbul	+90 (216) 385 19 17 +90 (216) 385 19 18 rsturk@superonline.com	
Ukraine	ROHDE & SCHWARZ Representative Office Kiev 4, Patris Loumoumba ul 01042 Kiev	+38 (044) 268 60 55 +38 (044) 268 83 64 rohdeukr@rsoe.rohde-schwarz.com	
United Arab Emirates	ROHDE & SCHWARZ International GmbH Liaison Office Abu Dhabi P.O. Box 31156 Abu Dhabi	+971 (2) 633 56 70 +971 (2) 633 56 71 michael.rogler@rsd.rohde-schwarz.com	
United Arab Emirates	ROHDE & SCHWARZ Bick Mobile Communication P.O.Box 17466 Dubai	+971 (4) 883 71 35 +971 (4) 883 71 36 www.rsbeck.de	
United Arab Emirates	ROHDE & SCHWARZ Emirates L.L.C. Ahmed Al Nasri Building, Mezzanine Floor, P.O.Box 31156 Off old Airport Road Behind new GEMACO Furniture Abu Dhabi	+971 (2) 631 20 40 +971 (2) 631 30 40 rsuaeam@emirates.net.ae	
United Kingdom	ROHDE & SCHWARZ UK Ltd. Ancells Business Park Fleet Hampshire GU 51 2UZ England	+44 (1252) 81 88 88 (sales) +44 (1252) 81 88 18 (service) +44 (1252) 81 14 47 sales@rsuk.rohde-schwarz.com	
Uruguay	AEROMARINE S.A. Cerro Largo 1497 11200 Montevideo	+598 (2) 400 39 62 +598 (2) 401 85 97 mjm@aeromarine.com.uy	
USA	ROHDE & SCHWARZ, Inc. Broadcast & Comm. Equipment (US Headquarters) 8661-A Robert Fulton Drive Columbia, MD 21046-2265	+1 (410) 910 78 00 +1 (410) 910 78 01 rsatv@rsa.rohde-schwarz.com rsacomms@rsa.rohde-schwarz.com	
USA	Rohde & Schwarz Inc. Marketing & Support Center / T&M Equipment 2540 SW Alan Blumlein Way M/S 58-925 Beaverton, OR 97077-0001	+1 (503) 627 26 84 +1 (503) 627 25 65 info@rsa.rohde-schwarz.com	
USA	Rohde & Schwarz Inc. Systems & EMI Products 8080 Tristar Drive Suite 120 Irving, Texas 75063	+1 (469) 713 53 00 +1 (469) 713 53 01 info@rsa.rohde-schwarz.com	
Venezuela	EQUILAB TELECOM C.A. Centro Seguros La Paz Piso 6, Local E-61 Ava. Francisco de Miranda Boleita, Caracas 1070	+58 (2) 12 34 46 26 +58 (2) 122 39 52 05 r_ramirez@equilabtelecom.com	
Venezuela	REPRESENTACIONES BOPIC S.A. Calle C-4 Qta. San Jose Urb. Caurimare Caracas 1061	+58 (2) 129 85 21 29 +58 (2) 129 85 39 94 incotr@cantv.net	
Vietnam	Schmidt Vietnam Co., (H.K.) Ltd., Representative Office in Hanoi Intern. Technology Centre 8/F, HITC Building 239 Xuan Thuy Road Cau Giay, Tu Liem Hanoi		+84 (4) 834 61 86 +84 (4) 834 61 88 svnhn@schmidtgroup.com
West Indies	siehe / see Mexico		

Contents of Manual for Spectrum Analyzer R&S FSH

Service Manual - Instrument

The Service Manual - Instrument describes how to check compliance with rated specifications, as well as instrument function, repair, troubleshooting and fault elimination. It contains all information required when repairing the R&S FSH by replacing modules.

This Service Manual consists of four chapters and an annex (chapter 5) that describes how to ship the instrument and to order spare parts.

- Chapter 1** provides all the information necessary to check for compliance with rated specifications. The required test equipment is also specified.
- Chapter 2** describes the manual adjustment of the calibration source and of the frequency accuracy as well as the automatic adjustment of individual module data following module replacement.
- Chapter 3** describes the design as well as simple measures for repair and fault diagnosis, including in particular the replacement of modules.
- Chapter 4** contains information about extensions and modifications by installing instrument software and retrofitting options.
- Chapter 5** describes how to ship the instrument and order spare parts, and contains spare parts lists.

Operating Manual

The Operating Manual provides information about the technical specifications, the controls and connectors on the front and rear panel, required steps for placing the instrument into operation, the basic operating concept, as well as manual and remote control.

Typical measurement tasks are explained in detail using the functions of the user interface and program examples.

The Operating Manual also provides useful information on preventive maintenance and fault diagnosis by means of warnings and error messages output by the unit.

Quick Start Manual

The Quick Start Manual provides information about typical measurement tasks, the basic operation concept, as well as manual and remote control. Each of these items is explained in detail using the functions of the user interface and program examples.

Service and Repair

If your equipment requires service or repair or if you want to order spare parts and modules, please contact your Rohde & Schwarz support center or our spare parts express service.

Rohde & Schwarz representatives and the address of our spare parts express service are listed in the front section of this service manual.

You will need to provide the following information in order for us to respond to your inquiries quickly and accurately and to determine whether the warranty for your instrument is still valid:

- Instrument model
- Serial number
- Firmware version
- Detailed error description in case of repair
- Contact partner for checkbacks

Rohde & Schwarz offers the following calibrations:

- Calibration on R&S-type test systems. The calibration documentation meets the requirements of the quality management system ISO 9000.
- Calibration at an R&S calibration center approved by the German Calibration Service (DKD). The calibration documentation consists of the DKD calibration certificate.

Refer to Chapter 5 for a detailed description of how to ship the instrument and to order spare parts.

1 Performance Test

Test Instructions

- The rated specifications of the analyzer are tested after a warm-up time of at least 15 minutes. Only by adhering to this requirement can compliance with the guaranteed data be ensured.
- Values specified in the following sections are not guaranteed. Only the technical specifications provided on the data sheet are binding.
- The values specified in the data sheet are the guaranteed limits.
- Inputs for settings during measurements are shown as following:

[<KEY>] Press a key on the front panel, eg [SPAN]

[<SOFTKEY>] Press a softkey, e.g. [MARKER -> PEAK].

[<nn unit>] Enter a value and terminate by entering the unit, e.g. [12 kHz].

Successive entries are separated by [:], e.g. [BW : MANUAL RES BW : 3 kHz].

Measuring Equipment and Accessories

Item	Type of equipment	Specifications recommended	Equipment recommended	R&S order no.	Use
1	Signal generator	Frequency: R&S [®] FSH3 10 MHz to 3 GHz R&S [®] FSH6 10 MHz to 6 GHz Uncertainty of frequency: 0.1 ppm Phase noise at 500 MHz: < -100 dBc (1Hz) @ 10 kHz < -110 dBc (1Hz) @ 100 kHz < -130 dBc (1Hz) @ 1 MHz	R&S SML03 R&S SMT06	1090.3000.13 1039.2000.06	Frequency response Frequency accuracy of reference oscillator
2	6-dB divider (power splitter)		Weinschel 1506A		Frequency response
3	Power meter		R&S NRVD	0857.8008.02	Frequency response
4	Power sensor	1 MHz to 6 GHz RSS ≤ 0.8% Meter noise ≤ 20 pW	R&S NRV-Z4	0828.3618.02	Frequency response
5	N cable	Attenuation < 1 dB to 6 GHz			Tracking generator output level
6	50-Ω termination	1 MHz to 6 GHz Return loss ≤ -10 dB			Noise display

Performance Test

Checking the frequency accuracy

- Test equipment: Signal generator (refer to section "Measurement Equipment and Accessories", item 1)
- Test setup: ➤ Connect the signal generator to the RF input of the R&S FSH.
- Signal generator settings:
- Frequency 1 GHz
 - Level -30 dBm
- R&S FSH settings:
- [**PRESET**]
 - [**FREQ : 1 GHz**]
 - [**SPAN : 100 kHz**]
 - [**BW : MANUAL RES BW : 10 kHz**]
 - [**MARKER : MARKER MODE : FREQ COUNT**]
- Measurement: ➤ Read out the frequency value (Count:) of the marker.
- Nominal frequency: 1.0 GHz ± 1 kHz
- Note:** *The frequency of the reference oscillator can be adjusted by means of a service function (refer to Chapter 2 "Adjustment").*

Checking the level accuracy and the frequency response

- Test equipment:
- Signal generator (refer to section "Measurement Equipment and Accessories", item 1)
 - Power meter (refer to section "Measurement Equipment and Accessories", item 3)
 - Power sensor (refer to section "Measurement Equipment and Accessories", item 4)
 - 6-dB power splitter (refer to section "Measurement Equipment and Accessories", item 2)

Determining the level accuracy at 100 MHz

- Test setup:
- Connect the power sensor (item 4) to the power meter and execute function 'ZERO' when there is no signal applied to the power sensor.
 - Connect the RF output of the signal generator to the input of the divider.
 - Connect output 1 of the divider to the power sensor / power meter.
 - Connect output 2 of the divider to the RF input of the R&S FSH.

- Signal generator settings:
- Frequency 100 MHz
 - Level 6 dBm
- Determine the output power of the signal generator with the power meter. Adjust the output power of the generator until the power meter shows 0 dBm.

- R&S FSH settings:
- [**PRESET**]
 - [**FREQ : 100 MHz**]
 - [**AMPT: 0 dBm**]
 - [**SPAN : 100 kHz**]
 - [**BW : MANUAL RES BW : 10 kHz**]
 - [**TRACE : DETECTOR : RMS**]
- Set the marker to the peak of the signal.
 - [**MARKER: SET MARKER: PEAK**]

Evaluation: The difference between the signal levels measured with the power meter and the level reading of the marker reflects the absolute level error of the R&S FSH. It can be calculated as:

$$\text{Level error}_{100\text{ MHz}} = L - L_{\text{powermeter}}$$

Checking the frequency response

For the measurement of the frequency response, the value at 100 MHz for each reference level setting is used as the reference. The reference level influences the RF attenuation (RF attenuation = +10 dBm + reference level).

- Test setup:
- Connect the RF output of the signal generator to the input of the divider.
 - Connect output 1 of the divider to the power sensor / power meter.
 - Connect output 2 of the divider to the RF input of the SA..

- Signal generator settings:
- Frequency $\{f_{in}\}^*$
 - Level -4 dBm

Determine the output power of the signal generator with the power meter. Adjust the output power of the generator until the power meter shows -10 dBm.

- R&S FSH settings:
- [**PRESET**]
 - [**AMPT** : Ref_Lev*)]
 - [**SPAN** : 100 kHz]
 - [**BW** : MANUAL RES BW : 10 kHz]
 - [**TRACE** : DETECTOR : RMS]
 - [**FREQ** : CENTER : $\{f_{in}\}^*$]
 - [**SETUP** : Hardware Setup: Low Noise]

*) Refer to table under "Performance Test Report" for values of Ref_Lev and f_{in} .

If the a RF preamplifier is installed, its frequency response has to be checked also. To switch it on please enter:

- Reference measurement:
- [**SETUP** : Hardware Setup: Preamp: ON]
 - Determine signal level $L_{\text{powermeter}}$.
 - Set the marker to the peak of the signal.
 - [**MARKER**: SET MARKER: PEAK]

The signal level L is displayed by the level reading of the marker.

$$\text{Ref}_{100\text{MHz}} = L - L_{\text{powermeter}}$$

Measurement

- Signal generator settings:
- Frequency $\{f_{in}\}$
- Refer to table under "Performance Test Report" for values of $\{f_{in}\}$.

- Power meter settings:
- Determine the signal level $L_{\text{powermeter}}$. To achieve higher accuracy, compensating the frequency response of the power sensor is recommended.

- R&S FSH settings:
- [**FREQ** : $\{f_{in}\}$]

Refer to table under "Performance Test Report" for values of $\{f_{in}\}$.

- Set the marker to the peak of the signal.

- [**MARKER**: SET MARKER: PEAK]

The signal level L is displayed by the level reading of the marker.

Evaluation:

The frequency response can be calculated as:

$$\text{Frequency response} = L - L_{\text{powermeter}} - \text{Ref}_{100\text{ MHz}}$$

Checking the accuracy of the RF attenuator

- Test principle: The RF attenuator of the R&S FSH can be switched from 0 to 30 dB in 10-dB increments by changing the reference level (RF attenuation = +10 dBm + reference level).
- Test equipment:
- Signal generator (refer to section "Measurement Equipment and Accessories", item 3)

Frequency	100 MHz
Maximum level	≥ 6 dBm
- Test setup:
- Connect the RF output of the signal generator to the input of the divider.
 - Connect output 1 of the divider to the power sensor / power meter.
 - Connect output 2 of the divider to the RF input of the R&S FSH.
- Signal generator settings:
- Frequency 100 MHz
 - Level -14 dBm
 - Determine the output power of the signal generator with the power meter. Adjust the output power of the signal generator until the power meter shows -20 dBm ± 0.2 dB.
- R&S FSH settings:
- [**PRESET**]
 - [**FREQ : 100 MHz**]
 - [**SPAN : 10 kHz**]
 - [**BW : MANUAL RES BW : 1 kHz**]
 - [**BW : MANUAL VIDEO BW : 100 Hz**]
 - [**TRACE : DETECTOR : RMS**]
 - [**AMPT : 0 dBm**]
 - [**SETUP : Hardware Setup: Low Noise**]
- Reference measurement:
- Set the marker to the peak of the signal.
[**MARKER: SET MARKER: PEAK**]

The signal level L is displayed by the level reading of the marker.

$$\text{Ref}_{0\text{dBm}} = L - L_{\text{powermeter}}$$

Measurement

- Signal generator settings:
- Frequency 100 MHz
 - Level Ref_Lev *) – 14 dB
- *) Refer to table under "Performance Test Report" for values of {Ref_Lev}.
- Determine the output power of the signal generator with the power meter. Adjust the output power of the generator until the power meter shows the value Ref_Lev – 10 dB.
- R&S FSH settings:
- [**AMPT : {Ref_Lev}**]
 - [**MARKER: SET MARKER: PEAK**]

Evaluation: The signal level L is displayed by the level reading of the marker.

The difference between the level inaccuracy of the R&S FSH and $\text{Ref}_{0\text{dBm}}$ (at 10 dB RF-Att) is the uncertainty of the RF attenuation:

$$\text{IF-Gain}_{\text{accuracy}} = (L - L_{\text{powermeter}}) - \text{Ref}_{0\text{dBm}}$$

Checking the accuracy of the IF gain setting

- Test principle: The IF gain of the R&S FSH can be switched from 0 to 15 dB by changing the reference level.
- Test equipment:
- Signal generator (refer to section "Measurement Equipment and Accessories", item 3)

Frequency	100 MHz
Maximum level	≥ -10 dBm
- Test setup:
- Connect the RF output of the signal generator to the input of the divider.
 - Connect output 1 of the divider to the power sensor / power meter.
 - Connect output 2 of the divider to the RF input of the SA.
- Signal generator settings:
- Frequency 100 MHz
 - Level -4 dBm
 - Determine the output power of the signal generator with the power meter. Adjust the output power of the generator until the power meter shows $-10 \text{ dBm} \pm 0.2 \text{ dB}$.
- R&S FSH settings:
- [**PRESET**]
 - [**FREQ: 100 MHz**]
 - [**SPAN : 10 kHz**]
 - [**BW : MANUAL RES BW: 1 kHz**]
 - [**BW : MANUAL VIDEO BW : 100 Hz**]
 - [**TRACE : DETECTOR : RMS**]
 - [**AMPT : Ref_Lev ***]
- *) Refer to table under "Performance Test Report" for values of {Ref_Lev}.
- Reference measurement:
- Set the marker to the peak of the signal.
 - [**MARKER: SET MARKER: PEAK**]
- The signal level L is displayed by the level reading of the marker.
- $$\text{Ref}_{-10\text{dBm}} = L - L_{\text{powermeter}}$$

Measurement

- Signal generator settings:
- Frequency 100 MHz
 - Level Ref_Lev + 6 dB
 - Determine the output power of the signal generator with the power meter. Adjust the output power of the generator until the power meter shows the value $\text{Ref_Lev} \pm 0.2 \text{ dB}$.
- R&S FSH settings:
- [**AMPT : {Ref_Lev}**]
 - *) Refer to table under "Performance Test Report" for values of Ref_Lev.
 - [**MARKER: SET MARKER: PEAK**]
- Evaluation:
- The signal level L is displayed by the level reading of the marker.
The difference between the level inaccuracy of the R&S FSH and $\text{Ref}_{-10\text{dBm}}$ (at 0 dB IF gain) is the uncertainty of the IF gain:
- $$\text{IF-Gain}_{\text{accuracy}} = (L - L_{\text{powermeter}}) - \text{Ref}_{-10\text{dBm}}$$

Checking the displayed average noise floor

Test equipment:	50- Ω termination (refer to section "Measurement Equipment and Accessories", item 6)
Test setup:	➤ Terminate the RF input of the R&S FSH with 50 Ω .
R&S FSH settings:	<ul style="list-style-type: none">- [PRESET]- [SPAN : ZERO SPAN]- [Manual Res BW : 1 kHz]- [Manual Video BW : 10 Hz]- [TRACE : TRACE MODE: AVERAGE]- [AMPT : -30 dBm]- [FREQ : {f_n}] Refer to table under "Performance Test Report" for values of f _n .
Measurement:	➤ Read out the marker level.
Evaluation:	The displayed average noise floor is displayed by the level reading of the marker.

Checking the phase noise

Test equipment: Signal generator (refer to section "Measurement Equipment and Accessories", item 3)

Frequency	500 MHz
Level	≥ 0 dBm
Phase noise at 500 MHz:	< -100 dBc (1Hz) @ 10 kHz
	< -110 dBc (1Hz) @ 100 kHz
	< -120 dBc (1Hz) @ 1 MHz

Test setup: ➤ Connect the RF output of the signal generator to the RF input of the R&S FSH.

Signal generator settings:

- Frequency 500 MHz
- Level 8 dBm *)

*) The overrange of the AD converter is used for higher dynamic range.

R&S FSH settings:

- [**PRESET**]
- [**FREQ : 500 MHz**]
- [**AMPT : 0 dBm**]
- [**SPAN : {span}**]
- [**BW : RBW MANUAL : {RBW}**]

Depending on the offset, refer to the table below for values of RBW and span.

- [**TRACE : TRACE MODE: AVERAGE**]
- Marker to peak
[**MARKER: SET MARKER: PEAK**]
- Delta marker to {offset}
[**MARKER: DELTA: {offset}: kHz**]
- Set marker mode to noise measurement
[**MARKER: MARKER MODE: NOISE**]

Evaluation: The phase noise is displayed in the marker field by the reading Delta [dBc/Hz].

Phase noise measurement settings		
Offset	Span	RBW
30 kHz	100 kHz	1 kHz
100 kHz	220 kHz	10 kHz
1 MHz	2.2 MHz	100 kHz

Checking the display linearity

- Test equipment:
- Signal generator (refer to section "Measurement Equipment and Accessories", item 1)
 - Power meter (refer to section "Measurement Equipment and Accessories", item 3)
 - Power sensor (refer to section "Measurement Equipment and Accessories", item 4)
 - 6-dB power splitter (refer to section "Measurement Equipment and Accessories", item 2)

- Test setup:
- Connect the power sensor (item 4) to the power meter and execute function 'ZERO' when there is no signal applied to the power sensor.
 - Connect the RF output of the signal generator to the input of the divider.
 - Connect output 1 of the divider to the power sensor / power meter.
 - Connect output 2 of the divider to the RF input of the R&S FSH.

1st Measurement

0 to 30 dB below reference level

- Signal generator settings:
- Frequency 100 MHz
 - Level + 6 dBm
- Determine the output power of the signal generator with the power meter. Adjust the output power of the generator until the power meter shows 0 dBm.

- R&S FSH settings:
- [**PRESET**]
 - [**AMPT: 0 dBm**]
 - [**FREQ: 100 MHz**]
 - [**SPAN : 10 kHz**]
 - [**Manual Res BW : 1 kHz**]
 - [**Manual SWPTime : 1 s**]
 - [**TRACE : DETECTOR : RMS**]

- Reference measurement:
- Set the marker to the peak of the signal.
 - [**MARKER: SET MARKER: PEAK**]

The signal level L is displayed by the level reading of the marker.

$$\text{Ref}_{0\text{dBm}} = L - L_{\text{powermeter}}$$

- Signal generator settings:
- Frequency 100 MHz
 - Level Sig_Lev + 6 dB

Refer to table under "Performance Test Report" for values of {Sig_Lev}.

- Determine the output power of the signal generator with the power meter. Adjust the output power of the generator until the power meter shows the value of {Sig_Lev}.

Evaluation: The signal level L is displayed by the level reading of the marker.
The difference between the level inaccuracy of the R&S FSH and Ref_{0dBm} is the uncertainty of the display linearity:

$$Linearity_{uncertainty} = (L - L_{powermeter}) - Ref_{0dBm}$$

2nd Measurement

30 to 50 dB below reference level

Because the sensitivity of the power meter is limited, the internal RF attenuator of the Galaxy is used to increase the dynamic range of the input signal.

R&S FSH settings:

- [**AMPT: 20 dBm**]

Signal generator settings:

- Frequency 100 MHz
- Level - 4 dBm

- Determine the output power of the signal generator with the power meter. Adjust the output power of the generator until the power meter shows -10 dBm.

Reference measurement:

- Set the marker to the peak of the signal.
- [**MARKER: SET MARKER: PEAK**]

The signal level L is displayed by the level reading of the marker.

With the result of the 1st linearity measurement, a new correction factor is to be calculated. "Linearity_{uncertainty} (-30dB)" is the measured uncertainty of the R&S FSH linearity at 30 dB below reference level.

$$Ref_{20dBm} = (L - L_{powermeter}) - Linearity_{uncertainty} (-30dB)$$

Signal generator settings:

- Frequency 100 MHz
- Level Sig_Lev + 6 dB

Refer to table under "Performance Test Report" for values of {Sig_Lev}.

- Determine the output power of the signal generator with the power meter. Adjust the output power of the generator until the power meter shows the value Sig_Lev ± 0.2 dB.

Evaluation:

The signal level L is displayed by the level reading of the marker.

The difference between the level inaccuracy of the R&S FSH and Ref_{20dBm} is the uncertainty of the display linearity:

$$Linearity_{uncertainty} = (L - L_{powermeter}) - Ref_{20dBm}$$

Performance Test Report

Table 1-1 Performance Test Report

ROHDE & SCHWARZ	Performance Test Report	Spectrum Analyzer	Version 2 April 2004
Model (): Order number: Serial number: Test person: Date: Sign:			

Characteristic	Included in	Min. value	Actual value	Max. value	Unit	Measurement uncertainty
Frequency accuracy Reference oscillator	Page 1.2	0.999999	_____	1.000001	GHz	
Level accuracy at 100 MHz with Ref_Lev = 0 dBm	Page 1.3	-0.5	_____	+0.5	dB	

Characteristic	Included in	Min. value	Actual value	Max. value	Unit	Measurement uncertainty
Frequency response with Ref_Lev = 20 dBm	Page 1.3					
f_{fresp}						
10 MHz		-1	_____	+1	dB	
100 MHz			Reference		dB	
500 MHz		-1	_____	+1	dB	
1000 MHz		-1	_____	+1	dB	
1500 MHz		-1	_____	+1	dB	
2000 MHz		-1	_____	+1	dB	
2500 MHz		-1	_____	+1	dB	
2990 MHz		-1	_____	+1	dB	
R&S°FSH6 only :						
3500 MHz		-1	_____	+1	dB	
4000 MHz		-1	_____	+1	dB	
4500 MHz		-1	_____	+1	dB	
5000 MHz		-1	_____	+1	dB	
5500 MHz		-1	_____	+1	dB	
5990 MHz		-1	_____	+1	dB	
Frequency response with Ref_Lev = 10 dBm	Page 1.3					
f_{fresp}						
10 MHz		-1	_____	+1	dB	
100 MHz			Reference		dB	
500 MHz		-1	_____	+1	dB	
1000 MHz		-1	_____	+1	dB	
1500 MHz		-1	_____	+1	dB	
2000 MHz		-1	_____	+1	dB	
2500 MHz		-1	_____	+1	dB	
2990 MHz		-1	_____	+1	dB	
R&S°FSH6 only :						
3500 MHz		-1	_____	+1	dB	
4000 MHz		-1	_____	+1	dB	
4500 MHz		-1	_____	+1	dB	
5000 MHz		-1	_____	+1	dB	
5500 MHz		-1	_____	+1	dB	
5990 MHz		-1	_____	+1	dB	

Characteristic	Included in	Min. value	Actual value	Max. value	Unit	Measurement uncertainty
Frequency response with Ref_Lev = 0 dBm	Page 1.3					
f_{resp}						
10 MHz		-1	_____	+1	dB	
100 MHz			Reference		dB	
500 MHz		-1	_____	+1	dB	
1000 MHz		-1	_____	+1	dB	
1500 MHz		-1	_____	+1	dB	
2000 MHz		-1	_____	+1	dB	
2500 MHz		-1	_____	+1	dB	
2990 MHz		-1	_____	+1	dB	
R&S [®] FSH6 only :						
3500 MHz		-1	_____	+1	dB	
4000 MHz		-1	_____	+1	dB	
4500 MHz		-1	_____	+1	dB	
5000 MHz		-1	_____	+1	dB	
5500 MHz		-1	_____	+1	dB	
5990 MHz		-1	_____	+1	dB	
Frequency response with Ref_Lev = -10 dBm	Page 1.3					
f_{resp}						
10 MHz		-1	_____	+1	dB	
100 MHz			Reference		dB	
500 MHz		-1	_____	+1	dB	
1000 MHz		-1	_____	+1	dB	
1500 MHz		-1	_____	+1	dB	
2000 MHz		-1	_____	+1	dB	
2500 MHz		-1	_____	+1	dB	
2990 MHz		-1	_____	+1	dB	
R&S [®] FSH6 only :						
3500 MHz		-1	_____	+1	dB	
4000 MHz		-1	_____	+1	dB	
4500 MHz		-1	_____	+1	dB	
5000 MHz		-1	_____	+1	dB	
5500 MHz		-1	_____	+1	dB	
5990 MHz		-1	_____	+1	dB	

Characteristic	Included in	Min. value	Actual value	Max. value	Unit	Measurement uncertainty
Displayed average Noise floor with PreAmp = ON (only if PreAmp is implemented)	Page 1.7					
f_{noise} :						
9.9 MHz		-	_____	-120	dBm	
101 MHz		-	_____	-120	dBm	
501 MHz		-	_____	-120	dBm	
1001 MHz		-	_____	-120	dBm	
1501 MHz		-	_____	-120	dBm	
2001 MHz		-	_____	-120	dBm	
2499 MHz		-	_____	-120	dBm	
2999 MHz		-	_____	-115	dBm	
R&S°FSH6 only :						
3501 MHz		-	_____	-115	dBm	
4001 MHz		-	_____	-115	dBm	
4501 MHz		-	_____	-115	dBm	
4999 MHz		-	_____	-115	dBm	
5501 MHz		-	_____	-105	dBm	
5999 MHz		-	_____	-105	dBm	
Phase noise at 500 MHz	Page 1.8					
Offset frequency:						
30 kHz		-	_____	-85	dBc (1Hz)	
100 kHz		-	_____	-100	dBc (1Hz)	
1 MHz		-	_____	-120	dBc (1Hz)	

Characteristic	Included in	Min. value	Actual value	Max. value	Unit	Measurement uncertainty
Display linearity 0 to -30 dB Reference level: 0 dBm Sig_Lev : 0 dBm -5 dBm -10 dBm -15 dBm -20 dBm - 25 dBm - 30 dBm	Page 1.9	- -0.2 -0.2 -0.2 -0.2 -0.2 -0.2	Reference _____ _____ _____ _____ _____ _____	- +0.2 +0.2 +0.2 +0.2 +0.2 +0.2	- dB dB dB dB dB dB	
Display linearity -30 to -50 dB Reference level: 20 dBm Sig_Lev : -10 dBm -15 dBm -20 dBm - 25 dBm - 30 dBm	Page 1.9	- -0.3 -0.3 -0.3 -0.3	Reference _____ _____ _____ _____	- +0.3 +0.3 +0.3 +0.3	- dB dB dB dB	

Performance Test Report Tracking Generator

(model 1145.5850.13, 1145.5850.23 or 1145.5850.26 only)

Table 1-2 Performance Test Report

ROHDE & SCHWARZ	Performance Test Report	Option -B9	Version 2 April 2004
Serial number: Test person: Date: Sign:			

Characteristic	Included in	Min. value	Actual value	Max. value	Unit	Measurement uncertainty
R&S°FSH3: Level accuracy output level: -20 dBm Maximum value Minimum value	Page 1.11	-3 -7	_____ _____	+5 -1	dB dB	
R&S°FSH3: Level accuracy output level: 0 dBm (model 1145.5850.23 only) Maximum value Minimum value	Page 1.11	-3 -7	_____ _____	+5 -1	dB dB	
R&S°FSH6: Level accuracy 10 MHz to: 3 GHz Maximum value Minimum value 3 GHz to 6 GHz Maximum value Minimum value	Page 1.11	-2 -5 2 -11	_____ _____ _____ _____	+6 +4 11 6	dB dB dB dB	

2 Adjustment

This chapter describes the adjustment of the software-controlled module data following the replacement of modules.

Adjustments can be performed only by using the adjustment program that is available from the R&S Service Board on the R&S Internet site. Using this program prevents mistakes in the calibration data.

The R&S FSH permits the following manual adjustments:

- Adjustment of the 10-MHz reference oscillator that determines the frequency accuracy of the R&S FSH.
- Adjustment of the level accuracy of the R&S FSH for different attenuator settings.

Adjustment enables you to maintain and restore the data integrity of the instrument.

Manual adjustments must be performed at an ambient temperature between +20°C and +30°C after the instrument has warmed up.

After the adjustments have been performed, the R&S FSH is ready for use and offers full data integrity. This can be verified by performing the Performance Test as described in Chapter 1.

Verifying the functionality of the R&S FSH is recommended before you start performing adjustments or the performance test. The verification procedure is described in the following section, "Quick Verification".

Quick Verification

The quick verification procedure verifies hardware functionality before full testing can start. Testing of the following is recommended:

- On/off functionality
- Connections of the power adapter and the AF output
- Display
- Level and noise

Measurement Equipment and Accessories for Quick Verification

The quick verification procedure requires a very limited amount of equipment.

Item	Type of equipment	Specifications recommended	Equipment recommended	R&S order no.	Use
1	Signal generator	Frequency: 10 MHz to 3 GHz	R&S SML		Level
2	N-cable	Attenuation: < 0.2 dB to 3 GHz			Tracking generator output level

Verifying on/off functionality

Test equipment	None
R&S FSH settings	Switch instrument ON.
Measurement	➤ Verify that the instrument switches ON.

Verifying power and AF connections

Test equipment	None
Accessories	AC power adapter Headphone
R&S FSH settings	Switch instrument ON. Connect the AC power supply.
Reference measurement	➤ Verify in the display that the battery symbol changes to a power plug.
R&S FSH settings	Connect the headphone. - [Marker : MARKER DEMOD : AM]
Reference measurement	➤ Verify that a noise signal is heard on the headphone.

Verifying the display

Test equipment	None
R&S FSH settings	Switch instrument ON.
Reference measurement	➤ Check the display for disturbance.

Verifying the level and noise

Test principle The RF attenuator of the R&S FSH can be switched from 0 to 30 dB by changing the reference level in the instrument.

Test equipment

- Signal generator (refer to section "Measurement Equipment and Accessories for Quick Verification", item 1).

Frequency	100 MHz
Maximum level	≥ 6 dBm

Test setup ➤ Connect the RF output of the signal generator to the input of the R&S FSH.

Signal generator settings

- Frequency 100 MHz
- Level - 20 dBm

R&S FSH settings

- [**PRESET**]
- [**FREQ : 100 MHz**]
- [**SPAN : 10 kHz**]
- [**BW : RES BW MANUAL : 1 kHz**]
- [**BW : VIDEO BW MANUAL : 100 Hz**]
- [**TRACE : DETECTOR : RMS**]
- [**AMPT : 0 dBm**]

Verification

- Read the level and verify that it shows -20 dBm +/- 2 dB.
- Verify that the noise level in the display is < - 60 dBm.

Check 30 dB attenuation

Change signal generator setting - Level -30 dBm

Change R&S FSH setting - [**AMPT : -10 dBm**]

Verification ➤ Read the level and verify that it shows -30 dBm +/- 2 dB.

Check 10 dB attenuation

Change signal generator setting - Level -10 dBm

Change R&S FSH setting - [**AMPT : 10 dBm**]

Verification ➤ Read the level and verify that it shows -10 dBm +/- 2 dB.

Check 0 dB attenuation

Change signal generator setting - Level 0 dBm

Change R&S FSH setting - [**AMPT : 20 dBm**]

Verification ➤ Read the level and verify that it shows 0 dBm +/- 2 dB.

Verify the tracking generator output level

Test principle	The generator output must be connected to the RF input and verified.
Test equipment	None
Test setup	➤ Connect the generator output of the R&S FSH to the RF input.
R&S FSH settings	- [PRESET] - [MEAS : TRACKING GEN :]
Verification	➤ Verify that the level of the sweep shows 0 dB +5 /-7 dB. ➤ <i>Following internal calibration, verify that the level shows 0 +/-1 dB.</i>

Adjustment functions



Caution:

Only qualified personnel should carry out the re-alignment since any change substantially influences the measurement accuracy of the instrument. For this reason, the calibration program is available only on the R&S Service Board.

Adjustment

This section describes the measurement equipment and accessories required for the manual adjustment of the R&S FSH, the appropriate preparations of the equipment, and the individual adjustments.

An adjustment program provides the instructions for the input settings.

Adjustment Instructions

- The adjustment of the analyzer must be performed after a warm-up time of at least 30 minutes. Only by adhering to this requirement can compliance with the guaranteed data be ensured.
- Inputs for setting the R&S FSH during adjustment will be programmed automatically.

Measurement Equipment and Accessories

Item	Type of equipment	Specifications recommended	Equipment recommended	R&S order no.	Use
1	Signal generator	Frequency: 10 MHz to 3 GHz Uncertainty of frequency: 0.1 ppm Phase noise at 500 MHz: < -100 dBc (1Hz) @ 10 kHz < -110 dBc (1Hz) @ 100 kHz < -130 dBc (1Hz) @ 1 MHz	R&S SML		Frequency accuracy of reference oscillator
2	6-dB divider (power splitter)				Frequency response
3	Power meter		R&S NRVD	0857.8008.02	Frequency response
4	Power sensor	1 MHz to 3 GHz RSS ≤ 0.8% Meter noise ≤ 20 pW	R&S NRV-Z4	0828.3618.02	Frequency response

Adjusting the reference frequency accuracy

Test equipment	Signal generator (refer to section "Measurement Equipment and Accessories", item 2)
Test setup	➤ Connect the generator to the RF input.
Generator settings	- Frequency 1 GHz - Level -30 dBm
R&S FSH settings	- [PRESET] - [FREQ : 1 GHz] - [SPAN : 100 kHz] - [BW : MANUAL RES BW : 10 kHz] - [MARKER : MARKER MODE : FREQ COUNT]
Adjustment	The program will adjust the reference oscillator to 10 MHz ± 1 ppm.

Adjusting the level accuracy

- Test equipment
- Signal generator (refer to section "Measurement Equipment and Accessories ", item 1)
 - Power meter (refer to section "Measurement Equipment and Accessories ", item 3)
 - Power sensor (refer to section "Measurement Equipment and Accessories ", item 4)
 - 6-dB power splitter (refer to section "Measurement Equipment and Accessories ", item 2)

Determining the level accuracy at 100 MHz

- Test setup
- Connect the power sensor (item 4) to the power meter and execute function 'ZERO' when there is no signal applied to the power sensor.
 - Connect the RF output of the signal generator to the input of the divider.
 - Connect output 1 of the divider to the power sensor / power meter.
 - Connect output 2 of the divider to the RF input of the R&S FSH.
- Signal generator settings
- Frequency 100 MHz
 - Level 6 dBm
 - Determine the output power of the signal generator with the power meter. Adjust the output power of the generator until the power meter shows the expected level "Ampt". This level is displayed on the PC display during adjustment.
- R&S FSH settings
- Performed automatically via the adjustment program.
- Adjustment
- The program will guide you through the required adjustments for different levels.
- Save calibration data**
- If the measured values are within the programmed limits, the new constants will be automatically stored in the R&S FSH and will be used for future measurements.

Frequency Response Correction

Frequency response correction is part of the RF/IF module and is delivered with the module in an EEPROM. Any change requires the use of a special test program and test setup. If necessary, the module must be sent to R&S Service.

3 Repair

This chapter describes the design of the R&S FSH, simple measures for repair and troubleshooting, and, in particular, the replacement of modules.

Firmware updates and the installation of the DTF option are described in Chapter 4.

Instrument Design and Functional Description

The following figure shows a block diagram of the R&S FSH.




Fig. 3-1 Block Diagram R&S FSH

Description of the block diagram

The R&S FSH is a triple-conversion super-heterodyne receiver for the frequency range 100 kHz to 3 GHz. After signals are received, they are processed by the RF/IF board and the mainboard.

The RF/IF board contains the functions as described below.

Attenuator

The RF signal passes from the input connector RF INPUT to the programmable input attenuator, which can be switched from 0 dB to 30 dB in increments of 10 dB. The circuitry is protected from overvoltage.

RF to IF conversion

The RF/IF board converts the received frequencies in the range 100 kHz to 3 GHz to the low 31.25 MHz IF, which is digitized with 25 MHz before it is sent to the mainboard for digital processing. The RF/IF board also includes the required local oscillators and associated frequency processing circuits. The unit is housed in silver-plated aluminum packaging.

The input signal passes via the input attenuator and the lowpass filter to the first mixer. The lowpass filter provides suppression of the image frequency (image = $LO + IF$) to keep the conversion unambiguous. In the 1st mixer the input signal is up-converted to an IF of 4031.25 MHz by means of the first LO (4031.25 MHz to 7031.25 MHz). The mixer is followed by a low noise IF amplifier, which compensates for the loss due to mixing. The signal then passes a filter with a 3-dB bandwidth of approximately 400 MHz for filtering the first IF. The local oscillator frequency required for this conversion is also generated on the board. This signal is generated by three VCOs synchronized to 100 MHz, which in turn is synchronized to a Temperature Compensated 10-MHz Xtal Oscillator (TCXO). This TCXO is electrically calibrated.

The signal from the 1st IF filter is converted to the 2nd IF of 831.25 MHz. The signal is routed to an 831.25 MHz filter with a 3-dB bandwidth of 20 MHz for further signal processing. The filter is followed by the 3rd mixer, which converts to 31.25 MHz and utilizes an IF filter that has a -3-dB bandwidth of approximately 2 MHz.

The frequency range above 3°GHz in the R&S FSH6 is converted via two additional mixers to a first IF of 7231.25°MHz and to the same 2nd IF as in the FSH3 of 831.25 MHz. As LO signals the oscillator signals of the FSH3 are doubled.




Fig. 3-2 Block Diagram: RF to IF Conversion and Synthesizer

Tracking generator (Model 1145.5850.13/23/26 only)

The LO frequency of the 1st mixer is routed via isolation amplifiers to the TG mixer. The other input of the mixer is a fixed frequency of 4031.25 MHz generated with a VCO locked to the TCXO frequency.

The resulting IF signal is routed to the generator output connector.

RF/IF control

The microcontroller available on the mainboard controls the RF/IF setting by programming registers via an internal serial bus.

For calibration purposes the level correction values are stored in an EEPROM. This EEPROM also contains module-specific information.

The temperature of the module is continuously measured, and the measured levels will be compensated for drift if the temperature change is too great.

Mainboard

The mainboard is a combination of the power supply and the functions controlled by a dedicated RISC controller (ARM 720).

Power and battery management

The ON/OFF key is de-bounced with the real-time clock in the controller. The ON/OFF function is completely software controlled. This implies that the controller must be operational in order for the instrument to be switched ON. The μ P-clock (50 MHz) is derived from the RF/IF board, thus requiring that this board be present. This frequency will always be present if the power adapter is connected or the instrument is in the ON state.

If the instrument is in the OFF state and the power supply is connected, the μ P will control the charging function of the battery depending on the battery condition. The maximum charging current is 1000 mA, which drops to a trickle charge of about 100 mA if the battery is fully loaded. To prevent damage to the battery, the charging stops if the battery temperature reaches $\leq 0^{\circ}\text{C}$ or $> 45^{\circ}\text{C}$. In the OFF state, the charging current is approximately 90 mA.

This power supply and battery management arrangement uses a dedicated IC. The instrument can be switched ON only if the battery is in operating condition. Thus, if the battery is completely empty, the instrument cannot be switched ON until the charging current has re-loaded the battery, which takes several minutes.

Processing of measured data detectors

The measured data is processed in two dedicated ICs to reduce the sample rate of the input signal to a value that can be handled by the hardware. The DDC converts the digital IF signal to I/Q base band and filters the base band signals using low pass filters with programmable bandwidth. In addition it delivers the AM or FM demodulated audio signal. The DCON Asic detects the envelope of the filtered and combined base band signal and calculates its logarithm. It contains also the video filter and the different detectors. In addition it is responsible for the sweep control of the FSH.




Fig. 3-3 Measured Data Processing

Resolution bandwidths (RBW)

The resolution bandwidths are implemented in the R&S FSH through digital processing in the DDC ASIC (Digital Down Converter). The RBW can be selected from within the range 1 kHz to 1 MHz in 1-, 3- or 10-unit increments. The DDC first mixes its input IF to the baseband using an NCO (Numeric Controlled Oscillator) and then filters the resulting IQ signals via a combination of HDF (High Decimation Filter) and an FIR (Finite Impulse Response) stages. At the end of the DDC processing chain, the IQ signal is split into magnitude and phase.

For AF demodulation the amplitude information is used. In the case of FM the phase information is used and fed to the headphone connector. In the analyzer mode the signal at the position of the marker can be demodulated. In this case the R&S FSH stops the sweep for a selectable period of time and demodulates the input signal. The volume can be adjusted.

For a standard log display of the analyzed spectrum, the magnitude data is converted from linear to logarithmic in the DCON ASIC (Digital Controller).

Video bandwidths (VBW)

The video filters can be adjusted between 10 Hz and 3 MHz in increments of 1/3/10. They are designed as digital lowpass filters for the video signals in the DCON ASIC. Software can couple the VBW to the RBW, or the VBW can be set independently.

Detectors

The R&S FSH uses a detector for the positive peak and the negative peak value. In the “sample” mode the measured value is routed directly to the display. In the RMS mode the detector determines the rms value of the input signal for one specific point in the display during the measured time.

Keypad control

Keypad control is a dedicated function of the controller. For the implementation of the rotary knob, an encoder is used that is detected with a dedicated CPLD (Complex Programmable Logic Device). This “One Time Programmable” CPLD is programmed during production.

Serial optical interface

The interface to an external PC has been implemented with optical technology to avoid electrical loops. The protocol is RS-232-based and is implemented in the instrument by the UART of the controller. It requires a special optical RS-232 cable for communication (R&S FSH-Z34, delivered with the instrument). The maximum baud rate is 115200.

Power sensor

The power sensor uses the display of the R&S FSH. Communication is achieved with a separate UART from the controller.

Color LCD module

The ¼ VGA passive matrix display is backlit by an FCC backlight, whose light output can be adjusted to an optimum between visibility and battery use.

Module Replacement


This section describes the service concept and contains the spare parts list and the basic documents for the R&S FSH instrument.

Note: The numbers indicated in brackets refer to items in the mechanical exploded drawings.

Note: The words “left” and “right” in the manual always refer to the front view of the instrument.



Caution!



- Please pay close attention to the safety instructions in the front section of this manual.
- Disconnect the power connector from the instrument before opening the case.
- Safeguard the replacement site against electrostatic discharge to prevent damage to electronic components of the modules.
- The following two methods of ESD protection can be used together or separately:
 - Wrist strap with cord to ground connection
 - Conductive floor mat and heel strap combination




Fig. 3-4 Exploded View

Overview of the modules

Table 3-1 List of spare parts and order numbers

Reference	Part	R&S Order Number
1	Battery Pack for R&S FSH (R&S FSH-Z32)	1145.5796.02
2	Housing R&S FSH without top holster	1157.3258.00
2.4	Top holster for FSH without tracking generator	1157.3487.00
	Top holster for FSH with tracking generator	1157.3493.00
3	Front unit for R&S FSH3	1157.3241.00
	Front unit for R&S FSH6	1300.7591.00
4	LCD module	1157.3229.00
	LCD plane for FSH3	1300.7704.00
	LCD plane for FSH6	1300.7710.00
5	RF/IF module for R&S FSH3 without tracking generator	1157.3606.00
	RF/IF Module for R&S FSH3 with tracking generator	1157.3612.00
	RF/IF Module for R&S FSH6 without tracking generator	1300.7604.00
	RF/IF Module for R&S FSH6 with tracking generator	1300.7610.00
6	Mainboard for R&S FSH	1157.3570.00
7	N connector	1157.3235.00
8	Interconnection board	1157.3587.00
9	Input unit (power and audio connectors, including wire tree)	1157.3270.00
10	Set of cables for R&S FSH	1157.3329.00
21	AC mains adapter for R&S FSH (EU Version)	1157.3293.00
22	AC mains adapter for R&S FSH (UK Version)	1157.3306.00
23	AC mains adapter for R&S FSH (US Version)	1157.3312.00
	AC mains adapter for R&S FSH (AUS Version)	1157.3370.00

See exploded drawing on the previous page.

Opening the instrument

(See exploded drawing for related numbers.)

- Disconnect the power plug.
- Switch the instrument to OFF.
- Loosen the six (S1) screws and remove the top cover (2.4) and bottom cover (2.1).
- Disconnect the connector (X2).
- Loosen the three (S2) screws and remove the grip cover (2.3).
- Loosen the two (S3) screws and remove the rear case (2.2).
- Loosen the nine (S4) screws and remove the mainboard shielding.

Closing the instrument

- Mount the mainboard shielding and fasten the nine (S4) screws.

Note that the shielding of wire-tree (W1) is reconnected again.

- Mount the rear case (2.2) and fasten the two (S3) screws.
- Mount the grip cover and fasten the three (S2) screws.
- Connect the connector (X2).
- Mount the top cover (2.4) and bottom cover (2.1).
- Fasten the six (S1) screws .
- Perform the quick verification test.

Refer to Chapter 2 "Adjustment".



Caution!

Note that the connecting cables are still connected.

- **Note:** When detaching the connectors, proceed with caution.




Fig. 3-5 Opening the instrument

Replacing the battery

- Open the instrument.
- Disconnect connector (X1).
- Replace the battery.
- Connect (X1).
- Close the instrument.
- Charge the battery.
- Perform the quick verification test.

Refer to Chapter 2 "Adjustment".

- **Note:** *It is recommended that battery charging be performed with the instrument switched OFF and the AC power connected to the mains. The charging time for a full battery is about 4 hours.*




Fig. 3-6 Replacing the battery

Replacing the housing

Housing parts:

- 2.1: Bottom cover
- 2.2: Rear case
- 2.3: Grip cover
- 2.4: Top cover

Notes: When replacing the rear case, the existing type plate must be placed on the new rear case, or the old series number must be written on the new type plate.

When the grip cover is replaced, the “input unit power/audio connections” have to be placed in the new grip cover. See also Replacing the power/audio connections.

- Open the instrument.
- Replace the specific housing part.
- Close the instrument.
- Perform the quick verification test.

Refer to Chapter 2 “Adjustment”.




Fig. 3-7 Replacing the housing

Replacing the front unit for R&S FSH

- Open the instrument.
- Remove the battery .
- Remove the Main Unit:
 - Disconnect the connectors (X3), (X4), and (X5).
 - Remove the main unit by unscrewing the two (S5) screws.
- Remove the LCD colour module:
 - Losen the four (S6) screws.
 - Remove the LCD colour module.
- Use the new front unit to assemble the instrument again.



Before mounting the unit, make sure that no dust is present between the front unit and the LCD colour module.

- Mount the LCD colour module with the four (S6) screws.
 - Mount the Main Unit with the two (S5) screws.
 - Connect the connectors (X3), (X4), and (X5).
 - Mount the battery.
 - Close the instrument.
 - Perform the quick verification test.
- Refer to Chapter 2 “Adjustment”.*




Fig. 3-8 Replace Front Unit

Replacing the Color LCD Module

- Open the instrument.
- Remove the battery
- Remove the Main Unit:
 - Disconnect the connectors (X3), (X4), and (X5).
 - Remove the main unit by unscrewing the two (S5) screws.
- Remove the LCD colour module:
 - Disconnect the connector (X6).
 - Loosen the four (S6) screws.
 - Remove the LCD colour module.
- Use the new module to assemble the instrument again.



Before mounting the unit, make sure that no dust is present between the front unit and the colour module.

- Mount the LCD colour module with the four (S6) screws.
 - Mount the Main Unit with the two (S5) screws.
 - Connect the connectors (X3), (X4), and (X5).
 - Mount the battery.
 - Close the instrument.
 - Perform the quick verification test.
- Refer to Chapter 2 "Adjustment".*




Fig. 3-9 Replacing the Color LCD Module

Replacing the RF/IF module

- Open the instrument.
- Disconnect the flat cable (X8) and remove the tape.
- Disconnect the connectors (X7) and (X9).
- Remove the RF/IF module by unscrewing (S7).
- Remove the binder and BNC connector block:
 - Loosen the four (S8) screws.
 - Remove the connector block.
- Mount the new RF/IF module.
- Mount the binder and BNC connector block with the four (S8) screws.
- Connect connectors (X7) and (X9).
- Mount the flat cable (X8), including the ferrite.
- Fasten the flat cable with the tape.
- Close the instrument.
- Perform the manual adjustment.

Refer to Chapter 2 "Adjustment".




Fig. 3-10 Replacing the RF/IF Module

Replacing the mainboard

The mainboard contains information about the instrument like the serial number. Special tools are necessary to update this information after replacement of the mainboard. Therefore the exchange of the mainboard is possible in a R&S Service Center, only.

- Open the instrument.
- Remove the battery.
- Loosen the two (S5) screws.
- Disconnect the connectors (X3), (X4), (X5), (X7), (X8) and (X9).
- Loosen the three screws (S11) and the remove the board.

Note that the two lower screws are isolated.

- Remove the distance screw (S12)
- Mount the new board and fasten (S11) and (S12).
- Connect connectors (X3), (X4), (X5), (X7), (X8) and (X9).
- Mount the Battery.
- Close the instrument.
- Perform the manual adjustment.

Refer to Chapter 2 "Adjustment".




Fig. 3-11 Replacing the Main Board

Replacing the N connector

- Open the instrument.
- Remove the battery.
- Remove the RF/IF module by unscrewing (S7).
- Disconnect the flat cable (X8).
- Disconnect the connectors (X7) and (X9).
- Remove the binder and BNC connector block:
 - Loosen the four (S8) screws.
 - Remove the connector block.
- Loosen the two screws (S9) from front RF housing for each N connector.
- Loosen the 9 screws (S10) from the RF housing.
- Remove the front RF housing.
- Clean the center contact of solder left from the N connector to be replaced.
- Loosen the other two screws (S9) from the appropriate N connector.
- Mount the new connector by first screwing it into the rear RF housing.
- Solder the center connection.
- Mount the front RF housing (S10).
- Fasten the two screws (S9) to the front RF housing for each the N connector.
- Mount the binder and BNC connector block with the (S8) screws.
- Mount the flat cable (X8), including the ferrite.
- Connect the connectors (X7) and (X9).
- Mount the RF/IF module (S7).
- Mount the Battery and close the instrument.
- Perform the manual adjustment.
Refer to Chapter 2 "Adjustment".




Fig. 3-12 Replacing the N-Connector

Replacing the binder and BNC connector block

(See exploded view for references).

- Open the instrument.
- Disconnect the flat cable (X10).
- Disconnect the connector (X7).
- Remove the binder and BNC connector block:
 - Loosen the four (S8) screws.
 - Remove the connector block.
- Mount the binder and BNC connector block with the four (S8) screws.
- Connect the connectors (X7).
- Mount the flat cable (X10).
- Close the instrument.
- Perform the quick verification test.

Refer to Chapter 2 "Adjustment".




Fig. 3-13 Replacing the Binder and BNC connector block

Replacing the power/audio connections

- Remove the top cover.
- Disconnect the connector (X2)
- Remove the connection wire tree from the grip cover.
- Mount the wire tree again.
- Mount the top cover.
- Perform the quick verification test.

Refer to Chapter 2 "Adjustment".




Fig. 3-14 Replacing the Power/ Audio Connections

Replacing a cable from the cable set

Note: The cable set is needed in the event that a cable is damaged during the replacement of one of the modules.

Cables from the set:

- 10.1: 50-p
- 10.2: Flat flexible cable, 8 connections
- 10.3: Flat cable 22-p

For replacement instructions, refer to the individual modules.




Fig. 3-15 Cable set

Troubleshooting

Malfunctions can have simple causes but can also be due to faulty components or modules.

These troubleshooting instructions can be used to locate causes of error down to the board level and to return the instrument to operability by replacing boards.

We recommend that the instrument be shipped to our experts at the service centers (refer to address list) for module replacement and further error correction.



Warning! *Do not plug or unplug boards without first disconnecting the battery and the AC Power Supply!*

Note: *When problems occur, first check whether any connections (cables, plug-in connections of boards, etc) are damaged or incorrectly connected.*

Overview of errors, causes, and possible corrective actions

This section lists various errors, the probable module causing the problem, and the suggested corrective action.

Troubleshooting problems in switching on the instrument

- **Error: R&S FSH cannot be switched on.**

Note: *When the instrument is switched on, a beep is issued to indicate that the instrument has started.*

Troubleshooting procedure	Possible cause of error and further steps
Verify that the AC power is present. ↓	Connect the adapter to the mains and wait several minutes until the charger has recharged the battery.
Press the On button for > 5 s. ↓	This will force the instrument to perform a software reset and a reset of the internal RAM. The instrument firmware will restart and all data will be reset.
Open the instrument and check the battery. ↓	Voltage > 7.2 V.
Check the connectors from the AC power supply: X2 and X7 (refer to section "Repair").	Power connector broken. <i>Replace the power and audio connections. Replace the mainboard (refer to "Replacing the module").</i>

- **Error: Display remains dark although the beep indicated that the software was started.**

Troubleshooting procedure	Possible cause of error and further steps
Open the instrument and check X4 (backlight connector).	Backlight connection open or backlight converter broken. <i>Connect again, or replace the mainboard or LCD colour module.</i>

- **Error: Display has erroneous colours and characters.**

Troubleshooting procedure	Possible cause of error and further steps
Open the instrument and check X5 and X6 (LCD data).	Data connection broken, or circuitry on the mainboard defective. <i>Connect again, or replace the mainboard or LCD colour module</i>

- **Error: Frequency response not compliant with specification.**

This response can only be corrected at the service center. **Replace the RF/IF module.**

- **Error: Level display very noisy.**

Troubleshooting procedure	Possible cause of error and further steps
Check the N connector. ↓	The N connector is soiled. <i>Clean or replace the N connector.</i> <i>Replace the RF/IF module.</i>

- **Error: Several keys on the keypad do not respond.**

Troubleshooting procedure	Possible cause of error and further steps
Check X3.	The connection is not operational or the keypad is broken. <i>Correct the connection, or replace the front unit.</i>

- **Error: Power sensor does not respond properly.**

Troubleshooting procedure	Possible cause of error and further steps
Check X8 and X10.	The connection is not operating correctly, the binder connector is broken, the mainboard is broken, or the cables are broken. <i>Correct the connection.</i> <i>Replace the binder and BNC connector block.</i> <i>Replace the mainboard.</i> <i>Replace any broken cable in the cable set.</i>

4 Software Updates / Installing Options

This chapter provides information on software updates and how to install options on the R&S FSH. Additional manuals supplied along with software/firmware updates or with options obtained later can be recorded here.

Installing New R&S FSH Software

A new firmware version can be installed via the R&S website. You can download the newest software version, and the new software can be loaded onto the R&S FSH by using the setup program.

The instructions are included in the program.

Installing the Options

The following options are available with the R&S FSH:

Distance to Fault Measurement for R&S FSH	R&S FSH-B1	1145.5750.02
Remote Control via RS-232-C	R&S FSH-K1	1145.3458.02
Vector Transmission and Reflection Measurements	R&S FSH-K2	1145.3387.02

5 Documents

This chapter provides information on how to order spare parts, and it also contains the spare parts list.

Shipping of Instrument and Ordering of Spare Parts

Please contact your Rohde & Schwarz support center or our spare parts express service if you need to request service, repair your equipment, or order spare parts and modules.

The list of Rohde & Schwarz representatives and the address of our spare parts express service are provided in the front section of this service manual.

You will need to provide the following information in order for us to respond to your inquiries quickly and accurately and to determine whether the warranty for your instrument is still valid:

- Instrument model
- Serial number
- Detailed error description in case of repair
- Contact partner for checkbacks

Shipping of instrument

When shipping the instrument, be sure to provide sufficient mechanical and anti-static protection:

- Repack the instrument as it was originally packed. The antistatic packing foil prevents unintentional electrostatic charging from occurring.
- If you do not use the original packaging, include sufficient padding to prevent the instrument from slipping inside the package. Wrap antistatic packing foil around the instrument to protect it from electrostatic charging.

Shipping of a module

When shipping a module, be sure to provide sufficient mechanical and antistatic protection:

- Ship the module in a sturdy, padded box.
- Wrap the board in antistatic foil.
If the packaging is antistatic but not conductive, additional conductive packaging is required. The additional packaging is not required if the enclosed packaging is conductive.

Ordering spare parts

To deliver replacement parts promptly and correctly, we need the following information:

- R&S order number (refer to the spare part lists in this chapter)
- Designation
- Number of units
- Instrument type for the replacement part
- Contact person for possible questions

The R&S order number to be used when ordering replacement parts and modules as well as power cables can be found further below.

Refurbished modules

- Refurbished modules are an economical alternative to original modules. It should be kept in mind that refurbished modules are not new, but repaired and fully tested parts. They may have signs of use but they are electrically and mechanically equivalent to new modules.
- To find out which refurbished modules are available, please contact your Rohde & Schwarz representative (or the central service division at Rohde & Schwarz in Munich).

Return of defective replaced modules

- Defective modules of the replacement program that can be repaired may be returned within **3 months** after delivery of the replaced module. A repurchasing value is credited.
- Excluded are parts that cannot be repaired, e.g. PCBs that are burned, broken or damaged by repair attempts, incomplete modules, or parts that have endured heavy mechanical damage.
- Defective parts must be sent back with an **accompanying document of returned items** containing the following information:
 - R&S order number, serial number and designation of the removed part
 - **Precise** description of the error
 - R&S order number, serial number and designation of the instrument the part was removed from
 - Date of part removal
 - Name of the technician who exchanged the part
- A **document of returned items** is provided along with each replacement module.

Spare Parts

The R&S Order numbers necessary for ordering replacement parts and modules can be found in the spare part lists provided below.

List of R&S FSH spare parts

The following table lists available spare parts together with their R&S order numbers.

Reference	Part	R&S Order Number
1	Battery Pack for R&S FSH (R&S FSH-Z32)	1145.5796.02
2	Housing R&S FSH without top holster	1157.3258.00
2.4	Top holster for FSH without tracking generator	1157.3487.00
	Top holster for FSH with tracking generator	1157.3493.00
3	Front unit for R&S FSH3	1157.3241.00
	Front unit for R&S FSH6	1300.7591.00
4	LCD module	1157.3229.00
	LCD plane for FSH3	1300.7704.00
	LCD plane for FSH6	1300.7710.00
5	RF/IF module for R&S FSH3 without tracking generator	1157.3606.00
	RF/IF Module for R&S FSH3 with tracking generator	1157.3612.00
	RF/IF Module for R&S FSH6 without tracking generator	1300.7604.00
	RF/IF Module for R&S FSH6 with tracking generator	1300.7610.00
6	Mainboard for R&S FSH	1157.3570.00
7	N connector	1157.3235.00
8	Interconnection board	1157.3587.00
9	Input unit (power and audio connectors, including wire tree)	1157.3270.00
10	Set of cables for R&S FSH	1157.3329.00
21	AC mains adapter for R&S FSH (EU Version)	1157.3293.00
22	AC mains adapter for R&S FSH (UK Version)	1157.3306.00
23	AC mains adapter for R&S FSH (US Version)	1157.3312.00
	AC mains adapter for R&S FSH (AUS Version)	1157.3370.00

Note: *The reference can be found in the exploded drawing in Chapter 3.*



Important Note!

When replacing a module, please pay careful attention to the safety instructions and the repair instructions provided in chapter 3 and at the beginning of this service manual.

When shipping a module, be sure to provide sufficient mechanical and antistatic protection.
