

Engineering

ManualsPlus.com

# communications



**OPERATING and SERVICE  
INSTRUCTIONS**

*VA6 1-312-259-9600 Sales*  
*1-312-826-6300 Admin*



**the hallicrafters co.**

MANUFACTURERS OF RADIO, TELEVISION AND ELECTRONIC EQUIPMENT, CHICAGO 24, U. S. A.




Fig. 1. Communications Receiver Model S-76

92X1778

## DESCRIPTION

The Model S-76 is a precision built, highly sensitive, double conversion superheterodyne communications receiver employing 9 tubes plus voltage regulator and rectifier and covering the frequency range of 538 KC to 1580 KC and 1720 KC to 34 MC. It is the only communications receiver, at present, to employ a 50 KC second I.F. (intermediate frequency) and to provide the advantages of double conversion throughout its entire frequency range. The use of double conversion makes possible greater image rejection than is practical in a single conversion superheterodyne receiver.

The use of a 50 KC second I.F. provides a greater selectivity than most crystal circuits due to the extreme steepness of the selectivity curve. The five position **SELECTIVITY** control provides variable selectivity from 5 KC to 500 cycles at the nose of the curve and from 15 KC to 4 KC at the skirt. This high degree of selectivity makes possible a form of single side band reception of AM (phone) signals which is advantageous under crowded band conditions.

The four frequency ranges are clearly indicated on the large main tuning dial and provide complete coverage of the frequency spectrum between 538 KC and 34 MC with the exception of a small gap between bands 1 and 2 in the vicinity of 1650 KC, which is the first intermediate frequency of the receiver. In addition to the four frequency ranges, a special logging scale has been provided on the main tuning dial for logging shortwave stations of special interest.

The electrical **BANDSPREAD** control, calibrated specifically for the 80, 40, 20, 15, 11 and 10 meter amateur bands, provides a vernier or fine tuning adjustment throughout the entire tuning range of the receiver.

A 4-inch rectangular "S" meter, the largest presently being used on any receiver and calibrated in both "S" units and microvolts, has been provided to aid in tuning the receiver and to give a relative indication of received signal strength.

Other special features included in the S-76 are automatic volume control (AVC), automatic series noise limiter (ANL) and provision for headphone operation, standby operation and record player attachment. For speaker operation, a separate external loud speaker of either 3.2 or 500 ohms impedance is required.

The receiver is housed in an attractive, well ventilated metal cabinet which has a length of 18-1/2 inches, a height of 8-7/8 inches and a depth of 9-1/2 inches.

The S-76 normally operates from a 105-125 volt 50-60 cycle alternating current (AC) power source. The S-76U, a universal model of the S-76, permits operation from 25-60 cycle AC sources at voltages ranging from 115 to 250 volts. Both models have provision for operation from an external DC power source. The power consumption of each model is 77 watts.


**IMPORTANT**

Your careful attention is especially invited to the installation and operating instructions. They have been provided to insure the satisfaction you have a right to expect from a Hallicrafters "Precision Built" product. Your receiver has an unusually high degree of sensitivity necessary to receive weak and distant stations. Careless operation of a high sensitivity receiver may result in excess noise or background hiss. These undesirable effects can be held to a minimum by careful adjustment of the sensitivity, tuning and tone controls as well as the proper selection and arrangement of the antenna.

**INSTALLATION INSTRUCTIONS**

**UNPACKING** - Check all shipping tags and labels for instructions before removing or destroying them.

**LOCATION** - The receiver is equipped with rubber mounting feet for table top or shelf mounting. When locating the receiver, avoid excessively warm locations and recessed installations which prevent proper air circulation. The separate loud speaker should not be placed on the top of the cabinet but should be located as far from the receiver as is practical.



**Fig. 2. Rear View of Cabinet**

92C1376

**POWER SOURCE** - This receiver may be operated directly from an AC source or indirectly from a DC or battery source.

**AC OPERATION** - The S-76 can be operated directly from a 105-125 volt, 50-60 cycle AC power outlet. The universal model, the S-76U, is designed for operation from 115, 130, 150, 220 and 250 volt, 25-60 cycle AC sources. A selector switch, located on the power transformer, permits operation of the S-76U on any of the line voltages shown. The normal power consumption of each model is 77 watts. If in doubt as to the frequency and voltage rating of your power source, contact the local power company representative. Attempting to operate the receiver from sources of power not specified may result in damage to the receiver.

**CAUTION** - When operating the universal model, it is essential that the selector switch setting correspond to the operating line voltage before connecting the receiver to the AC power source.

**NOTE:** The receiver will not operate from an AC source unless the JUMPER PLUG is inserted in the DC POWER SOCKET. See Fig. 2.

**DC OPERATION** - The receiver may be operated from a 6 volt DC source (storage battery or equivalent) and a 280 volt DC supply in the form of "B" batteries, vibrator power supply or motor generator set. The voltage and current requirements for DC operation are listed below.

DC power is connected to the receiver through the DC POWER SOCKET located on the rear apron of the chassis. The JUMPER PLUG, normally located in this socket for AC operation, is replaced with a standard octal plug for DC operation. Wire the octal plug for DC operation as shown in Fig. 3.

VOLTAGE AND CURRENT REQUIREMENTS FOR DC OPERATION	
"B" Voltage	280 volts
"B" Current	115 ma
Heater Voltage	6.3 volts
Heater Current	3.3 amps




Fig. 3. Wiring Diagram for DC Operation

**SPEAKER CONNECTION** - Three screw type terminals, marked 3.2, 500 and G, are provided on the rear apron of the chassis for connection to an external 3.2 or 500 ohm speaker. It is recommended that Hallicrafters speaker R-46 be employed.

**RECORD PLAYER CONNECTION** - A shielded type phono jack is provided on the rear of the chassis to accommodate any record player employing a crystal pickup. Refer to Fig. 6 for wiring details.

**ANTENNA** - The terminals marked A1, A2 and G on the back of the receiver are for antenna and ground connection. Satisfactory results can be obtained in most localities with the 15 foot antenna wire included with your receiver. Simply uncoil the wire, connect one end of it to terminal A1 and then connect the jumper between terminals A2 and G. An outside antenna 50 to 100 feet long may be necessary if the receiver is operated in a difficult reception area or steel constructed building. Reception may be improved in some locations by connecting a lead from terminal G to a cold water pipe or outside ground rod.




Fig. 4. Single Wire Antenna Installation

For really top performance on the shortwave bands, there is no substitute for an outside antenna such as used by the commercial radio stations. Provision has been made on your receiver for the connection of this type of antenna, commonly called a doublet. When properly constructed and installed, the doublet antenna will provide not only optimum shortwave reception but excellent standard broadcast reception as well. Refer to page 5 for installation details for the doublet antenna.

**DOUBLET ANTENNA** - The overall length (in feet) of the doublet antenna is determined by dividing 468 by the frequency (in megacycles) at the high end of the range to which you wish to listen. Construct the antenna as shown in Fig. 5. A doublet antenna is directional broadside to its length and should be so oriented with respect to a desired station for maximum signal pickup.

By feeding the doublet antenna with a transmission line of 300 ohms surge impedance, a broader frequency response is obtained than that possible with a 50-75 ohm line.

When feeding the antenna with a ribbon type transmission line, connect the line to terminals A1 and A2. Disconnect the jumper between A2 and G.

When using a coaxial transmission line, connect the inner conductor to A1 and the outer conductor to A2. Connect the jumper between A2 and G.





Fig. 5. Doublet Antenna Installation

92B1392-A

**REMOTE STANDBY/RECEIVE SWITCH CONNECTION** - The receiver may be disabled remotely by connecting a remote spst switch between pins 1 and 4 of the JUMPER PLUG (see Fig. 2). To operate the receiver remotely, set the STANDBY/RECEIVE switch, located on the front panel of the receiver, to the STANDBY position. The receiver can then be placed in RECEIVE or STANDBY operation with the remote switch.



92B1395-B

Fig. 6. Wiring Diagram for Record Player Connection

**TRANSMITTER CONTROL SWITCH** - One section of the dpst STANDBY/RECEIVE switch is available for transmitter relay control. This section of the switch connects to pins 2 and 5 of the DC POWER SOCKET (see Fig. 2) and is in the open position with the STANDBY/RECEIVE switch at STANDBY.

## OPERATING INSTRUCTIONS

Each control of the receiver performs a definite function which contributes to the outstanding reception capabilities of the receiver. Full appreciation of the receiver is to be expected only after you have become familiar with the controls and the effect their operation has on the performance of the receiver. The control positions for standard broadcast reception are marked with a dot for convenience to the listener.

**RADIO TELEPHONE RECEPTION** - To receive amplitude modulated (AM) radio telephone signals, the following use of the controls is recommended to obtain optimum performance from the receiver.

### SENSITIVITY control

This control is normally set fully clockwise for maximum sensitivity. In some rare instances, strong local signals may overload the receiver input. Distortion, caused by this condition, can be eliminated by reducing the receiver sensitivity slightly. For a correct "S" meter indication, the SENSITIVITY control must be set fully clockwise.

### BAND SELECTOR switch

This switch is used to select the desired band or frequency range. The frequencies covered by each position of the BAND SELECTOR are read directly from the main tuning dial.

### VOLUME control

This control is used to regulate audio volume. Turning the control clockwise increases volume.

## RADIO TELEPHONE RECEPTION (Cont.)

**AVC switch** This switch should be set to the ON position to place the automatic volume control (AVC) circuit in operation. The AVC circuit provides a constant audio output level over large variations in signal strength at the antenna.

**TUNING control** This control should be set for the desired station frequency after setting the BAND SELECTOR for the desired band. Frequencies on all bands are shown in megacycles.

**IMPORTANT** - The main tuning dial calibration is correct only when the BAND-SPREAD control is fully clockwise.

**CW/AM switch** This switch should be set at AM.

**BANDSPREAD control** This control, calibrated specifically for the 80, 40, 20, 15, 11 and 10 meter amateur bands, is a fine tuning adjustment provided for electrically spreading out the congested amateur and shortwave bands.

**AMATEUR BAND RECEPTION** - To use the BANDSPREAD control on the amateur bands, set the BANDSPREAD control fully clockwise, index the TUNING control for the high end of any of the amateur bands as indicated by the white dots on the main tuning dial and then tune through the band using the BANDSPREAD control. The station frequency is read directly from the bandspread dial.

**SHORTWAVE RECEPTION** - To tune in shortwave stations with the BANDSPREAD control, set the BANDSPREAD control fully clockwise, position the TUNING control for the high frequency end of the range of frequencies to be covered and then tune through the frequency range with the BANDSPREAD control. Note that the station frequency CANNOT be read directly from either the main tuning or bandspread dials. However, it is possible to log shortwave stations by recording the settings of both the bandspread dial and the main tuning logging scale. See inside of back cover for the shortwave station log.

**NOISE LIMITER switch** This switch is normally set at OFF. Set the switch at ON when severe electrical disturbances interfere with reception.

**SELECTIVITY switch** This switch is normally set at BROAD for maximum fidelity. Positions 2, 3, 4 and 5 provide increasing steps of selectivity. Note that as the receiver is made more selective (clockwise rotation of the SELECTIVITY control), the background noise and interference from nearby stations is reduced. The setting of the SELECTIVITY control is generally best determined by receiving conditions, the SHARP position providing maximum selectivity. A slight readjustment of the BANDSPREAD control may be necessary when changing the position of the SELECTIVITY control.

**SINGLE SIDE BAND RECEPTION** - The method of bandwidth expansion used in this receiver makes possible a form of single side band reception. As the selectivity is changed from the SHARP to the BROAD position the bandwidth of the receiver not only increases but also shifts in reference to the 50 KC intermediate frequency, permitting only one side band to be accepted. For single side band reception, set the SELECTIVITY control to SHARP, tune in the AM signal and then set the SELECTIVITY control to BROAD. The "S" meter level will decrease with an increase in bandwidth and if the receiver is not retuned, only one side band will be accepted.

**PITCH CONTROL** This control is not used for RADIO TELEPHONE RECEPTION.

**TONE control** This control turns the receiver on and off and also attenuates the high audio frequencies to the extent required by the various receiving conditions. To turn the receiver on, turn the TONE control clockwise beyond the point of switch action. For maximum high frequency audio response, turn the TONE control fully clockwise.

**STANDBY/RECEIVE** This switch, normally set at **RECEIVE**, is particularly useful to the "ham" as it switch permits disabling of the receiver for standby periods, at the same time maintaining the tube heaters at operating temperature for instant use. The receiver is disabled by setting this switch to the **STANDBY** position.

**CW RECEPTION** - The following use of the controls is recommended for CW (code) reception.

**SENSITIVITY** Increase receiver sensitivity by turning the **SENSITIVITY** control clockwise. If control strong code signals block the receiver, reduce the sensitivity slightly.

**BAND SELECTOR** Same as for **RADIO TELEPHONE RECEPTION**.

**VOLUME** control Set the **VOLUME** control clockwise near the maximum volume position and use the **SENSITIVITY** control to regulate the audio output.

**AVC** switch This switch should be set at **OFF**.

**TUNING** control Same as for **RADIO TELEPHONE RECEPTION**.

**CW/AM** switch This switch should be set at **CW** to place the 50 KC beat frequency oscillator circuit in operation.

**BANDSPREAD** Same as for **RADIO TELEPHONE RECEPTION**. control

**NOISE LIMITER** This switch should be set at **OFF**. switch

**SELECTIVITY** The setting of the **SELECTIVITY** control for CW reception is generally best determined by receiving conditions. Note that as the **SELECTIVITY** is increased from the **BROAD** to the **SHARP** position, the background noise and interference is considerably reduced. CW reception under extremely congested conditions is possible with the **SELECTIVITY** control set at **SHARP**. A slight readjustment of the **BANDSPREAD** control may be necessary when changing the position of the **SELECTIVITY** control. switch

**PITCH CONTROL** This control varies the frequency of the beat frequency oscillator thus varying the pitch of the CW code signal. It may be necessary, after setting the **PITCH CONTROL**, to readjust the tuning of the receiver slightly with the **BANDSPREAD** control. Alternately adjust the **PITCH CONTROL** and **BANDSPREAD** control for a maximum audible signal.

**TONE** control This control should be turned counterclockwise.

**STANDBY/RECEIVE** Same as for **RADIO TELEPHONE RECEPTION**. switch

**USE OF THE "S" METER** - The "S" meter has been provided to aid in tuning the receiver for **RADIO TELEPHONE RECEPTION** and to give an indication of the relative carrier strength of each incoming AM signal. For a correct "S" meter indication; the **SENSITIVITY** control must be fully clockwise, the **AVC** switch must be in the **ON** position and the receiver must be tuned for a maximum reading on the "S" meter.

To afford greater utility of the "S" meter, it has been calibrated in both "S" units and microvolts. It is suggested that the limitations of these microvolt indications be fully appreciated before any assumption as to the indicated signal voltages be accepted. The meter indicates approximate microvolts of signal strength as developed at the 300 ohm antenna input terminals of the receiver at 14 MC. This approximation

will have a variation of  $\pm 5$  db on a new receiver and, obviously, as the receiver tubes age the variations may be greater.

Variations in the microvolt indication between receivers is not indicative of the overall sensitivity variation but is caused by normal tolerances in vacuum tube conductances which are reflected in variations in the AVC/S METER curve. Thus, two similar receivers with identical overall sensitivities could, under the same signal conditions, indicate signal levels of 5 microvolts and 25 microvolts and yet each be a perfect receiver. All readings 60 microvolts or less will be more accurate and correlate more closely than those higher.

The indicated microvolt reading at 30, 7 and 3.5 MC will vary  $\pm 3$  db from that at 14 MC. While these variations may seem large, the microvolt calibration is advantageous as it provides a useful tool for antenna work and harmonic measurements with a suitable converter.

**RECORD PLAYER OPERATION** - Set the SELECTIVITY control to PHONO. Turn the receiver ON by rotating the TONE control clockwise beyond the point of switch action. Operate the VOLUME and TONE controls as explained under RADIO TELEPHONE RECEPTION. The settings of the remaining controls is immaterial as they are not in use for record player operation.

**HEADPHONE OPERATION** - The PHONES jack, located on the front panel, permits the use of headphones with this receiver. Insertion of the headphones disables the speaker. Use any standard headset with an impedance of 500 to 12,000 ohms.




Fig. 7. 50 KC I.F. System

92C1408

**50 KC I. F. SYSTEM** - Figure 7 is a simplified schematic diagram of the 50 KC I.F. system. It is unique in that the coupling between primary and secondary coils is through a resistive-capacitive network instead of the more common mutual inductive arrangement. All coupling occurs through C and R since each 50 KC coil is completely shielded to prevent inductive coupling. By increasing the value of C and R the selectivity can be made broad or conversely, by decreasing C and R, made sharp. This coupling arrangement affords a more accurate means of selectivity control than that readily obtainable by any other method.

# SERVICE INSTRUCTIONS

## GENERAL SPECIFICATIONS

- Tubes . . . . . 9 plus voltage regulator and rectifier
- Power Supply - Model S-76 . . 105-125 volts, 50-60 cycles AC
- Model S-76U . 105-250 volts, 25-60 cycles AC
- Power Consumption . . . . . 77 watts
- Speaker Output Impedances, . . 3.2 and 500 ohms
- Headset Output Impedance . . . 500 ohms
- Antenna Input Impedance . . . . 300 ohms
- Phono Input Impedance . . . . High impedance
- 1st Intermediate Frequency . . 1650 KC
- 2nd Intermediate Frequency . . 50 KC

## "S" METER ADJUSTMENTS

**MECHANICAL ADJUSTMENT** - Turn the receiver OFF. The "S" meter mechanical adjustment screw is located on the "S" meter escutcheon. Carefully rotate this screw until the pointer is in line with the right hand index mark on the "S" meter.

### ELECTRICAL ADJUSTMENT

1. Short the antenna terminals to the chassis.
2. Set the STANDBY/RECEIVE switch at RECEIVE, AM/CW switch at AM, AVC switch at ON, NOISE LIMITER switch at OFF and the SENSITIVITY control fully clockwise.
3. Turn the receiver ON.
4. The electrical adjustment control for the "S" meter is located on the rear apron of the chassis. Turn this control slowly until the "S" meter pointer indicates 0 on the micro-volt scale.


**DIAL LAMP REPLACEMENT** - Refer to Fig.9 for the location of the dial lamps used in the receiver. To gain access to defective lamps, open the hinged top cover of the cabinet.

**CAUTION** - To avoid electrical shock, disconnect the receiver from the power source before making any dial lamp replacement.

To replace the bandspread and main tuning dial lamps, unclip the dial lamp assembly from the mounting bracket. This enables the defective lamp to be brought out into the open where it may be replaced. Make replacements with a 6-8 volt 250 ma (blue bead) Mazda #44 pilot lamp or equivalent.

To replace the pilot lamps which illuminate the "S" meter, remove either socket assembly from the meter by pulling it slightly sideways. The socket assembly and defective lamp may then be brought out into the open for service. Make replacements with a 6-8 volt, 1 c.p. (pink bead) Mazda #51 pilot lamp or equivalent.

**TUBE REPLACEMENT** - The tube types and their relative location in the receiver are shown in Fig. 9. Access to all tubes is possible by opening the hinged top cover of the cabinet. When installing a replacement octal tube, insert the center guide pin into the center hole of the tube socket, rotate the tube until the key on the guide pin drops into the notch in the socket hole and push down until the base of the tube rests firmly on the socket. A slightly different technique must be used on the miniature tubes. They have seven small pins which must be lined up with the socket holes before pushing the tube into place. Handle all tubes with care as they are fragile and will not withstand mechanical abuse.



NOTE: MAIN TUNING & BANDSPREAD GANGS FULLY MESHED

Fig. 8. Dial Cord Stringing Diagram

92C1396-A

**EQUIPMENT REQUIRED**

**I-F ALIGNMENT PROCEDURE**

1. Vacuum tube voltmeter (VTVM)
2. Signal generator (unmodulated) covering 50 KC and 1650 KC. If a 50 KC signal generator is not available, use two separate generators to provide a 50 KC beat frequency. Set the frequency of one generator to 700 KC and the other to 750 KC.
3. 3.2 or 500 ohm speaker

It is necessary to remove the receiver chassis from the cabinet to make the I-F alignment. The chassis is held in the cabinet by three screws along both the bottom edge of the front panel and the rear of the cabinet and by two screws on each side of the front panel.

The I-F alignment should be made with the main tuning and bandspread tuning capacitors meshed half way, VOLUME, TONE and SENSITIVITY controls fully clockwise, NOISE LIMITER and AVC switches at OFF, RECEIVE/STANDBY switch at RECEIVE, CW/AM switch at AM and the BAND SELECTOR switch at 2. Refer to Figs. 9 and 10 for the location of all adjustments.

Connect the high side of the VTVM to the junction of [C-75], [R-38], [R-43], [R-44] and [R-59]. See Fig. 13. Connect the common side of the VTVM to the chassis. Use just enough signal generator output to give a 1 volt DC indication on the VTVM.

STEP	SIGNAL GENERATOR COUPLING	SIGNAL GEN. FREQUENCY	SELECTIVITY CONTROL SETTING	ADJUST	REMARKS
1	Connect the high side of the generator to terminal 1 of transformer (T <sub>2</sub> ) (see Fig. 13) and the ground side to the chassis.	50 KC (No Mod.)	5	1	Maximum output
			5	2	Maximum output
			5	3	Maximum output
			5	4	Maximum output
			5	1	Maximum output
			5	2	Maximum output
			5	3	Maximum output
			5	4	Maximum output
2	Connect the high side of the generator to stator plates of center section of main tuning capacitor. Connect the ground side of the generator to frame of main tuning capacitor.	1650 KC (No Mod.)	5	5	Maximum output. After making adjustment 5 retune the generator for a maximum indication on the VTVM.
			5	6	Maximum output
			5	7	Maximum output
			5	8	Maximum output
			5	9	Maximum output
					Rotate the SELECTIVITY control from position 5 to 1. The VTVM reading should decrease progressively with each position of the SELECTIVITY control. If this does not occur, it is an indication that the 50 KC I-F system is not properly aligned. This indicates that steps 1 and 2 must be repeated.
3	Connect the high side of the generator to terminal 1 of transformer (T <sub>2</sub> ) (see Fig. 13) and the ground side to the chassis.	50 KC (No Mod.)	4	10	Disconnect the VTVM. Set the CW/AM switch at CW. Remove the PITCH CONTROL knob. Using a speaker as an indicating device, adjust 10 for a zero beat. After completing this adjustment, replace the knob with the index mark in the top center position.

**R-F ALIGNMENT PROCEDURE**

**EQUIPMENT REQUIRED**

1. Output meter. The AC scale of a vacuum tube voltmeter (VTVM) or other suitable meter may be used.
2. Signal generator covering 600 KC to 30 MC. Generator must have amplitude modulated output.
3. Alignment tool made of polystyrene or other similar material.

It is not necessary to remove the chassis from the cabinet for the R-F alignment. All R-F alignment adjustments can be made through the holes in the bottom of the cabinet.

The R-F alignment should be made with the BANDSPREAD, VOLUME, TONE and SENSITIVITY controls fully clockwise, NOISE LIMITER and AVC switches at OFF, RECEIVE/STANDBY switch at RECEIVE, CW/AM switch at AM and the SELECTIVITY control at 3. Refer to Figs. 9 and 10 for the location of all adjustments.

**CONNECTING THE TEST EQUIPMENT**

1. Connect the output meter between the 500 ohm speaker terminal and the chassis.
2. Connect the high side of the signal generator to antenna terminal A1 through a 330 ohm carbon resistor. Place the jumper between antenna terminals A2 and G. Connect the ground side of the generator to the chassis. Keep the output of the signal generator as low as possible at all times to prevent overloading of the receiver.

STEP	SIGNAL GENERATOR FREQUENCY (MOD.)	BAND SELECTOR SETTING	MAIN TUNING DIAL SETTING	ADJUST	REMARKS
1	30 MC	4	30 MC	A	Adjust A thru F for maximum output. Oscillator trimmer A should be set so that the oscillator operates on the high side as indicated by an image at 26.7 MC. If the oscillator is operating on the low side, an image will be obtained at 33.3 MC.
	30 MC	4	30 MC	B	
	30 MC	4	30 MC	C	
	14 MC	4	14 MC	D	
	14 MC	4	14 MC	E	
	14 MC	4	14 MC	F	
2	11.5 MC	3	11.5 MC	G	Maximum output
	11.5 MC	3	11.5 MC	H	Maximum output
	11.5 MC	3	11.5 MC	J	Maximum output
	5.1 MC	3	5.1 MC	K	Maximum output
	5.1 MC	3	5.1 MC	L	Maximum output
5.1 MC	3	5.1 MC	M	Maximum output	
3	4.6 MC	2	4.6 MC	N	Maximum output
	4.6 MC	2	4.6 MC	P	Maximum output
	4.6 MC	2	4.6 MC	Q	Maximum output
	1.925 MC	2	1.925 MC	R	Maximum output
4	1400 KC	1	1.4 MC	S	Maximum output
	1400 KC	1	1.4 MC	T	Maximum output
	1400 KC	1	1.4 MC	U	Maximum output
	600 KC	1	.6 MC	V	Maximum output




Fig. 9. Top View of Chassis Showing Location of Alignment Adjustments, Tubes and Dial Lamps

92D1387-A





Fig. 10. Bottom View of Chassis Showing Location of Alignment Adjustments

92D1386



92X1397-A


Fig. 11. Top View of Chassis Showing Component Location

**SERVICE OR OPERATING QUESTIONS** - For further information regarding operation or servicing of the receiver, contact your dealer. Make no shipments directly to the factory as the factory will not accept responsibility for unauthorized shipments. Factory type service is available at any HALICRAFTERS AUTHORIZED SERVICE CENTER which displays the sign shown below. For the location of the SERVICE CENTER nearest you, consult your dealer or telephone directory.



92X1401-C


The Hallicrafters Co. reserves the privilege of making revisions in current production of equipment and assumes no obligation to incorporate these revisions in earlier models.



92X1416

Fig. 12. Bottom View of 2nd Converter Showing Component Location





**NOTES**


1. SOCKET VIEWS ARE BOTTOM VIEWS.
2. ALL VOLTAGES ARE MEASURED BETWEEN TUBE SOCKET TERMINALS AND THE CHASSIS WITH ZERO SIGNAL INPUT.
3. LINE VOLTAGE - 117 VOLTS, 60 CYCLES AC.
4. ALL VOLTAGES SHOWN ARE DC AND POSITIVE UNLESS OTHERWISE SPECIFIED
5. DC VOLTAGES WERE MEASURED WITH A VACUUM TUBE VOLTMETER (VTVM).
6. "NC" - NO CONNECTION. VOLTAGE SHOWN FOR THIS TERMINAL ONLY WHEN TERMINAL IS USED AS A TIE LUG.
7. "NR" - NOT READABLE. VOLTAGES MEASURED AT THESE TERMINALS GENERALLY MEANINGLESS.
8. "CW" - COUNTERCLOCKWISE
9. VOLTAGE AT THIS TERMINAL VARIES WITH SETTING OF BAND SELECTOR SWITCH.
10. AM WHERE TUBE SOCKET VOLTAGES CHANGE FROM AM TO CW OPERATION, TWO READINGS ARE SHOWN. THE UPPER READING IS WITH THE AM/CW SWITCH IN THE AM POSITION WHILE THE LOWER READING IS WITH THE SWITCH IN THE CW POSITION.

Fig. 14. Tube Socket Voltage Chart


92D1589-A

## SERVICE PARTS LIST

Schematic Symbol	Description	Hallicrafters Part Number	Schematic Symbol	Description	Hallicrafters Part Number
<b>CAPACITORS</b>			<b>RESISTORS</b>		
C-1A,B,C	Capacitor, MAIN TUNING; 3 section	48C244	R-1	22 ohms 1/2 watt, carbon	23X20X220K
C-2A,B,C	Capacitor, BANDSPREAD; 3 section	48C243	R-2,25,58,59	1 megohm 1/2 watt, carbon	23X20X105K
C-3,4,5,6	Trimmers (part of antenna coils L-1,2,3, and 4)	-----	R-3,15,26	100 ohms 1/2 watt, carbon	23X20X101K
C-7,41,67, 75,76	220 mmf. 500 V., ceramic	47B20221K5	R-4,8,14,21	15 ohms 1/2 watt, carbon	23X20X150K
C-8,9,10,12, 13,14,15, 16,17,18, 42	5000 mmf. 450 V., ceramic	47A168	R-5,39,47	180 ohms 1/2 watt, carbon	23X20X181K
C-11,19,22, 52,55	100 mmf. 500 V., ceramic	47X20UJ101K	R-6	1000 ohms 1/2 watt, carbon (part of L-5)	-----
C-20	2200 mmf. 500 V., mica (part of osc. coil, L-6)	-----	R-7,27	39,000 ohms 1 watt, carbon	23X30X393K
C-21,23,78	.05 mfd. 200 V., tubular paper	46AU503J	R-9	2.2 megohms 1/2 watt, carbon	23X20X225K
C-24,25,31, 32	390 mmf. 500 V., mica	47X20D391J	R-10	2200 ohms 1/2 watt, carbon	23X20X222K
C-26,33,35, 38,44	2.2 mmf. 450 V., ceramic	47A160-4	R-11,42,52	330,000 ohms 1/2 watt, carbon	23X20X334K
C-27,30,34	.05 mfd. 600 V., tubular paper	46AY503J	R-12,24,28, 29,30	3300 ohms 1/2 watt, carbon	23X20X332K
C-28,72	470 mmf. 500 V., mica	47X20B471K	R-13,56	100,000 ohms 1/2 watt, carbon	23X20X104K
C-29,61	.25 mfd. 200 V., tubular paper	46AT254J	R-16	8200 ohms 1/2 watt, carbon	23X20X822K
C-36,45	25 mmf. 500 V., ceramic	47X20UK250K	R-17,32	3300 ohms 1 watt, carbon	23X30X332K
C-37,39,40	Trimmers (part of RF coils L-8,9 and 10)	-----	R-18	Resistor; variable; 500 ohms ("S" METER ADJUSTMENT)	25C022
C-43	Trimmer (for RF coil L-10, band 1)	44A399	R-19	270 ohms 1/2 watt, carbon	23X20X271K
C-46	Trimmer, 7-35 mmf. (for osc. coil L-11)	44A378	R-20	150 ohms 1/2 watt, carbon	23X20X151K
C-47	2400 mmf. 500 V., mica	47X30D242J	R-22,33	22,000 ohms 1/2 watt, carbon	23X20X223K
C-48	1000 mmf. 500 V., mica	47X25D102J	R-23,34	10,000 ohms 1 watt, carbon	23X30X103K
C-49	Trimmer, 7-35 mmf. (for osc. coil L-12)	44A378	R-31	6800 ohms 1 watt, carbon	23X30X682K
C-50	470 mmf. 500 V., mica	47X20C471G	R-35	3000 ohms 10 watts, WW	24BG302E
C-51,53	Trimmers (part of osc. coils L-13 and 14)	-----	R-36	470 ohms 1/2 watt, carbon	23X20X471K
C-54	Padder, 170 mmf. (for osc. coil L-14)	44B398	R-37,60	470,000 ohms 1/2 watt, carbon	23X20X474K
C-56	Capacitor, temperature compensated	44A158	R-38	3.3 megohms 1/2 watt, carbon	23X20X335K
C-57,62	4700 mmf. 600 V., molded tubular paper	46A181	R-40,48	220 ohms 1/2 watt, carbon	23X20X221K
C-58,63	.01 mfd. 600 V., molded tubular paper	46A179	R-41,49	390 ohms 1/2 watt, carbon	23X20X391K
C-59,64	.022 mfd. 600 V., molded tubular paper	46A180	R-43	82,000 ohms 1/2 watt, carbon	23X20X823K
C-60,68,69, 70,71,77	.02 mfd. 600 V., tubular paper	46AY203J	R-44,55	47,000 ohms 1/2 watt, carbon	23X20X473K
C-65	.01 mfd. 600 V., molded paper	46X35X103M	R-45	Resistor, variable; 10,000 ohms (SENSITIVITY control)	25B590
C-66A,B,C	60-20-20 mfd. 450 V., electrolytic	45B113	R-46	1.5 megohms 1/2 watt, carbon	23X20X155K
C-73	560 mmf. 500 V., mica	47X20D561J	R-50	10,000 ohms 1/2 watt, carbon	23X20X103K
C-74	47 mmf. 500 V., ceramic	47X20UK470K	R-51	220,000 ohms 1/2 watt, carbon	23X20X224K
C-79,80	.005 mfd. 600 V., tubular paper	46AY502J	R-53	Resistor, variable; 500,000 ohms (VOLUME control)	25B534
C-81	10 mfd. 25V., electrolytic	45A121	R-54	15 megohms 1/2 watt, carbon	23X20X156K
C-82	.001 mfd. 600 V., tubular paper	46AZ102J	R-55	Resistor, variable; 500,000 ohms (TONE control)	25B605
			R-61	390 ohms 1 watt, carbon	23X30X391K
			R-62	560 ohms 1 watt, carbon	23X30X561K
			R-63	6.8 ohms 1 watt, carbon	23X30X068K
			R-64	Resistor, variable; 200 ohms ("S" METER ADJUSTMENT)	25B714
			R-65	22 ohms 1/2 watt, carbon	23X20X220K



LAST R SYMBOL R-65  
 LAST C SYMBOL C-82  
 LAST T SYMBOL T-8  
 LAST L SYMBOL L-16



1. RESISTOR VALUES ARE IN OHMS AND 1/2 WATT UNLESS OTHERWISE SPECIFIED.
  2. CAPACITOR VALUES ARE IN MMF UNLESS OTHERWISE SPECIFIED.
  3. BAND SELECTOR SWITCH (S1) SHOWN IN BAND I POSITION (EXTREME COUNTER-CLOCKWISE). SEE FIG.13 FOR LOCATION OF SWITCH SECTIONS.
  4. SELECTIVITY CONTROL (S2) SHOWN IN BROAD POSITION (EXTREME COUNTER-CLOCKWISE). SEE FIG.13 FOR LOCATION OF SWITCH SECTIONS.
- ⊥ CHASSIS GROUND
- ⊙ ON SOME SETS, "S" METER CIRCUIT IS AS SHOWN AT THE LEFT. WHEN MAKING REPLACEMENT, REFER TO APPROPRIATE CIRCUIT FOR SCHEMATIC SYMBOL AND THEN LOCATE PART IN SERVICE PARTS LIST.

VALUES AND TOLERANCES SHOWN ARE NOMINAL AND VARIATIONS MAY BE FOUND. IT IS RECOMMENDED THAT THE VALUE OF ANY REPLACEMENT CORRESPOND TO THE NOMINAL VALUE OF THE PART BEING REPLACED.

89F365-C

Fig. 15. Schematic Diagram

## Warranty

"The Hallicrafter's Company warrants each new radio product manufactured by it to be free from defective material and workmanship and agrees to remedy any such defect or to furnish a new part in exchange for any part of any unit of its manufacture which under normal installation, use and service discloses such defect, provided the unit is delivered by the owner to our authorized radio dealer, wholesaler, from whom purchased, or, authorized service center, intact, for examination, with all transportation charges prepaid within ninety days from the date of sale to original purchaser and provided that such examination discloses in our judgment that it is thus defective.

This warranty does not extend to any of our radio products which have been subjected to misuse, neglect, accident, incorrect wiring not our own, improper installation, or to use in violation of instructions furnished by us, nor extend to units which have been repaired or altered outside of our factory or authorized service center, nor to cases where the serial number thereof has been removed, defaced or changed, nor to accessories used therewith not of our own manufacture.

Any part of a unit approved for remedy or exchange hereunder will be remedied or exchanged by the authorized radio dealer or wholesaler without charge to the owner.

This warranty is in lieu of all other warranties expressed or implied and no representative or person is authorized to assume for us any other liability in connection with the sale of our radio products."

Form No. 94X622

*the Hallicrafters co.*