

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.
4HG8	4	38	25	4	5	3	2	1	5BK7	5	8	55					1	5HG8	5	38	24	4	5	3	2	1
4HK5	4	40	27	3	4	12	1	1	5BQ5	5	23	68					1	5HZ6	5	1	83	4	5	1	6	1
4HM5	4	40	27	3	4	2	1	1	5BQ7	5	8	54					1	5J6	5	2	60					1
4HM6	4	38	24	4	5	1	2	1				54					2				60					2
4HQ5	4	40	25	3	4	7	1	1	5BR8	5	14	72					1	5JN6	5	1	61					1
4HR8	4	38	33	4	5	2	9	1				55					2	5JL6	5	1	23					1
4HS8	4	21	99					1	5BS8	5	8	54					1	5JW8	5	11	80					1
			99					2				54					2				85					2
4HT6	4	38	28	4	5	1	2	1	5BT8	5	38	33	5	4	12	8	1	5KD8	5	11	68					1
4JC6	3	38	25	4	5	1	2	1				54	5	4	12	1	1				52					2
4JD6	4	38	26	4	5	1	2	1				54	5	4	12	2	1	5KE8	5	38	24	4	5	12	2	1
4JH6	4	1	64					1	5BW8	5	38	33	5	4	2	6	1				24	4	5	12	9	1
4JK6	4	1	61					1				34	5	4	7	1	1	5KZ8	5	38	26	4	5	12	2	1
4JL6	4	1	23					1				34	5	4	7	3	1				26	4	5	12	9	1
4JW8	4	11	80					1	5BZ7	5	8	53					1	5LJ8	5	14	85					1
			85					2				53					2				60					2
4KE8	4	38	24	4	5	12	2	1	5CG8	5	14	73					1	5MB8	5	14	84					1
4KF8	4	21	92					1				57					2				61					2
								2	5C18	5	14	69					1	5MF8	5	35	35	1	12	6	7	1
4KN8	4	38	92					2				51					2				34	1	12	6	10	1
4KT6	4	9	52					1	5CM6	5	16	64					1	5M-HH3	5	2	56					1
4LJ8	4	14	85					1	5CM8	5	38	33	5	4	12	2	1				56					2
								1				38	5	4	12	9	1	5M-K9	5	40	30	3	4	12	5	1
								1	5CQ8	5	11	72					1	5MQ8	5	11	65					1
								2				55					2				66					2
4LU6	4	1	52					1	5CR8	5	38	*32	5	4	12	2	1	5N1039A	6	1	63					1
4MK8	4	21	98					1				*34	5	4	12	9	1	5P-29	6	29	*62					1
			98					2									1				53					2
4M-P12	4	1	60					1									1									2
4M-P26	4	7	81					1	5CU4	5	37	28	8	2	12	4	1									1
4R-HH2	4	8	53					1				28	8	2	12	6	1				22					1
			53					2	5CZ5	5	16	60					1	5R4	5	33	22					2
4R-HH8	4	38	86	4	5	12	1	1	5DB4	5	33	16					1	5RDDH1	5	38	41	5	4	12	8	1
			90	4	5	12	6	1				16					2				35	5	4	12	1	1
								1	5DH8	5	14	61					1				33	5	4	12	6	1
4RHH15	4	8	53					1				73					2	5R-HP1	4	11	66					1
5AF4	5	40	*24	4	3	2	6	1	5DJ4	5	33	16					1				55					2
5AF11	5	35	31	1	12	12	11	1				16					2	5R-HR1	5	11	52					1
			31	1	12	12	6	1	5EA8	5	11	71					1				55					2
								1				56					2	5R-K16	5	38	27	4	5	12	1	1
5AM8	5	38	35	1	12	12	3	1	5EH8	5	12	71					1				27	4	5	12	8	1
			30	5	4	12	2	1				54					2	5T4	5	33	16					1
5AN8	5	13	30	5	4	12	8	1	5ES8	5	8	30					1				16					2
			62					1				30					2	5T8	5	17	90					1
			61					2	5EUR	5	38	32	5	4	12	7	1				63					2
5AQ5	5	3	77					1				32	5	4	12	2	1	5U4	5	33	16					1
5AR4	5	33	10					1	5EW6	5	1	77					1				16					2
			10					2	5FG7	5	14	68					1	5U8	5	11	79					1
5AS4	5	33	17					1				56					2				55					2
			17					2	5FV8	5	14	65					1	5U9	5	43	28	5	6	12	3	1
5AS8	5	38	31	5	4	12	2	1				54					2				32	5	6	12	10	1
			32	5	4	12	6	1	5GJ7	5	38	24	4	5	3	2	1	5V3	5	33	15					1
5AT8	5	14	77					1				26	4	5	3	9	1				15					2
			55					2	5GH8	5	11	68					1	5V4	5	33	12					1
5AU4	5	33	16					1				56					2				12					2
								2	5GH8A	5	11	68					1	5V6	5	29	79					1
5AV8	5	22	62					1				56					2	5V9	5	43	31	5	6	12	3	1
			86					2	5GM6	5	1	64					1				30	5	6	12	8	1
5AW4	5	33	17					1	5GS7	5	14	80					1	5W4	5	33	32					1
			17					2				53					2				32					2
5AZ4	5	36	53	8	2	12	4	1	5GX6	5	1	85					1	5X4	5	37	47	8	7	12	3	1
			53	8	2	12	6	1	5GX7	5	38	24	4	5	3	2	1				47	8	7	12	5	1
5B8	5	22	62					1				24	4	5	3	9	1	5X8	5	12	73					1
			86					2	5HA7	5	35	35	1	12	5	9	1				61					2
5BC3	5	42	*33	1	3	6	5	1				35	1	12	5	11	1	5X9	5	43	30	5	6	12	3	1
								1													30	5	6	12	10	1
								1	5HB7	5	38	24	4	5	3	2	1	5Y3	5	33	32					1
								2				24	4	5	3	9	1				32					2
								1	5HC7	5	35	*35	1	12	5	9	1	5Y4	5	37	52	8	7	12	3	1
								2				*35	1	12	5	11	1				52	8	7	12	5	1
								1																		1
								2																		1

*Normally Shows Short Position 2-3-8-9

**Normally Shows Short Position 2-3-5-6

*Normally shows short position 7-10

*Normal Shorts Refer to Position of "D" Switch.

4HG8-5Y4

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitivity	A	B	C	D	Test Pos.
5Z4	5	33	12					1	6AL9	6	35	28	1	12	12	5	1	6AX8	6	11	73					1
5Z10	5	33	16					1	6AL11	6	35	31	1	12	12	3	1	6AY3	6	42	27	5	4	7	2	1
6A8	6	37	45	7	2	1	5	1	6AM4	6	38	*96	8	7	1	5	1	6AY3B	6	42	27	5	4	7	2	1
6AB4	6	40	30	4	3	12	6	1	*Normally Shows Short Position 3-4-6-9.									6AY11	6	35	30	1	12	12	5	1
6AB7	6	30	74					1	6AM5	6	40	34	4	3	12	1	1				30	1	12	12	8	1
6AB8	6	38	37	5	4	12	9	1	6AM6	6	40	30	4	3	12	1	1				30	1	12	12	10	1
6AB9	6	43	79	5	6	10	2	1	6AM8	6	38	30	5	4	12	2	1	6AZ8	6	38	32	5	4	12	6	1
6AC5	6	37	79	5	6	4	8	1	6AN4	6	40	*30	4	3	2	6	1				36	5	4	12	9	1
6AC7	6	30	40	7	2	12	5	1	*May Show Short Position 1-7.									6B4	6	37	35	7	2	12	5	1
6AC9	6	35	28	1	12	3	9	1	6AN5	6	1	26					1	6B6	6	37	37	7	2	12	10	1
			45	1	12	3	2	1	6AN6	6	40	52	7	1	12	2	1				58	7	2	12	4	1
			35	1	12	2	3	1				52	7	1	12	4	1	6B8	6	37	55	7	2	12	10	1
6AC10	6	35	35	1	12	2	3	1	6AN8	6	13	62					1				65	7	2	12	5	1
			32	1	12	12	7	1				52	7	1	12	5	1	6B10	6	35	34	1	12	12	3	1
			32	1	12	12	9	1	6AQ4	6	40	*29	4	3	6	1	1				34	1	12	12	5	1
			32	1	12	12	11	1	*Normally Shows Short Position 2-5.												34	1	12	12	10	1
6AD7	6	37	54	7	2	12	5	1	6AQ5	6	3	77					1	6B31	6	5	62					1
6AD10	6	35	62	7	2	12	1	1	6AQ6	6	6	89					2	6B32	6	5	62					1
6AF3	6	15	33	1	12	12	8	1	6AQ7	6	37	45	8	7	12	4	1				62					2
6AF4	6	40	12					1				58	8	7	12	1	1	6BA3	6	42	33	4	5	7	2	1
6AF9	6	43	27	5	6	7	1	1	6AQ8	6	8	70	8	7	12	3	1	6BA6	6	1	78					1
6AF11	6	35	27	5	6	2	8	1	6AR5	6	3	70					1	6BA7	6	38	33	5	4	12	2	1
			31	1	12	12	11	1	6AR6	6	37	91					2	6BA8	6	12	53					1
6AG5	6	1	31	1	12	12	6	1	6AR8	6	38	33	8	6	12	7	1	6BA11	6	35	29	1	12	12	4	1
6AG7	6	30	35	1	12	12	3	1	6AR11	6	35	28	1	12	12	5	1	6B-B14	6	42	*37	1	12	12	9	1
6AG9	6	35	30	1	12	12	5	1				28	1	12	12	10	1	*Normally shows short position 3-6-7-8.								
6AG11	6	35	28	1	12	12	11	1	6AS5	6	4	55					1	6BC4	6	39	30	5	4	3	7	1
			28	1	12	12	8	1	6AS6	6	1	77					1	6BC5	6	1	74					1
			28	1	12	12	5	1	6AS7	6	37	35	8	7	12	1	1	6BC7	6	38	32	5	4	12	2	1
			33	1	12	12	10	1	6AS8	6	38	35	8	7	12	4	1				32	5	4	12	6	1
			33	1	12	12	3	1				31	5	4	12	2	1	6BC8	6	8	53					1
6AH4	6	37	33	7	2	12	1	1	6AS11	6	35	28	1	12	12	11	1				53					2
6AH6	6	1	58					1				32	1	12	12	6	1	6BC32	6	6	91					1
6AH7	6	37	48	8	7	12	1	1	6AT6	6	6	85	1	12	12	3	1				78					2
6AH9	6	35	48	8	7	12	5	1				78					1	6BD5	6	37	29	7	2	12	1	1
6AJ4	6	38	30	1	12	5	6	1	6AT8	6	14	77					2	6BD6	6	1	85					1
6AJ5	6	40	*84	8	7	1	5	1	6AU4	6	34	10					1	6BD11	6	35	26	1	12	12	11	1
6AJ7	6	30	36	4	3	2	1	1	6AU5	6	28	71					1				31	1	12	12	3	1
6AJ8	6	38	60					1	6AU6	6	1	82					1	6BE3	6	35	26	1	12	4	10	1
			85	5	4	12	1	1	6AU7	6	8	75					1	6BE6	6	1	91					1
			38	5	4	12	9	1	6AU8	6	12	75					2	6BE7	6	38	33	5	4	3	7	1
6AJ9	6	43	29	5	6	12	3	1	6AV5	6	28	62					2	6BE8	6	14	72					1
6AK5	6	1	33	5	6	12	10	1				72					1				55					2
6AK6	6	1	63					1	6AV6	6	6	91					1	6BF5	6	3	40					1
6AK7	6	30	82					1	6AV11	6	35	30	1	12	12	7	1	6BF6	6	6	85					1
6AK8	6	17	78					1				30	1	12	12	9	1				80					2
6AK9	6	35	90					2				30	1	12	12	11	1	6BF8	6	38	25	4	5	12	1	1
			63					1				30	1	12	12	11	1				25	4	5	12	2	1
			33	1	12	6	10	1	6AW8	6	12	44					1				25	4	5	12	3	1
6AK10	6	35	35	1	12	6	8	1	6AX2	6	24	78					2				25	4	5	12	7	1
			32	1	12	12	7	1	6AX3	6	35	88					1	6BF11	6	35	25	1	12	12	3	1
			32	1	12	12	9	1	6AX4	6	34	13					1	6BG6	6	26	66					1
			32	1	12	12	11	1	6AX5	6	37	44	7	2	1	5	1	6BH3	6	42	27	5	4	7	2	1
6AL3*	6	39	30	5	4	7	3	1	6AX7	6	8	44	7	2	1	3	1	6BH3A	6	42	27	5	4	7	2	1
6AL3	6	39	30	5	4	3	7	1				*85					1	6BH6	6	1	89					1
6AL5	6	5	62					2				*85					2	6BH8	6	12	59					1
			62					2	*Tube Good if it Reads 72 or More.												54					2

*Use TC-80 Adapter.

▲Use TC-75 Adapter.

*Normal Shorts Refer to Position of "D" Switch.

5Z4-6BH8

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.
6BH11	6	35	27	1	12	12	4	1	6BW8	6	38	33	5	4	2	6	1	6CK3	6	42	25	4	5	7	2	1
			27	1	12	12	6	1				34	5	4	7	1	1	6CK4	6	37	34	7	2	1	3	1
			27	1	12	12	8	1				34	5	4	7	3	1	6CK6	6	38	30	5	4	12	2	1
6BJ3	6	35	26	1	12	4	10	1	6BW11	6	35	30	1	12	12	3	1	6CL3	6	42	27	4	5	2	7	1
6BJ6	6	1	81					1				30	1	12	12	11	1	6CL5	6	26	54					1
6BJ7	6	38	33	5	4	12	2	1	6BX6	6	38	33	5	4	1	2	1	6CL6	6	38	*32	5	4	2	9	1
			33	5	4	12	6	1	6BX7	6	25	55					1	*Normally Shows Short Position 3-8.								
			33	5	4	12	8	1				55					2	6CL8	6	14	69					1
6BJ8	6	38	38	5	4	12	8	1	6BX8	6	38	33	5	4	12	2	1				51					2
			34	5	4	12	1	1				33	5	4	12	7	1	6CM3	6	42	30	4	5	2	7	1
									6BY5	5	37	38	7	2	12	4	1	6CM4	6	39	29	4	5	3	6	1
6BK4▲	6	37	78	7	2	6	5	1				38	7	2	12	5	1	6CM5	6	27	58					1
6BK4A▲	6	37	78	7	2	6	5	1	6BY6	6	1	93					1	6CM6	6	16	64					1
6BK4B▲	6	37	78	7	2	6	5	1	6BY7	6	38	33	5	4	1	2	1	6CM7	6	19	80					1
6BK5	6	10	53					1	6BY8	6	38	34	5	4	12	1	1				94					2
6BK6	6	6	86					1				34	5	4	12	6	1	6CM8	6	38	33	5	4	12	2	1
			70					2	6BY11	6	35	32	1	12	12	3	1				38	5	4	12	9	1
6BK7	6	8	55					1				32	1	12	12	8	1	6CN6	6	29	*62					1
			55					2	6BZ3	6	35	30	1	12	4	10	1	*For Plate Cap Use Jack Next to Socket 26.								
6BK11	6	35	35	1	12	12	7	1	6BZ6	6	1	61					1	6CN7	6	18	94					1
			35	1	12	12	9	1	6BZ7	6	8	53					1				60					2
			35	1	12	12	11	1				53					2	6CQ4	6	34	11					1
6BL4	6	34	10					1	6BZ8	6	8	55					1	6CQ6	6	40	35	4	3	12	1	1
6BL7	6	25	57					1				55					2	6CQ8	6	11	72					1
			57					2	6C4	6	40	41	4	3	1	6	1				55					2
6BL8	6	11	66					1	6C5	6	29	99					1	6CR6	6	40	39	4	3	12	7	1
			55					2	6C8	6	37	48	7	2	12	5	1				61	4	3	12	2	1
6BM8	6	38	33	5	4	12	3	1				48	7	2	12	10	1	6CR8	6	38	*32	5	4	12	2	1
			39	5	4	12	1	1	6C9	6	38	28	5	4	6	1	1				*34	5	4	12	9	1
6BN4	6	40	*33	4	3	2	7	1				28	5	4	10	7	1	*Normally Shows Short Position 8								
*Normally Shows Short Position 1-6.									6C10	6	35	42	1	12	12	7	1	6CS6	6	1	94					1
6BN5	6	38	*39	5	4	1	2	1	6C16	6	11	66					1	6CS7	6	20	96					1
*Normally Shows Short Position 6-8.												55					2				95					2
6BN6	6	7	75					1				42	1	12	12	9	1	6CT3	6	38	32	4	5	6	2	1
6BN8	6	38	35	5	4	12	8	1				42	1	12	12	11	1	6CU5	6	4	47					1
			35	5	4	12	1	1	6C18	6	38	30	4	5	8	7	1	6CU6	6	27	69					1
6BN11	6	35	35	5	4	12	6	1				33	4	5	8	9	1	6CU8	6	38	32	5	4	1	7	1
			29	1	12	12	3	1	6C31	6	40	*80	4	3	1	7	1				33	5	4	6	8	1
			29	1	12	12	7	1	*Normally Shows Short Position 5-6.									6CW4	6	41	*87	10	12	12	2	1
6BQ5	6	23	68					1	6CA4	6	38	34	5	4	12	1	1	*For Grid Emission Turn D Switch to Position 4.								
6BQ6	6	27	69					1				34	5	4	12	7	1	6CW5	6	23	58					1
6BQ7	6	8	54					1	6CA5	6	4	55					1	6CW7	6	38	33	5	4	7	2	1
			54					2	6CA7	6	29	53					1				33	5	4	7	6	1
6BR3	6	15	10					1	6CA11	6	35	35	1	12	8	3	1	6CX8	6	12	45					1
6BR8	6	14	72					1				33	1	12	8	6	1				67					2
			55					2				33	1	12	7	8	1	6CY5	6	1	54					1
6BS3	6	42	27	4	5	2	7	1	6CB5	6	26	43					1	6CY7	6	38	31	5	4	2	3	1
6BS3A	6	42	27	4	5	2	7	1	6CB6	6	1	64					1				45	5	4	2	7	1
6BS8	6	8	54					1	6CC31	6	2	60					1	6CZ5	6	16	60					1
			54					2				60					1	6D1	6	40	43	4	3	1	6	1
6BT6	6	6	85					1	6CCY2	6	38	29	9	1	12	3	1	6D2	6	5	62					1
			78					2				29	9	1	12	7	1				62					2
6BT8	6	38	33	5	4	12	8	1	6CD3	6	35	*27	1	12	4	10	1	6D4	6	40	43	4	3	12	1	1
			54	5	4	12	1	1	*Some tubes may show short position 5-6-8-9.									6D8	6	37	43	7	2	12	5	1
			54	5	4	12	2	1	6CD6	6	26	53					1	6D10	6	35	32	1	12	12	7	1
6BU6	6	6	85					1													32	1	12	12	9	1
			80					2	6CE3	6	35	25	1	12	4	10	1				32	1	12	12	11	1
6BU8	6	21	92					1	6CE5	6	1	62					1	6DA4	6	34	11					1
			92					2	6CF6	6	1	60					1	6DA6	6	38	34	5	4	1	2	1
6BV8	6	38	31	5	4	12	2	1	6CG3	6	35	30	1	12	4	10	1	6DB5	6	16	30					1
			33	5	4	12	6	1	6CG7	6	8	76					1									
			33	5	4	12	6	1				76					2	6DB6	6	1	87					1
6BV11	6	35	30	1	12	12	6	1	6CG8	6	14	73					1	6DC6	6	1	67					1
			30	1	12	12	7	1				57					2	6DC8	6	38	33	5	4	12	2	1
6BW3	6	35	28	1	12	4	10	1	6CH3	6	42	29	4	5	7	2	1				60	5	4	12	7	1
									6CH6	6	38	28	5	4	12	2	1				60	5	4	12	8	1
6BW4	6	38	50	5	4	12	1	1	6CH8	6	38	33	5	4	12	7	1	6DE4	6	34	13					1
			50	5	4	12	7	1				36	5	4	12	8	1	6DE6	6	1	61					1
6BW6	6	38	42	4	5	1	2	1	6CJ3	6	42	25	4	5	7	2	1	6DE7	6	20	81					1
6BW7	6	9	76					1	6CJ6	6	38	*32	5	4	7	2	1				90					2
									*Normally Shows Short Position 1-6-9.									6DG6	6	29	38					1

▲Use TC-75 Adapter.

*Normal Shorts Refer to Position of "D" Switch.

6BH11-6DG6

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	
6GM5	6	38	*26	4	5	2	6	1	6HG8	6	38	25	4	5	3	2	1	6JE6B	6	42	*26	4	5	6	2	1	
*May Show Short Position 3-8.									*Normally shows short position 1-7.									*Normally shows short position 1-7.									
6GM6	6	1	64					1	6HJ5	6	35	*27	1	12	3	11	1	6JE6C	6	42	*26	4	5	6	2	1	
6GM8	6	38	33	5	4	12	2	1	*Normally shows short position 4-5-9-10									*Normally shows short position 1-7.									
			33	5	4	12	7	1	6HJ7	6	38	*78	4	5	1	7	1	6JE8	6	12	56					1	
6GN7	6	9	21					1				30	4	5	1	9	1				78					2	
6GN8	6	12	36					2	*For grid emission turn D switch to position 2.									6JF6	6	42	*26	4	5	2	6	1	
			98					1	6HJ8	6	38	29	5	4	12	2	1	*Normally shows short position 1-7.									
6GQ7	6	38	24	4	5	3	2	1				31	5	4	12	8	1	6JG5	6	12	29					1	
			24	4	5	3	6	1	6HK5	6	40	27	3	4	12	1	1	6JG6	6	42	24	4	5	1	2	1	
								1	6HL5	6	38	30	4	5	1	2	1	6JG6A	6	42	24	4	5	1	2	1	
6GS7	6	14	80					1	6HL8	6	11	60					1	6JH5	6	35	*32	1	12	11	2	1	
			53					2				60					2	*Normally shows short position 3-7-8-10									
6GS8	6	21	95					1	6HM5	6	40	27	3	4	2	1	1	6JH6	6	1	64					1	
			95					2	6HM6	6	38	24	4	5	1	2	1	6JH8	6	38	30	4	5	12	6	1	
6GT5	6	42	*30	4	5	6	2	1	6HQ5	6	40	25	3	4	/	1	1	6JK5	6	35	*32	1	12	11	2	1	
*Normally Shows Short Position 1-7.									6HR5	6	3	77				1	*Normally shows short position 3-7-8-10										
6GT5A	6	42	*30	4	5	6	2	1	6HR6	6	1	71				1	6JK6	6	1	61					1		
*Normally shows short position 1-7.									6HS5	6	35	*30	1	12	11	2	1	6JK8	6	8	54					1	
6GU5	6	40	27	3	4	2	1	1	*Normally shows short position 3-10.											55					2		
6GU7	6	8	56					1	6HS6	6	1	66					1	6JL6	6	1	23					1	
			56					2	6HS8	6	21	99					1	6JL8	6	12	40					1	
6GV5	6	35	*26	1	12	5	9	1				99					2			70					2		
*Normally Shows Short Position 3-4-7-10-11.									6HT5	6	35	*52	1	12	2	6	1	6JM6	6	35	26	1	12	4	5	1	
6GV7	6	38	30	4	5	8	7	1	*May show short position 4-7-9-11.									6JN6	6	35	27	1	12	4	11	1	
			33	4	5	8	9	1	6HT6	6	38	28	4	5	1	2	1	6JN8	6	14	67					1	
6GV8	6	38	25	4	5	12	9	1	6HU6	6	38	52	4	5	2	1	1			53					2		
			25	4	5	12	2	1	6HU8	6	38	29	4	5	12	2	1	6JQ6	6	38	*34	4	5	8	7	1	
6GW5	6	40	29	3	4	6	2	1				29	4	5	12	6	1			57	4	5	8	6	1		
6GW6	6	27	62					1	6HV5	6	35	*33	1	12	2	11	1	*May show short position 2-3.									
6GW8	6	38	25	4	5	2	8	1	*Normally shows short position 3-10.									6JR6	6	42	34	4	5	1	2	1	
			35	4	5	7	1	1	6HW8	6	38	32	4	5	12	6	1	6JS6	6	35	*29	1	12	9	5	1	
6GX6	6	1	85					1	6HZ5	6	35	*30	1	12	2	11	1	*Normally shows short position 3-4-10-11									
6GX7	6	38	24	4	5	3	2	1	*Normally shows short position 3-10									6JT6	6	42	27	4	5	1	2	1	
			24	4	5	3	9	1	6HZ6	6	1	83					1	6JT6A	6	42	27	4	5	1	2	1	
6GY5	6	35	*25	1	12	5	9	1	6HZ8	6	12	28					1	6JT8	6	12	20					1	
*Normally shows short position 3-4-7-10-11.												75				2		*Tube good if it reads 60 or more.									
6GY6	6	1	82					1	6J4	6	40	*85	4	3	1	7	1	6JU6	6	42	*30	4	5	2	6	1	
6GY8	6	38	*32	5	4	12	1	1	*Normally Shows Short Position 5-6.									*Normally shows short position 1-7.									
			*32	5	4	12	3	1	6J5	6	29	93					1		*Normally shows short position 1-7.								
			*94	5	4	12	6	1	6J6	6	2	60					1	6JU8	6	38	*32	4	5	2	1	1	
*Normally Shows Short Position 4.												60				2			*32	4	5	5	8	7	1	1	
6GZ5	6	40	30	3	4	2	5	1	6J7	6	37	50	7	2	1	10	1	*Normally Shows Short Position 8.									
6H6	6	37	48	7	2	1	3	1	6J9	6	38	26	4	5	12	2	1	**Normally Shows Short Position 2.									
			48	7	2	1	5	1				26	4	5	12	9	1	6JU8A	6	38	*32	4	5	2	1	1	
6H31	6	1	91					1				26	4	5	12	7	1			*32	4	5	8	7	1		
6HA5	6	40	27	3	4	2	1	1	6J10	6	35	96	1	12	12	6	1	*Normally shows short position 8.									
6HA6	6	9	23					1	6J11	6	35	28	1	12	12	11	1	**Normally shows short position 2.									
6HB5	6	35	*25	1	12	11	3	1				22	1	12	12	5	1	6JV8	6	12	55					1	
*Normally Shows Short Position 4-10.												22	1	12	12	11	1			85					2		
6HB6	6	38	*24	4	5	6	2	1	6JA8	6	38	25	4	5	12	7	1	6JW8	6	11	80					1	
*Normally Shows Short Position 3-9.												95	4	5	12	3	1			85					2		
6HB7	6	38	24	4	5	3	2	1	6JB5	6	35	*35	1	12	9	2	1	6JX8	6	38	23	4	5	12	2	1	
			24	4	5	3	9	1	*Normally shows short position 3-4-10-11.											26	4	5	12	9	1		
6HC8	6	38	36	5	4	12	3	1	6JB6	6	42	*29	4	5	6	2	1	6JY8	6	12	40					1	
			38	5	4	12	1	1	*Normally Shows Short Position 1-7.											55					2		
6HD5	6	35	*27	1	12	3	11	1	6JB6A	6	42	*29	4	5	6	2	1	6JZ6	6	35	*31	1	12	9	5	1	
*Normally shows short position 4-5-9-10									*Normally shows short position 1-7.									*Some tubes may show short position 3-4-10-11.									
6HD7	6	38	30	4	5	1	2	1	6JC5	6	35	*32	1	12	9	2	1	6JZ8	6	35	29	1	12	6	7	1	
			30	4	5	1	9	1	*Normally shows short position 3-4-10-11											40	1	12	6	10	1		
6HE5	6	35	*32	1	12	9	2	1	6JC6	6	38	25	4	5	1	2	1	6K6	6	29	92					1	
*Normally Shows Short Position 3-4-10-11									6JC6A	6	9	59				1	6K7	6	37	52	7	2	1	10	1		
6HE7	6	35	27	1	12	10	2	1	6JC8	6	38	24	4	5	1	2	1	6K8	6	37	35	7	2	1	5	1	
			27	1	12	10	9	1				24	4	5	1	8	1	6K11	6	35	38	1	12	12	7	1	
6HF5	6	35	*25	1	12	9	5	1	6JD5	6	35	*30	1	12	2	11	1			38	1	12	12	9			
*Normally Shows Short Position 3-4-6-8-10-11.									*Normally shows short position 3-10											38	1	12	12	11	1		
6HF8	6	12	27					1	6JD6	6	38	26	4	5	1	2	1	6KA8	6	38	26	4	5	12	6	1	
			80					2	6JE6	6	42	*26	4	5	6	2	1			33	4	5	12	2	1		
6HG5	6	3	85					1	*Normally shows short position 1-7									6KD6	6	35	*26	1	12	9	5	1	
																		*Normally shows short position 3-4-10-11.									

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	
6KD8	6	11	68					1	6LJ8	6	14	85					1	6ML8	6	38	34	4	5	12	6	1	
			52					2				60					2										
6KE8	6	38	24	4	5	12	2	1	6LM8	6	11	68					1										
			24					1				58					2										
6KF8	6	21	92					1	6LN8	6	11	66					1	6MN8	6	35	33	1	12	7	8	1	
								2				55					2										
6KG6♦	6	42	*26	4	5	1	8	1	6LP12	6	39	33	5	4	12	3	1										
	*Normally shows short position 2-3-6-7.											39	5	4	12	1	1	6M-P17	6	3	33	1	12	7	10	1	
6KL8	6	38	31	4	5	12	2	1	6LQ6	6	42	*26	4	5	6	2	1		6M-P18	6	40	34	3	4	7	1	1
			70					1		*Normally shows short position 1-7.								6MP20	6	1	43					1	
6KM6	6	42	*29	4	5	6	2	1	6LQ8	6	12	31					1	6MQ8	6	11	65					1	
	*Normally shows short position 1-7											50					2										
6KM8	6	38	31	4	5	12	7	1	6LR6	6	35	*32	1	12	9	5	1	6MU8	6	11	42					1	
			75					1		*May show short position 3-4-7-10-11.																2	
6KN6	6	35	*30	1	12	9	5	1	6LR8	6	42	31	4	5	12	2	1	6MV8	6	12	63					1	
	*Normally shows short position 3-4-10-11.											31	4	5	12	9	1	6MX8	6	42	27	4	5	12	2	1	
6KN8	6	38	86	4	5	12	1	1	6LT8	6	38	27	4	5	7	9	1									1	
			90					1				32	4	5	1	6	1	6MY8	6	35	27	1	12	6	7	1	
6KR8	6	12	22					1				32	4	5	1	8	1									1	
								2	6LU6	6	1	52					1	6N3	6	38	29	4	5	6	9	1	
6KR8A	6	12	22					1	6LU8	6	35	27	1	12	6	7	1	6N7	6	37	47	7	2	1	4	1	
			59					2				35	27	1	12	6	10									1	
6KS6	6	7	83					1	6LV6	6	35	*31	1	12	5	9	1	6N8	6	38	37	5	4	12	2	1	
6KS8	6	12	33					1		*May show short position 3-4-7-10-11																1	
								2	6LW6	6	37	*31	7	8	1	5	1										1
6KT6	6	9	84					1		*Normally shows short position 2-6.								6NK7GT	6	30	84					1	
6KT8	6	12	67					1	6LX8	6	11	80					1	6P5	6	29	93					1	
			91					2				85					2	6P15	6	23	68					1	
6KU8	6	38	22	4	5	12	7	1	6LY8	6	12	21					1	6PL12	6	39	33	5	4	12	3	1	
								1				*99					2									1	
			60	4	5	12	2	1		*Tube good if it reads 28 or more								6Q7	6	37	40	7	2	1	10	1	
6KV6	6	42	30	4	5	1	2	1	6LZ6	6	42	*31	4	5	6	2	1									1	
6KV8	6	12	22					1		*Normally shows short position 1-7																	1
			82					2	6M11	6	35	25	1	12	12	5	1	6Q8	6	37	45	7	2	1	5	1	
6KW6♦	6	42	30	4	5	1	8	1				25	1	12	12	8	1	6Q11	6	35	38	1	12	12	7	1	
6KY6	6	9	20					1				25	1	12	12	8	1									1	
6KY8	6	42	27	4	5	12	2	1	6MA6	6	37	*58	3	8	2	6	1									1	
			39					1		*Tube good if it reads 40 or more.								6R3	6	38	33	5	4	2	9	1	
6KY8A	6	42	27	4	5	12	2	1		*No Short test.								6R4	6	38	30	4	5	12	1	1	
6KZ8	6	38	26	4	5	12	2	1	6MB6	6	35	*32	1	12	9	5	1	6R7	6	37	52	7	2	1	10	1	
			26					1		*Normally shows short position 3-4-10-11.																	1
6L5	6	37	53	7	2	6	5	1	6MB8	6	14	84					1									1	
6L6	6	29	63					1				61					2	6R8	6	17	86					1	
6L7	6	37	44	7	2	1	10	1	6MC6	6	42	*29	4	5	6	2	1									2	
								1		*Normally shows short position 1-7								6RA6	6	39	34	4	5	9	7	1	
6L10	6	30	38					1	6MD8	6	42	35	4	5	12	6	1	6R-A9	6	38	30	4	5	7	2	1	
6L12	6	8	70					2				35	4	5	12	8	1	6R-B11	6	38	32	4	5	6	3	1	
			70					2				35	4	5	12	9	1	6R-HH2	6	8	53					1	
6L41	6	38	33	5	4	8	9	1	6ME6	6	42	*29	4	5	6	2	1									2	
6L43	6	38	*32	5	4	2	9	1		*Normally shows short position 1-7.								6R-HH8	4	38	86	4	5	12	1	1	
	*Normally Shows Short Position 3-8.								6ME8	6	38	30	4	5	12	6	1										1
6LB6	6	35	*30	1	12	9	5	1	6MF8	6	35	35	1	12	6	7	1	6R-K19	6	15	10					1	
	*Normally shows short position 3-4-10-11.											34	1	12	6	10	1	6R-P15	6	38	35	4	5	1	2	1	
6LB8	6	12	21					1	6MG8	6	11	80					1	6R-P22	6	38	*32	4	5	2	9	1	
			71					2				59					2		*Normally shows short position 3-8.								
6LC6▲	6	37	78	7	2	12	5	1	6M-H1	6	40	*85	4	3	1	7	1	6S2	6	24	35					1	
6LC8	6	38	24	4	5	3	6	1		*Normally shows short position 5-6								6S4	6	16	58					1	
			24					1	6MH6	6	35	*31	1	12	5	9	1	6S7	6	37	47	7	2	1	10	1	
6LD6	6	9	51					1		*May show short position 3-4-7-10-11								6S8	6	37	45	8	7	5	10	1	
6LD12	6	16	90					1	6M-HH3	6	2	56					1									1	
								2				56					2									1	
6LE8	6	38	29	4	5	12	9	1	6MJ6	6	42	*26	4	5	6	2	1									1	
6LF6	6	35	*31	1	12	5	9	1		*Normally shows short position 1-7								6SA7	6	37	37	7	2	1	5	1	
	*May show short position 3-4-7-10-11.								6MJ8	6	35	35	1	12	7	8	1		6SB7Y	6	37	34	7	2	1	5	1
6LF8	6	12	55					1				35	1	12	7	10	1		6SC7	6	37	48	8	7	1	3	1
								2				35	1	12	7	11	1									1	
6LG6	6	35	*32	1	12	9	5	1	6MK8	6	21	98					1	6SD7	6	30	69					1	
	*May show short position 2-3-4-7-10-11.											98					2	6SF5	6	37	41	8	7	1	3	1	
6LH6▲	6	37	78	7	2	12	5	1	6M-L4	6	40	*24	4	3	2	6	1		6SF7	6	37	46	8	7	1	2	1
6LJ6▲	6	37	78	2	7	12	5	1		*Normally shows short position 1-7.																	1

♦Use TC-80 Adapter

♦Use TC-80 Adapter.

*Normal Shorts Refer to Position of "D" Switch.

6KD8 - 6SF7

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.
6SG7	6	30	77					1	6Y10	6	35	29	1	12	4	3	1	7KZ6	7	9	17					1
6SH7	6	30	77					1				29	1	12	4	8	1				65	8	1	12	5	1
6SJ7	6	30	83					1	6Z10	6	35	30	1	12	12	11	1				65	8	1	12	6	1
6SK7	6	30	84					1				95	1	12	12	6	1	7L7	6	36	36	8	1	12	6	1
6SL7	6	25	*85					1										7M-P18	7	40	34	3	4	7	1	1
			*85					2	6Z31	6	40	44	4	3	12	1	1	7N7	6	36	42	8	1	12	4	1
			*Tube Good If It Reads 22 or More.									44	4	3	12	6	1				42	8	1	12	5	1
6SN7	6	25	78					1	6ZY5	6	33	17						7Q7	6	36	35	8	1	12	4	1
			78					2	7A4	6	36	41	8	1	12	6	1	7R7	6	36	35	8	1	12	6	1
6SQ7	6	37	42	8	7	1	2	1	7A5	6	36	34	8	1	12	6	1				72	8	1	12	3	1
			71	8	7	1	4	1	7A6	6	36	48	8	1	12	3	1				72	8	1	12	4	1
6SR7	6	37	71	8	7	1	5	1				48	8	1	12	6	1	7S7	6	36	38	8	1	12	6	1
			46	8	7	1	2	1	7A7	6	36	45	8	1	12	6	1				52	8	1	12	4	1
			68	8	7	1	4	1	7A8	6	36	40	8	1	12	4	1	7V7	6	36	32	8	1	12	6	1
			68	8	7	1	5	1	7AD7	6	36	35	8	1	12	6	1	7W7	6	36	31	8	1	4	6	1
6SS7	6	37	46	7	2	1	4	1	7AF7	6	36	41	8	1	12	4	1	7X6	6	36	35	8	1	12	3	1
6ST7	6	37	52	8	7	1	2	1				41	8	1	12	5	1				35	8	1	12	6	1
			72	8	7	1	4	1	7AG7	6	36	32	8	1	12	6	1	7X7	6	36	43	8	1	12	3	1
			72	8	7	1	5	1	7AH7	6	36	32	8	1	12	6	1				36	8	1	12	5	1
6SU7	6	37	43	8	7	2	1	1	7AK7	6	36	33	8	1	12	6	1				35	8	1	12	6	1
			43	8	7	12	4	1	7AN7	7	38	33	5	4	7	2	1	7Y4	6	36	45	8	1	12	3	1
6SZ7	6	37	44	8	7	1	2	1				33	5	4	7	6	1	7Z4	6	36	45	8	1	12	6	1
			72	8	7	1	4	1	7AU7	7	8	75					1			50	8	1	12	3	1	
			72	8	7	1	5	1	7B4	6	36	40	8	1	12	6	1				50	8	1	12	6	1
6T4	6	40	*33	4	3	2	6	1				75				2		8A8	8	11	66					1
			*Normally Shows Short Position 1-7.						7B5	6	36	52	8	1	12	6	1	8AC9	8	35	28	1	12	3	9	1
6T8	6	17	90					1	7B6	6	36	40	8	1	4	3	1				45	1	12	3	2	1
			63					2				68	8	1	4	5	1				35	1	12	2	3	1
6T8A	6	17	90					1	7B7	6	36	45	8	1	12	6	1	8AC10	8	35	32	1	12	12	7	1
			63					2				68	8	1	4	5	1				32	1	12	12	9	1
6T9	6	35	27	1	12	12	8	1	7B8	6	36	42	8	1	12	4	1				32	1	12	12	11	1
			27	1	12	12	4	1	7C4	6	36	53	8	1	12	4	1	8AL9	8	35	28	1	12	12	5	1
6T10	6	35	28	1	12	12	3	1	7C5	6	36	38	8	1	12	6	1				28	1	12	12	11	1
			25	1	12	12	8	1	7C6	6	36	50	8	1	4	3	1	8AR11	8	35	28	1	12	12	5	1
6U4	6	34	11					1				68	8	1	4	5	1				28	1	12	12	10	1
6U6	6	29	54					1				37	8	1	12	6	1	8AU8	8	12	56					1
6U7	6	37	35	7	2	12	10	1	7C7	6	36	37	8	1	12	6	1				72					2
6U8	6	11	79					1	7D10	6	9	55					1	8AV11	8	35	30	1	12	12	7	1
			55					2	7DJ8	7	38	31	5	4	12	2	1				30	1	12	12	9	1
6U9	6	43	28	5	6	12	3	1				31	5	4	12	7	1				30	1	12	12	11	1
			32	5	6	12	10	1	7E5	6	36	*33	8	2	1	5	1	8AW8	8	12	44					1
6U10	6	35	32	1	12	12	7	1				40	8	1	4	3	1				78					2
			32	1	12	12	9	1	7E6	6	36	40	8	1	4	3	1	8B8	8	38	33	4	5	12	3	1
			32	1	12	12	11	1				69	8	1	4	5	1				39	4	5	12	1	1
6V3	6	15	10					1				69	8	1	4	6	1	8B10	8	35	34	1	12	12	3	1
6V4	6	38	40	5	4	12	1	1	7E7	6	36	47	8	1	12	6	1				34	1	12	12	5	1
			40	5	4	12	7	1				68	8	1	12	3	1				34	1	12	12	8	1
6V6	6	29	79					1				68	8	1	12	4	1				34	1	12	12	10	1
6V8	6	38	40	5	4	12	6	1	7ES8	7	8	30					1	8BA8	8	12	53					1
			32	5	4	12	2	1				30				2					59					2
			32	5	4	12	7	1	7EY6	7	29	65					1	8BA11	8	35	29	1	12	12	4	1
			61	5	4	12	9	1	7F7	6	36	45	8	1	12	4	1				37	1	12	12	9	1
6V9	6	43	31	5	6	12	3	1				45	8	1	12	5	1	8BH8	8	12	59					1
			30	5	6	12	8	1	7F8	6	36	30	7	2	12	1	1				54					2
6W4	6	34	11					1				30	7	2	12	8	1	8BM11	8	35	30	1	12	12	6	1
6W6	6	29	51					1	7FC7	7	38	29	4	5	7	2	1				30	1	12	12	11	1
6W7	6	37	50	7	2	12	10	1				29	4	5	7	6	1	8BN8	8	38	35	5	4	12	8	1
6X4	6	40	44	4	3	12	1	1	7G7	6	36	36	8	1	12	6	1				35	5	4	12	1	1
			44	4	3	12	6	1	7GS7	7	14	80					1	8BN11	8	35	29	1	12	12	3	1
6X5	6	33	15					1				53				2					29	1	12	12	7	1
			15					2	7GV7	7	38	30	4	5	8	7	1	8BQ5	8	23	68					1
6X6	6	37	48	7	2	12	3	1				33	4	5	8	9	1	8BQ7	8	8	54					1
			48	7	2	12	5	1	7H7	6	36	35	8	1	12	6	1				54					2
6X8	6	12	73					1	7HG8	7	38	25	4	5	3	2	1	8BQ11	8	35	28	1	12	12	5	1
			61					2				25	4	5	1	6	1				28	1	12	12	10	1
6X9	6	43	30	5	6	1																				

*Normal Shorts Refer to Position of "D" Switch.

6SG7-8CB11

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.
8CG7	8	8	76					1	8KT8	8	12	67					1	9KG6♦	9	42	*26	4	5	1	8	1
8CH8	8	38	33	5	4	12	7	1	8LC8	6	38	24	4	5	3	6	1	*Normally shows short position 2-3-6-7.	9	12	22					1
8CL8	8	14	69	5	4	12	8	1	8LE8	8	38	24	4	5	6	2	1	9KV8	9	9	82					2
8CM7	8	19	51					2	8LS6	8	9	44					1	9KX6	9	9	16					1
8CN7	8	18	80					1	8LT8	8	38	27	4	5	7	9	1	9KZ8	9	38	26	4	5	12	2	1
8CS7	8	20	96					1	8MD8	8	42	32	4	5	1	8	1	9LA6	9	9	21					1
8CU8	8	38	32	5	4	1	7	1	8M-P12	8	1	60					1	9M-HH3	9	2	56					2
8CW5	8	23	33	5	4	6	8	1	8MU8	8	11	42					2	9ML8	9	38	34	4	5	12	6	1
8CX8	8	12	45					1	8R-HP1	8	38	33	4	5	12	3	1	9MN8	9	35	33	1	12	7	10	1
8CY5	8	1	67					2	8RLP1	8	38	39	4	5	12	1	1	9M-P12	9	40	38	3	4	2	1	1
8CY7	8	38	54	4	5	12	1	1	8SN7	8	25	35	4	5	12	1	1	9R-A6	9	39	34	4	5	9	7	1
8D8	8	38	45	5	4	2	7	1	8X9	8	43	32	5	6	12	10	1	9R-AL1	9	38	33	4	5	2	3	1
8DE7	8	20	81					1	8U9	8	43	28	5	6	12	3	1	9R-HR2	9	11	68					1
8DX8	8	38	90					2	8X9	8	43	30	5	6	12	3	1	9U8	9	11	79					2
8EB8	8	12	26	4	5	12	8	1	9A8	9	11	78					1	9V9	9	43	56					1
8EM5	8	16	41	5	4	2	9	1	9AB4	9	40	30	4	3	12	6	1	9X8	9	12	79					2
8ET7	8	38	81					1	9AH9	9	35	37	1	12	5	2	1	10AF11	10	35	55					1
			90					2	9AK8	9	16	30	1	12	5	6	1			61					2	
8FQ7	8	8	70	5	4	12	3	1	9AK10	9	35	30	1	12	5	6	1	10AL11	10	35	31	1	12	12	3	1
8GJ7	8	38	68					2				32	1	12	12	7	1	10BQ5	10	23	27	1	12	12	8	1
8GM6	8	1	68					1	9AM10	9	35	32	1	12	12	11	1	10C8	10	13	68					1
8GN8	8	12	24	4	5	3	9	1	9AQ8	9	8	32	1	12	12	11	1	10CW5	10	23	59					2
8GU7	8	8	26	4	5	3	9	1				34	1	12	12	9	1	10DE7	10	20	73					1
8GX7	8	38	56					2	9AU7	9	8	70					1	10D2	19	5	81					1
8HA6	8	9	56					1	9BJ11	9	35	75					2	10DR7	10	38	90					2
8HG8	8	38	95					2	9BR7	9	38	75					1	10DX8	10	38	32	5	4	2	3	1
8JE8	8	12	23	4	5	3	2	1				28	1	12	12	6	1			41	5	4	2	7	1	
8JK8	8	8	25	4	5	1	6	2	9BR8	9	14	28	1	12	12	11	1	10E/312	25	29	26	4	5	12	1	1
8JL8	8	12	40					1	9CG8A	9	14	32	5	4	9	2	1	10E/349	6	29	47					1
8JT8	8	12	56					2				37	5	4	9	6	1	10E/558	6	37	79					1
8JU8A	8	38	78					1	9CL8	9	14	37	5	4	9	7	1	10E/11448	6	29	52	7	2	12	10	1
			54					2	9DZ8	9	38	72					1	10E/11533	6	29	93					1
			55					1	9EA8	9	11	55					2	10E/11581	6	37	63					1
			40					2	9EG8A	9	14	73					1	10EB8	10	12	40	7	2	12	10	1
			70					2				57					2	10EG7	10	37	35					1
			20					1	9GL8	9	14	69					1	10EM7	10	37	99					2
			*99					2	9DZ8	9	38	51					2	10EW7	10	20	32	8	7	12	1	1
			*32	4	5	2	1	1	9EA8	9	11	27	4	5	8	3	1	10FD7	10	37	45	8	7	12	4	1
			**32	4	5	8	7	1	9ED4♦	9	42	30	4	5	2	1	1	10FR7	10	38	32	8	7	12	1	1
			**Normally shows short position 8.					1	9GH8A	9	11	68					1	10GF7	10	42	32	4	5	2	7	1
			**Normally shows short position 2.					2				56					2	10GH8	10	11	25	4	5	2	3	1
8JV8	8	12	85					1	9GV8	9	38	25	4	5	12	9	1	10GK6	10	38	32	4	5	2	7	1
8K11	8	35	38	1	12	12	7	1	9HS6	9	1	66					1	10GM8	10	38	27	4	5	12	2	1
8KA8	8	38	38	1	12	12	11	1	9J6	9	2	60					1			38	4	5	12	9	1	
8KR8	8	12	26	4	5	12	6	1	9JW8	9	11	80					2	10H8	10	11	68					1
8KS8	8	12	33	4	5	12	2	1	9KC6	9	38	25	4	5	12	2	1			56					2	
			84					2				83	4	5	12	9	1	10K6	10	38	33	5	4	3	2	1
																	2	10M8	10	38	33	5	4	12	2	1
																	1			33	5	4	12	7	1	

♦Use TC-80 Adapter

*Normal Shorts Refer to Position of "D" Switch.

8CG7 - 10GM8

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.
10GN8	10	12	36					1	11JE8	10	12	56					1	12AW8	12	12	44					1
			98					2				78					2				78					2
10GV8	10	38	25	4	5	12	9	1	11KV8	10	12	22					1	12AX3	12	35	30	1	12	10	4	1
			25	4	5	12	2	1				82					2	12AX4	12	34	13					1
10HA6	10	9	23					1	11LQ8	12	12	31					1	12AX7	12	8	*85					1
10HF8	10	12	27					1				50					2				*85					2
			80					2	11LT8	12	38	27	4	5	7	9	1				*Tube Good if it Reads 22 or More.					
10JA5	10	35	*33	1	12	9	2	1				32	4	5	1	6	1	12AY3	12	42	27	5	4	7	2	1
*Normally shows short position 3-4-10-11												32	4	5	1	8	1	12AY3A	12	42	27	5	4	7	2	1
10JA8	10	38	25	4	5	12	7	1	11LY6	10	9	46					1	12AY7	12	8	93					1
			95	4	5	12	3	1	11MS8	10	38	25	4	5	12	9	1				93					2
10JT8	10	12	20					1				25	4	5	12	2	1	12AZ7	12	8	73					1
*Tube good if reads 60 or more.			*99					2	11R3	10	38	33	5	4	2	9	1				73					2
10JY8	10	12	36					1	11Y9	12	43	27	5	6	12	1	1	12B4	12	39	35	5	4	3	7	1
			61					2				27	5	6	12	8	1	12B7	12	36	45	8	1	12	6	1
10KR8	10	12	22					1	12A4	12	39	32	5	4	3	7	1	12BA6	12	1	78					1
			59					2	12A6	12	29	92					1	12BA7	12	38	33	5	4	12	2	1
10KU8	10	38	22	4	5	12	7	1	12A8	12	37	45	7	2	12	5	1	12BA11	12	35	28	1	12	12	4	1
			60	4	5	12	2	1	12AB5	12	16	67					1				36	1	12	12	9	1
			60	4	5	12	3	1	12AC6	12	40	42	4	3	12	1	1	12B-B14	12	42	*33	4	5	1	2	1
10LB8	10	12	21					1	12AC10	12	35	32	1	12	12	7	1				*Normally shows short position 3-6-7-8.					
			71					2				32	1	12	12	9	1	12BC32	12	6	91					1
10LD6	10	9	51					1				32	1	12	12	11	1				78					2
10LD12	10	17	90					1	12AD6	12	40	35	4	3	12	1	1	12BD6	12	1	85					1
			63					2	12AD7	12	8	85					1	12BE3	12	35	26	1	12	4	10	1
10LE8	10	38	29	4	5	12	9	1				85					2	12BE6	12	1	91					1
10LW8	10	12	25					1	12AE6	12	40	52	4	3	12	1	1	12BF6	12	6	85					1
			92					2				66	4	3	12	5	1				80					2
10LY8	10	12	21					1	12AE7	12	38	32	5	4	9	2	1	12BF11	12	35	25	1	12	12	3	1
			*99									32	5	4	9	7	1				25	1	12	12	8	1
*Tube good if it reads 28 or more.			54					1	12AE10	12	35	30	1	12	12	8	1	12BH7	12	8	56					1
*Tube good if it reads 40 or more			*99					2				31	1	12	12	3	1	12BK5	12	10	53					1
10T10	10	35	28	1	12	12	3	1	12AF3	12	15	12					1	12BK6	12	6	86					1
			25	1	12	12	8	1	12AF6	12	40	37	4	3	12	1	1				70					2
10Z10	10	35	30	1	12	12	11	1	12AF11	12	35	31	1	12	12	11	1	12BL6	12	40	35	4	3	12	1	1
			95	1	12	12	6	1				31	1	12	12	6	1	12BN6	12	7	75					1
11AF9	10	43	27	5	6	7	1	1	12AG6	12	40	35	4	3	12	1	1	12BQ6	12	27	69					1
			27	5	6	7	1	1	12AH7	12	37	48	8	7	12	1	1	12BR3	12	15	10					1
11AR11	12	35	27	5	6	2	8	1				48	8	7	12	5	1	12BR7	12	38	32	5	4	9	2	1
			28	1	12	12	5	1	12AJ6	12	40	40	4	3	12	1	1				36	5	4	9	6	1
11BM8	12	38	33	5	4	12	3	1				66	4	3	12	5	1				36	5	4	9	7	1
			39	5	4	12	1	1	12AJ7	12	38	32	5	4	12	2	1	12BS3	12	42	27	4	5	2	7	1
11BN11	10	35	29	1	12	12	3	1				35	5	4	12	9	1	12BT3	12	35	27	1	12	4	10	1
			29	1	12	12	7	1	12AL5	12	5	62					1	12BT6	12	6	85					1
11BQ11	10	35	28	1	12	12	5	1				62					2	12BU6	12	6	85					1
			28	1	12	12	10	1	12AL8	12	38	34	5	4	12	3	1				80					2
11BT11	10	35	27	1	12	6	11	1				52	5	4	12	8	1	12BV7	12	9	39					1
			30	1	12	8	5	1	12AL11	12	35	31	1	12	12	3	1	12BV11	12	35	30	1	12	12	6	1
11C5	12	4	54					1				77	1	12	12	8	1				30	1	12	12	7	1
11CA11	10	35	35	1	12	8	3	1	12AQ5	12	3	77					1	12BW4	12	38	50	5	4	12	1	1
			33	1	12	8	6	1	12AS5	12	4	55					1				50	5	4	12	7	1
			33	1	12	8	6	1	12AT6	12	6	85					1	12BX6	12	38	33	5	4	1	2	1
11CF11	10	35	34	1	12	7	9	1				78					2	12BX7	12	25	55					1
			34	1	12	8	11	1	12AT7	12	8	74					1				55					2
			32	1	12	8	5	1				74					2	12BY7	12	9	42					1
11CH11	10	35	31	1	12	6	11	1	12AU5	12	28	71					1	12BZ6	12	1	61					1
			34	1	12	8	5	1	12AU6	12	1	82					1	12BZ7	12	8	95					1
11CY7	12	38	31	5	4	2	3	1	12AU7	12	8	75					1				95					2
			45	5	4	2	7	1				75					2	12C5	12	4	44					1
11DS5	10	3	76					1	12AU8	12	12	56					1	12C8	12	37	55	7	2	12	10	1
11FY7	12	35	25	1	12	12	3	1				72					2				65	7	2	12	4	1
			42	1	12	12	10	1	12AV5	12	28	62					1				65	7	2	12	5	1
11HM7	10	38	*29	4	5	6	2	1	12AV6	12	6	91					1	12C8Y	12	37	55	7	2	12	10	1
*Normally shows short position 3-9.												78					2				65	7	2	12	4	1
									12AV7	12	8	55					1	12CA5	12	4	55					1
												55					2	12CK3	12	42	25	4	5	7	2	1
									12AW6	12	1	78					1	12CL3	12	42	27	4	5	2	7	1

◆Use TC-80 Adapter.

*Normal Shorts Refer to Position of "D" Switch.

10GN8 - 12CL3

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.			
12CM6	12	16	64					1	12E13	6	29	52					1	12H6	12	37	48	7	2	12	3	1			
12CN5	12	40	33	4	3	2	5	1	12EA6	12	40	32	4	3	12	1	1	12H31	12	1	91					1			
12CR6	12	40	39	4	3	12	7	1	12EC8	12	38	30	5	4	12	9	1	12HB25♦	12	42	*33	4	5	1	2	1			
			61	4	3	12	2	1				32	5	4	12	1	1	*Normally shows short position 3-6-7-8.											
12CS6	12	1	94					1	12ED5	12	4	57					1	12HE7	12	35	27	1	12	10	2	1			
12CT3	12	38	32	4	5	6	2	1	12EG6	12	40	36	4	3	12	1	1				27	1	12	10	9	1			
12CT8	12	13	57					2	12EH5	12	4	57					1	12HG7	12	9	28					1			
			63					1	12EK6	12	40	31	4	3	12	1	1	12HL5	12	38	30	4	5	1	2	1			
12CU5	12	4	47					1	12EL6	12	40	38	4	3	12	1	1	12HL7	12	38	*33	4	5	6	2	1			
12CU6	12	27	69					1				68	4	3	12	5	1	*Normally shows short position 3-9.											
12CX6	12	40	30	4	3	12	1	1	12EM6	12	38	34	5	4	12	1	1	12HU8	12	38	29	4	5	12	2	1			
12D4	12	34	11					1				90	5	4	12	9	1				29	4	5	12	6	1			
12DA6	12	9	80					1	12EN6	12	29	36	*				1	12J5	12	29	93					1			
12DB5	12	16	30					1	12EQ7	12	38	34	5	4	12	2	1	12J7	12	37	50	7	2	12	10	1			
12DE8	12	38	36	5	4	12	1	1				71	5	4	12	8	1	12J8	12	38	30	5	4	12	1	1			
			34	5	4	12	3	1	12EZ6	12	40	32	4	3	12	1	1				35	5	4	12	8	1			
12DF5	12	38	52	5	4	9	1	1	12F5	12	37	40	7	2	12	10	1				35	5	4	12	9	1			
			52	5	4	9	6	1	12F8	12	38	40	5	4	12	8	1	12JB6	12	42	*29	4	5	6	2	1			
12DF7	12	8	*85					1				62	5	4	12	1	1	*Normally Shows Short Position 1-7.											
			*85					2				62	5	4	12	6	1	12JB6A	12	42	*29	4	5	6	2	1			
*Tube Good if it Reads 22 or More.									12F31	12	1	78					1	*Normally shows short position 1-7.											
12DJ8	12	38	31	5	4	12	2	1	12FK6	12	40	40	4	3	12	1	1	12JF5	12	35	*32	1	12	11	3	1			
			31	5	4	12	7	1				65	4	3	12	5	1	*Normally shows short position 4-10											
12DK6	12	1	61					1				65	4	3	12	6	1	12JM6	12	35	26	1	12	4	5	1			
12DK7	12	38	33	5	4	8	1	1	12FM6	12	40	35	4	3	12	1	1	12JN6	12	35	27	1	12	4	11	1			
			80	5	4	8	6	1				68	4	3	12	5	1	12JN8	12	14	67					1			
12DL8	12	38	35	5	4	12	3	1	12FQ7	12	8	68	4	3	12	6	1				53					2			
			65	5	4	12	9	1				68					1	12JQ6	12	38	*34	4	5	8	7	1			
			65	5	4	12	1	1				68					2				57	4	5	8	6	1			
12DM4	12	34	11					1	12FQ8	12	38	39	5	4	12	2	1	*May show short position 2-3.											
12DN6	12	26	47					1				39	5	4	12	7	1	12JS6	12	35	*29	1	12	9	5	1			
12DQ4	12	34	11					1	12FR8	12	38	*25	4	5	12	3	1	*Normally shows short position 3-4-10-11.											
12DQ6	12	27	65					1				*37	4	5	12	1	1	12JT6	12	42	27	4	5	1	2	1			
12DQ6B	12	27	62					1				*62	4	5	12	8	1	12JT6A	12	42	27	4	5	1	2	1			
12DQ7	12	9	36					1	*Normally Shows Short on Position No. 5.									12JZ8	12	35	29	1	12	6	7	1			
12DS7	12	38	34	5	4	12	3	1	12FS5	12	1	99					1				40	1	12	6	10	1			
			*85	5	4	12	1	1	12FT6	12	40	52	4	3	12	1	1	12K5	12	40	35	4	3	5	6	1			
			*85	5	4	12	9	1				66	4	3	12	5	1	12K7	12	37	52	7	2	12	10	1			
*Tube good if it reads 20 or more.												66	4	3	12	6	1	12K8	12	37	35	7	2	12	5	1			
12DT5	12	16	45					1	12FV7	12	8	42					1	12KA8	12	38	26	4	5	12	6	1			
12DT6	12	1	91					1				42					2				33	4	5	12	2	1			
12DT7	12	8	*85					1	12FX5	12	4	68					1	12KL8	12	38	31	4	5	12	2	1			
			*85					2	12FX8	12	38	32	5	4	12	2	1				70	4	5	12	8	1			
*Tube Good if it Reads 22 or More.												28	5	4	12	6	1	12L6	12	29	47					1			
12DT8	12	8	71					1	12FY8	12	38	30	4	5	12	3	1	12MD8	12	42	35	4	5	12	6	1			
			71					2				39	4	5	12	1	1				35	4	5	12	8	1			
12DU7	12	38	31	5	4	12	1	1	12G4	12	40	41	4	3	1	6	1				35	4	5	12	9	1			
			77	5	4	12	7	1	12G11	12	35	33	1	12	12	3	1	12MX8	12	42	27	4	5	15	2	1			
			77	5	4	12	9	1				31	1	12	12	8	1				39	4	5	12	9	1			
12DV7	12	38	49	5	4	9	7	1	12GA6	12	40	36	4	3	12	1	1	12Q7	12	37	40	7	2	12	10	1			
			78	5	4	9	2	1	12G-B3A	12	27	65					1				63	7	2	12	4	1			
			78	5	4	9	3	1	12G-B7	12	27	61					1				63	7	2	12	5	1			
12DV8	12	38	35	5	4	12	3	1	12GC5	12	16	26					1	12R5	12	40	39	4	3	2	5	1			
			58	5	4	12	9	1	12GC6	12	26	52					1	12R-K19	12	15	10					1			
			58	5	4	12	1	1	12GE5	12	35	*24	1	12	11	3	1				55					1			
12DW4A	12	42	27	4	5	2	7	1	*Normally Shows Short Positions 4-10.									12R-LL3	12	8	55					2			
12DW5	12	16	30					1	12GJ5	12	42	*30	4	5	6	2	1				55					1			
12DW7	12	8	75					1	*Normally Shows Short Position 1-7.									12R-LL5	12	8	68					1			
			*90					2	12G-K17	12	34	12					1				68					2			
*Tube Good if it Reads 22 or More									12GN7	12	9	21					1	12S8	12	37	45	8	7	5	10	1			
12DW8	12	38	32	5	4	12	2	1	12GT5	12	42	*30	4	5	6	2	1				62	8	7	5	1	1			
			32	5	4	12	7	1	*Normally Shows Short Position 1-7.												62	8	7	5	4	1			
			44	5	4	12	9	1	12GT5A	12	42	*30	4	5	6	2	1				63	8	7	2	3	1			
12DY8	12	38	30	5	4	12	1	1	*Normally shows short position 1-7.									12SA7	12	37	37	7	2	12	5	1			
			35	5	4	12	9	1				12GV5	12	35	*26	1	12	5	9	1	12SC7	12	37	48	8	7	12	3	1
12DZ6	12	40	33	4	3	12	1	1	*Normally shows short position 3-7-10-11.												48	8	7	12	4	1			
12DZ8	12	38	27	4	5	8	3	1	12GW6	12	27	62					1	12SF5	12	37	41	8	7	12	3	1			
			30	4	5	2	1	1	12H4	12	40	44	4	3	2	6	1	12SF7	12	37	46	8	7	12	2	1			
12E5	12	25	93					1				69	8	7	12	5	1	12SG7	12	30	77					1			

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.
12SH7	12	30	77					1	14A5	12	36	34	8	1	12	6	1	15CW5	15	23	58					1
12SJ7	12	30	83					1	14A7	12	36	45	8	1	12	6	1	15DQ8	15	38	26	4	5	12	8	1
12SK7	12	30	84					1	14AF7	12	36	41	8	1	12	4	1				26	4	5	12	1	1
12SL7	12	25	*85					1				41	8	1	12	5	1	15EA7	15	37	35	8	7	12	1	1
			*85					2	14B6	12	36	40	8	1	4	3	1				39	8	7	12	4	1
*Tube Good if it Reads 22 or More.												68	8	1	4	5	1	15EW6	15	1	77					1
12SN7	12	25	78					1				68	8	1	4	6	1	15EW7	15	20	87					1
			78					2	14B8	12	36	42	8	1	12	4	1				92					2
12SQ7	12	37	42	8	7	12	2	1	14BF11	14	35	25	1	12	12	3	1	15FM7	15	35	25	1	12	3	8	1
			71	8	7	12	4	1				25	1	12	12	8	1				36	1	12	3	10	1
			71	8	7	12	5	1	14BL11	14	35	29	1	12	12	3	1	15FY7	15	35	25	1	12	12	3	1
12SR7	12	37	46	8	7	12	2	1				31	1	12	12	5	1				42	1	12	12	10	1
			68	8	7	12	4	1	14BQ11	14	35	29	1	12	12	11	1	15HA6	15	9	23					1
			68	8	7	12	5	1				28	1	12	12	5	1	15HB6	15	38	*24	4	5	6	2	1
12SS7	12	30	97					1				28	1	12	12	10	1	*Normally Shows Short Position 3-9.								
12SW7	12	37	52	8	7	12	2	1	14BR11	14	35	30	1	12	12	2	1	15KY8	15	42	27	4	5	12	2	1
			70	8	7	12	4	1				31	1	12	12	8	1				39	4	5	12	9	1
			70	8	7	12	5	1	14C5	12	36	33	1	12	12	10	1	15LE8	15	38	29	4	5	12	9	1
12SX7	12	25	78					1	14C7	12	36	37	8	1	12	6	1	15MF8	15	35	35	1	12	6	7	1
			78					2	14E6	12	36	40	8	1	4	3	1				34	1	12	6	10	1
12SY7	12	37	39	7	2	12	5	1				69	8	1	4	5	1	15MX8	15	42	27	4	5	12	2	1
12T10	12	35	28	1	12	12	3	1	14E7	12	36	69	8	1	4	6	1				39	4	5	12	9	1
			25	1	12	12	8	1				69	8	1	4	6	1	16A5	16	23	68					1
12U7	12	38	40	5	4	9	2	1	14F7	12	36	47	8	1	12	6	1	16A8	16	38	33	5	4	12	3	1
			40	5	4	9	7	1				68	8	1	12	3	1				39	5	4	12	1	1
12V6	12	29	79					1	14F8	12	36	45	8	1	12	4	1	16AK9	7	35	33	6	12	6	10	1
12W6	12	29	51					1				45	8	1	12	4	1				35	6	12	6	3	1
12X4	12	40	44	4	3	12	1	1	14F7	12	36	45	8	1	12	5	1				31	6	12	6	8	1
			44	4	3	12	6	1	14F8	12	36	30	7	2	12	1	1	16AQ3*	16	39	30	5	4	7	3	1
13CM5	12	27	57					1				30	7	2	12	8	1	*If no test, use alternate settings.								
13CW4	14	41	*87	10	12	12	2	1	14GT8	14	38	52	5	4	12	8	1	16AQ3	16	39	30	5	4	3	7	1
*For Grid Emission Turn D Switch to Position 4.												35	5	4	12	2	1	16BQ11	16	35	28	1	12	12	5	1
13D1	25	25	78					1				35	5	4	12	6	1				28	1	12	12	10	1
			78					2	14GW8	14	38	25	4	5	2	8	1	16BX11	16	35	32	1	12	12	2	1
13DE7	12	20	81					1				35	4	5	7	1	1				31	1	12	12	5	1
			90					2	14H7	12	36	35	8	1	12	6	1				31	1	12	12	8	1
13DF7	12	8	*85					1	14J7	12	36	35	8	1	12	6	1	16C-B28	16	35	*28	1	12	5	9	1
			*85					2				50	8	1	12	4	1	*Normally shows short position 3-4-10-11.								
*Tube Good if it Reads 22 or More.									14JG8	14	38	32	4	5	12	8	1	16CL8	16	14	69					1
13DR7	12	38	32	5	4	2	3	1				27	4	5	12	2	1				51					2
			41	5	4	2	7	1	14N7	12	36	27	4	5	12	6	1	16GK6	16	38	33	5	4	3	2	1
13EM7	12	37	32	8	7	12	1	1				42	8	1	12	4	1	16GY5	16	35	*25	1	12	5	9	1
			45	8	7	12	4	1				42	8	1	12	5	1	*Normally Shows Short Position 1-3-4-7-10								
13FD7	12	38	25	4	5	2	3	1	14Q7	12	36	35	8	1	12	4	1	16HB5	16	35	*25	1	12	11	3	1
			32	4	5	2	7	1	14R7	12	36	35	8	1	12	6	1	*Normally shows short position 4-10.								
13FG7	12	14	68					1				72	8	1	12	3	1	16K11	16	35	38	1	12	12	7	1
			56					2				72	8	1	12	4	1				38	1	12	12	9	1
13FM7	14	35	25	1	12	3	8	1	14S7	12	36	38	8	1	12	6	1				38	1	12	12	11	1
			36	1	12	3	10	1				52	8	1	12	4	1	16KA6	16	35	30	1	12	9	5	1
13FR7	12	38	24	4	5	2	3	1	14V7	12	36	32	8	1	12	6	1	*May show short position 3-4-7-11.								
			32	4	5	2	7	1	14W7	12	36	31	8	1	4	6	1	16LD6	16	9	51					1
13GB5♦	12	42	*25	4	5	2	1	1	14X7	12	36	43	8	1	12	3	1	16LU8	16	35	27	1	12	6	7	1
*Normally shows short position 3-6-7-8.												36	8	1	12	5	1				27	1	12	6	10	1
13GF7	12	42	27	4	5	12	2	1				35	8	1	12	6	1	16MY8	16	35	27	1	12	6	7	1
			38	4	5	12	9	1	14Y4	12	36	45	8	1	12	3	1				27	1	12	6	10	1
13GF7A	12	42	27	4	5	12	2	1				45	8	1	12	6	1	16Y9	16	43	27	5	6	12	1	1
			38	4	5	12	9	1	15A6	15	38	30	5	4	12	2	1				27	5	6	12	8	1
13J10	12	35	96	1	12	12	6	1	15A8	15	37	36	7	2	12	4	1	17A8	17	11	66					1
			28	1	12	12	11	1				40	7	2	12	3	1				55					2
13JT8	12	12	20					1	15AB9	15	43	79	5	6	10	2	1	17AB9	17	43	79	5	6	10	2	1
			*99					2				79	5	6	4	8	1				79	5	6	4	8	1
*Tube good if it reads 60 or more.									15AF11	15	35	31	1	12	12	11	1	17AB10	17	35	29	1	12	12	11	1
13JZ8	12	35	29	1	12	6	7	1				31	1	12	12	6	1				95	1	12	12	6	1
			40	1	12	6	10	1				35	1	12	12	3	1	17AF3	17	15	12					1
13SJ7	12	30	83					1	15BD11	15	35	26	1	12	12	11	1	17AV5	17	28	62					1
13V10	12	35	33	1	12	12	3	1				31	1	12	12	3	1	17AX3	17	35	30	1	12			

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.		
17B-B14♦	17	42	*33	4	5	1	2	1	17JG6A	17	42	24	4	5	1	2	1	19CL8-A	19	14	74					1		
*Normally shows short position 3-6-7-8.									17JK8	17	8	54					1	19D8	19	38	32	5	4	12	2	2		
17BD11	17	35	26	1	12	12	11	1				55					2				35	5	4	12	9	1		
			31	1	12	12	3	1	17JM6	17	35	26	1	12	4	5	1	19DE7	19	20	81					1		
			31	1	12	12	6	1	17JN6	17	35	27	1	12	4	11	1				90					2		
17BE3	17	35	26	1	12	4	10	1	17JQ6	17	38	*34	4	5	8	7	1	19DK3	19	42	31	4	5	2	7	1		
17BF11	17	35	25	1	12	12	3	1				57	4	5	8	6	1	19DKQ3	19	35	30	1	12	4	10	1		
			25	1	12	12	8	1	*May show short position 2-3.									19DN6	19	26	47				1			
17BF11A	17	35	25	1	12	12	3	1	17JR6	17	42	34	4	5	1	2	1	19EA8	19	11	71					1		
			25	1	12	12	8	1	17JS6	17	35	*29	1	12	9	5	1				56					2		
17BH3	17	42	27	5	4	7	2	1	*Normally shows short position 3-4-10-11.									19EW7	19	20	87					1		
17BH3A	17	42	27	5	4	7	2	1	17JT6	17	42	27	4	5	1	2	1				92					2		
17BJ6	17	1	81					1	17JT6A	17	42	27	4	5	1	2	1	19EZ8	19	38	33	5	4	12	2	1		
17BQ6	17	27	69					1	17JZ8	17	35	29	1	12	6	7	1				33	5	4	12	7	1		
17BR3	17	15	10					1				40	1	12	6	10	1				33	5	4	12	9	1		
17BS3	17	42	27	4	5	2	7	1	17KV6	17	42	30	4	5	1	2	1	19FX5	19	4	68					1		
17BW3	17	35	28	1	12	4	10	1	17KW6♦	17	42	30	4	5	1	8	1	19GQ7	19	38	24	4	5	3	2	1		
17BZ3	17	35	30	1	12	4	10	1	17L6	17	29	47					1				24	4	5	3	6	1		
17C5	17	4	44					1	17LD8	17	42	25	4	5	12	2	1				24	4	5	3	8	1		
17C8	17	38	33	5	4	12	2	1				33	4	5	12	9	1	19GY5	19	35	*25	1	12	5	9	1		
			65	5	4	12	7	1	17R5	17	4	50					1	*Normally shows short position 3-4-7-10-11.										
			65	5	4	12	8	1	17R-HH2	17	8	65					1	19HR6	19	1	71					1		
17C9	17	38	28	5	4	6	1	1				65				2	19HS6	19	1	66					1			
			28	5	4	10	7	1	17R-K19	17	15	10					1	19HV8	19	14	64					1		
17CA5	17	4	55					1	17W6	17	29	52					1									2		
17CK3	17	42	25	4	5	1	2	1	17X10	17	35	98	1	12	12	6	1	*Tube Good If It Reads 40 or More.										
17CL3	17	42	27					1				28	1	12	12	11	1	19J6	19	2	60					1		
17CQ4	17	34	11					1	17Y9	17	43	27	5	6	12	1	1				60					2		
17CT3	17	38	32	4	5	6	2	1				27	5	6	12	8	1	19JC6	19	9	65					1		
17CU5	17	4	47					1	17Z3*	17	38	33	4	5	2	9	1				67					1		
17D4	17	34	11					1	*If no test use alternate setting below.									19JN8	19	14	53					2		
17DE4	17	34	13					1				17	39	33	4	5	2	3	1	19KF6♦	19	42	33	4	5	7	1	1
17DM4	17	34	11					1	18A5	18	28	69					1	19KG8	19	38	21	4	5	12	9	1		
17DQ4	17	34	11					1	18AJ10	18	35	32	1	12	4	3	1				21	4	5	12	2	1		
17DQ6	17	27	65					1				33	1	12	4	8	1				21	4	5	12	2	1		
17DQ6B	17	27	62					1	18AK5	18	1	63					1	19MR9	19	1	73					1		
17DW4A	17	42	27	4	5	2	7	1	18AQ5	18	3	77					1	19Q9	19	38	25	4	5	12	1	1		
17EW8	17	8	65					1	18C51	18	38	29	9	1	12	3	1				25	4	5	12	8	1		
			65					2				29	9	1	12	7	1	19T8	19	17	90					1		
17FY7	17	35	25	1	12	12	3	1	18DZ8	18	38	27	4	5	8	3	1				63					2		
			42	1	12	12	10	1				30	4	5	2	1	1	19U3	19	38	29	5	4	12	9	1		
17GE5	17	35	*24	1	12	11	3	1	18FW6	18	1	79					1	19V8	19	38	40	5	4	12	6	1		
*Normally Shows Short Position 4-10.									18FX6	18	1	92					1				32	5	4	12	2	1		
17GJ5	17	42	*30	4	5	6	2	1	18FY6	18	6	84					1				32	5	4	12	7	1		
*Normally Shows Short Position 1-7.												81				2				61	5	4	12	9	1			
17GJ5A	17	42	*30	4	5	6	2	1	18GB5♦	18	42	*25	4	5	2	1	1	19W3	19	38	29	5	4	12	9	1		
*Normally shows short position 1-7.									*Normally shows short position 3-6-7-8.									19X3	19	38	29	5	4	12	9	1		
17GT5	17	42	*30	4	5	6	2	1	18GD6	18	1	80					1	19X8	19	12	73					1		
*Normally Shows Short Position 1-7.									18GE6	18	6	78					1				61					2		
17GT5A	17	42	*30	4	5	6	2	1				85				2		19Y3	19	38	29	4	5	12	9	1		
*Normally shows short position 1-7.									18GV5	18	35	*26	1	12	5	9	1	20AQ3*	19	39	30	5	4	7	3	1		
17GV5	17	35	*26	1	12	9	5	1	*Normally shows short position 3-4-7-10-11.									*If no test, use alternate settings.										
*Normally Shows Short Position 3-4-7-10-11.									18GV8	18	38	25	4	5	12	9	1	20AQ3	19	39	30	5	4	3	7	1		
17GW6	17	27	62					1				25	4	5	12	2	1	20D1	9	5	62					1		
17GY5	17	35	*25	1	12	5	9	1	18HRR	18	38	36	5	4	12	9	1				62					2		
*Normally shows short position 3-4-7-10-11.												33	5	4	12	1	1	20EQ7	19	38	34	5	4	12	2	1		
17H3	17	15	13					1	18J6	18	2	60					1				71	5	4	12	8	1		
17H-B25♦	17	42	*33	4	5	1	2	1				60				2	20EW7	19	20	87					1			
*Normally shows short position 3-6-7-8.									18R-AL1	18	38	33	4	5	2	3	1				92					2		
17HC8	17	38	36	5	4	12	3	1	19A3	19	40	32	3	4	6	5	1	20F77	19	38	35	2	1	3	5	1		
			38	5	4	12	1	1	19AJ8	19	38	85	5	4	12	1	1				35	2	1	3	8	1		
17HG8	17	38	25	4	5	3	2	1				38	5	4	12	9	1	20LF6	20	35	*31	1	12	5	9	1		
			25	4	5	1	6	1	19AQ5	19	3	77					1	*May show short position 3-4-7-10-11.										
17JB6	17	42	*29	4	5	6	2	1	19AU4	19	34	10					1	21A6	22	38	*32	5	4	7	2	1		
*Normally Shows Short Position 1-7.									19BG6	19	26	66					1	*Normally Shows Short Position 1-6-9										
17JB6A	17	42	*29	4	5	6	2	1	19BX6	19	9	76					1	21AK6	22	1	82					1		
*Normally shows short position 1-7.									19BY7	19	9	62					1	21FX6	22	26	42					1		
17JF6	17	42	*26	4	5	2	6	1	19C8	19	17	94					2	21GY5	22	35	*25	1	12	5	9	1		
*Normally shows short position 1-7.												62				2	*Normally shows short position 3-4-7-10-11.											
17JG6	17	42	24	4	5	1	2	1	19CG3	19	35	30	1	12	4	10	1									1		

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.		
21HB5	22	35	*25	1	12	11	3	1	25C5	25	4	44					1	28EC4	30	37	32	7	8	2	5	1		
*Normally Shows Short Position 4-10									25C6	25	29	45					1	28GB5	30	42	*25	4	5	2	1	1		
21HD5	22	35	*27	1	12	3	11	1	25CA5	25	4	55					1	*Normally shows short position 3-6-7-8.										
*Normally shows short position 4-5-9-10									25CD6	25	26	53					1	28HA6	30	9	23					1		
21HJ5	22	35	*27	1	12	3	11	1	25CG3	25	35	30	1	12	4	10	1	28HD5	30	35	*27	1	12	3	11	1		
*Normally Shows Short Position 4-5-9-10									25CK3	25	42	30	4	5	7	2	1	*Normally shows short position 4-5-9-10										
21JS6	22	35	*29	1	12	9	5	1	25CM3	25	42	30	4	5	2	7	1	29GK6	30	38	33	5	4	3	2	1		
*Normally shows short position 3-4-10-11.									25CT3	25	38	32	4	5	6	2	1	29KQ6	30	42	*29	4	5	1	8	1		
21JV6	22	35	28	1	12	4	11	1	25CU6	25	27	69					1	*Normally shows short position 2-3-6-7.										
21JZ6	22	35	*31	1	12	9	5	1	25D4	25	34	11					1	29LE6	30	42	*30	4	5	8	1	1		
*Some tubes may show short position 3-4-10-11.									25DK3	25	42	31	4	5	2	7	1	*Normally shows short position 2-3-6-7.										
21KA6	22	35	*30	1	12	9	5	1	25DK4	25	40	26	3	4	6	5	1	30A5	30	40	27	3	4	5	2	1		
May show short position 3-4-7-11.									25DL3	25	42	29	4	5	7	2	1	30AE3	30	39	30	5	4	7	3	1		
21KQ6	22	42	*29	4	5	1	8	1	25DN6	25	26	47					1	*If no test, use alternate settings.										
*Normally shows short position 2-3-6-7.									25DQ6	25	27	65					1	30AE3	30	39	30	5	4	3	7	1		
21LG6	22	35	*32	1	12	9	5	1	25DT5	25	16	45					1	30AG11	30	35	28	1	12	12	8	1		
*May show short position 2-3-4-7-10-11.									25E5	25	27	58					1											
21LR8	22	42	31	4	5	12	2	1	25EC6	25	26	53					1											
			31	4	5	12	9	1	25EH5	25	4	57					1											
21LU8	22	35	27	1	12	6	7	1	25F5	25	4	54					1	30C1	9	11	66					1		
			35	27	1	12	6	10	25F5A	25	4	54					1	30CW5	30	23	58					1		
21MY8	22	35	27	1	12	6	7	1	25FY8	25	38	30	4	5	12	3	1	30HD5	30	35	*27	1	12	3	11	1		
			27	1	12	6	10	1			39	4	5	12	1	1	1	*Normally shows short position 4-5-9-10										
22AL3*	22	39	30	5	4	7	3	1	25G-B6	25	27	64					1	30HJ5	30	35	*27	1	12	3	11	1		
*If no test, use alternate settings.									25GE5	25	35	*24	1	12	11	3	1	*Normally shows short position 4-5-9-10										
22AL3	22	39	30	5	4	3	7	1	*Normally shows short position 4-10.									30JZ6	30	35	*31	1	12	9	5	1		
22BH3	22	42	27	5	4	7	2	1	25HX5	25	42	*30	4	5	7	1	1	*Some tubes may show short position 3-4-10-11.										
22BH3A	22	42	27	5	4	7	2	1	*Normally shows short position 2-3.									30KD6	30	35	*26	1	12	9	5	1		
22BW3	22	35	28	1	12	4	10	1	25JQ6	25	38	*34	4	5	8	7	1	*Normally shows short position 3-4-10-11.										
22DE4	22	34	13								57	4	5	8	6	1	1	30KG6	30	42	*26	4	5	1	8	1		
22JF6	22	42	*26	4	5	2	6	1	*May show short position 2-3.									*Normally shows short position 2-3-6-7.										
*Normally shows short position 1-7.									25JZ8	25	35	29	1	12	6	7	1	30L1	7	38	33	5	4	7	2	1		
22JG6	22	42	24	4	5	1	2	1			40	1	12	6	10	1	1											
22JG6A	22	42	24	4	5	1	2	1	25L6	25	29	47					1	30MB6	30	35	*32	1	12	9	5	1		
22JR6	22	42	34	4	5	1	2	1	25M-P20	25	1	43					1	*Normally shows short position 3-4-10-11.										
22JU6	22	42	*30	4	5	2	6	1	25R-K19	25	15	10					1	30M-P23	30	40	30	3	4	5	2	1		
*Normally shows short position 1-7									25SN7	25	25	78					1	30M-P27	30	40	30	3	4	5	2	1		
22KM6	22	42	*29	4	5	6	2	1			78						2	30P16	16	23	68					1		
*Normally shows short position 1-7.									25U4	25	34	11					1	30PL12	16	38	33	5	4	12	3	1		
22KV6	22	42	30	4	5	1	2	1	25W4	25	34	11					1											
23JS6	22	35	*29	1	12	9	5	1	25W6	25	29	51					1	31AL10	30	35	51	1	12	6	3	1		
*Normally shows short position 3-4-10-11.									25Z6	25	37	34	7	2	12	3	1											
23JS6A	22	35	*29	1	12	9	5	1			34	7	2	12	5	1	1											
*Normally shows short position 3-4-10-11.									26A6	25	1	77					1	31JS6A	30	35	*29	1	12	9	5	1		
23MB6	22	35	*32	1	12	9	5	1	26A7	25	37	29	7	6	12	1	1	*Normally shows short position 3-4-10-11										
*Normally shows short position 3-4-10-11.											29	7	6	12	3	1	1	31LQ6	30	42	*26	4	5	6	2	1		
23Z9	22	35	30	1	12	6	10	1	26AQ8	25	8	70					1	*Normally shows short position 1-7.										
			39	1	12	6	3	1			70						2	31LR8	30	42	31	4	5	12	2	1		
			28	1	12	6	8	1	26BK6	25	6	86					1											
24AX4	25	34	13					1			70						2	31LZ6	30	42	*31	4	5	6	2	1		
24BF11	25	35	25	1	12	12	3	1	26C6	25	6	85					1	*Normally shows short position 1-7.										
			25	1	12	12	8	1			82						2	32A8	30	38	33	5	4	12	3	1		
24JE6A	25	42	*26	4	5	6	2	1	26D6	25	1	93					1											
*Normally shows short position 1-7.									26DQ5	25	26	55					1	32ET5	30	4	60					1		
24JZ8	25	35	29	1	12	6	7	1	26E6	25	29	40					1	32HQ7	35	35	34	1	12	7	2	1		
			40	1	12	6	10	1	26HU5	25	37	*28	7	8	1	5	1											
24LQ6	25	42	*26	4	5	6	2	1	*Normally shows short position 2-6.									33GT7	30	35	*55	1	12	7	10	1		
*Normally shows short position 1-7.									26JG6	25	42	56					1											
24LZ6	24	42	*31	4	5	6	2	1	26LW6	25	37	*31	7	8	1	5	1	*Normally Shows Short Position 9-11.										
*Normally shows short position 1-7.																	1	33GY7	30	35	*56	1	12	7	11	1		
25A6	25	29	74					1	26Z5	25	38	36	5	4	9	1	1											
25AU4	25	34	10					1			36	5	4	9	6	1	1	*Normally Shows Short Position 9-10.										
25AV5	25	28	62					1	27GB5	25	42	*25	4	5	2	1	1	33GY7A	30	35	*56	1	12	7	11	1		
25AX4	25	34	13					1	*Normally shows short position 3-6-7-8.																			
25B6	25	29	48					1	27KG6	25	42	*26	4	5	1	8	1	*Normally shows short position 9-10.										
*Normally shows short position 2-3-6-7.									*Normally shows short position 2-3-6-7.									33HE7	30	35	27	1	12	10	2	1		
*Normally shows short position 3-6-7-8									27LF6	25	35	*31	1	12	5	9	1											
25BK5	25	10	53					1	*May show short position 3-4-7-10-11									33JR6	30	42	34	4	5	1	2	1		
25BQ6	25	27	69					1	28D7	30	36	40	8	1	12	2	1	33JV6	30	35	28	1	12	4	11	1		
25BR3	25	15	10					1			40	8	1	12	7	1	1											

■Use TC-62B Adapter.

◆Use TC-80 Adapter.

*Normal Shorts Refer to Position of "D" Switch.

21HB5 - 33JV6

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.
6067	12	8	75					1	6463	12	38	28	4	5	9	3	1	7105	12	37	35	8	7	12	1	1
			75					2				28	4	5	9	8	1				35	8	7	12	4	1
6069	6	1	63					1	6485	6	1	58					1	7119	12	38	30	4	5	8	2	1
6072	12	8	93					1	6516	6	40	34	4	3	12	1	1				30	4	5	8	7	1
			93					2	6520	6	37	35	8	7	12	1	1	7167	12	1	54					1
6080	6	37	35	8	7	12	1	1				35	8	7	12	4	1	7189	6	38	*33	5	4	1	2	1
			35	8	7	12	4	1	6550	6	29	52					1	*Normally Shows Short Position 1-3-6-9.								
6082	25	37	35	8	7	12	1	1	6660	6	1	78					1	7199	6	38	30	5	4	12	7	1
			35	8	7	12	4	1	6661	6	1	89					1				32	5	4	12	9	1
6084	6	38	39	4	5	7	9	1	6662	6	1	81					1	7233	6	38	*33	5	4	2	7	1
6085	12	8	74					1	6663	6	5	62					1	*Normally Shows Short Position 1-3-6-9.								
			74					2				62					2	7247	12	8	75					1
6087	5	33	23					1	6664	6	40	30	4	3	12	6	1	*Tube Good If It Reads 22 or More.								
			23					2	6669	6	3	77					1								2	
6096	6	1	63					1	6676	6	1	64					1									
6097	6	5	62					1	6677	6	38	*32	5	4	2	9	1	7258	12	13	62					1
			62					2	*Normally Shows Short Position 3-8.											61						2
6100	6	40	41	4	3	1	6	1	6678	6	11	79					1	7308	6	8	23					1
6101	6	2	60					1				55					2				24					2
			60					2	6679	12	8	79					1	7320	6	23	68					1
6113	6	25	*85					1				79					2	7355	6	37	37	7	2	12	6	1
			*85					2	6680	12	8	75					1	7360	6	38	29	4	5	12	3	1
*Tube Good If It Reads 22 or More.												75					2	7370	40	38	24	4	5	8	2	1
6134	6	30	60					1	6681	12	8	*85					1				24	4	5	8	7	1
6135	6	40	41	4	3	1	6	1				*85					2	7408	6	29	80					1
6136	6	1	82					1	*Tube Good If It Reads 22 or More.								7543	6	1	85					1	
6137	6	30	84					1	6686	6	38	24	4	5	1	2	1	7551	15	38	*33	4	5	9	2	1
6146	6	37	*38	7	2	1	5	1	6687	6	1	89					1	*Normally Shows Short Position 3-8.								
*Normally Shows Short Position 4-6.									6688	6	38	25	4	5	1	2	1	7558	6	38	*26	4	5	3	2	1
6147	6	29	63					1	6689	6	38	25	4	5	12	2	1	*Normally Shows Short Position 1-9.								
6159	25	37	*38	7	2	1	5	1	6829	12	8	54					1	7581	6	29	64					1
*Normally Shows Short Position 4-6.												54					2	7586	6	41	*65	10	12	12	2	1
6180	6	25	78					1	6883	12	37	*38	7	2	1	5	1	*For Grid Emission Turn D Switch to Position 4.								
			78					2	*Normally Shows Short Position 4-6.								7587	6	41	*67	10	12	12	2	1	
6186	6	1	80					1	6887	6	40	33	4	3	12	2	1	*For Grid Emission Turn D Switch to Position 4.								
6187	6	1	87					1				33	4	3	12	7	1	7591	6	37	34	7	2	4	6	1
6188	6	25	*81					1	6888	6	30	62					1	7607	6	37	*32	7	2	1	5	1
			*81					2	6919	6	5	62					1	*Normally Shows Short Position 4-6.								
*Tube Good If It Reads 22 or More.												62					2	7643	6	11	72					1
6189	12	8	75					1	6922	6	8	24					1				55					2
			75					2				24					2	7687	6	11	77					1
6197	6	38	*32	5	4	2	9	1	6939	12	38	34	4	5	9	1	1				67					2
*Normally shows short position 3-8.												34	4	5	9	3	1	7693	6	1	93					1
6198	12	8	75					1	6968	6	1	63					1	7694	6	1	84					1
			75					2	6973	6	16	62					1	7695	50	38	34	5	4	12	6	1
6201	12	8	74					1	7000	6	37	50	7	2	12	10	1	7701	12	38	*38	5	4	1	2	1
			74					2	7025	12	8	*85					1	*Normally Shows Short Position 3-7-8-9.								
6202	6	40	44	4	3	12	1	1				*85					2	7716	12	12	53					1
			44	4	3	12	6	1	*Tube Good If It Reads 22 or More.											*97					2	
6203	6	38	41	4	5	12	1	1	7027	6	37	*36	7	2	5	6	1	*Tube Good If It Reads 20 or More.								
			41	4	5	12	9	1	*Normally Shows Short Position 1-4.								7719	12	39	29	4	5	1	7	1	
6211	12	8	54					1	7036	6	1	92					1	7722	6	23	80					1
			54					2	7044	12	38	30	4	5	8	2	1	7724	14	38	52	5	4	12	8	1
6216	6	38	*29	4	5	3	2	1				30	4	5	8	7	1				35	5	4	12	2	1
*Normally shows short position 1-6.									7054	12	9	42					1				35	5	4	12	6	1
6218	6	38	72	4	5	12	2	1	7055	12	5	62					1	7728	12	8	74					1
6227	6	38	25	4	5	1	2	1				62					2				74					2
6265	6	1	89					1	7056	12	1	64					1	7729	12	8	*85					1
6267	6	38	40	5	4	2	9	1	7057	12	8	53					1	*Tube Good If It Reads 22 or More.								
6293	6	37	*38	7	2	1	5	1				53					2				*85					2
*Normally shows short position 4-6									7058	12	8	*85					1	7730	12	8	75					1
6336	6	37	29	8	7	12	1	1				*85					2				75					2
*Tube Good If It Reads 22 or More.									7059	12	11	79					1	7731	6	11	79					1
6350	12	38	31	4	5	9	3	1				55					2				55					2
			31	4	5	9	8	1	7060	12	13	55					1	7732	6	1	64					1
6360	12	38	30	4	5	9	1	1				75					2	7733	12	9	42					1
			30	4	5	9	3	1				67					1	7738	6	40	*33	4	3	2	6	1
6384	6	37	33	8	6	12	7	1	7061	12	16	67					1	*Normally Shows Short Position 1-7.								
6417	12	38	33	5	4	8	9	1	7062	12	8	54					1	7751	6	37	30	2	7	4	5	1
												54					2	7754	6	38	34	5	4	12	6	1

◆Use TC-80 Adapter

△Use TC-70 Adapter

*Normal Shorts Refer to Position of "D" Switch.

6067 - 7754

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitiv- ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv- ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv- ity	A	B	C	D	Test Pos.	
7788	6 38	*29	4 5 3 2	1				1	B152	12 8	74						1	CV580	6 37	45	7 2 12 5	1				1	
*Normally shows short position 6-9.																											
7867	6 26	53						1	B309	12 8	74						1	CV581	6 29	99						1	
7868	6 42	*27	4 5 2 6	1				1			74						2	CV582	6 29	99						1	
*Normally Shows Short Position 1-7.																											
7895	6 41	*85	10 12 12 2	1				1	B319	7 38	33	5 4 7 2	1				1	CV583	6 29	99						1	
*For Grid Emission Turn D Switch to Position 4.																											
7898	14 8	73						1			33	5 4 7 6	1				1	CV586	6 29	63						1	
		73						2	B329	12 8	75						1			63	7 2 12 4	1				1	
7984	12 35	*59	1 12 7 11	1				1			75						2	CV587	6 37	40	7 2 12 10	1				1	
									B339	12 8	*85						1	CV588	6 37	40	7 2 12 10	1				1	
*Normally shows short position 2-3-4-5-6-8-9.																											
8016	1 32	55						1			*85						2			63	7 2 12 4	1				1	
8032	12 37	*38	7 2 1 5	1				1	B719	6 8	70						1	CV589	6 37	40	7 2 12 10	1				1	
*Normally shows short position 4-6.																											
8056	6 41	*63	10 12 12 2	1				1			70						2			63	7 2 12 4	1				1	
*For grid emission turn D switch to position 4.																											
8102	12 38	28	4 5 12 3	1				1	BPM04	6 3	77						1	CV590	6 30	83						1	
		27	4 5 12 9	1				1	CV131	6 40	35	4 3 12 1	1				1	CV591	6 30	83						1	
8106	12 38	*24	4 5 3 7	1				1	CV133	6 40	41	4 3 1 6	1				1	CV592	6 30	83						1	
*Normally Shows Short Position 2-6-9.																											
8113	6 1	58						1	CV136	6 40	34	4 3 12 1	1				1	CV593	5 33	12						1	
8136	6 1	65						1	CV138	6 40	30	4 3 12 1	1				1			12						2	
8156	13 35	*32	1 12 9 10	1				1	CV140	6 5	62						1	CV594	6 30	77						1	
*Normally Shows Short Position 2-3-4-5-6-7-8-11.																											
8233	6 42	*25	4 5 7 8	1				1			62						2	CV595	6 30	77						1	
*Normally shows short position 2-6.																											
*May show short on position 3.																											
8255	6 38	*85	4 5 7 8	1				1	CV216	50 37	*99	2 11 3 5	1				1	CV657	6 37	50	7 2 12 10	1				1	
*Normal short position 1-3-6-9																											
8278	6 42	*31	4 5 3 7	1				1	CV450	6 29	*62						1	CV660	6 30	60						1	
*Normally shows short position 1-2-6-8.																											
8327	6 23	65						1	CV452	6 6	85						1	CV661	6 30	74						1	
8417	6 29	54						1			78						2	CV664	6 40	*46	4 3 1 6	1				1	
8425	6 1	87						1	CV453	6 1	91						1	*Normally Shows Short Position 2-7.									
8458	12 42	32	4 5 9 1	1				1	CV454	6 1	78						1	CV665	6 1	*73						1	
		32	4 5 9 3	1				1	CV455	12 8	74						1	*Tube Good if it Reads 23 or More.									
8552	12 37	*38	7 2 1 5	1				1	CV491	12 8	75						1	CV686	50 37	*85	2 11 3 5	1				1	
*Normally shows short position 4-6.																											
8908	6 37	*30	7 8 1 5	1				1			75						2	*Normally Shows Short Position 11.									
*Normally shows short position 2-6.																											
9001	6 1	93						1	CV492	12 8	*85						1	*Normally Shows Grid Emission.									
9002	6 40	*46	4 3 1 6	1				1			*85						2	CV692	6 31	8						1	
9003	6 1	*73						1	CV493	6 40	44	4 3 12 1	1				1	CV694	12 30	77						2	
*Tube Good if it Reads 23 or More.																											
9006	6 40	*55	4 3 1 5	1				1			44	4 3 12 6	1				1	CV697	12 30	83						1	
*Normally Shows Short Position 2-7.																											
A863	6 37	50	7 2 12 10	1				1	CV511	6 29	79						1	CV698	12 30	83						1	
A1834	6 37	35	8 7 12 1	1				1	CV538	12 37	37	7 2 12 5	1				1	CV700	12 37	46	8 7 12 2	1				1	
		35	8 7 12 4	1				1	CV544	12 30	84						1			68	8 7 12 4	1				1	
AR18	6 37	40	7 2 12 10	1				1	CV547	12 37	42	8 7 12 2	1				1	CV703	6 37	35	7 2 12 5	1				1	
ARDD3	6 37	48	7 2 12 3	1				1			71	8 7 12 4	1				1	CV706	6 37	48	7 2 12 10	1				1	
		48	7 2 12 5	1				1	CV551	25 29	45						1	CV717	5 33	22						1	
ARH1	6 37	44	7 2 12 10	1				1	CV552	25 29	47						1			22						2	
ARP15	6 37	52	7 2 12 10	1				1	CV553	25 29	47						1	CV723	3 37	39	7 2 12 5	1				1	
ARP16	6 37	50	7 2 12 10	1				1	CV554	6 37	48	7 2 12 3	1				1	CV726	35 36	31	8 1 12 2	1				1	
ARP17	6 29	91						1	CV559	25 37	34	7 2 12 3	1				1	CV728	2 37	53	7 2 12 10	1				1	
ARP32	6 29	79						1			34	7 2 12 5	1				1	CV729	5 33	12						1	
ARP33	6 29	79						1	CV561	35 29	54						1			12						2	
ARTH-1	6 37	35	7 2 12 5	1				1	CV562	35 29	54						1	CV731	6 29	91						1	
AU13	5 33	32						1	CV565	35 36	31	8 1 12 2	1				1	CV732	6 34	11						1	
		32						2	CV567	35 37	33	7 2 3 5	1				1	CV747	6 30	60						1	
AZ32	4 33	32						1	CV568	35 37	33	7 2 3 5	1				1	CV753	2 40	*70	7 1 2 6	1				1	
		32						2	CV571	50 29	47						1	*Normally Shows Short Position 5-11.									
B36	12 25	78						1	CV572	6 33	15						1	CV755	1 37	55	7 2 12 5	1				1	
		78						2			15						2	CV756	1 37	55	7 2 12 5	1				1	
B65	6 25	78						1	CV573	6 33	15						1	CV760	1 37	55	7 2 12 5	1				1	
		78						2	CV574	6 33	15						1	CV764	2 37	54	7 2 12 10	1				1	
		78						1			15						2	CV768	2 37	48	7 2 12 5	1				1	
		78						2	CV575	5 33	16						1	CV770	2 37	54	7 2 12 10	1				1	
		78						1	CV578	6 37	45	7 2 12 5	1				1			64	7 2 12 4	1				1	
		78						2	CV579	6 37	45	7 2 12 5	1				1	CV772	1 37	55	7 2 12 4	1				1	
		78						1			16						2	CV773	1 37	55	7 2 12 5	1				1	
		78						2			15						1			55	7 2 12 4	1				1	
		78						1			15						1			55	7 2 12 5	1				1	
		78						2			15						2	CV775	1 36	62	8 1 12 4	1				1	
		78						1			16						2	CV776	1 36	55	8 1 12 6	1				1	
		78						2			16						2	CV777	1 36	54	8 1 5 6	1				1	
		78						1			45	7 2 12 5	1				1	CV778	1 36	68	8 1 12 4	1				1	
		78						2			45	7 2 12 5	1				1									1	

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.
CV779	2	36	53	8	1	12	6	1	CV892	6	36	47	8	1	12	6	1	CV1790	6	36	50	8	1	12	3	1
			63	8	1	12	4	1				68	8	1	12	3	1				50	8	1	12	6	1
CV780	2	36	52	8	1	12	6	1	CV893	6	36	68	8	1	12	4	1	CV1800	1	37	57	7	2	12	5	1
			60	8	1	12	4	1				45	8	1	12	4	1	CV1802	1	37	57	7	2	12	5	1
CV781	1	36	53	8	1	5	6	1				45	8	1	12	5	1	CV1803	1	37	54	7	2	12	5	1
CV782	1	40	57	7	1	5	4	1	CV894	6	36	36	8	1	12	6	1	CV1805	1	37	54	7	2	12	5	1
CV783	1	40	*55	7	1	5	3	1	CV895	6	36	35	8	1	12	6	1	CV1811	1	37	58	7	2	12	5	1
			*Normally Shows Short Position 2-6.						CV896	6	36	45	8	1	12	4	1				86	7	2	12	10	1
CV784	1	40	56	7	1	12	6	1				65	8	1	12	5	1				*99	7	2	12	8	1
			95	7	1	12	3	1				65	8	1	12	6	1				*Tube Good If It Reads 30 or More.					
CV785	1	40	55	7	1	5	6	1	CV897	6	36	35	8	1	12	6	1	CV1818	1	37	55	7	2	12	10	1
CV786	1	37	54	7	2	12	5	1				50	8	1	12	4	1				96	7	2	12	5	1
CV797	6	40	32	4	3	5	1	1	CV898	6	36	42	8	1	12	4	1	CV1819	6	29	93					1
CV805	50	37	35	7	2	12	3	1				42	8	1	12	5	1	CV1820	1	37	55	7	2	12	10	1
			35	7	2	12	5	1	CV899	6	36	35	8	1	12	4	1				96	7	2	12	5	1
CV807	3	40	*36	7	1	5	4	1	CV900	6	36	35	8	1	12	6	1	CV1821	2	37	53	7	2	12	10	1
			*Normally Shows Short Position 2-6.									72	8	1	12	3	1	CV1823	2	37	53	7	2	12	10	1
CV808	3	40	45	7	1	4	3	1				72	8	1	12	4	1	CV1824	1	37	48	7	2	12	5	1
			45	7	1	4	5	1	CV901	6	36	45	8	1	12	3	1	CV1826	1	37	48	7	2	12	5	1
CV815	2	36	43	8	1	7	6	1				45	8	1	12	6	1	CV1829	1	37	54	7	2	12	5	1
CV818	3	40	*42	7	1	5	3	1	CV910	12	37	45	7	2	12	5	1	CV1846	5	33	22					1
			*Normally Shows Short Position 2-6.						CV916	12	37	48	7	2	12	3	1				22				2	
CV819	3	37	45	7	2	8	5	1				48	7	2	12	5	1	CV1849	5	33	32					1
CV820	3	40	*48	7	1	5	3	1	CV917	12	37	50	7	2	12	10	1				32					2
			*Normally Shows Short Position 2-6.						CV918	12	37	52	7	2	12	10	1	CV1851	5	37	47	8	7	12	3	1
CV841	5	33	16					1	CV919	12	37	41	8	7	12	3	1				47	8	7	12	5	1
			16					2	CV920	12	37	41	8	7	12	3	1	CV1852	5	37	47	8	7	12	3	1
CV842	5	33	32					1	CV921	12	37	46	8	7	12	2	1				47	8	7	12	5	1
			32					2				69	8	7	12	5	1	CV1854	5	33	32					1
CV844	6	37	40	7	2	12	5	1	CV922	12	30	77					1				32					2
CV845	6	37	40	7	2	12	5	1	CV924	12	25	*85					1	CV1856	5	33	32					1
CV846	6	30	60					1				*85					2				32					2
CV848	6	1	80					1	*Tube Good if It Reads 22 or More.								CV1857	5	37	52	8	7	12	3	1	
CV849	6	30	60					1	CV925	12	25	78					1				52	8	7	12	5	1
CV850	6	1	63					1				78					2	CV1862	6	3	77					1
CV851	6	37	35	7	2	12	5	1	CV930	12	36	45	8	1	12	4	1	CV1863	5	33	12					1
CV852	6	40	41	4	3	1	6	1				45	8	1	12	5	1				12					2
CV858	6	2	60					1	CV939	25	37	40	7	2	12	5	1	CV1864	5	33	12					1
			60					2	CV945	30	36	40	8	1	12	2	1				12					2
CV862	6	37	53	7	2	12	5	1				40	8	1	12	7	1	CV1873	6	30	74					1
CV865	6	30	69					1	CV946	30	36	40	8	1	12	2	1	CV1876	6	30	60					1
CV866	6	30	83					1				40	8	1	12	7	1	CV1878	6	37	54	7	2	12	5	1
CV867	6	37	46	8	7	12	2	1	CV995	6	40	36	4	3	2	1	1				62	7	2	12	1	1
			68	8	7	12	4	1	CV1067	6	29	93					1	CV1882	6	30	38					1
			68	8	7	12	5	1	CV1071	5	33	16					1	CV1893	6	37	55	7	2	12	10	1
CV873	6	33	17					1				16					2				65	7	2	12	4	1
			17					2	CV1074	6	37	50	7	2	12	10	1				65	7	2	12	5	1
CV876	6	36	48	8	1	12	3	1	CV1268	5	33	32					1	CV1894	6	37	55	7	2	12	10	1
			48	8	1	12	6	1				32					2				65	7	2	12	4	1
CV877	6	36	45	8	1	12	6	1	CV1280	6	37	44	7	2	12	10	1				65	7	2	12	4	1
CV878	6	36	40	8	1	12	4	1	CV1285	6	37	47	7	2	12	4	1				65	7	2	12	5	1
CV879	6	36	40	8	1	12	6	1				47	7	2	12	5	1	CV1895	50	37	*70	2	11	3	5	1
CV880	6	36	52	8	1	12	6	1	CV1301	6	37	48	7	2	12	3	1				*Normally Shows Short Position 11.					
CV881	6	36	52	8	1	12	6	1				48	7	2	12	5	1				*Normally Shows Grid Emission.					
CV882	6	36	40	8	1	4	3	1	CV1375	6	38	33	5	4	1	2	1	CV1902	6	37	45	7	2	12	5	1
									CV1377	5	33	10					1	CV1908	6	37	40	7	2	12	10	1
			68	8	1	4	5	1				10					2	CV1909	6	37	40	7	2	12	10	1
CV883	6	36	42	8	1	12	4	1	CV1633	12	8	74					1	CV1910	6	37	40	7	2	12	10	1
CV885	6	36	38	8	1	12	6	1				74					2	CV1911	6	29	91					1
CV886	6	36	38	8	1	12	6	1	CV1649	6	29	99					1	CV1912	6	29	91					1
CV887	6	36	50	8	1	4	3	1									1	CV1926	6	26	52					1
			68	8	1	4	5	1	CV1741	6	29	53					1	CV1928	12	1	78					1
			68	8	1	4	6	1	CV1753	35	36	34	8	1	12	6	1	CV1929	6	37	48	7	2	12	3	1
			68	8	1	4	6	1	CV1757	6	1	93					1				48	7	2	12	5	1
CV890	6	36	*33	8																						

△Use TC-70 Adapter.

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitiv- ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv- ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv- ity	A	B	C	D	Test Pos.	
CV1935	6	37	50	7	2	12	10	1	CV2390	3	40	*36	7	1	5	4	1	DF91	1	40	55	7	1	5	6	1	
CV1936	6	37	50	7	2	12	10	1	*Normally Shows Short Position 2-6.									DF92	1	40	55	7	1	5	6	1	
CV1937	6	37	50	7	2	12	10	1	CV2500	35	37	33	7	2	12	5	1	DF96	1	40	58	7	1	5	6	1	
CV1938	6	29	92						CV2507	1	40	52	7	1	5	6	1	DF97	1	40	40	7	1	5	6	1	
CV1940	6	29	92						CV2522	6	1	77						DF904	1	40	52	7	1	5	6	1	
CV1941	6	37	52	7	2	12	10	1	CV2524	6	1	82						DH63	6	37	40	7	2	12	10	1	
CV1942	6	37	52	7	2	12	10	1	CV2526	6	6	91									63	7	2	12	4	1	
CV1943	6	37	52	7	2	12	10	1				78									63	7	2	12	5	1	
CV1944	6	37	35	7	2	12	5	1	CV2534	50	29	47						DH74	12	37	40	7	2	12	10	1	
CV1945	6	37	35	7	2	12	5	1	CV2704	6	36	*33	8	2	1	5	1				63	7	2	12	4	1	
CV1946	6	37	35	7	2	12	5	1	*Normally Shows Short Position 3-4-6-7.												63	7	2	12	5	1	
CV1947	6	29	63						CV2706	6	36	53	8	1	12	4	1	DH76	12	37	40	7	2	12	10	1	
CV1948	6	29	63						CV2714	6	29	67									63	7	2	12	4	1	
CV1949	6	40	43	4	3	12	1	1	CV2716	6	37	48	8	7	12	3	1				63	7	2	12	5	1	
CV1950	6	37	44	7	2	12	10	1				48	8	7	12	4	1	DH77	6	6	85					1	
CV1951	6	37	44	7	2	12	10	1	CV2721	6	38	*32	5	4	7	2	1				78					2	
CV1956	6	37	47	7	2	12	4	1	*Normally Shows Short Position 1-6-9.									DH107	19	6	85					1	
			47	7	2	12	5	1	CV2748	5	33	12									78					2	
CV1957	6	37	47	7	2	12	4	1				12						DH149	6	36	50	8	1	4	3	1	
			47	7	2	12	5	1	CV2769	6	40	*55	4	3	1	5	1				68	8	1	4	5	1	
CV1958	6	37	47	7	2	12	4	1	*Normally Shows Short Position 2-7.												68	8	1	4	6	1	
			47	7	2	12	5	1	CV2901	6	38	40	4	5	2	9	1	DH710	6	17	90					1	
CV1959	50	4	44						CV2938	6	29	53										63					2
CV1961	12	1	82						CV2975	6	38	33	5	4	1	2	1	DH719	6	17	90					1	
CV1962	6	37	52	7	2	12	10	1	CV2983	3	40	45	7	1	5	6	1				63					2	
			63	7	2	12	4	1	CV2984	6	37	35	8	7	12	1	1	DK91	1	40	57	7	1	5	4	1	
CV1963	6	37	52	7	2	12	10	1				35	8	7	12	4	1	DK92	1	40	48	7	1	12	4	1	
			63	7	2	12	4	1	CV3512	6	40	34	4	3	5	6	1	DK96	1	40	54	7	1	12	4	1	
			63	7	2	12	5	1	CV3523	6	37	*38	7	2	1	5	1	DL33	3	37	45	7	2	8	5	1	
CV1964	6	37	52	7	2	12	10	1	*Normally Shows Short Position 4-6.									DL35	1	37	54	7	2	12	5	1	
			63	7	2	12	4	1	*Normally Shows Grid Emission.									DL36	1	37	48	7	2	12	5	1	
CV1966	6	37	37	7	2	12	5	1	CV3798	50	37	*70	2	11	3	5	1	DL91	1	40	*55	7	1	5	3	1	
CV1967	6	37	37	7	2	12	5	1	*Normally Shows Short Position 11.									*Normally Shows Short Position 2-6.									
CV1969	6	37	48	8	7	12	3	1	*Normally Shows Grid Emission.									DL92	3	40	*48	7	1	5	3	1	
CV1970	6	37	48	8	7	12	3	1	CV3799	50	37	*69	2	11	3	5	1	*Normally Shows Short Position 2-6.									
CV1972	6	37	41	8	7	12	3	1	*Normally Shows Short Position 11.									DL93	3	40	*36	7	1	5	4	1	
CV1973	6	37	41	8	7	12	3	1	*Normally Shows Grid Emission.									DL94	3	40	45	7	1	5	6	1	
CV1974	6	37	47	7	2	12	10	1	CV4007	6	5	62						DL95	3	40	*42	7	1	5	3	1	
CV1975	6	37	47	7	2	12	10	1				62						*Normally Shows Short Position 2-6.									
CV1976	6	37	37	7	2	12	5	1	CV4010	6	1	63						DL96	3	40	45	7	1	5	6	1	
CV1978	6	30	77						CV4018	6	40	32	4	3	5	1	1	DP61	6	1	63					1	
CV1981	6	30	84						CV4024	12	8	74						DY30	1	32	55					1	
CV1982	6	30	84									74						DY80	1	24	85					1	
CV1985	6	25	*85						D2M9	6	5	62						DY86	1	24	35					1	
			*85									62						DY87	1	24	35					1	
*Tube Good If it Reads 22 or More.									D63	6	37	48	7	2	12	3	1	DY802	1	24	56					1	
CV1988	6	25	78						D77	6	5	62						E55L	6	42	*25	4	5	7	8	1	
			78									62						*Normally shows short position 2-6.									
CV1990	6	37	42	8	7	12	2	1	D152	6	5	62						E80CC	12	8	74					1	
			71	8	7	12	4	1				62									74					2	
			71	8	7	12	5	1	D193	3	40	*36	7	1	5	4	1	E80CF	6	11	72					1	
CV1991	6	37	42	8	7	12	2	1	*Normally Shows Short Position 2-6.												55					2	
			71	8	7	12	4	1	DA90	2	40	*70	7	1	2	6	1	E80F	6	38	34	4	5	7	9	1	
			71	8	7	12	5	1	*Normally Shows Short Position 5-11.									E80L	6	38	25	4	5	1	2	1	
CV1993	6	30	92						DAC32	1	37	55	7	2	12	10	1	E80T	6	38	72	4	5	12	2	1	
CV1995	6	37	52	8	7	12	2	1				96	7	2	12	5	1	E81CC	12	8	74					1	
			71	8	7	12	5	1	DAF91	1	40	56	7	1	12	6	1				74					2	
CV1996	6	37	52	8	7	12	2	1				95	7	1	12	3	1	E81L	6	38	24	4	5	1	2	1	
			72	8	7	12	4	1	DAF92	2	40	55	7	1	12	6	1	E81OF	6	38	*29	4	5	3	2	1	
			72	8	7	12	5	1				70	7	1	12	4	1	*Normally shows short position 6-9.									
CV2128	6	38	85	5	4	12	1	1	DAF96	1	40	58	7	1	12	6	1	E83F	6	38	25	4	5	12	2	1	
CV2129	6	38	33	5	4	8	9	1				70	7	1	12	3	1	E88CC	6	8	24					1	
CV2370	3	40	*48	7	1	5	3	1	DC90	1	40	*70	7	1	5	6	1				24					2	
*Normally Shows Short Position 2-6.									*Normally Shows Short Position 2-3.												24					2	
									DCC90	3	40	45	7	1	4	3	1	E90CC	6	2	49					1	
												45	7	1	4	5	1				49					2	
									DD6	6	5	62						E90F	6	1	82					1	
												62						E91AA	6	5	62					1	
												62									62					2	
									DF33	2	37	53	7	2	12	10	1	E91H	6	1	89					2	

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.
E91N	6	40	32	4	3	5	1	1	ECC801S	12	8	74					1	EFL200	6	43	27	5	6	12	1	1
E92CC	6	2	61					1	ECC802S	12	8	75					1	EH90	6	1	94					1
E99F	6	1	84					1				75					2	EH-900S	6	1	91					1
E180F	6	38	25	4	5	1	2	1	ECC808	6	38	36	4	5	12	1	1	EK90	6	1	91					1
E182CC	6	38	30	4	5	8	2	1				36	4	5	12	9	1	EL34	6	29	53					1
E188CC	6	8	23	30	4	5	8	7	ECC808	6	38	41	4	5	6	1	1	EL36	6	27	58					1
E235L	6	37	24					2	ECC960	6	2	49	4	5	6	9	1	EL37	6	29	63					1
E280F	6	23	80					1				49					2	EL38	6	29	*62					1
EA91	6	5	62					1	ECF80	6	11	66					1	*For Plate Cap Use Jack Next to Socket 26.								
EABC80	6	17	62					2	ECF82	6	11	79					1	EL81	6	38	*32	5	4	7	2	1
EAF801	6	38	34	4	5	7	2	1	ECF86	6	38	25	4	5	3	2	1	*Normally Shows Short Position 1-6-9.								
EB34	6	37	48	7	2	1	3	1	ECF200	6	43	30	5	6	12	3	1	EL82	6	23	68					1
EB91	6	5	48	7	2	1	5	1	ECF201	6	43	28	5	6	12	3	1	EL83	6	38	30	5	4	12	2	1
EBC90	6	6	62					2				32	5	6	12	10	1	EL84	6	23	68					1
EBC91	6	6	85					1	ECF801	6	38	24	4	5	3	2	1	EL85	6	38	*39	5	4	1	2	1
EBF80	6	38	78					2	ECF802	6	11	80					1	*Normally Shows Short Position 6-8.								
EBF83	6	38	91					1	ECF805	6	38	85					2	EL86	6	23	58					1
EBF89	6	38	62	5	4	12	7	1				30	4	5	8	7	1	EL90	6	3	77					1
EC81	6	38	62	5	4	12	8	1	ECH81	6	38	33	4	5	8	9	1	EL91	6	40	34	4	3	12	1	1
EC86	6	39	64	5	4	12	7	1	ECH83	6	38	85	5	4	12	1	1	EL95	6	3	88					1
EC88	6	38	64	5	4	12	8	1	ECH84	6	38	38	5	4	12	9	1	EL500♦	6	42	*25	4	5	2	1	1
EC9C	6	40	31	5	4	12	2	1	ECH200	6	43	31	5	6	12	3	1	*Normally shows short position 3-6-7-8.								
EC91	6	40	62	5	4	12	7	1	ECL80	6	38	34	5	4	12	9	1	EL503♦	6	42	*31	4	5	3	7	1
*Normally Shows Short Position 1-3-6-9.									ECL82	6	38	33	5	4	12	3	1	*Normally shows short position 1-2-6-8.								
ECC81	12	8	74					1	ECL84	6	38	26	4	5	12	8	1	EL505♦	6	42	*26	4	5	1	8	1
ECC82	12	8	75					2				44	5	4	12	2	1	*Normally shows short position 2-3-6-7.								
ECC83	12	8	85					2	ECL85	6	38	25	4	5	12	9	1	EL802	6	9	51					1
ECC84	6	38	33	5	4	12	2	1	ECL86	6	38	25	4	5	12	2	1	EL803	6	38	30	5	4	12	2	1
ECC85	6	8	70					2	ECL88	6	38	35	4	5	7	1	1	EL820	6	38	*32	5	4	7	2	1
ECC86	6	38	33	5	4	12	2	1	ECL800	6	38	*99	4	5	12	1	1	*Normally Shows Short Position 1-6-9.								
ECC88	6	38	31	5	4	12	7	1				36	4	5	12	2	1	EL821	6	38	28	5	4	12	2	1
ECC89	6	38	29	4	5	7	2	1	ED2	6	5	62					1	ELL80	6	38	29	4	5	12	2	1
ECC91	6	2	60					1	*Tube good if it reads 25 or more.							2	EM-87	6	38	29	4	5	12	6	1	
ECC189	6	8	60					2	ED500♦	6	42	*52	4	5	12	8	1	EN93	6	40	43	4	3	12	1	1
			30					2	EF22	6	36	36	8	1	12	6	1	EQ80	6	38	33	5	4	3	7	1
			30					2	EF37-A	6	37	37	2	7	1	10	1	EY81	6	38	33	5	4	2	9	1
			30					2	EF80	6	38	33	5	4	1	2	1	EY82	6	38	29	4	5	6	9	1
			30					2	EF85	6	38	33	5	4	1	2	1	EY86	6	39	*95	5	4	1	10	1
			30					2	EF86	6	38	40	5	4	2	9	1	*Normally Shows Short Position 6-11.								
			30					2	EF89	6	38	34	5	4	1	2	1	EY87	6	39	*95	5	4	1	10	1
			30					2	EF91	6	40	30	4	3	12	1	1	*Normally Shows Short Position 6-11.								
			30					2	EF92	6	40	35	4	3	12	1	1	EY88*	6	39	30	5	4	7	3	1
			30					2	EF93	6	1	78					1	*If no test, use alternate settings.								
			30					2	EF94	6	1	82					1	EY88	6	39	30	5	4	3	7	1
			30					2	EF95	6	1	63					1	EY500■	6	37	32	7	8	2	5	1
			30					2	EF96	6	1	80					1	EZ35	6	33	15					1
			30					2	EF98	6	40	30	4	3	12	1	1				15					2
			30					2	EF183	6	38	30	5	4	3	2	1	EZ80	6	38	40	5	4	12	1	1
			30					2	EF184	6	38	29	5	4	3	2	1	EZ81	6	38	40	5	4	12	7	1
			30					2	EF804	6	38	39	5	4	2	9	1				40	5	4	12	1	1
			30					2	EF806S	6	38	40	4	5	2	9	1	EZ90	6	40	44	4	3	12	1	1
			30					2									1	G180/ZM	50	37	*99	2	11	3	5	1
			30					2	*Tube Good If It Reads 60 or More.								*Normally Shows Short Position 11.									
			30					2	*Normally Shows Grid Emission.								*Normally Shows Short Position 11.									
			30					2	GY501♦	3	42	*94	4	5	4	10	1	*No short test								
			30					2	GZ-30	5	33	12					1									
			30					2									1	GZ-32	5	33	12					2
			30					2									1				12					2
			30					2									1	GZ34	5	33	10					1
			30					2									1				10					2

■Use TC-62B Adapter. ♦Use TC-80 Adapter △Use TC-70 Adapter *Normal Shorts Refer to Position of "D" Switch.

E91N - GZ34

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.
H63	6	37	40	7	2	12	10	1	LZ329	9	11	66					1	PCF200	8	43	30	5	6	12	3	1
HABC80	19	17	90					1				55					2	PCF201	8	43	30	5	6	12	10	1
HBC90	12	6	63					2	M8081	6	2	60					1				28	5	6	12	3	1
			85					2				60					2	PCF801	8	38	24	4	5	3	2	1
			78					2	M8100	6	1	63					1				26	4	5	3	9	1
HBC91	12	6	91					1	N14	1	37	54	7	2	12	5	1	PCF802	9	11	80					1
			78					2	N17	3	40	*48	7	1	5	3	1				85					2
HCC85	17	8	65					1	*Normally Shows Short Position 2-6.									PCF805	7	38	30	4	5	8	7	1
			65					2	N18	3	40	*42	7	1	5	3	1				33	4	5	8	9	1
HCH81	12	38	32	5	4	12	2	1	*Normally Shows Short Position 2-6.									PCH200	9	43	31	5	6	12	3	1
			35	5	4	12	9	1	N19	3	40	45	7	1	5	6	1				30	5	6	12	8	1
HD14	1	37	55	7	2	12	10	1	N22LL	19	42	33	4	5	7	1	1	PCL82	16	38	33	5	4	12	3	1
			96	7	2	12	5	1	N152	19	38	*32	5	4	7	2	1				39	5	4	12	1	1
HF93	12	1	78					1	*Normally Shows Short Position 1-6-9.									PCL84	15	38	26	4	5	12	8	1
HF94	12	1	82					1	N329	16	23	68					1				26	4	5	12	1	1
HK90	12	1	91					1	N709	6	23	68					1	PCL85	18	38	25	4	5	12	9	1
HL90	19	3	77					1	NCC189	4	38	30	5	4	12	2	1				25	4	5	12	2	1
HL92	50	4	44					1				30	5	4	12	7	1	PCL86	14	38	25	4	5	12	2	1
HL94	30	40	27	3	4	5	2	1	NR67	6	37	44	7	2	12	10	1				35	4	5	7	1	1
HMO4	6	1	91					1	NR78	6	29	99					1	PD500	9	42	*52	4	5	12	8	1
HY90	35	40	33	4	3	6	5	1	NR78A	6	29	93					1	*Normally shows short position 2-3-6-7-9.								
KT32	25	29	47					1	NR81	6	37	52	7	2	12	10	1	PF9	6	37	52	7	2	12	10	1
KT63	6	29	91					1	NR83	6	37	50	7	2	12	10	1	PF86	4	38	33	4	5	2	9	1
KT66	6	29	63					1	NR85	6	29	91					1	PFL200	16	43	27	5	6	12	1	1
KT88	6	29	43					1	NR95	25	29	47					1				27	5	6	12	8	1
KTZ63	6	37	50	7	2	12	10	1	NU20	5	33	32					2	PH4	6	37	45	7	2	12	5	1
L63	6	29	93					1				32					1	PL36	25	27	58					1
L77	6	40	41	4	3	1	6	1	OBC3	12	37	42	8	7	12	2	1	PL81	19	38	*32	5	4	7	2	1
LC900	3	40	27	3	4	2	1	1	OF1	6	37	47	7	2	12	10	1	*Normally Shows Short Position 1-6-9.								
LCF80	6	11	66					2	OH4	12	37	45	7	2	12	5	1	PL82	16	23	68					1
			55					1	OSW2190	6	30	60					1	PL83	12	38	30	5	4	12	2	1
LCF200	5	43	30	5	6	12	3	1	OSW2192	6	30	38					1	PL84	15	23	58					1
			30	5	6	12	10	1	OSW2600	6	30	60					1	PL95	4	3	88					1
LCF201	5	43	28	5	6	12	3	1	OSW2601	6	30	38					1	PL500	30	42	*25	4	5	2	1	1
			32	5	6	12	10	1				42	8	1	12	2	1	*Normally shows short position 3-6-7-8.								
LCF-201	6	11	80					2	OSW3105	6	37	71	8	1	12	4	1	PL504	30	42	*25	4	5	2	1	1
			85					1				71	8	1	12	5	1	*Normally shows short position 3-6-7-8.								
LCF801	5	38	24	4	5	3	2	1	OSW3106	6	29	79					1	PL505	40	42	*26	4	5	1	8	1
			26	4	5	3	9	1	OSW3108	6	29	63					1	*Normally shows short position 2-3-6-7.								
LCH200	5	43	31	5	6	12	3	1				48	7	2	12	3	1	PL508	17	42	30	4	5	1	8	1
			30	5	6	12	8	1	OSW3109	6	37	48	7	2	12	5	1	PL-509	30	42	*26	4	5	1	8	1
LCL80	4	38	37	5	4	12	9	1				48	7	2	12	5	1	*Normally shows short position 2-3-6-7.								
			44	5	4	12	2	1	OSW3111	6	30	84					1	PL521	30	42	*29	4	5	1	8	1
LCL82	12	38	33	5	4	12	3	1	OSW3112	6	29	93					1	*Normally shows short position 2-3-6-7.								
			39	5	4	12	1	1	PABC80	9	17	90					1	PL802	16	9	51					1
LCL84	10	38	26	4	5	12	8	1				63					2	PL820	19	38	*32	5	4	7	2	1
			26	4	5	12	1	1	PC86	4	39	29	4	5	3	6	1	*Normally Shows Short Position 1-6-9.								
LCL85	10	38	25	4	5	12	9	1	PC88	4	38	*85	4	5	7	8	1	PM04	6	1	78					1
			25	4	5	12	2	1	*Normally shows short position 1-3-6-9.									PM05	6	1	63					1
LF183	4	38	30	5	4	3	2	1	PC92	3	40	30	4	3	12	6	1	PY32	30	37	24	2	7	6	3	1
LF184	4	38	29	5	4	3	2	1	PC-95	4	40	33	4	3	1	2	1				24	2	7	6	5	1
LFL200	12	43	27	5	6	12	1	1	PC97	5	40	33	3	4	1	2	1	PY80	19	38	29	5	4	12	9	1
			27	5	6	12	8	1	PC900	4	40	27	3	4	2	1	1	PY81	17	38	33	5	4	2	9	1
LL86	10	23	58					1	PCC84	7	38	33	5	4	7	2	1	PY82	19	38	29	4	5	6	9	1
LL500	18	42	*25	4	5	2	1	1				33	5	4	7	6	1	PY88*	30	39	30	5	4	7	3	1
*Normally shows short position 3-6-7-8.									PCC85	9	8	70					2	*If no test, use alternate settings.								
LL505	25	42	*26	4	5	1	8	1				70					1	PY88	30	39	30	5	4	3	7	1
*Normally shows short position 2-3-6-7.									PCC88	7	38	31	5	4	12	2	1	PY500	40	37	32	7	8	2	5	1
LL521	22	42	*29	4	5	1	8	1				31	5	4	12	7	1	QA240	6	40	41	4	3	1	6	1
*Normally shows short position 2-3-6-7.									PCC89	7	38	29	4	5	7	2	1				62					1
			29	4	5	7	6	1				29	4	5	7	6	1	QA2404	6	5	62					1
LL802	10	9	51					1	PCC189	7	8	30					2	QA2406	12	8	74					2
LN152	6	38	37	5	4	12	9	1				30					1				62				1	
			44	5	4	12	2	1	PCF80	9	11	66					1	QA2407	6	40	44	4	3	12	1	1
LY-81	10	38	33	5	4	2	9	1				55					2				44	4	3	12	6	1
LY88*	22	39	30	5	4	7	3	1	PCF82	9	11	79					1	QA2408	6	25	78					1
*If no test, use alternate settings.												55					2				78				2	
LY88	22	39	30	5	4	3	7	1	PCF86	7	38	25	4	5	3	2	1	QE03/10	6	38	33	5	4	8	9	1
LY500	30	37	32	7	8	2	5	1				25	4	5	1	6	1									1
LZ319	9	11	66					2				25	4	5	1	6	1									2
			55					2																		1

B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensi- tivity	A	B	C	D	Test Pos.		
QE05/40	6	37	*38	7	2	1	5	1	V177	6	40	35	4	3	12	1	1	X73 (M)	6	37	45	7	2	12	5	1		
*Normally Shows Short Position 4-6.									V741	6	40	41	4	3	1	6	1	X107	19	1	91					1		
QS150/40	50	37	*99	2	11	3	5	1	V884	6	40	35	4	3	12	1	1	X155	6	8	55					1		
*Tube Good if it Reads 60 or More.									V886	6	40	34	4	3	12	1	1				55					2		
*Normally Shows Short Position 11.									VP6	6	40	35	4	3	12	1	1	X727	6	1	91					1		
*Normally Shows Grid Emission.									VP1321	12	40	*55	4	3	1	5	1	XB767A	6	37	34	7	2	12	5	1		
QV03/12	6	38	33	5	4	8	9	1	*Normally Shows Short Position 2-7.									XC95	2	40	33	4	3	1	2	1		
QV06/20	6	37	*38	7	2	1	5	1	VR75	50	37	*70	2	11	3	5	1	XC97	2	40	33	4	3	1	2	1		
*Normally Shows Short Position 4-6.									*Normally Shows Short Position 11.									XC900	2	40	27	3	4	2	1	1		
R52	5	33	12					1	*Normally Shows Grid Emission.									XCC189	4	8	30					1		
SN7	1	32	55					2	VR90	50	37	*69	2	11	3	5	1				30					2		
SP6	6	40	30	4	3	12	1	1	*Normally Shows Short Position 11.									*Normally shows short position 4-6										
TJ880	12	9	35					1	*Normally Shows Grid Emission.									XCF80	4	11	66					1		
T2M05	6	40	34	4	3	12	5	1	VR105	50	37	*85	2	11	3	5	1	XCF86	5	38	24	4	5	3	2	1		
									*Normally Shows Short on Position 11.												65					2		
TM12	6	40	*85	4	3	12	6	1	*Normally Shows Grid Emission.									XCF801	4	38	24	4	5	3	2	1		
*Normally Shows Short Position 5-6.									VR150/30	50	37	*99	2	11	3	5	1				25	4	5	1	6	1		
TS51	6	1	63					1	*Tube Good if it Reads 60 or More.												24	4	5	3	2	1		
TS52	6	2	60					1	*Normally Shows Short on Position 11.									XCH81	3	38	85	5	4	12	1	1		
									*Normally Shows Grid Emission.												38	5	4	12	9	1		
TS-876C	6	9	28					2	VT52	6	29	92					1	XCL82	8	38	33	5	4	12	3	1		
U5Q	5	33	32					1	VT65	7	29	99					1				39	5	4	12	1	1		
									VT66	6	29	91					1	XCL84	8	38	26	4	5	12	8	1		
U52	5	33	16					2	VT74	5	33	12					1				26	4	5	12	1	1		
																		XCL85	18	38	25	4	5	12	9	1		
U54	5	33	10					2	VT86	6	37	52	7	2	12	10	1				25	4	5	12	2	1		
									VT87	6	37	44	7	2	12	10	1	XF80	3	38	33	5	4	1	2	1		
U78	6	40	44	4	3	12	1	1	VT88	6	37	52	7	2	12	10	1	XF85	3	38	33	5	4	1	2	1		
																		XF183	3	38	30	5	4	3	2	1		
U147	6	33	15					1										XF184	3	38	29	5	4	3	2	1		
U149	6	36	45	8	1	12	3	1	VT90	6	37	48	7	2	12	3	1	XL36	12	27	57					1		
																		XL84	8	23	68					1		
U153	17	38	33	4	5	2	9	1	VT91	6	37	50	7	2	12	10	1	XL86	8	23	58					1		
U154	19	38	29	4	5	6	9	1	VT93	6	37	55	7	2	12	10	1	XL500♦	12	42	*25	4	5	2	1	1		
U192	19	38	29	4	5	6	9	1										*Normally shows short position 3-6-7-8.										
U709	6	38	34	5	4	12	1	1	VT94	6	29	93					1	XXD	12	36	41	8	1	12	4	1		
									VT96	6	37	47	7	2	12	4	1				41	8	1	12	5	1		
UAA91	19	5	62					1	VT97	5	33	32					1	XXFM	6	36	43	8	1	12	3	1		
																					36	8	1	12	5	1		
UABC80	25	17	62					2	VT99	6	37	45	7	2	12	5	1				35	8	1	12	6	1		
																		XXL	6	36	41	8	1	12	6	1		
UBF80	17	38	33	5	4	12	2	1	VT102	6	29	92					1	XY88*	16	39	30	5	4	7	3	1		
									VT103	6	37	42	8	7	12	2	1	*If no test, use alternate settings.										
UC92	9	40	30	4	3	12	6	1										XY88	16	39	30	5	4	3	7	1		
UCC84	22	38	33	5	4	7	2	1										YF183	4	38	30	5	4	3	2	1		
																					4	38	29	5	4	3	2	1
UCC85	25	8	70					1	VT104	12	37	42	8	7	12	2	1	YF184	4	38	29	5	4	3	2	1		
																		YL1371	12	37	*38	7	2	1	5	1		
UCF80	25	11	66					2	VT105	6	37	48	8	7	12	3	1	Z14	2	37	53	7	2	12	10	1		
																		Z63	6	37	50	7	2	12	10	1		
UCH81	19	38	32	5	4	12	2	1										Z719	6	38	33	5	4	1	2	1		
																		Z729	6	38	40	5	4	2	9	1		
UCL82	50	38	33	5	4	12	3	1	VT107	6	29	79					1	ZD17	1	40	*55	7	1	5	3	1		
UF80	19	9	76					1	VT112	6	30	60					1	*Normally Shows Short Position 2-6.										
UF85	19	9	62					1	VT114	5	33	16					1	ZD25	1	40	58	7	1	12	6	1		
UF86	12	38	40	5	4	2	9	1													70	7	1	12	3	1		
UF89	12	38	34	4	5	1	2	1	VT115	6	29	63					1	ZD151	6	38	37	5	4	12	2	1		
UL84	50	23	58					1	VT116	6	30	83					1				64	5	4	12	7	1		
UU12	6	38	34	5	4	12	1	1	VT117	6	30	84					1	ZD152	6	38	37	5	4	12	2	1		
UY82	50	38	29	4	5	6	9	1	VT124	1	37	55	7	2	12	5	1				64	5	4	12	7	1		
UY85	35	39	30	4	5	1	6	1	VT125	1	37	54	7	2	12	5	1											
V2M70	6	40	44	4	3	12	1	1	VT126	6	33	15					1											
																					15					2		
									W17	1	40	55	7	1	5	6	1											
									W77	6	40	35	4	3	12	1	1											
									W149	6	36	45	8	1	12	6	1											
									W719	6	38	33	5	4	1	2	1											
									W727	6	1	78					1											
									X63 (M)	6	37	45	7	2	12	5	1											
									X64	6	37	44	7	2	1	10	1											