




NOTE:
CONDENSERS ARE IN MFD.
UNLESS OTHERWISE SPECIFIED.

BAND SELECTOR SWITCH SW-1	
POSITION	RANGE AM
1 -	.54 TO 1.62 MC. AM
2 -	1.62 TO 5 MC. AM
3 -	5 TO 15 MC. AM
4 -	15 TO 30 MC. AM
5 -	27 TO 55 MC. AM / FM
6 -	55 TO 108 MC. AM / FM

SWITCH SHOWN IN POSITION NO. 1









RECEPTION SWITCH SW - 3	
1 -	CW
2 -	AM
3 -	FM
4 -	PHONO

SWITCH SHOWN IN CW POSITION

Figure 19. Model SX-42 Schematic W







RECEPTION SWITCH SW - 3

- 1 - CW
- 2 - AM
- 3 - FM
- 4 - PHONO

SWITCH SHOWN IN CW POSITION

Model SX-42 Schematic Wiring Diagram





SELECTIVITY SWITCH SW - 2

1 -		BROAD
2 -	NORMAL	MED.
3 -		SHARP
4 -		BROAD
5 -	CRYSTAL	MED.
6 -		SHARP

SWITCH SHOWN IN NORMAL BROAD POSITION

89 D 210 - D