



**SCHEMATIC OF THE  
HEATHKIT®  
SOLID-STATE MONO  
FM RECEIVER  
MODEL AR-27**

**NOTE:**

1. RESISTOR AND CAPACITOR NUMBERS ARE IN THE FOLLOWING GROUPS:  
 0-99 NUMBERS IN THE FM TUNER SECTION,  
 100-199 NUMBERS IN THE AMPLIFIER SECTION,  
 200-299 NUMBERS IN THE POWER SUPPLY SECTION,  
 \* DENOTES PARTS NOT MOUNTED ON THE CIRCUIT BOARD.
2. ALL RESISTORS ARE 1/2 WATT UNLESS MARKED OTHERWISE. RESISTOR VALUES ARE IN OHMS (K = 1000, MEG = 100,000).
3. CAPACITOR VALUES LESS THAN 1 ARE IN μfd. VALUES OF 1 AND ABOVE ARE IN pF, UNLESS THEY ARE MARKED OTHERWISE.
4. ○ THIS SYMBOL INDICATES A POSITIVE DC VOLTAGE MEASUREMENT. TAKEN WITH AN 11 MEGOHM ELECTRONIC VOLTMETER OR VTVM FROM THE POINT INDICATED TO CHASSIS GROUND.
5. □ INDICATES B- VOLTAGE POINTS.
6. ○ INDICATES CONNECTING POINTS ON THE CIRCUIT BOARD.
7. REFER TO THE CIRCUIT BOARD X-RAY VIEW AND CHASSIS PHOTO FOR THE PHYSICAL LOCATION OF PARTS.
8. → INDICATES CW ROTATION.
9. ALL VOLTAGES ARE MEASURED WITH NO SIGNAL INPUT.

