



SCHEMATIC OF THE
HEATHKIT
MODEL HD - 1410
ELECTRONIC KEYSER

IC Vcc AND GROUND PINS

IC	TYPE	Vcc +5V	GROUND
IC1	7403	PIN 28	PIN 7
IC2	7400	PIN 14	PIN 7
IC3	7410	PIN 14	PIN 7
IC4	7413	PIN 4	PIN 11
IC5	7402	PIN 14	PIN 7



SHOWN WIRED FOR RIGHT HAND OPERATION

SEE NOTE 16C
SEE NOTE 16D

SEE NOTE 16A