

SPECIAL SET-UP CHANGE

FOR ManualsPlus.com

8233-TUBE CHECK

PROBLEM: 8233 is damaged when checked in Mighty Mite (TC114*, TC130, TC136 and the Semi-Automatic TC131)

CORRECTION: Change the 8233 set-up information to the following:

TC114*, TC130, TC136	$\frac{A}{6}$	$\frac{B}{D}$	$\frac{C}{10}$	$\frac{D}{H}$	$\frac{SKT}{5}$	$\frac{Norm\ Sht.}{B,F}$
----------------------	---------------	---------------	----------------	---------------	-----------------	--------------------------

*Do not make a short test with the TC114 or permanent damage to the 8233 will result. This is a double frame grid tube and only the TC130, TC136 and TC131 are capable of safely making a short test

TC131	$\frac{Fil}{6}$	$\frac{Ld}{D}$	$\frac{SKT}{7}$	$\frac{SHT\ SS}{H}$	$\frac{Norm\ Shts}{G,J}$
-------	-----------------	----------------	-----------------	---------------------	--------------------------

NOTE: The 8233 is a magnoval. Do not insert this tube into the socket. Apply firm pressure downward with tube, toward socket, while making test.