
Agilent Technologies
11716A/C
Interconnection Kit

Operating Note



11716-90004

Agilent Part Number: 11716-90004
Printed in USA
June 2002
Supersedes: April 2002

Notice

The information contained in this document is subject to change without notice.

Agilent Technologies makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Agilent Technologies shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Agilent Technologies assumes no responsibility for the use or reliability of its software on equipment that is not furnished by Agilent Technologies.

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without prior written consent of Agilent Technologies.

Restricted Rights Legend

Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 for DOD agencies, and subparagraphs (c)(1) and (c)(2) of the Commercial Computer Software Restricted Rights clause at FAR 52.227-19 for other agencies.

Warranty

Certification

Agilent Technologies certifies that this product met its published specifications at the time of shipment from the factory.

Documentation Warranty

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED "AS IS," AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, AGILENT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED WITH REGARD TO THIS MANUAL AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. AGILENT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR ANY INFORMATION CONTAINED HEREIN. SHOULD AGILENT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS COVERING THE MATERIAL IN THIS DOCUMENT THAT CONFLICT WITH THESE TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT WILL CONTROL.

Assistance

Product maintenance agreements and other customer assistance agreements are available for Agilent Technologies products.

For assistance, call your local Agilent Technologies Sales and Service Office (refer to [“Support and Service”](#)).

Support and Service

You can find a list of local service representatives on the Web at:

<http://www.agilent.com/find/assist>

Click on “Contact Us” and select your country.

If you do not have access to the Internet, one of these centers can direct you to your nearest Agilent Technologies representative:

United States	(800) 403-0801
Canada	(877) 429-9969
Europe	(41 22) 780.6111 (Switzerland) (33 1) 69 82 66 66 (France) (49 7031) 464-6222 (Germany) (44 188) 9696622 (Great Britain)
Japan	0120-32-0119
Latin America	(11) 7297-3700 (Brazil)
Australia/New Zealand	1-800-802-540 (Australia) 0800-738-378 (New Zealand)
Asia-Pacific	080-047-669

General Information

This operating note contains information for the 11716A and 11716C Interconnection Kits. Included in the note is a list of parts with part numbers and instructions for using the kit.

Description

The 11716A and 11716C Interconnection Kit provides the necessary parts to connect various attenuators in series. See [Table 1](#) for possible combinations. The 11716A interconnection ridged cable has type-N connectors, and the 11716C has SMA connectors.

- Overall height with attenuators is 3.235 inches.
- Typical return loss of the cable is ≤ 20 dB.

Interconnection Kit Matrix

Table 1 *Interconnection Kit Parts*

	8494	8495	8496
8494	Yes	Yes	Yes
8495	Yes	No	Yes
8496	Yes	Yes	Yes

Items Supplied

Parts included in the interconnection kits are listed in [Table 2](#).

Table 2 *Interconnection Kit Parts*

Description	Qty	Part Number
Combining bracket	1	11716-00001
Base	1	11716-00002
Interconnect rigid cable		
Type-N male connectors 11716A	1	11716-20001
SMA connectors 11716C	1	11716-20003
Felt feet	4	0403-0309
Screw 4-40 x 7.9 mm (0.312 inch)	4	2200-0105
Screw 4-40 x 9.5 mm (0.375 inch)	2	2220-0769

Installation

Initial Inspection

Inspect the shipping container for damage. Inspect the kit for any mechanical damage incurred in transit. If the shipping container or cushioning material is damaged, it should be kept until the contents of the shipment have been checked for completeness and the kit has been checked mechanically and electrically.

If the contents of this shipment are incomplete, or if there is mechanical damage or defect, notify the nearest Agilent Technologies Office. If the shipping container is damaged, or the cushioning material shows signs of stress, notify the carrier as well as the Agilent Technologies office. At Agilent's option, the office will arrange for repair or replacement without waiting for claim settlement.

Installing Interconnection Kit

CAUTION

Do not allow connectors on the Interconnection Kit to bear torque or support weight.

To connect two attenuators using the kit:

1. Remove the pedestal bases of both attenuators.
2. Select the attenuator to be located on top and connect it to the outer bracket surface that has the three small holes. Use two of the 4-40 x 7.9 mm (0.312 inch) screws supplied.

NOTE

If one of the two attenuators is an 8495 70 dB attenuator, this physically shorter unit should be selected for the top location.

3. Fasten the remaining attenuator to the inside of the bracket, with or without the sheet metal base. The screws should pass through the two elongated holes. Do not tighten these screws at this time.

NOTE

The 4-40 x 9.5 mm (0.375 inch) screws are for fastening to a plastic attenuator pedestal base. The 4-40 x 7.9 mm (0.312 inch) are for fastening to the bracket.

4. Connect the rigid cable between the two attenuators. The lower attenuator should be adjusted laterally so that the rigid cable connects easily without strain.
5. Firmly tighten the two screws holding the lower attenuator to the bracket.
6. If no sheet metal base is being used, the adhesive-backed felt feet that are supplied may be attached to the underside of the bracket to prevent marring the surface on which the combined attenuators are set. [Figure 1](#) shows how the interconnection kit is typically used.
7. When using the sheet metal base, use the .375 long screws to connect the attenuator bracket to the sheet metal base.




Figure 1 Typical Installation