

# B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Normal-evity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Normal-evity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Normal-evity	A	B	C	D	Test Pos.
OA3	50 37	*70	2 11 3 5 1					1	1LD5	2 36	53	8 1 12 6 1					1	3AL5	3 5	62						1
*Normally Shows Short on Position No. 11.									11E3									3AU6								
*Normally Shows Grid Emission.									11E5									3AV6								
OB3	50 37	*69	2 11 3 5 1					1	11L4									3AW3								
*Normally Shows Short on Position No. 11.									11N5									3B2								
*Normally Shows Grid Emission.									1N2-A									3B7								
OC3	50 37	*85	2 11 3 5 1					1	1N5									3BA6								
*Normally Shows Short on Position No. 11.									1P5									3BC5								
*Normally Shows Grid Emission.									1P10									3BE6								
OD3	50 37	*99	2 11 3 5 1					1	*Normally Shows Short Position 2-6.									3BN4								
*Normally Shows Short on Position No. 11.									1P11									*Normally Shows Short Position 1-6.								
*Normally Shows Grid Emission.									1Q5									3BN6								
*Tube Good if it Reads 60 or More.									1R4									3BU8								
OZ4	6 31	8						1	1R5									3BX6								
									1S2-A									3BY6								
									1S4									3BZ6								
1A3	2 40	*70	7 1 2 6 1					1	1S5									3C2								
*Normally Shows Short on Position 5 and 11.									1T4									3C4								
1A5	1 37	55	7 2 12 5 1					1	1T5									3CB6								
1A7	1 37	57	7 2 12 5 1					1	1U4									3CE5								
1AB6	1 40	54	7 1 12 4 1					1	1U5									3CF6								
1AC6	1 40	48	7 1 12 4 1					1	1V2									3CS6								
1AF4	1 40	50	7 1 5 6 1					1	1X2									3CY5								
1AH5	1 40	58	7 1 12 6 1					1	2AF4									3D6								
1AJ4	1 40	58	7 1 5 6 1					1	*Normally Shows Short Position 1-7.									3DG4								
1AN5	1 40	40	7 1 5 6 1					1	2B3									3DK6								
1AU3	1 32	95						1	2BN4									3DT6								
1AX2	1 24	93						1	*Normally Shows Short Position 1-6.									3EA5								
1B3	1 32	55						1	2C51									3EH7								
1B7	1 37	55	7 2 12 5 1					1	2CW4									3EJ7								
1C1	1 40	57	7 1 5 4 1					1	*For Grid Emission Turn D Switch to Position 4.									3ER5								
1C5	1 37	54	7 2 12 5 1					1	2CY5									3ES5								
1C7	2 37	54	7 2 12 5 1					1	2D21									3EV5								
1D5GT	2 37	54	7 2 12 10 1					1	2E26									3FH5								
1D8	1 37	58	7 2 12 5 1					1	*Normally Shows Short Position 4-6.									3FQ5								
*Tube Good if it Reads 30 or More.									2EA5									3FQ5A								
1DN5	1 40	60	7 1 12 6 1					1	2EN5									3FS5								
1F1	1 40	58	7 1 5 6 1					1	2ER5									3FY5								
1F2	1 40	55	7 1 5 6 1					1	2ES5									3GK5								
1F3	1 40	55	7 1 5 6 1					1	2EV5									3GS8								
1F5	2 37	48	7 2 12 5 1					1	2FH5									3HS8								
1F7	2 37	54	7 2 12 10 1					1	2FS5									3L35								
1FD1	1 40	67	7 2 12 5 1					1	2FQ5									*Normally Shows Short Position 2-6.								
1FD9	1 40	56	7 1 12 6 1					1	2FQ5A									3LF4								
1G3	1 32	55						1	2FV6									3Q4								
1G6	1 37	55	7 2 12 4 1					1	2FY5									*Normally Shows Short Position 2-6.								
1H2	1 24	58						1	2GK5									3Q5								
1H5	1 37	55	7 2 12 10 1					1	2T4									3S4								
1H6	2 37	54	7 2 12 6 1					1	*Normally Shows Short Position 1-7.									*Normally Shows Short Position 2-6.								
1J3	1 32	88						1	3A2									3V4								
1J6	2 37	53	7 2 12 4 1					1	3A3									4AU6								
1K3	1 37	53	7 2 12 5 1					1	3A4									4AU8								
1L4	1 40	55	7 1 5 6 1					1	*Normally Shows Short Position 2-6.									4AV6								
1L6	1 40	58	7 1 12 4 1					1	3A5									4BA6								
1LA4	1 36	54	8 1 12 6 1					1	3A8									4BC5								
1LA6	1 36	62	8 1 12 4 1					1	3AF4									4BC8								
1LB4	1 36	55	8 1 12 6 1					1	*Normally Shows Short Position 1-7.									4BE6								
1LC5	1 36	54	8 1 5 6 1					1	3AJ8									4BL8								
1LC6	1 36	68	8 1 12 4 1					1																		

# B & K DYNA-QUIK MODEL 700 TUBE CHART

ManualsPlus.com

TUBE TYPE	Heater	Socket	Serial-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Serial-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Serial-ity	A	B	C	D	Test Pos.							
4BN4	4	40	*33	4	3	2	7	1	5BS8	5	8	54					1	5X8	5	12	73					1							
*Normally Shows Short Position 1-6.																									5Y3	5	33	32					1
4BN6	4	7	75					1	5BT8	5	38	33	5	4	12	8	1	5Y4	5	37	52	8	7	12	3	1							
4BQ7	4	8	54					1				54	5	4	12	2	1	5Z4	5	33	12					1							
			54					2	5BW8	5	38	33	5	4	2	6	1	5Z10	5	33	12					2							
4BS8	4	8	54					1				34	5	4	7	1	1																
			54					2	5BZ7	5	8	53	5	4	7	3	1																
4BU8	4	21	92					1				53					2																
			92					2	5CG8	5	14	73					1	6A8	6	37	45	7	2	1	5	1							
4BX8	4	38	33	5	4	12	2	1				59					2	6AB4	6	40	30	4	3	12	6	1							
			33	5	4	12	7	1	5CL8	5	14	69					1	6AB7	6	30	74					1							
4BZ6	4	1	61					1				51					2	6AB8	6	38	37	5	4	12	9	1							
4BZ7	4	8	53					1	5CM6	5	16	64					1																
			53					2	5CM8	5	38	33	5	4	12	2	1	6AC5	6	37	40	7	2	12	5	1							
4BZ8	4	8	55					1				38	5	4	12	9	1	6AC7	6	30	60					1							
			55					2	5CQ8	5	11	72					1	6AD7	6	37	54	7	2	12	5	1							
4CB6	4	1	64					1				55					2	6AF3	6	15	12					1							
4CE5	4	1	62					1	5CR8	5	38	*32	5	4	12	2	1	6AF4	6	40	*33	4	3	2	6	1							
4CS6	4	1	94					1				*34	5	4	12	9	1																
4CY5	4	1	54					1									1	6AG5	6	1	80					1							
4DE6	4	1	61					1	5CU4	5	37	28	8	2	12	4	1	6AG7	6	30	38					1							
4DK6	4	1	61					1				28	8	2	12	6	1	6AH4	6	37	33	7	2	12	1	1							
4DT6	4	1	91					1	5CZ5	5	16	60					1	6AH6	6	1	58					1							
4EH7	4	38	30	5	4	3	2	1	5DB4	5	33	16					1	6AH7	6	37	48	8	7	12	1	1							
4EJ7	4	38	29	5	4	3	2	1				16					2	6AJ4	6	38	*84	8	7	1	5	1							
4ES8	4	38	30	5	4	12	2	1	5DH8	5	14	61					1																
			30	5	4	12	7	1				73					2	6AJ5	6	40	36	4	3	2	1	1							
4EW6	4	1	77					1	5DJ4	5	33	16					1	6AJ7	6	30	60					1							
4GK5	4	40	25	4	3	1	2	1				16					2	6AJ8	6	38	85	5	4	12	1	1							
4GM6	4	1	64					1	5EA8	5	11	71					2	6AK5	6	1	63					1							
4GS8	4	21	95					1				56					2	6AK6	6	1	82					1							
			95					2	5EH8	5	12	71					2	6AK7	6	30	38					1							
4HS8	4	21	99					1				54					2	6AK8	6	17	90					1							
			99					2	5ES8	5	38	30	5	4	12	2	1	6AL3	6	39	25	5	4	6	3	1							
5AM8	5	38	30	5	4	12	2	1				30	5	4	12	7	1	6AL5	6	5	62					2							
			30	5	4	12	8	1	5EU8	5	38	32	5	4	12	2	1	6AM4	6	38	*96	8	7	1	5	1							
5AN8	5	13	62					2	5EW6	5	1	77					1	6AM5	6	40	34	4	3	12	1	1							
			61					1	5FG7	5	14	68					2	6AM6	6	40	30	4	3	12	1	1							
5AQ5	5	3	77					1				56					2	6AM8	6	38	30	5	4	12	2	1							
5AR4	5	33	10					1	5FV8	5	14	65					1	6AN4	6	40	*30	4	3	2	6	1							
			10					2	5GH8	5	11	68					2																
5AS4	5	33	17					2	5GM6	5	1	64					1	6AN5	6	1	26					1							
			17					2	5GX6	5	1	85					1	6AN6	6	40	52	7	1	12	2	1							
5AS8	5	38	31	5	4	12	2	1	5J6	5	2	60					1																
			32	5	4	12	6	1				60					2	6AN8	6	13	62					1							
5AT8	5	14	77					1	5N1039A	6	1	63					1	6AQ4	6	40	*29	4	3	6	1	1							
			55					2	5R4	5	33	22					2	6AQ5	6	3	77					1							
5AU4	5	33	16					1	5T4	5	33	16					1	6AQ6	6	6	89					1							
			16					2	5T8	5	17	90					2	6AQ7	6	37	80					2							
5AV8	5	22	62					1	5U4	5	33	16					2																
			62					2	5U8	5	11	79					1	6AQ8	6	8	70					1							
5AW4	5	33	17					2	5V3	5	33	15					2	6AR5	6	3	91					1							
			17					2	5V4	5	33	12					1	6AR6	6	37	33	8	6	12	7	1							
5AZ4	5	36	53	8	2	12	4	1				12					2	6AR8	6	38	30	5	4	12	6	1							
			53	8	2	12	6	1	5V6	5	29	79					1																
5B8	5	22	62					1	5W4	5	33	32					1																
			62					2	5X4	5	37	47	8	7	12	3	1																
5BC3	5	42	*33	1	3	6	5	1				47	8	7	12	5	1																
			*33	1	3	8	9	1				55					2																
*Normally Shows Short Position 8-9.																																	
**Normally Shows Short Position 5-6.																																	
5BE8	5	14	72					1	5Y3	5	33	15					2	6AR8	6	38	30	5	4	12	6	1							
			55					2	5Y4	5	33	12					1																
5BK7	5	8	55					1	5V6	5	29	79					1																
			55					2	5W4	5	33	32					1																
5BQ5	5	23	68					1	5X4	5	37	47	8	7	12	3	1																
5BQ7	5	8	54					1				47	8	7	12	5	1																
			54					2									2																
5BR8	5	14	72					1									2																
			55					2									2																

# B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sens.-tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sens.-tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sens.-tivity	A	B	C	D	Test Pos.		
6AS5	6	4	55					1	6BE8	6	14	72					1	6BX6	6	38	33	5	4	1	2	1		
6AS6	6	1	77					1	6BX7	6	25	55					2	6BX8	6	38	33	5	4	12	2	1		
6AS7	6	37	35	8	7	12	1	1	6BF5	6	3	40					1				55					2		
6AS8	6	38	31	5	4	12	2	1	6BF6	6	6	85					1	6BY5	6	38	33	5	4	12	2	1		
6AT6	6	6	32	5	4	12	6	1	6BF8	6	38	25	4	5	12	1	1	6BY6	6	1	88	7	2	12	4	1		
6AT8	6	14	77					1			25	4	5	12	2	1	6BY7	6	38	33	5	4	1	2	1			
6AU4	6	34	10					1			25	4	5	12	3	1	6BY8	6	38	34	5	4	12	1	1			
6AU5	6	28	71					1	6BG6	6	26	66	25	4	5	12	9	1	6BZ6	6	1	61	5	4	12	6	1	
6AU6	6	1	82					1	6BH3	6	42	27	5	4	7	2	1	6BZ7	6	8	53					1		
6AU7	6	8	75					1	6BH6	6	1	89					1	6BZ8	6	8	55					2		
6AU8	6	12	56					1	6BH8	6	12	59					1				55					1		
6AV5	6	28	62					2	6BJ6	6	1	81					1	6C4	6	40	41	4	3	1	6	1		
6AV6	6	6	91					1	6BJ7	6	38	33	5	4	12	6	1	6C5	6	29	99	7	2	12	5	1		
6AV11	6	35	30	1	12	12	7	1	6BJ8	6	38	38	5	4	12	8	1	6C8	6	37	48	7	2	12	10	1		
6AW8	6	12	44					1			34	5	4	12	6	1	6C9	6	38	28	5	4	6	1	1			
6AX2	6	24	88					1	6BK4	6	37	*55	7	2	3	5	1	6C31	6	40	*80	4	3	1	7	1		
6AX3	6	35	30	1	12	10	4	1	*Normally Shows Short Position 1-4-6-8.								6CA4	6	38	34	5	4	12	1	1			
6AX4	6	34	13					1	6BK5	6	10	53					1	6CA5	6	4	55					1		
6AX5	6	33	22					2	6BK6	6	6	86					1	6CA7	6	29	53					1		
6AX7	6	8	*85					1	6BK7	6	8	70					1	6CB5	6	26	43					1		
6AX8	6	11	73					1	6BL4	6	34	10					1	6CB6	6	1	64					1		
6AY3	6	42	27	5	4	7	2	1	6BL7	6	25	57					1	6C10	6	35	42	1	12	12	7	1		
6AZ8	6	38	32	5	4	12	6	1	6BL8	6	11	66					1	6CCYZ	6	38	29	9	1	12	3	1		
6B4	6	37	35	7	2	12	5	1			55						2				42	1	12	12	9	1		
6B6	6	37	37	7	2	12	10	1	6BM8	6	38	33	5	4	12	3	1	6CD6	6	26	53					1		
6B8	6	37	58	7	2	12	4	1	6BN4	6	40	*33	4	3	2	7	1	6CE5	6	1	62					1		
6B10	6	35	34	1	12	12	3	1	6BN5	6	38	*39	5	4	1	2	1	6CF6	6	1	60					1		
6B31	6	5	62					1	*Normally Shows Short Position 1-6.								6CG7	6	8	76					1			
6B32	6	5	62					2	6BN6	6	7	75					1	6CG8	6	14	73					1		
6BA6	6	1	78					1	6BN8	6	38	35	5	4	12	8	1	6CH6	6	38	28	5	4	12	2	1		
6BA7	6	38	33	5	4	12	2	1			35	5	4	12	1	1	6CH8	6	38	33	5	4	12	7	1			
6BA8	6	12	53					1	6BQ5	6	23	68					1				36	5	4	12	8	1		
6BC4	6	39	30	5	4	3	7	1	6BQ6	6	27	69					1	6CJ6	6	38	*32	5	4	7	2	1		
6BC5	6	1	74					1	6BQ7	6	8	54					1	*Normally Shows Short Position 1-6-9.			6	37	34	7	2	1	3	1
6BC7	6	38	32	5	4	12	2	1	6BR8	6	14	72					2	6CK4	6	38	30	5	4	12	2	1		
6BC8	6	8	53					1			55						1	6CL5	6	26	54					1		
6BC32	6	6	91					1	6BS8	6	8	54					2	6CL6	6	38	*32	5	4	2	9	1		
6BD5	6	37	29	7	2	12	1	1	6BT6	6	6	85					1	*Normally Shows Short Position 3-8.			6	14	69			1		
6BD6	6	1	85					1	6BT8	6	38	33	5	4	12	8	1	6CL8	6	14	51					2		
6BE6	6	1	91					1			78						1	6CM5	6	27	58					1		
6BE7	6	38	33	5	4	3	7	1	6BU6	6	6	80					2	6CM6	6	16	64					1		
									6BU8	6	21	92					1	6CM7	6	19	80					1		
									6BV8	6	38	31	5	4	12	6	1	6CM8	6	38	33	5	4	12	2	1		
											33	5	4	12	2	1	1	6CN6	6	29	*62					1		
									6BW4	6	38	50	5	4	12	1	1	*For Plate Cap Use Jack Next to Socket 26.	6CN7	6	18	94					1	
									6BW8	6	38	50	5	4	12	7	1		6CQ4	6	34	11					1	
											33	34	5	4	7	1	1	6CQ5	6	40	35	4	3	12	1	1		
											34	34	5	4	7	1	1	6CQ8	6	11	72					2		
											34	34	5	4	7	3	1	6CR6	6	40	39	4	3	12	7	1		
																					61	4	3	12	2	1		

2857326

\*Tube Good if it Reads 22 or More.

\*Normal Shorts refer to position of "D" Switch.

# B & K DYNA-QUIK MODEL 700 TUBE CHART

ManualsPlus.com

TUBE TYPE	Heater	Socket	Beam-Livity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Beam-Livity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Beam-Livity	A	B	C	D	Test Pos.
6CR8	6	38	*32 *34	5	4	12	2	1	6DX8	6	38	26 26	4	5	12	8	1	6FJ7	6	35	36 44	1	12	12	3	1
*Normally Shows Short Position 8.									6DZ7	6	37	40 40	7	2	12	1	1	6FM8	6	38	47 34 34	5	4	12	8	1
6CS6	6	1	94					1	6DZ8	6	38	27 4	4	5	2	1	1	6FQ5	6	40	33	4	3	1	2	1
6CS7	6	20	96					1	6EA5	6	1	80					1	6FQ5A	6	40	31	4	3	1	2	1
6CU5	6	4	47					1	6EA7	6	37	35 39	8	7	12	1	1	6FQ7	6	8	68 68					2
6CU6	6	27	69					1	6EA8	6	11	71					1	6FR7	6	38	24	4	5	2	3	1
6CU8	6	38	32 33	5	4	1	7	1									2									
6CW4	6	41	*87	10	12	12	2	1	6EB5	6	5	56 71					2	6F55	6	1	99					1
*For Grid Emission Turn D Switch to Position 4.									6EB8	6	12	35 99					2	6FV6	6	1	54					1
6CW5	6	23	58					1	6EH5	6	4	57					2	6FV8	6	14	65 54					1
6CW7	6	38	33 33	5	4	7	2	1	6EH7	6	38	30	5	4	3	2	1	6FW5	6	28	57					1
6CX8	6	12	45 67					1	6EH8	6	12	71					2	6FW8	6	8	30 30					1
6CY5	6	1	54					1	6EJ7	6	38	29	5	4	3	2	1	6FY5	6	40	33	4	3	1	2	1
6CY7	6	38	31 45	5	4	2	3	1	6EM5	6	16	53					2	6GB5	6	42	*25	4	5	2	*1	1
6CZ5	6	16	60					1	6EM7	6	37	32	8	7	12	1	1	*Normally Shows Short Position 3-6-7-8.								
6D2	6	5	62 62					2	6EQ7	6	38	45 34 71	8	7	12	4	1	6G6	6	29	94					1
6D4	6	40	43	4	3	12	1	1	6ER5	6	40	33	4	3	1	2	1	6GC5	6	16	26					1
6D8	6	37	43	7	2	12	5	1	6ES5	6	40	33	4	3	1	2	1	6GC6	6	26	52					1
6D10	6	35	32 32 32	1	12	12	7	1	6ES8	6	38	30	5	4	12	2	1	6GE5	6	35	*24	1	12	11	3	1
6DA4	6	34	11					1	6ET6	6	40	30	5	4	3	12	1	*Normally Shows Short Position 4-10.								
6DA6	6	38	34	5	4	1	2	1	6ET7	6	38	30 70 70	5	4	12	7	1	6GE8	6	38	33 33	5	4	12	8	1
6DB5	6	16	30					1	6EU7	6	38	35 35	2	1	12	5	1	6GF5	6	35	*24	1	12	11	3	1
6DB6	6	1	87					1	6EU8	6	38	32 32	5	4	12	7	1	*Normally Shows Short Position 4-10.								
6DC6	6	1	67					1	6EV5	6	1	52					2	6GH8	6	11	68 56					1
6DC8	6	38	33 60	5	4	12	2	1	6EV7	6	8	78 78					2	6GJ5	6	42	*30	4	5	6	2	1
6DE4	6	34	13					1	6EW6	6	1	77					2	6GJ8	6	11	70					1
6DE6	6	1	61					1	6EW7	6	20	83 92					2	6GK5	6	40	25	4	3	1	2	1
6DE7	6	20	81 90					2	6EX6	6	26	42					1	6GK6	6	38	33	5	4	3	2	1
6DG6	6	29	38					1	6EY6	6	29	65					1	6GM5	6	38	*26	4	5	2	6	1
6DJ8	6	38	31 31	5	4	12	2	1	6EZ5	6	29	65					1	*May Show Short Position 3-8.								
6DK6	6	1	61					1	6EZ8	6	38	33 33	5	4	12	7	1	6GM6	6	1	64					1
6DL5	6	3	88					1	6F5	6	37	40	7	2	1	10	1	6GM8	6	38	33 33	5	4	12	2	1
6DM4	6	34	11					1	6F6	6	29	91					1	6GN8	6	12	36 98					1
6DN6	6	26	47					1	6F8	6	37	45 45	7	2	12	5	1	6GS8	6	21	95 95					2
6DN7	6	25	56 77					2	6F10	6	30	60					1	6GT5	6	42	*30	4	5	6	2	1
6DQ4	6	34	11					1	6F31	6	1	78					1	*Normally Shows Short Position 1-7.								
6DQ5	6	26	55					1	6F33	6	1	77					1	6GV8	6	38	25	4	5	12	9	1
6DQ6	6	27	65					1	6F36	6	1	58					1	6GW6	6	27	62					1
6DQ6B	6	27	62					1	6F40	6	38	39	5	4	2	9	1	6GW8	6	38	25	4	5	2	8	1
6DR7	6	38	32 40	4	4	5	2	3	6FA7	6	38	33 65	5	4	12	3	1	6GX6	6	1	85					1
*Normally Shows Short Position 2-10.									6FD6	6	40	26	3	4	2	1	1	6GY6	6	1	82					1
6DR8	6	38	31 62 62	5	4	12	2	1	6FD7	6	38	25 32	4	5	2	3	1	6GY8	6	38	*32 *32 *94	5	4	12	1	1
6DS4	6	41	*87	10	12	12	2	1	6FE5	6	29	37					1	*Normally Shows Short Position 4.								
*For Grid Emission Turn D Switch Position 4.									6FG5	6	40	31	4	3	2	1	1	6H5	6	37	48 48	7	2	1	3	1
6DS5	6	3	76					1	6FG7	6	14	68					2	6H31	6	1	91					1
6DS8	6	38	30 34	5	4	12	2	1	6FH5	6	40	33	4	3	1	2	1	6HB6	6	38	*24	4	5	6	2	1
6DT5	6	16	45					1	6FH8	6	38	32 32	5	4	12	6	1	*Normally Shows Short Position 3-9.								
6DT6	6	1	91					1									2	6HC8	6	38	36 38	5	4	12	3	1
6DT8	6	8	71 71					2									1	6HF8	6	12	27 80					1
6DW5	6	16	30					1									2	6HG8	6	38	25	4	5	3	2	1
																										1

\*Normal Shorts refer to position of "D" Switch.

# B & K DYNA-QUIK MODEL 700 TUBE CHART

ManualsPlus.com

TUBE TYPE										TUBE TYPE										TUBE TYPE											
Heater	Socket	Beam-Unity	A	B	C	D	Test Pos.	Heater	Socket	Beam-Unity	A	B	C	D	Test Pos.	Heater	Socket	Beam-Unity	A	B	C	D	Test Pos.	Heater	Socket	Beam-Unity	A	B	C	D	Test Pos.
6HJ8	6 38	29	5	4	12	2	1	6S8	6 37	45	8	7	5	10	1	7A6	6 36	48	8	1	12	3	1								
		31	5	4	12	8	1			62	8	7	5	1	1			48	8	1	12	6	1								
6HL8	6 11	60					1			63	8	7	5	4	1	7A7	6 36	45	8	1	12	6	1								
		60					2			37	7	2	1	5	1	7A8	6 36	40	8	1	12	4	1								
6HS6	6 1	66					1	6SA7	6 37	37	7	2	1	5	1	7AD7	6 36	35	8	1	12	6	1								
6HS8	6 21	99					1	6SB7Y	6 37	34	7	2	1	5	1	7AF7	6 36	41	8	1	12	4	1								
		99					2	6SC7	6 37	48	8	7	1	3	1			41	8	1	12	4	1								
6HZ8	6 12	28					1			48	8	7	1	4	1	7AG7	6 36	32	8	1	12	6	1								
		75					2	6SD7	6 30	69					1	7AH7	6 36	32	8	1	12	6	1								
6J4	6 40	*85	4	3	1	7	1	6SF5	6 37	41	8	7	1	3	1	7AK7	6 36	33	8	1	12	6	1								
	*Normally Shows Short Position 5-6.								6SF7	6 37	46	8	7	1	2	1	7AN7	7 38	33	5	4	7	2	1							
6J5	6 29	93					1			69	8	7	1	5	1			33	5	4	7	6	1								
6J6	6 2	60					1	6SG7	6 30	77					1	7AU7	7 8	75					1								
		60					2	6SH7	6 30	77					1			75					2								
6J7	6 37	50	7	2	1	10	1	6SI7	6 30	83					1	7B4	6 36	40	8	1	12	6	1								
6J11	6 35	22	1	12	12	5	1	6SK7	6 30	84					1	7B5	6 36	52	8	1	12	6	1								
		22	1	12	12	11	1	6SL7	6 25	*85					2	7B6	6 36	40	8	1	4	3	1								
6JC8	6 38	24	4	5	1	2	1			*85					1			68	8	1	4	5	1								
		24	4	5	1	8	1		*Tube Good if it Reads 22 or More.										68	8	1	4	6	1							
6JE8	6 12	56					1	6SN7	6 25	78					1	7B7	6 36	45	8	1	12	6	1								
		78					2			78					2	7B8	6 36	42	8	1	12	4	1								
6JH8	6 38	26	4	5	12	6	1	6SQ7	6 37	42	8	7	1	2	1	7C4	6 36	53	8	1	12	4	1								
6JK8	6 8	54					1			71	8	7	1	4	1	7C5	6 36	38	8	1	12	6	1								
		55					2	6SR7	6 37	46	8	7	1	2	1	7C6	6 36	50	8	1	4	3	1								
6JU8	6 38	*32	4	5	2	1	1			71	8	7	1	5	1			68	8	1	4	5	1								
		**32	4	5	8	7	1			68	8	7	1	4	1			68	8	1	4	6	1								
	*Normally Shows Short Position 8.								6SS7	6 37	46	7	2	1	4	1	7C7	6 36	37	8	1	12	6	1							
	**Normally Shows Short Position 2.								6ST7	6 37	52	8	7	1	2	1	7DJ8	7 38	31	5	4	12	2	1							
6K6	6 29	92					1			72	8	7	1	4	1			31	5	4	12	7	1								
6K7	6 37	52	7	2	1	10	1	6SU7	6 37	72	8	7	1	5	1	7E5	6 36	*33	8	2	1	5	1								
6K8	6 37	35	7	2	1	5	1			43	8	7	12	1	1		*Normally Shows Short Position 3-4-6-7.														
6K11	6 35	38	1	12	12	9	1	6SZ7	6 37	44	8	7	1	2	1	7E6	6 36	40	8	1	4	3	1								
		38	1	12	12	7	1			43	8	7	12	4	1			69	8	1	4	5	1								
		38	1	12	12	11	1	6T4	6 40	*33	4	3	2	6	1	7E7	6 35	47	8	1	12	6	1								
6L5	6 37	53	7	2	6	5	1	6T8	6 17	90					1			68	8	1	12	3	1								
6L6	6 28	63					1			63					2	7ES8	7 38	30	5	4	12	2	1								
6L7	6 37	44	7	2	1	10	1	6U4	6 34	11					1	7EY6	7 29	65					1								
6L10	6 30	38					1	6U6	6 29	54					1	7F7	6 36	45	8	1	12	4	1								
6L12	6 8	70					1	6U7	6 37	35	7	2	12	10	1	7F8	6 36	30	7	2	12	1	1								
		70					2	6U8	6 11	79					1	7G7	6 36	36	8	1	12	6	1								
6L41	6 38	33	5	4	8	9	1	6V3	6 15	10					1	7H7	6 36	35	8	1	12	6	1								
6L43	6 38	*32	5	4	2	9	1	6V4	6 38	40	5	4	12	1	1	7HG8	7 38	25	4	5	3	2	1								
	*Normally Shows Short Position 3-8.								6V6	6 29	79					1	7J7	6 36	35	8	1	12	6	1							
6LD12	6 16	90					1	6V8	6 38	40	5	4	12	6	1	7K7	6 36	45	8	1	12	4	1								
		63					2			32	5	4	12	2	1			65	8	1	12	5	1								
6N7	6 37	47	7	2	1	4	1	6W4	6 34	11					1	7L7	6 36	36	8	1	12	6	1								
		47	7	2	1	5	1	6W6	6 29	51					1	7N7	6 36	42	8	1	12	4	1								
6N8	6 38	37	5	4	12	2	1	6W7	6 37	50	7	2	12	10	1			42	8	1	12	5	1								
		64	5	4	12	7	1	6X4	6 40	44	4	3	12	1	1	7Q7	6 36	35	8	1	12	4	1								
		64	5	4	12	8	1	6X5	6 33	15					1	7R7	6 36	35	8	1	12	6	1								
6NK7GT	6 30	84					1			15					2			72	8	1	12	3	1								
6P5	6 29	93					1	6X6	6 37	48	7	2	12	3	1	7S7	6 36	38	8	1	12	6	1								
6P15	6 23	68					1	6X8	6 12	73					1			52	8	1	12	4	1								
6Q7	6 37	40	7	2	1	10	1	6Y6	6 29	40					1	7V7	6 36	32	8	1	12	6	1								
		63	7	2	1	4	1	6Z31	6 40	44	4	3	12	1	1	7W7	6 36	31	8	1	4	6	1								
		63	7	2	1	5	1			44	4	3	12	6	1	7X6	6 36	35	8	1	12	3	1								
6Q11	6 35	38	1	12	12	7	1	6ZY5	6 33	17					1			35	8	1	12	6	1								
		38	1	12	12	9	1	7A4	6 36	41	8	1	12	6	1	7X7	6 36	43	8	1	12	3	1								
		38	1	12	12	11	1	7A5	6 36	34	8	1	12	6	1			36	8	1	12	5	1								
6R3	6 38	33	5	4	2	9	1								1			35	8	1	12	6	1								
6R4	6 38	30	4	5	12	1	1								1								1								
6R7	6 37	52	7	2	1	10	1								1								1								
		63	7	2	1	4	1								1								1								
		63	7	2	1	5	1								1								1								
6R8	6 17	86					1								1								1								
		62					2								1								1								
6S2	6 24	35					1								1								1								
6S4	6 16	58					1								1								1								
6S7	6 37	47	7	2	1	10	1								1								1								

# B & K DYNA-QUIK MODEL 700 TUBE CHART

ManualsPlus.com

TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.
7Y4	6	36	45	8	1	12	3	1	9BR8	9	14	72					1	12AL5	12	5	62					1
			45	8	1	12	6	1				55					2				62					2
7Z4	6	36	50	8	1	12	3	1	9CL8	9	14	69					1	12AL8	12	38	34	5	4	12	3	1
			50	8	1	12	6	1				51					2				52					1
8A8	9	11	66					1	9J6	9	2	60					1	12AQ5	12	3	77					1
8AU8	8	12	56					1				60					2	12AS5	12	4	55					1
			72					2	9U8	9	11	79					1	12AT6	12	6	85					1
8AW8	8	12	44					1				55					2	12AT7	12	8	74					2
			78					2	9X8	9	12	73					1				74					1
8B8	8	38	33	4	5	12	3	1				61					2	12AU5	12	28	71					1
			39	4	5	12	1	1	10BQ5	10	23	68					1	12AU6	12	1	82					1
8BA8	8	12	53					1	10C8	10	13	59					1	12AU7	12	8	75					1
			59					2	10D2	19	5	62					1				75					2
8BH8	8	12	59					1				62					2	12AU8	12	12	56					1
			54					2	10DE7	10	20	81					1				72					2
8BN8	8	38	35	5	4	12	8	1				90					2	12AV5	12	28	62					1
			35	5	4	12	1	1	10DR7	10	38	32	5	4	2	3	1	12AV6	12	6	91					1
8BQ5	8	23	68					1				41	5	4	2	7	1				78					2
8BQ7	8	8	54					1	10/E/312	25	29	47					1	12AV7	12	8	55					1
			54					2	10/E/349	6	29	79					1				55					2
8CG7	8	8	76					1	10/E/558	6	37	52	7	2	12	10	1	12AW6	12	1	78					1
			76					2	10/E/11448	6	29	93					1	12AW8	12	12	44					1
8CH8	8	38	33	5	4	12	7	1	10/E/11533	6	29	63					1				78					2
			36	5	4	12	8	1	10/E/11581	6	37	40	7	2	12	10	1	12AX3	12	35	30	1	12	10	4	1
8CM7	8	19	80					1	10EB8	10	12	35					1	12AX4	12	34	13					1
			94					2				99					2	12AX7	12	8	*85					2
8CN7	8	18	94					1	10EG7	10	37	32	8	7	12	1	1				*85					2
			60					2	10EM7	10	37	32	8	7	12	4	1									1
8CS7	8	20	96					1	10EW7	10	20	83					1	12AY3	12	42	27	5	4	7	2	1
			95					2				92					2	12AY7	12	8	93					1
8CU8	8	38	32	5	4	1	7	1	10FD7	10	38	25	4	5	2	3	1	12AZ7	12	8	73					2
			33	5	4	6	8	1				32	4	5	2	7	1				73					1
8CW5	8	23	58					1	10FR7	10	38	24	4	5	2	3	1	12B4	12	39	35	5	4	3	7	1
8CX8	8	12	45					1	10GN8	10	12	36	4	5	2	7	1	12B7	12	36	45	8	1	12	6	1
			67					2				32	4	5	2	7	1	12BA6	12	1	78					1
8CY7	8	38	31	5	4	2	3	1	10HF8	10	12	27					1	12BA7	12	38	33	5	4	12	2	1
			45	5	4	2	7	1				80					2	12BC32	12	6	91					1
8DE7	8	20	81					1	11C5	12	4	54					1				78					2
			90					2	11CY7	12	38	31	5	4	2	3	1	12BD6	12	1	85					1
8DX8	8	38	26	4	5	12	8	1				45	5	4	2	7	1	12BE6	12	1	91					1
			26	4	5	12	1	1	11EB	10	12	56					1	12BF6	12	6	85					1
8EB8	8	12	35					1				78					2				80					2
			99					2	1244	12	39	32	5	4	3	7	1	12BH7	12	8	56					1
8EM5	8	16	53					1	12A6	12	29	92					1				56					2
8ET7	8	38	30	5	4	12	7	1	12A8	12	37	45	7	2	12	5	1	12BK5	12	10	53					1
			70	5	4	12	2	1	12AB5	12	16	67					1	12BK6	12	6	86					1
			70	5	4	12	3	1	12AC6	12	40	42	4	3	12	1	1	12BL6	12	40	35	4	3	12	1	1
8FQ7	8	8	68					1	12AD6	12	40	35	4	3	12	1	1				70					2
			68					2	12AD7	12	8	85					1	12BN6	12	7	75					1
8GN8	8	12	36					1	12AE6	12	40	52	4	3	12	1	1	12BQ6	12	27	69					1
			98					2				66	4	3	12	5	1	12BR7	12	38	32	5	4	9	2	1
8HG8	8	38	25	4	5	3	2	1	12AE7	12	38	32	5	4	9	2	1				36					1
			25	4	5	1	6	1	12AF3	12	15	12					1				36					1
8JE8	8	12	56					1	12AF6	12	40	37	4	3	12	1	1	12B76	12	6	85					1
			78					2	12AG6	12	40	35	4	3	12	1	1	12BU6	12	6	85					1
8JK8	8	8	54					1	12AH7	12	37	48	8	7	12	1	1				80					2
			55					2	12AJ6	12	40	40	4	3	12	1	1	12BV7	12	9	39					1
8SN7	8	25	78					1				66	4	3	12	5	1	12BW4	12	38	50					1
			78					2	12AJ7	12	38	32	5	4	12	2	1				50					1
9A8	9	11	66					1				35	5	4	12	9	1	12EX6	12	38	33	5	4	1	2	1
			55					2				66	4	3	12	5	1	12EX7	12	25	55					1
9AK3	9	16	90					1				66	4	3	12	6	1				55					2
			63					2				66	4	3	12	6	1	12BY7	12	9	42					1
9AQ8	9	8	70					1				35	5	4	12	9	1	12BZ6	12	1	61					1
			70					2				66	4	3	12	6	1	12BZ7	12	8	95					1
9AU7	9	8	75					1				66	4	3	12	6	1				95					2
			75					2				35	5	4	12	9	1	12C5	12	4	44					1
9BR7	9	38	32	5	4	9	2	1				35	5	4	12	9	1									1
			37	5	4	9	6	1																		1
			37	5	4	9	7	1																		1

\*Tube Good if it Reads 22 or More.

\*Normal Shorts refer to position of "D" Switch.

# B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE										TUBE TYPE										TUBE TYPE									
Heater	Socket	Genl. Utility	A	B	C	D	Test Pos.	Heater	Socket	Genl. Utility	A	B	C	D	Test Pos.	Heater	Socket	Genl. Utility	A	B	C	D	Test Pos.						
12C8	12 37	55	7	2	12	10	1	12E5	12 25	93					1	12S8	12 37	45	8	7	5	10	1						
		65	7	2	12	4	1	12EA6	12 40	32	4	3	12	1	1			62	8	7	5	1	1						
12C8Y	12 37	65	7	2	12	5	1	12EC8	12 38	30	5	4	12	9	1			62	8	7	5	4	1						
		65	7	2	12	10	1			32	5	4	12	1	1			63	8	7	2	3	1						
		65	7	2	12	4	1	12ED5	12 4	57					1	12SA7	12 37	37	7	2	12	5	1						
		65	7	2	12	5	1	12EG6	12 40	36	4	3	12	1	1	12SC7	12 37	48	8	7	12	3	1						
12CA5	12 4	55					1	12EH5	12 4	57				1	1			48	8	7	12	4	1						
12CM6	12 16	64					1	12EK6	12 40	31	4	3	12	1	1	12SF5	12 37	41	8	7	12	3	1						
12CN5	12 40	33	4	3	2	5	1	12EL6	12 40	38	4	3	12	1	1	12SF7	12 37	46	8	7	12	2	1						
12CR6	12 40	39	4	3	12	7	1			68	4	3	12	5	1			69	8	7	12	5	1						
		61	4	3	12	2	1	12EM6	12 38	68	4	3	12	6	1	12SG7	12 30	77					1						
12CS6	12 1	94					1			34	5	4	12	1	1	12SH7	12 30	77					1						
12CT8	12 13	57					1	12EN6	12 29	90	5	4	12	9	1	12SJ7	12 30	83					1						
		63					2	12EQ7	12 38	36	5	4	12	2	1	12SK7	12 30	84					1						
12CU5	12 4	47					1			34	5	4	12	2	1	12SL7	12 25	*85					1						
12CUG	12 27	69					1	12EZ6	12 40	71	5	4	12	8	1			*85					2						
12CX6	12 40	30	4	3	12	1	1	12F5	12 37	42	4	3	12	1	1	*Tube Good if it Reads 22 or More.													
12D4	12 34	11					1	12F8	12 38	30	7	2	12	10	1	12SN7	12 25	78					1						
12DB5	12 16	30					1			40	5	4	12	8	1			78					2						
12DE8	12 38	36	5	4	12	1	1	12F31	12 1	62	5	4	12	1	1	12SQ7	12 37	42	8	7	12	2	1						
		34	5	4	12	3	1	12FK6	12 40	78	5	4	12	6	1			71	8	7	12	4	1						
12DF5	12 38	52	5	4	9	1	1			65	4	3	12	5	1	12SR7	12 37	71	8	7	12	5	1						
12DF7	12 8	*85	5	4	9	6	1			65	4	3	12	6	1			46	8	7	12	2	1						
		*85					2	12FM6	12 40	62	4	3	12	1	1			68	8	7	12	4	1						
*Tube Good if it Reads 22 or More.										12F8	12 38	40	5	4	12	8	1	12SS7	12 30	97					1				
12DJ8	12 38	31	5	4	12	2	1			68	4	3	12	5	1	12SW7	12 37	52	8	7	12	2	1						
		31	5	4	12	7	1	12FQ8	12 38	68	4	3	12	6	1			70	8	7	12	4	1						
12DK7	12 38	33	5	4	8	1	1			39	5	4	12	2	1	12SX7	12 25	78					1						
		80	5	4	8	6	1	12FR8	12 38	39	5	4	12	7	1			78					2						
		80	5	4	8	9	1			*25	4	5	12	3	1	12SY7	12 37	39	7	2	12	5	1						
12DL8	12 38	35	5	4	12	3	1			*37	4	5	12	1	1	12U7	12 38	40	5	4	9	2	1						
		65	5	4	12	9	1			*62	4	5	12	8	1			40	5	4	9	7	1						
		65	5	4	12	1	1	*Normally Shows Short on Position No. 5.										12V6	12 29	79					1				
12DM4	12 34	11					1	12FT6	12 40	52	4	3	12	1	1	12W6	12 29	51					1						
12DN6	12 26	47					1			66	4	3	12	5	1	12X4	12 40	44	4	3	12	1	1						
12DQ4	12 34	11					1	12FV7	12 8	66	4	3	12	6	1			44	4	3	12	6	1						
12DQ6	12 27	65					1			42				1	1	13CM5	12 27	57					1						
12DQ6B	12 27	62					1	12FX8	12 38	42				2	1	13D1	25 25	78					1						
12DQ7	12 9	36					1			28	5	4	12	6	1			78					2						
12DS7	12 38	34	5	4	12	3	1	12G4	12 40	41	4	3	1	6	1	13DE7	12 20	81					1						
		85	5	4	12	1	1	12GA6	12 40	36	4	3	12	1	1			90					2						
		85	5	4	12	9	1	12GC6	12 26	52				1	1	13DR7	12 38	32	5	4	2	3	1						
12DT5	12 16	45					1	12GE5	12 35	*24	1	12	11	3	1			41	5	4	2	7	1						
12DT7	12 8	*85					2	*Normally Shows Short Positions 4-10.										13EM7	12 37	32	8	7	12	1	1				
		*85					2	12GJ5	12 42	*30	4	5	6	2	1			45	8	7	12	4	1						
*Tube Good if it Reads 22 or More.										12GT5	12 42	*30	4	5	6	2	1	13FD7	12 38	25	4	5	2	3	1				
12DT8	12 8	71					1	12GW6	12 27	62				1	1			32	4	5	2	7	1						
		71					2	12H4	12 40	44	4	3	2	6	1	13S7	12 30	83					1						
12DU7	12 38	31	5	4	12	1	1	12H6	12 37	48	7	2	12	3	1	14A4	12 36	41	8	1	12	6	1						
		77	5	4	12	7	1			48	7	2	12	5	1	14A5	12 36	34	8	1	12	6	1						
12DV7	12 38	49	5	4	9	7	1	12H31	12 1	91				1	1	14A7	12 36	45	8	1	12	6	1						
		78	5	4	9	2	1	12J5	12 29	93				1	1	14AF7	12 36	41	8	1	12	4	1						
		78	5	4	9	3	1	12J7	12 37	50	7	2	12	10	1			41	8	1	12	5	1						
12DV8	12 38	35	5	4	12	3	1	12J8	12 38	30	5	4	12	1	1	14B6	12 36	40	8	1	4	3	1						
		58	5	4	12	9	1			35	5	4	12	8	1			68	8	1	4	5	1						
		58	5	4	12	1	1			35	5	4	12	9	1			68	8	1	4	6	1						
12DW5	12 16	30					1	12K5	12 40	35	4	3	5	6	1	14B8	12 36	42	8	1	12	4	1						
12DW7	12 8	75					1	12K7	12 37	52	7	2	12	10	1	14C5	12 36	38	8	1	12	6	1						
		*78					2	12K8	12 37	35	7	2	12	5	1	14C7	12 36	37	8	1	12	6	1						
*Tube Good if it Reads 22 or More.										12L6	12 29	47				1	1	14E6	12 36	40	8	1	4	3	1				
12DW8	12 38	32	5	4	12	2	1	12Q7	12 37	40	7	2	12	10	1			69	8	1	4	5	1						
		32	5	4	12	7	1			63	7	2	12	4	1			69	8	1	4	6	1						
		44	5	4	12	9	1	12R5	12 40	39	4	3	2	5	1	14E7	12 36	47	8	1	12	6	1						
12DY8	12 38	30	5	4	12	1	1			63	7	2	12	5	1			68	8	1	12	3	1						
		35	5	4	12	9	1			63	7	2	12	5	1			68	8	1	12	4	1						
12DZ6	12 40	33	4	3	12	1	1			39	4	3	2	5	1			68	8	1	12	4	1						
12DZ8	12 38	27	4	5	8	3	1											68	8	1	12	4	1						
		30	4	5	2	1	1																						

\*Normal Shorts refer to position of "D" Switch.

12C8-14E7

# B & K DYNA-QUIK MODEL 700 TUBE CHART

ManualsPlus.com

TUBE TYPE	Heater				A	B	C	D	Test Pos.	TUBE TYPE	Heater				A	B	C	D	Test Pos.	TUBE TYPE	Heater				A	B	C	D	Test Pos.		
	Heater	Socket	Pin	Life							Heater	Socket	Pin	Life							Heater	Socket	Pin	Life						Heater	Socket
14F7	12	36	45	8	1	12	4	1	17G6	17	27	62						1	21A6	22	38	*32	5	4	7	2	1				
			45	8	1	12	5	1	17H3	17	15	13						1	*Normally Shows Short Position 1-6-9.												
14F8	12	36	30	7	2	12	1	1	17HC8	17	38	36	5	4	12	3	1	1	21EX6	22	26	42						1			
			30	7	2	12	8	1				38	5	4	12	1	1	1	22BH3	22	42	27	5	4	7	2	1				
14GT8	14	38	52	5	4	12	8	1	17JK8	17	8	54						1	22DE4	22	34	13	*				1				
			35	5	4	12	2	1				55						2	25A6	25	29	74					1				
14GW8	14	38	25	4	5	2	8	1	17L6	17	29	47						1	25AU4	25	34	10					1				
			35	4	5	7	1	1	17R5	17	4	50						1	25AV5	25	28	62					1				
14H7	12	36	35	4	5	7	1	1	17W6	17	29	52						1	25AX4	25	34	13					1				
14J7	12	36	35	8	1	12	6	1	17Z3	17	38	33	4	5	2	9	1	1	25B6	25	29	48					1				
			50	8	1	12	4	1	18A5	18	28	69						1	25BK5	25	10	53					1				
14JG8	14	38	32	4	5	12	8	1	18AK5	18	1	63						1	25BQ6	25	27	69					1				
			27	4	5	12	2	1	18AQ5	18	3	77						1	25C5	25	4	44					1				
			27	4	5	12	6	1	18C51	18	38	29	9	1	12	3	1	1	25C6	25	29	45					1				
14N7	12	36	42	8	1	12	4	1				29	9	1	12	7	1	1	25CA5	25	4	55					1				
			42	8	1	12	5	1	18DZ8	18	38	27	4	5	8	3	1	1	25CD6	25	26	53					1				
14Q7	12	36	35	8	1	12	4	1				4	4	5	2	1	1	1	25CU6	25	27	69					1				
14R7	12	36	35	8	1	12	6	1	18FW6	18	1	79						1	25D4	25	34	11					1				
			72	8	1	12	3	1	18FX6	18	1	92						1	25DX4	25	40	26	3	4	6	5	1				
			72	8	1	12	4	1	18FY6	18	6	84						1	25DN6	25	26	47					1				
14S7	12	36	38	8	1	12	6	1				81						2	25DQ6	25	27	65					1				
			52	8	1	12	4	1	18GD6	19	1	80						1	25DT5	25	16	45					1				
14V7	12	36	32	8	1	12	6	1	18GE6	19	6	78						1	25E5	25	27	58					1				
14W7	12	36	31	8	1	4	6	1				85						2	25EC6	25	26	53					1				
14X7	12	36	43	8	1	12	3	1	18GV8	18	38	25	4	5	12	9	1	1	25EH5	25	4	57					1				
			36	8	1	12	5	1				25	4	5	12	2	1	1	25F5	25	4	54					1				
			35	8	1	12	6	1	18HB8	18	38	36	5	4	12	9	1	1	25L6	25	29	47					1				
14Y4	12	36	45	8	1	12	3	1				33	5	4	12	1	1	1	25SN7	25	25	78					1				
			45	8	1	12	6	1	18J6	12	2	60						1	25U4	25	34	11					1				
												60						2	25W4	25	34	11					1				
15A6	12	38	30	5	4	12	2	1	19AQ5	19	3	77						1	25W6	25	29	51					1				
15A8	15	37	36	7	2	12	4	1	19AU4	19	34	10						1	25Z6	25	37	34	7	2	12	3	1				
			40	7	2	12	3	1	19BG6	19	26	66						1				34	7	2	12	5	1				
15CW5	15	23	58						19C8	19	17	94						1	26A6	25	1	77					1				
15EA7	15	37	35	8	7	12	1	1				62						2	26A7	25	37	29	7	6	12	1	1				
			39	8	7	12	4	1	19CL8-A	19	14	74						1				29	7	6	12	3	1				
15EW6	15	1	77									53						2	26B6	25	6	86					1				
16A8	16	38	33	5	4	12	3	1	19D8	19	38	32	5	4	12	2	1	1	26C6	25	6	85					1				
16AQ3	16	39	30	5	4	7	3	1	19DE7	19	20	81						1				82					1				
16CL8	16	14	69									90						2	26D6	25	1	93					1				
			51						19EA8	19	11	71						1	26E6	25	29	40					1				
16GK6	16	38	33	5	4	3	2	1				56						2	27GB5	25	42	*25	4	5	2	1	1				
17AV5	17	28	62						19DN6	19	26	47						1	*Normally Shows Short Position 3-6-7-8.												
17AX4	17	34	13						19EZ8	19	38	33	5	4	12	2	1	1	28D7	30	36	40	8	1	12	2	1				
17AY3	17	42	27	5	4	7	2	1				33	5	4	12	7	1	1				40	8	1	12	7	1				
17BH3	17	42	27	5	4	7	2	1				33	5	4	12	9	1	1	28GB5	30	42	*25	4	5	2	1	1				
17BQ6	17	27	69						19HS6	19	1	66						1	*Normally Shows Short Position 3-6-7-8.												
17C5	17	4	44						19HV8	19	14	64						1	30C1	9	11	66					1				
17C8	17	38	33	5	4	12	2	1				*99						2	30L1	7	38	33	5	4	7	2	1				
			65	5	4	12	7	1	*Tube Good if it Reads 40 or More.																						
17C9	17	38	28	5	4	6	1	1	19J6	19	2	60						1	32ET5	30	4	60					1				
			28	5	4	10	7	1				60						2	34GD5	35	4	57					1				
17CA5	17	4	55						19JN8	19	14	67						1	35A5	35	36	34	8	1	12	6	1				
												53						2	35B5	35	3	55					1				
17CQ4	17	34	11						19T8	19	17	90						1	35C5	35	4	54					1				
17CU5	17	4	47									63						2	35CD6	35	26	53					1				
17D4	17	34	11						19V8	19	38	40	5	4	12	6	1	1	35DZ8	35	38	27	4	5	8	3	1				
17DE4	17	34	13									32	5	4	12	2	1	1				30	4	5	2	1					
17DM4	17	34	11									32	5	4	12	7	1	1													
17DQ4	17	34	11									61	5	4	12	9	1	1	35EH5	35	4	57					1				
17DQ6	17	27	65						19X3	19	38	29	5	4	12	9	1	1	35GL6	35	40	39</									

# B & K DYNA-QUIK MODEL 700 TUBE CHART

TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	O	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	O	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	O	D	Test Pos.						
35Z5	35	37	33	7	2	3	5	1	1665	6	40	32	4	3	5	1	1	6066	6	6	85					1						
36AM3	35	40	35	4	3	6	5	1	1667	6	40	32	4	3	5	1	1				78					2						
38A3	35	39	30	4	5	1	6	1	1852	6	30	60					1	6067	12	8	75					1						
40FR5	40	4	54					1	1853	6	30	74					1				75					2						
40Z5	50	37	31	7	2	3	5	1	2050	6	37	34	7	2	12	5	1	6069	6	1	63					1						
45B5	50	23	68					1	5591	6	1	63					1	6072	12	8	93					1						
45Z3	50	40	32	7	1	6	2	1	5649	12	29	92					1				93					2						
45Z5	50	37	31	7	2	3	5	1	5654	6	1	63					1	6080	6	37	35	8	7	12	1	1						
50A5	50	36	35	8	1	12	6	1	5659	12	29	92					1				35	8	7	12	4	1						
50B5	50	3	38					1	5661	12	30	84					1	6082	25	37	35	8	7	12	1	1						
50BK5	50	10	53					1	5663	6	40	25	3	4	12	1	1				35	8	7	12	4	1						
50BM8	50	38	33	5	4	12	3	1	5670	6	38	29	9	1	12	3	1	6085	12	8	74					1						
			39	5	4	12	1	1				29	9	1	12	7	1				74					2						
50C5	50	4	44					1	5679	6	36	48	8	1	12	3	1	6087	5	33	23					1						
50C6	50	29	45					1				48	8	1	12	6	1				23					2						
50CA5	50	4	55					1	5686	6	23	87					1	6096	6	1	63					1						
50CD6	50	26	53					1	5687	12	38	37	5	4	8	2	1	6097	6	5	62					1						
50DC4	50	40	33	4	3	6	5	1				37	5	4	8	7	1				62					2						
50EH5	50	4	57					1	5691	6	25	*85					1	6100	6	40	41	4	3	1	6	1						
50FA5	50	4	54					1				*85					2	6101	6	2	60					1						
50FE5	50	29	37					1	*Tube Good if it Reads 22 or More.													6113	6	25	*85					2		
50FK5	50	4	88					1	5692	6	25	78					1				*85						1					
50HC6	50	40	26	3	4	6	2	1	5693	6	30	83					2	*Tube Good if it Reads 22 or More.														2
50HK6	50	40	27	3	4	6	2	1	5696	6	40	34	4	3	5	6	1	6134	6	30	60						1					
50HL6	50	29	47					1	5725	6	1	77					1	6135	6	40	41	4	3	1	6	1						
50X6	50	36	35	8	1	12	3	1	5726	6	5	62					1	6136	6	1	82					1						
			35	8	1	12	6	1				62					2	6137	6	30	84					1						
50Y6	50	37	35	7	2	12	3	1	5727	6	40	32	4	3	5	1	1	6146	6	37	*38	7	2	1	5	1						
			35	7	2	12	5	1	5749	6	1	78					1	*Normally Shows Short Position 4-6.														
50Y7	50	37	35	7	2	6	3	1	5750	6	1	91					1	6147	6	29	63					1						
			35	7	2	6	5	1	5751	12	8	*85					1	6159	25	37	*38	7	2	1	5	1						
53KU	5	33	10					2				*85					2	*Normally Shows Short Position 4-6.														
60EH5	50	4	57					1	*Tube Good if it Reads 22 or More.													6180	6	25	78					1		
60FX5	50	4	68					1	5763	6	38	33	5	4	8	9	1				78						2					
64SPT	6	38	33	5	4	1	2	1	5814-A	12	8	75					1	6186	6	1	80					1						
150G3	50	37	*99	2	11	3	5	1				75					2	6187	6	1	87					1						
								1	5824	25	29	48					1	6188	6	25	*81					1						
								1	5871	6	29	79					1	*Tube Good if it Reads 22 or More.														2
								1	5879	6	38	52	5	4	12	1	1	6189	12	8	75					1						
213PEN	19	38	*32	5	4	7	2	1	5881	6	29	63					1	6197	6	38	32	5	4	2	9	1						
								1	5915	6	1	92					1	6198	12	8	75					1						
								1	5920	6	2	49					2				75					2						
403B	6	1	63					1	5931	5	33	16					1	6201	12	8	74					1						
407A	40	38	29	1	9	5	3	1				16					2				74					2						
			29	1	9	5	7	1	5932	6	29	63					1	6202	6	40	44	4	3	12	1	1						
408A	19	1	65					1	5961	6	37	37	7	2	12	5	1				44	4	3	12	6	1						
884	6	37	35	2	7	12	5	1	5963	12	8	76					1	6211	12	8	54					1						
1003	6	31	8					2				76					2				54					1						
1201	6	36	*33	8	2	1	5	1	5964	6	2	67					1	6227	6	38	25	4	5	1	2	1						
								1				67					2	6265	6	1	89					1						
								1	5965	12	8	54					1	6267	6	38	40	5	4	2	9	1						
								1	5992	6	29	79					1	6336	6	37	29	8	7	12	1	1						
								1	6005	6	3	77					1				29	8	7	12	4	1						
								1	6006	6	30	77					1	6350	12	38	31	4	5	9	3	1						
								1	6028	19	1	63					1				31	4	5	9	8	1						
								1	6042	6	25	78					1	6360	12	38	30	4	5	9	1	1						
								2				78					2				30	4	5	9	3	1						
1611	6	29	91					1	6046	25	29	47					1	6384	6	37	33	8	6	12	7	1						
1614	6	29	67					1	6057	12	8	*85					1	6417	12	38	33	5	4	8	9	1						
1619	3	37	39	7	2	12	5	1				*85					2	6463	12	38	28	4	5	9	3	1						
1620	6	37	50	7	2	12	10	1	*Tube Good if it Reads 22 or More.															28	4	5	9	8	1			
1621	6	29	91					1	6058	6	5	62					1	6485	6	1	58					1						
1622	6	29	63					1				62					2	6516	6	40	34	4	3	12	1	1						
1631	6	29	63					1	6060	12	8	74					1	6520	6	37	35	8	7	12	1	1						
1632	12	29	47					1				74					2				35	8	7	12	4	1						
1634	12	37	48	8	7	12	3	1	6062	6	38	33	5	4	8	9	1	6550	6	29	52					1						
			48	8	7	12	4	1										6660	6	1	78					1						

\*Normal Shorts refer to position of "D" Switch.

# B & K DYNA-QUIK MODEL 700 TUBE CHART

ManualsPlus.com

TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.
6661	6	1	89					1	7308	6	8	23					1	ARP33	6	29	79					1
6662	6	1	81					1				24					2	ARTH-1	6	37	35	7	2	12	5	1
6663	6	5	62					1	7355	6	37	37	7	2	12	6	1	AU13	5	33	32					1
6664	6	40	30	4	3	12	6	1	7370	40	38	24	4	5	8	2	1				32					2
6669	6	3	77					1				24	4	5	8	7	1	AZ32	4	33	32					1
6676	6	1	64					1	7408	6	29	80					1				32					2
6677	6	38	*32	5	4	2	9	1	7543	6	1	85					1	B36	12	25	78					1
6678	6	11	79					1	7558	6	38	*26	4	5	3	2	1	B65	6	25	78					1
6679	12	8	55					2	7581	6	29	64					1				78					2
6680	12	8	79					2	7586	6	41	*65	10	12	12	2	1	B152	12	8	74					1
6681	12	8	*85					1	*For Grid Emission Turn D Switch to Position 4.												74					2
6686	6	38	24	4	5	1	2	1	7587	6	41	*67	10	12	12	2	1	B309	12	8	74					1
6688	6	38	25	4	5	1	2	1	*For Grid Emission Turn D Switch to Position 4.												74					2
6829	12	8	54					1	7591	6	37	34	7	2	4	6	1	B319	7	38	33	5	4	7	2	1
6883	12	37	*38	7	2	1	5	1	7607	6	37	*32	7	2	1	5	1				33	5	4	7	6	1
6887	6	40	33	4	3	12	2	1	*Normally Shows Short Position 4-6.									B329	12	8	75					1
6919	6	5	62					1	7643	6	11	72					1				75					2
6922	6	8	24					1	7687	6	11	77					1	B339	12	8	*85					1
6968	6	1	63					1	7695	50	38	34	5	4	12	6	1				*85					2
6973	6	16	62					1	7701	12	38	*38	5	4	1	2	1				*85					2
7000	6	37	50	7	2	12	10	1	7716	12	12	53					1				*85					2
7025	12	8	*85					1	*Normally Shows Short Position 3-7-8-9.									B719	6	8	70					1
7027	6	37	*36	7	2	5	6	1	7724	14	38	*97					2				70					2
7036	6	1	92					1	*Tube Good if it Reads 20 or More.									BPM04	6	3	77					1
7044	12	38	30	4	5	8	2	1	7728	12	8	74					1	CV131	6	40	35	4	3	12	1	1
7054	12	9	42					1	7729	12	8	74					2	CV133	6	40	41	4	3	1	6	1
7055	12	5	62					2	7730	12	8	75					1	CV136	6	40	34	4	3	12	1	1
7056	12	1	64					1	7731	6	11	79					1	CV138	6	40	30	4	3	12	1	1
7057	12	8	53					1	7732	6	1	64					1	CV140	6	5	62					1
7058	12	8	*85					2	7733	12	9	42					1	CV216	50	37	*99	2	11	3	5	1
7059	12	11	79					1	7738	6	40	*33	4	3	2	6	1	*Normally Shows Short Position No. 11.								
7105	12	37	35	8	7	12	1	1	*Normally Shows Short Position 1-7.									*Normally Shows Grid Emission.								
7167	12	1	54					1	7895	6	41	*85	10	12	12	2	1	*Tube Good if it Reads 60 or More.								
7189	6	38	*33	5	4	1	2	1	*For Grid Emission Turn D Switch to Position 4.									CV283	6	5	62					1
7199	6	38	30	5	4	12	7	1	8016	1	32	55					1	CV450	6	29	*62					2
7233	6	38	*33	5	4	2	7	1	8056	6	41	23	10	12	12	4	1	*For Plate Cap Use Jack Next to Socket 26.								
7247	12	8	75					1	9001	6	1	93					1	CV452	6	6	85					1
7258	12	13	62					1	9002	6	40	*46	4	3	1	6	1				78					2
			61					2	9003	6	1	*73					1	CV453	6	1	91					1
									*Tube Good if it Reads 23 or More.									CV454	6	1	78					1
									9006	6	40	*55	4	3	1	5	1	CV455	12	8	74					1
									*Normally Shows Short Position 2-7.									CV491	12	8	75					1
									A863	6	37	50	7	2	12	10	1				75					2
									A1834	6	37	35	8	7	12	1	1	CV492	12	8	*85					1
									AR18	6	37	40	7	2	12	10	1	*Tube Good if it Reads 22 or More.								
									ARDD3	6	37	48	7	2	12	5	1	CV493	6	40	44	4	3	12	1	1
									ARH1	6	37	44	7	2	12	10	1				44	4	3	12	6	1
									ARP15	6	37	52	7	2	12	10	1	CV511	6	29	79					1
									ARP16	6	37	50	7	2	12	10	1	CV538	12	37	37	7	2	12	5	1
									ARP17	6	29	91					1	CV544	12	30	84					1
									ARP32	6	29	79					1	CV547	12	37	42	8	7	12	2	1
																					71	8	7	12	4	1
																					71	8	7	12	5	1
																		CV551	25	29	45					1
																		CV552	25	29	47					1
																		CV553	25	29	47					1
																		CV554	6	37	48	7	2	12	3	1
																		CV559	25	37	34	7	2	12	3	1
																		CV561	35	29	54					1
																		CV562	35	29	54					1
																		CV565	35	36	31	8	1	12	2	1
																		CV567	35	37	33	7	2	3	5	1
																		CV568	35	37	33	7	2	3	5	1
																		CV571	50	29	47					1

\*Normal Shorts refer to position of "D" Switch.

6661-CV571



# B & K DYNA-QUIK MODEL 700 TUBE CHART

ManualsPlus.com

TUBE TYPE	Heater	Socket	Sens.-tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sens.-tivity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sens.-tivity	A	B	C	D	Test Pos.
CV1753	35	36	34	8	1	12	6	1	CV1929	6	37	48	7	2	12	3	1	CV1996	6	37	52	8	7	12	2	1
CV1757	6	1	93					1	CV1930	6	37	48	7	2	12	3	1	CV2128	6	38	85	5	4	12	1	1
CV1758	1	40	55	7	1	5	6	1	CV1931	6	37	48	7	2	12	3	1	CV2129	6	38	33	5	4	8	9	1
CV1762	6	1	82					1	CV1932	6	29	93					1	CV2370	3	40	*48	7	1	5	3	1
CV1763	6	40	*85					1	CV1933	6	29	93					1	CV2390	3	40	*36	7	1	5	4	1
*Normally Shows Short Position 5-6.									CV1934	6	29	93					1	CV2500	35	37	33	7	2	12	5	1
CV1777	6	36	37	8	1	12	6	1	CV1935	6	37	50	7	2	12	10	1	CV2507	1	40	52	7	1	5	6	1
CV1784	6	30	38					1	CV1936	6	37	50	7	2	12	10	1	CV2522	6	1	77					1
CV1790	6	36	50	8	1	12	3	1	CV1937	6	37	50	7	2	12	10	1	CV2524	6	1	82					1
CV1800	1	37	57	7	2	12	5	1	CV1938	6	29	92					1	CV2526	6	6	91					1
CV1802	1	37	57	7	2	12	5	1	CV1940	6	29	92					1									
CV1803	1	37	54	7	2	12	5	1	CV1941	6	37	52	7	2	12	10	1									
CV1805	1	37	54	7	2	12	5	1	CV1942	6	37	52	7	2	12	10	1									
CV1811	1	37	58	7	2	12	5	1	CV1943	6	37	52	7	2	12	10	1									
			86	7	2	12	10	1	CV1944	6	37	35	7	2	12	5	1									
			*99	7	2	12	8	1	CV1945	6	37	35	7	2	12	5	1									
CV1818	1	37	55	7	2	12	10	1	CV1946	6	37	35	7	2	12	5	1									
			96	7	2	12	5	1	CV1947	6	29	63					1									
*Tube Good if it Reads 30 or More.									CV1948	6	29	63					1									
CV1819	6	29	93					1	CV1949	6	40	43	4	3	12	1	1									
CV1820	1	37	55	7	2	12	10	1	CV1950	6	37	44	7	2	12	10	1									
			96	7	2	12	5	1	CV1951	6	37	44	7	2	12	10	1									
CV1821	2	37	53	7	2	12	10	1	CV1956	6	37	47	7	2	12	4	1									
CV1823	2	37	53	7	2	12	10	1	CV1957	6	37	47	7	2	12	4	1									
CV1824	1	37	48	7	2	12	5	1	CV1958	6	37	47	7	2	12	4	1									
CV1826	1	37	48	7	2	12	5	1																		
CV1829	1	37	54	7	2	12	5	1																		
CV1846	5	33	22					1																		
			22					2																		
CV1849	5	33	32					1																		
			32					2																		
CV1851	5	37	47	8	7	12	3	1																		
			47	8	7	12	5	1																		
CV1852	5	37	47	8	7	12	3	1																		
			47	8	7	12	5	1																		
CV1854	5	33	32					1																		
			32					2																		
CV1856	5	33	32					1																		
			32					2																		
CV1857	5	37	52	8	7	12	3	1																		
			52	8	7	12	5	1																		
CV1862	6	3	77					1																		
CV1863	5	33	12					1																		
			12					2																		
CV1864	5	33	12					1																		
			12					2																		
CV1873	6	30	74					1																		
CV1876	6	30	60					1																		
CV1878	6	37	54	7	2	12	5	1																		
			62	7	2	12	1	1																		
CV1882	6	30	38					1																		
CV1893	6	37	55	7	2	12	10	1																		
			65	7	2	12	4	1																		
			65	7	2	12	5	1																		
CV1894	6	37	55	7	2	12	10	1																		
			65	7	2	12	4	1																		
			65	7	2	12	5	1																		
CV1895	50	37	*70	2	11	3	5	1																		
*Normally Shows Short Position 11.																										
*Normally Shows Grid Emission.																										
CV1902	6	37	45	7	2	12	5	1																		
CV1908	6	37	40	7	2	12	10	1																		
CV1909	6	37	40	7	2	12	10	1																		
CV1910	6	37	40	7	2	12	10	1																		
CV1911	6	29	91					1																		
CV1912	6	29	91					1																		
CV1926	6	26	52					1																		
CV1928	12	1	78					1																		

# B & K DYNA-QUIK MODEL 700 TUBE CHART

ManualsPlus.com

TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	
DC90	1	40	*70	7	1	5	6	1	EAA91	6	5	62					1	ECL84	6	38	26	4	5	12	8	1	
*Normally Shows Short Position 2-3.									EAB80	6	17	90					2	ECL85	6	38	26	4	5	12	1	1	
DCC90	3	40	45	7	1	4	3	1	EBC90	6	6	85					1	ECL86	6	38	25	4	5	2	8	1	
DD6	6	5	62	7	1	4	5	1	EB34	6	37	48	7	2	1	3	1	ED2	6	5	62	4	5	7	1	1	
DF33	2	37	53	7	2	12	10	1	EB91	6	5	62	7	2	1	5	1	EF22	6	36	36	8	1	12	6	1	
DF91	1	40	55	7	1	5	6	1	EBC91	6	6	91					1	EF80	6	38	33	5	4	1	2	1	
DF92	1	40	55	7	1	5	6	1	EBF80	6	38	37	5	4	12	2	1	EF85	6	38	33	5	4	1	2	1	
DF96	1	40	58	7	1	5	6	1	EBF83	6	38	64	5	4	12	7	1	EF86	6	38	40	5	4	2	9	1	
DF97	1	40	40	7	1	5	6	1	EBF89	6	38	64	5	4	12	8	1	EF89	6	38	34	5	4	1	2	1	
DF904	1	40	52	7	1	5	6	1	EC81	6	38	30	4	5	12	1	1	EF91	6	40	30	4	3	12	1	1	
DH63	6	37	40	7	2	12	10	1	EC90	6	40	41	4	3	1	6	1	EF92	6	40	35	4	3	12	1	1	
			63	7	2	12	4	1	EC91	6	40	*29	4	3	6	1	1	EF93	6	1	78					1	
			63	7	2	12	5	1	*Normally Shows Short Position 2-5.									EF94	6	1	82						1
DH74	12	37	40	7	2	12	10	1	EC92	6	40	30	4	3	12	6	1	EF95	6	1	63					1	
			63	7	2	12	4	1	EC95	6	40	32	4	3	1	2	1	EF96	6	1	80					1	
DH76	12	37	40	7	2	12	10	1	EC97	6	40	33	4	3	1	2	1	EF98	6	40	30	4	3	12	1	1	
			63	7	2	12	4	1	ECC35	6	25	*85					1	EF183	6	38	30	5	4	3	2	1	
			63	7	2	12	5	1	*Tube Good if it Reads 22 Or More.									EF184	6	38	29	5	4	3	2	1	
DH77	6	6	85					1	ECC81	12	8	74					1	EF804	6	38	39	5	4	2	9	1	
DH107	19	6	85					1	ECC82	12	8	75					2	EH90	6	1	94					1	
			78					2	ECC83	12	8	*85					1	EK90	6	1	91					1	
DH149	6	36	50	8	1	4	3	1	*Tube Good if it Reads 22 or More.									EL34	6	29	53					1	
			68	8	1	4	5	1	ECC84	6	38	33	5	4	7	2	1	EL36	6	27	58					1	
			68	8	1	4	6	1	ECC85	6	8	70					1	EL37	6	29	63					1	
DH710	6	17	90					1	ECC86	6	38	33	5	4	12	7	1	EL38	6	29	*62					1	
			63					2	ECC87	6	38	33	5	4	12	6	1	*For Plate Cap Use Jack Next to Socket 26.									
DH719	6	17	90					1	ECC88	6	38	31	5	4	12	2	1	EL81	6	38	*32	5	4	7	2	1	
			63					2	ECC89	6	8	70					1	*Normally Shows Short Position 1-6-9.									
DK91	1	40	57	7	1	5	4	1	ECC90	6	8	70					2	EL83	6	38	30	5	4	12	2	1	
DK92	1	40	48	7	1	12	4	1	ECC91	6	2	60					1	EL84	6	23	68					1	
DK96	1	40	54	7	1	12	4	1	ECC92	6	38	33	5	4	7	2	1	EL85	6	38	*39	5	4	1	2	1	
DL33	3	37	45	7	2	8	5	1	ECC93	6	38	33	5	4	7	2	1	*Normally Shows Short Position 6-8.									
DL35	1	37	54	7	2	12	5	1	ECC94	6	38	33	5	4	7	2	1	EL86	6	23	58					1	
DL36	1	37	48	7	2	12	5	1	ECC95	6	38	33	5	4	12	7	1	EL90	6	3	77					1	
DL91	1	40	*55	7	1	5	3	1	ECC96	6	38	31	5	4	12	2	1	EL91	6	40	34	4	3	12	1	1	
*Normally Shows Short Position 2-6.									ECC97	6	8	70					1	EL95	6	3	88					1	
DL92	3	40	*48	7	1	5	3	1	ECC98	6	38	33	5	4	12	7	1	EL500	6	42	*25	4	5	2	1	1	
*Normally Shows Short Position 2-6.									ECC99	6	38	33	5	4	12	7	1	*Normally Shows Short Position 3-6-7-8.									
DL93	3	40	*36	7	1	5	4	1	ECC801S	12	8	74					1	EL803	6	38	30	5	4	12	2	1	
*Normally Shows Short Position 2-6.									ECC802S	12	8	75					1	EL820	6	38	*32	5	4	7	2	1	
DL94	3	40	45	7	1	5	6	1	ECC900	6	2	49					1	*Normally Shows Short Position 1-6-9.									
DL95	3	40	*42	7	1	5	3	1	ECF80	6	11	49					1	EL821	6	38	28	5	4	12	2	1	
*Normally Shows Short Position 2-6.									ECF82	6	11	66					1	EN93	6	40	43	4	3	12	1	1	
DL96	3	40	45	7	1	5	6	1	ECF88	6	38	25	4	5	3	2	1	EQ80	6	38	33	5	4	3	7	1	
DP61	6	1	63					1	ECH81	6	38	85	5	4	12	1	1	EY81	6	38	33	5	4	2	9	1	
DY30	1	32	55					1	ECH83	6	38	30	5	4	12	2	1	EY86	6	39	*95	5	4	1	10	1	
DY80	1	24	85					1	ECL80	6	38	37	5	4	12	9	1	*Normally Shows Short Position 6-11.									
DY86	1	24	35					1	ECL82	6	38	39	5	4	12	1	1	EY87	6	39	*95	5	4	1	10	1	
DY87	1	24	35					1									1	*Normally Shows Short Position 6-11.									
E80CC	12	8	74					1									1	EY88	6	39	25	5	4	6	3	1	
			74					2									1	EZ35	6	33	15					1	
E80CF	6	11	72					1	ECF86	6	38	25	4	5	3	2	1	EZ80	6	38	40	5	4	12	1	1	
			55					2	ECH81	6	38	85	5	4	12	1	1	EZ81	6	38	34	5	4	1	2	1	
E80L	6	38	25	4	5	1	2	1	ECH83	6	38	30	5	4	12	2	1									1	
E81L	6	38	24	4	5	1	2	1									1	EZ90	6	40	44	4	3	12	1	1	
E88CC	6	8	24					1									1									1	
			24					2									1									1	
E90CC	6	2	49					1									1									1	
			49					2									1									1	
E91AA	6	5	62					1									1									1	
			62					2									1									1	
E91N	6	40	32	4	3	5	1	1									1									1	
E180F	6	38	25	4	5	1	2	1									1									1	
E188CC	6	8	23					1									1									1	
			24					2									1									2	

\*Normal Shorts refer to position of "D" Switch.

# B & K DYNA-QUIK MODEL 700 TUBE CHART

ManualsPlus.com

TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.
GZ-32	5	33	12					1	OSW3109	6	37	48	7	2	12	3	1	T2M05	6	40	34	4	3	12	5	1
			12					2				48	7	2	12	5	1				34	4	3	12	6	1
GZ34	5	33	10					1	OSW3111	6	30	84						TM12	6	40	*85	4	3	12	6	1
			10					2	OSW3112	6	29	93									*85	4	3	1	7	1
H63	6	37	40	7	2	12	10	1	PABC80	9	17	90						TS51	6	1	63					1
								1				63						TS52	6	2	60					1
HABC80	19	17	90					1	PCC84	7	38	33	5	4	7	2	1				60					2
			63					2				33	5	4	7	6	1	U50	5	33	32					1
HBC90	12	6	85					1	PCC85	9	8	70									32					2
			78					2				70						U52	5	33	16					1
HBC91	12	6	91					1	PCC88	7	38	31	5	4	12	2	1				16					2
								2				31	5	4	12	7	1	U54	5	33	10					1
HCC85	17	8	65					1	PCG189	7	38	30	5	4	12	2	1				10					2
			65					2				30	5	4	12	2	1	U78	6	40	44	4	3	12	1	1
HCH81	12	38	32	5	4	12	2	1	PCF80	9	11	66	5	4	12	7	1				44	4	3	12	6	1
			35	5	4	12	9	1										U147	6	33	15					1
HD14	1	37	55	7	2	12	10	1	PCF82	9	11	55									15					2
			96	7	2	12	5	1				55						U149	6	36	45	8	1	12	3	1
HF93	12	1	78					1	PCF86	7	38	25	4	5	3	2	1				45	8	1	12	6	1
HF94	12	1	82					1				25	4	5	1	6	1	U153	17	38	33	4	5	2	9	1
HK90	12	1	91					1	PCL82	16	38	33	5	4	12	3	1	U709	6	38	34	5	4	12	1	1
								1				39	5	4	12	1	1				34	5	4	12	7	1
HL90	19	3	77					1	PCL84	15	38	26	4	5	12	8	1	UAA91	6	5	62					1
HL92	50	4	44					1				26	4	5	12	1	1				62				2	
HMO4	6	1	91					1	PCL85	18	38	25	4	5	12	9	1	UABC80	6	17	90					1
HY90	35	40	*33	4	3	6	5	1				25	4	5	12	2	1				63				2	
								1	PCL86	14	38	25	4	5	2	8	1	UBF80	17	38	33	5	4	12	2	1
								1				35	4	5	7	1	1				65	5	4	12	7	1
KT32	25	29	47					1	PF9	6	37	52	7	2	12	10	1				65	5	4	12	8	1
KT63	6	29	91					1	PH4	6	37	45	7	2	12	5	1	UCC84	22	38	33	5	4	7	2	1
KT66	6	29	63					1				58									33	5	4	7	6	1
KT88	6	29	43					1	PL36	25	27	58						UCC85	6	8	70					1
KTZ63	6	37	50	7	2	12	10	1	PL81	19	38	*32	5	4	7	2	1				70				2	
								1				*32	5	4	12	2	1	UCF80	25	11	66					1
L63	6	29	93					1	PL83	12	38	30	5	4	12	2	1				55					2
L77	6	40	41	4	3	1	6	1	PL84	15	23	58														
LN152	6	38	37	5	4	12	9	1				*32	5	4	7	2	1	UCH81	19	38	32	5	4	12	2	1
			44	5	4	12	2	1													35	5	4	12	9	1
LZ319	9	11	66					2	PL500	30	42	*25	4	5	2	1	1	UCL82	50	38	33	5	4	12	3	1
								1				*25	4	5	2	1	1				39	5	4	12	1	1
M8081	6	2	60					1				*32	5	4	7	2	1	UL84	50	23	58					1
			60					2	PL820	19	38	*32	5	4	7	2	1	UUI2	6	38	34	5	4	12	1	1
M8100	6	1	63					1				78						UY85	35	39	30	4	5	1	6	1
N14	1	37	54	7	2	12	5	1	PMD4	6	1	78						V2M70	6	40	44	4	3	12	1	1
N17	3	40	*48	7	1	5	3	1				63									44	4	3	12	6	1
								1	PMD5	6	1	63						V884	6	40	35	4	3	12	1	1
N18	3	40	*42	7	1	5	3	1	PY32	30	37	24	2	7	6	3	1	VP6	6	40	35	4	3	12	1	1
								1				24	2	7	6	5	1	VPI321	12	40	*55	4	3	1	5	1
N19	3	40	*45	7	1	5	6	1	PY80	19	38	29	5	4	12	9	1									
								1	PY81	17	38	33	5	4	2	9	1	VR75	50	37	*70	2	11	3	5	1
N152	19	38	*32	5	4	7	2	1	PY88	30	39	25	5	4	6	3	1									
								1	QA240	6	40	41	4	3	1	6	1									
N709	6	23	68					1	QA2404	6	5	62														
NR67	6	37	44	7	2	12	10	1				62														
NR78	6	29	99					1	QA2406	12	8	74														
								1				74														
NR78A	6	29	93					1	QA2407	6	40	44	4	3	12	1	1									
NR81	6	37	52	7	2	12	10	1				44	4	3	12	6	1	VR90	50	37	*69	2	11	3	5	1
NR83	6	37	50	7	2	12	10	1	QA2408	6	25	78														
NR85	6	29	91					1				78														
NR95	25	29	47					1																		
								1	QE03/10	6	38	33	5	4	8	9	1	VR105	50	37	*85	2	11	3	5	1
NU20	5	33	32					1	QE05/40	6	37	*38	7	2	1	5	1									
			32					2				*38	7	2	1	5	1									
OBC3	12	37	42	8	7	12	2	1																		
			71	8	7	12	4	1																		
OF1	6	37	47	7	2	12	10	1	QS150/40	50	37	*99	2													

**B & K DYNA-QUIK MODEL 700 TUBE CHART**

TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.	TUBE TYPE	Heater	Socket	Sensitiv-ity	A	B	C	D	Test Pos.
VT88	6	37	52	7	2	12	10	1	VT116	6	30	83					1	XF80	3	38	33	5	4	1	2	1
			63	7	2	12	4	1	VT117	6	30	84					1	XF85	3	38	33	5	4	1	2	1
			63	7	2	12	5	1	VT124	1	37	55	7	2	12	5	1	XF183	3	38	30	5	4	3	2	1
VT90	6	37	48	7	2	12	3	1	VT125	1	37	54	7	2	12	5	1	XF184	3	38	29	5	4	3	2	1
			48	7	2	12	5	1	VT126	6	33	15					1	XL36	12	27	57					1
												15					2	XL84	8	23	68					1
VT91	6	37	50	7	2	12	10	1	W17	1	40	55	7	1	5	6	1	XL86	8	23	58					1
VT93	6	37	55	7	2	12	10	1	W77	6	40	35	4	3	12	1	1	XY88	16	39	30	5	4	7	3	1
			65	7	2	12	4	1	W149	6	36	45	8	1	12	6	1	XXD	12	36	41	8	1	12	4	1
VT94	6	29	93	7	2	12	4	1	W719	6	38	33	5	4	1	2	1				41	8	1	12	5	1
VT96	6	37	47	7	2	12	4	1	W727	6	1	78					1	XXFM	6	36	43	8	1	12	3	1
			47	7	2	12	5	1	X63 (M)	6	37	45	7	2	12	5	1				36	8	1	12	5	1
VT97	5	33	32					1	X73 (M)	6	37	45	7	2	12	5	1				35	8	1	12	6	1
			32					2	X107	19	1	91					1	XXL	6	36	41	8	1	12	6	1
VT99	6	37	45	7	2	12	5	1	X155	6	8	55					1	YF183	4	38	30	5	4	3	2	1
			45	7	2	12	10	1				55					2	YF184	4	38	29	5	4	3	2	1
VT102	6	29	92					1	X727	6	1	91					1	Z14	2	37	53	7	2	12	10	1
VT103	6	37	42	8	7	12	2	1	XB767A	6	37	34	7	2	12	5	1	Z63	6	37	50	7	2	12	10	1
			71	8	7	12	4	1	XC95	2	40	33	4	3	1	2	1	Z719	6	38	33	5	4	1	2	1
			71	8	7	12	5	1	XCC189	4	38	30	5	4	12	2	1	Z729	6	38	40	5	4	2	9	1
VT104	12	37	42	8	7	12	2	1				30	5	4	12	7	1	ZD17	1	40	55	7	1	5	3	1
			71	8	7	12	4	1	XCF80	4	11	66					1				55	7	1	5	3	1
			71	8	7	12	5	1				66					2				37	5	4	12	2	1
VT105	6	37	48	8	7	12	3	1	XCH81	3	38	85	5	4	12	1	1	ZD151	6	38	37	5	4	12	7	1
			48	8	7	12	4	1				38	5	4	12	9	1				64	5	4	12	7	1
VT107	6	29	79					1	XCL82	8	38	33	5	4	12	3	1				64	5	4	12	8	1
VT112	6	30	60					1				39	5	4	12	1	1	ZD152	6	38	37	5	4	12	2	1
VT114	5	33	16					1	XCL84	8	38	26	4	5	12	8	1				64	5	4	12	7	1
			16					2				26	4	5	12	1	1				64	5	4	12	8	1
VT115	6	29	63					1				26	4	5	12	1	1									

\*Normally Shows Short Position 2-6.