


**SCHEMATIC OF THE
HEATHKIT®
DIGITAL MPH AND MFG METER**

Model CI-107B


Copyright © 1975
Heath Company
All Rights Reserved

Part of 595-1731-03



NOTES:

1. ALL RESISTORS ARE 1/4 WATT, 10% UNLESS OTHERWISE INDICATED.
 2. RESISTOR VALUES ARE IN OHMS (Ω). K= 100, M= 1,000,000.
 3. CAPACITOR VALUES ARE IN MICROFARADS, (μ F) UNLESS OTHERWISE SPECIFIED. pF = PICO FARADS.
 4. \equiv THIS SYMBOL INDICATES CHASSIS GROUND.
 5. ∇ THIS SYMBOL INDICATES
 6. \circ THIS SYMBOL INDICATES
 7. \square THIS SYMBOL INDICATES
- * THESE COLORS MAY BE REVERSED OF THE SPEED TRANSDUCER IN




ATES CIRCUIT BOARD GROUND.

ATES WIRE CONNECTION TO BOARD.

ATES PLUG-IN CONNECTOR.

VERSED TO GET PROPER POLARITY
R IN YOUR CAR.



SCHEMATIC OF THE HEATHKIT® DIGITAL MPH AND MFG METER
 Model CI-107B
 Copyright © 1975 Heath Company
 All Rights Reserved

Part of 595-1731-03

NOTES:

1. ALL RESISTORS ARE 1/4 WATT, 10% UNLESS OTHERWISE INDICATED.
 2. RESISTOR VALUES ARE IN OHMS (Ω). K = 100, M = 1,000,000.
 3. CAPACITOR VALUES ARE IN MICROFARADS (μF) UNLESS OTHERWISE SPECIFIED. pF = PICO FARADS.
 4. ≡ THIS SYMBOL INDICATES CHASSIS GROUND.
 5. ▽ THIS SYMBOL INDICATES CIRCUIT BOARD GROUND.
 6. ○ THIS SYMBOL INDICATES WIRE CONNECTION TO BOARD.
 7. □ THIS SYMBOL INDICATES PLUG-IN CONNECTOR.
- * THESE COLORS MAY BE REVERSED TO GET PROPER POLARITY OF THE SPEED TRANSDUCER IN YOUR CAR.